

Nexus(NX-OS)提示和技巧

目錄

[簡介](#)

[快速十六進位制/解碼器轉換](#)

[一次執行多個CLI](#)

[使用CLI變數](#)

[自定義終端設定](#)

[根據需要延遲命令執行](#)

[訪問路由環境/VRF](#)

[連線到LC時為各自VDC運行CLI:N7k特定](#)

[在Linux核心和NX-OS之間來回切換，而不退出調試外掛](#)

[直接通過VSH載入配置](#)

[使用Diffs — 列出計數器之間的差異](#)

[使用Watch CLI - 7.0\(3\)I2\(x\)後特定於N9k](#)

[在內部檢查CPU使用情況](#)

[發佈內部生成版本](#)

簡介

本文檔介紹一些可以增強NX-OS故障排除體驗的快速提示和技巧。

快速十六進位制/解碼器轉換

十六進位制表示十進位制，十進位制表示十進位制

```
NX-OS# dec 0x89
137
NX-OS# hex 137
0x89
```

一次執行多個CLI

CLI代表命令列介面

```
N7k-LabSW# show clock ; show switchname ; show license host-id
19:10:59.016 UTC Mon Apr 04 2016
N7k-LabSW
License hostid: VDH=TBM14354170
```

#也適用於配置：

```
N7k-LabSW# conf t ; hostname N7k-LabSW-DEFAULT ; end
```

Enter configuration commands, one per line. End with CNTL/Z.

N7k-LabSW-DEFAULT#

#完成CLI所用的時間：

```
N7k-LabSW# show clock ; show run | ex .* ; show clock
```

```
07:56:08.709 UTC Tue Apr 05 2016
```

```
07:56:08.834 UTC Tue Apr 05 2016
```

使用CLI變數

```
N7k-LabSW# show cli variables
```

```
VSH Variable List (* = session vars)
```

```
-----
```

```
SWITCHNAME="N7k-LabSW"
```

```
TIMESTAMP="2016-04-05-08.34.18"
```

```
N7k-LabSW# tac-pac bootflash:$(SWITCHNAME)-$(TIMESTAMP)-show-tech-all.gz
```

```
N7k-LabSW# dir bootflash: | i show-tech-all
```

```
15091722 Apr 05 08:41:27 2016 N7k-LabSW-2016-04-05-08.35.57-show-tech-all.gz
```

還可以建立自己的變數：

[CCO參考](#)

自定義終端設定

1)避免終端會話超時：

```
N7k-LabSW# show terminal | i Timeout
```

```
Session Timeout: 30 minutes
```

```
N7k-LabSW# terminal session-timeout ?
```

```
<0-525600> Enter timeout in minutes, 0 to disable
```

```
N7k-LabSW# terminal session-timeout 0
```

```
N7k-LabSW# show terminal | i Timeout
```

```
Session Timeout: 0 minutes
```

2)設定顯示終端的寬度/長度：

當不希望長寬輸出中斷到新行時，非常方便

```
N7k-LabSW# show terminal | i Width
```

```
Length: 25 lines, Width: 98 columns
```

```
N7k-LabSW# terminal width 300
```

```
N7k-LabSW# show terminal | i Width
```

```
Length: 25 lines, Width: 300 columns
```

根據需要延遲命令執行

```
N7k-LabSW# show clock ; sleep 10 ; show clock
```

```
19:27:07.435 UTC Mon Apr 04 2016
```

```
19:27:17.445 UTC Mon Apr 04 2016
```


<snipped>

直接通過VSH載入配置

VSH代表虛擬shell

```
NEXUS-LABSWITCH# echo "hostname LAB" | vsh
LAB#
```

```
Mon Apr  4 20:51:14 2016:type=update:id=10.61.236.97@pts/1:user=admin:cmd=echo "hostname LAB" |
vsh (SUCCESS)
Mon Apr  4 20:51:14 2016:type=start:id=vsh.9326:user=admin:cmd=
Mon Apr  4 20:51:14 2016:type=update:id=vsh.9326:user=admin:cmd=configure terminal ; hostname
LAB (SUCCESS)
```

```
LAB# echo "hostname NEXUS-LABSWITCH" | vsh
NEXUS-LABSWITCH#
```

```
Mon Apr  4 20:51:23 2016:type=update:id=10.61.236.97@pts/1:user=admin:cmd=echo "hostname NEXUS-
LABSWITCH" | vsh (SUCCESS)
Mon Apr  4 20:51:23 2016:type=start:id=vsh.9390:user=admin:cmd=
Mon Apr  4 20:51:23 2016:type=update:id=vsh.9390:user=admin:cmd=configure terminal ; hostname
NEXUS-LABSWITCH (SUCCESS)
```

```
N5600-Lab# show run | i hostname | sed "s/N5600-Lab/N56128/" | vsh
N56128#
```

```
N56128# show accounting log | last 3
Mon Apr  4 21:23:23 2016:type=start:id=vsh.6762:user=admin:cmd=
Mon Apr  4 21:23:23 2016:type=update:id=vsh.6762:user=admin:cmd=configure terminal ; hostname
N56128 (SUCCESS)
Mon Apr  4 21:23:23 2016:type=stop:id=vsh.6762:user=admin:cmd=
```

```
N5600-Lab# echo "hostname N56128" > bootflash:CLI
N5600-Lab#
N5600-Lab# show file CLI
hostname N56128
N5600-Lab# show file CLI | vsh
N56128#
```

使用Diffs — 列出計數器之間的差異

Diff代表差異

```
N5600-Lab# show int mgmt0 | diff
N5600-Lab# show int mgmt0 | diff
11,12c11,12
<    9393 input packets 829764 bytes
<141 unicast packets 3715 multicast packets
---
>    9395 input packets 830217 bytes
>142 unicast packets 3716 multicast packets
15,16c15,16
<    214 output packets 47396 bytes
<27 unicast packets 181 multicast packets
---
>    215 output packets 47640 bytes
>27 unicast packets 182 multicast packets
```

使用Watch CLI - 7.0(3)I2(x)後特定於N9k

N9K代表Nexus 9000

```
BRU-N9K3-1# watch differences interval 1 show int mgmt0 counter
```

```
Every 1.0s: vsh -c "show int mgmt0  
counter"
```

Mon Apr 4 23:42:27 2016

[CCO reference](#)

在內部檢查CPU使用情況

CPU代表中央處理器

此命令每5秒（可以更改）提供一個輸出，指出哪個進程正在消耗CPU。其輸出與linux top命令相同：

```
NEXUS# show system internal processes cpu 5 | no-more  
top - 12:41:55 up 117 days, 17:00, 5 users, load average: 0.44, 0.50, 0.55 Tasks: 2883 total, 2  
running, 1022 sleeping, 0 stopped, 1859 zombie Cpu(s): 1.0%us, 0.9%sy, 0.0%ni, 98.0%id, 0.0%wa,  
0.0%hi, 0.1%si, 0.0%st Mem: 32744992k total, 14563132k used, 18181860k free, 61308k buffers  
Swap: 0k total, 0k used, 0k free, 4091160k cached PID USER PR NI VIRT RES SHR S %CPU %MEM TIME+  
COMMAND 18465 admin 20 0 5200 3108 1148 R 16.6 0.0 0:00.17 top 6389 root 20 0 699m 53m 14m S 3.3  
0.2 113:49.07 netstack 18473 root 20 0 97940 3804 2796 R 3.3 0.0 0:00.02 vsh 10 root 15 -5 0 0 0  
S 1.7 0.0 9:10.85 ksoftirqd/2 4876 root 15 -5 369m 27m 6564 S 1.7 0.1 67:33.91 sysmgr 9581 svc-  
isan 20 0 446m 41m 11m S 1.7 0.1 21:16.15 isis_l2mp 1 root 20 0 1980 652 572 S 0.0 0.0 3:02.73  
init 2 root 15 -5 0 0 0 S 0.0 0.0 0:00.03 kthreadd 3 root RT -5 0 0 0 S 0.0 0.0 0:00.49  
migration/0 4 root 15 -5 0 0 0 S 0.0 0.0 22:48.66 ksoftirqd/0 5 root -2 -5 0 0 0 S 0.0 0.0  
0:00.00 watchdog/0 6 root RT -5 0 0 0 S 0.0 0.0 0:00.65 migration/1 7 root 15 -5 0 0 0 S 0.0 0.0  
2:27.70 ksoftirqd/1 top - 12:42:01 up 117 days, 17:00, 5 users, load average: 0.37, 0.48, 0.54  
Tasks: 2887 total, 1 running, 1027 sleeping, 0 stopped, 1859 zombie Cpu(s): 1.0%us, 0.9%sy,  
0.0%ni, 98.0%id, 0.0%wa, 0.0%hi, 0.1%si, 0.0%st Mem: 32744992k total, 14562360k used, 18182632k  
free, 61308k buffers Swap: 0k total, 0k used, 0k free, 4091160k cached PID USER PR NI VIRT RES  
SHR S %CPU %MEM TIME+ COMMAND 18502 admin 20 0 5200 3112 1148 R 18.5 0.0 0:00.17 top 6389 root  
20 0 699m 53m 14m S 1.7 0.2 113:49.08 netstack 6402 root -2 0 366m 13m 8660 S 1.7 0.0 1032:41  
clx 9015 root 20 0 482m 21m 11m S 1.7 0.1 225:45.72 pm 10066 svc-isan 20 0 403m 22m 9.9m S 1.7  
0.1 268:31.28 ospf 10487 svc-isan 20 0 354m 9992 6596 S 1.7 0.0 194:52.11 ecp 1 root 20 0 1980  
652 572 S 0.0 0.0 3:02.73 init 2 root 15 -5 0 0 0 S 0.0 0.0 0:00.03 kthreadd 3 root RT -5 0 0 0  
S 0.0 0.0 0:00.49 migration/0 4 root 15 -5 0 0 0 S 0.0 0.0 22:48.66 ksoftirqd/0 5 root -2 -5 0 0  
0 S 0.0 0.0 0:00.00 watchdog/0 6 root RT -5 0 0 0 S 0.0 0.0 0:00.65 migration/1 7 root 15 -5 0 0  
0 S 0.0 0.0 2:27.70 ksoftirqd/1
```

發佈內部生成版本

N7k/N9k

```
N7k-LabSW# show version internal build-identifier  
Kickstart image file: bootflash:///n7000-s2-kickstart.6.2.10.bin : S102  
System image file: bootflash:///n7000-s2-dk9.6.2.10.bin : S102
```

```
BRU-N9K3-1# show version internal build-identifier  
nxos image file: bootflash:///nxos.7.0.3.I2.2a.bin : S30
```

N5k/6k:

N5600-Lab# show platform fwm info global | i FwM

FwM build Details: Built at Sat Apr 18 11:11:18 PDT 2015 on nuo-sw-build40 in directory /auto/n5kiluka/daily_build/iplus/nexus/522/src/build by buildsa)