身份驗證代理身份驗證出站 — 無Cisco IOS防火 牆或NAT配置

目錄

<u>簡介</u> <u>必要條件</u> <u>需求</u> <u>採用元件</u> 慣例 <u>設路 圖表</u> <u>網 組態</u> <u>PC上的身份驗證</u> <u>疑難排解</u> <u>相關資訊</u>

<u> 簡介</u>

驗證代理功能允許使用者登入網路或透過HTTP存取網際網路,並自動從RADIUS或TACACS+伺服 器擷取和應用其特定存取設定檔。僅當存在來自已驗證使用者的活動流量時,使用者配置檔案才處 於活動狀態。

此示例配置阻止從內部網路上的主機裝置(40.31.1.47)到Internet上的所有裝置的流量,直到使用身份驗證代理執行瀏覽器身份驗證。從伺服器向下傳遞的訪問控制清單(ACL)(**permit tcp|ip|icmp any** any)會在授權後向訪問清單116新增動態條目,這些條目暫時允許從主機PC訪問Internet。

如需驗證代理的詳細資訊,請參閱設定驗證代理。

<u>必要條件</u>

<u>需求</u>

本文件沒有特定需求。

<u>採用元件</u>

本文中的資訊係根據以下軟體和硬體版本:

- Cisco IOS®軟體版本12.2(15)T
- 思科7206路由器

注意:ip auth-proxy指令是在Cisco IOS防火牆軟體版本12.0.5中匯入,

本文中的資訊是根據特定實驗室環境內的裝置所建立。文中使用到的所有裝置皆從已清除(預設))的組態來啟動。如果您的網路正在作用,請確保您已瞭解任何指令可能造成的影響。

<u>慣例</u>

如需文件慣例的詳細資訊,請參閱<u>思科技術提示慣例。</u>

<u>設定</u>

本節提供用於設定本文件中所述功能的資訊。

註:使用<u>Command Lookup Tool</u>(僅限<u>註冊</u>客戶)查詢有關本文檔中使用的命令的更多資訊。

<u>網路圖表</u>

本檔案會使用以下網路設定:



<u>組態</u>

本檔案會使用以下設定:

7206路由器 version 12.2 service timestamps debug datetime msec service timestamps log datetime msec service password-encryption ! hostname psy-rtr-2 !

logging queue-limit 100

username admin password 7 <deleted> aaa new-model

!--- Enable AAA. aaa authentication login default group radius none !--- Use RADIUS to authenticate users. aaa authorization exec default group radius none aaa authorization auth-proxy default group radius !---Utilize RADIUS for auth-proxy authorization. aaa session-id common ip subnet-zero ! ip cef ! ip authproxy auth-proxy-banner !--- Displays the name of the firewall router !--- in the Authentication Proxy login page. ip auth-proxy auth-cache-time 10 !--- Sets the global Authentication Proxy idle !--- timeout value in minutes. ip auth-proxy name restrict_pc http !---Associates connections that initiate HTTP traffic with !--- the "restrict_pc" Authentication Proxy name. ip audit notify log ip audit po max-events 100 ! no voice hpi capture buffer no voice hpi capture destination ! mta receive maximum-recipients 0 ! ! interface FastEthernet0/0 ip address 192.168.10.10 255.255.255.0 ip access-group 116 in !--- Apply access list 116 in the inbound direction. ip auth-proxy restrict_pc !--- Apply the Authentication Proxy list !--- "restrict_pc" configured earlier. duplex full ! interface FastEthernet4/0 ip address 10.89.129.195 255.255.255.240 duplex full ! ip classless ip http server !--- Enables the HTTP server on the router. !--- The Authentication Proxy uses the HTTP server to communicate !--- with the client for user authentication. ip http authentication aaa !--- Sets the HTTP server authentication method to AAA. ! access-list 116 permit tcp host 192.168.10.200 host 192.168.10.10 eq www !--- Permit HTTP traffic (from the PC) to the router. access-list 116 deny tcp host 192.168.10.200 any access-list 116 deny udp host 192.168.10.200 any access-list 116 deny icmp host 192.168.10.200 any !--- Deny TCP, UDP, and ICMP traffic from the client by default. access-list 116 permit tcp 192.168.10.0 0.0.0.255 any access-list 116 permit udp 192.168.10.0 0.0.0.255 any access-list 116 permit icmp 192.168.10.0 0.0.0.255 any !--- Permit TCP, UDP, and ICMP traffic from other !--- devices in the 192.168.10.0/24 network. ! radius-server host 192.168.10.103 auth-port 1645 acct-port 1646 key 7 <deleted> !--- Specify the IP address of the RADIUS !-server along with the key. radius-server authorization permit missing Service-Type call rsvp-sync ! ! line con 0 stopbits 1 line aux 0 stopbits 1 line vty 0 4 ! end

PC上的身份驗證

本節提供從PC獲取的螢幕截圖,其中顯示了身份驗證過程。第一個捕獲顯示一個視窗,使用者在該 視窗中輸入使用者名稱和密碼進行身份驗證,然後按**確定**。

Authentication Proxy Login Page - Microsoft Internet Explorer	. 0 ×
Rie Edit Waw Forceites Tools Help	
, ⇔Back + → - 🎯 🗄 🚮 🖓 Stardi 🕞 Faccillos ()∰History 🔩 + 🍎 🕅 + 🛄 🤴	
Address 🔁 http://172.22.53.1/	▼ 2 ² 60 Units ×
Cisco Systems	
psy-rtr-2 Authentication	
Username: pc_user	
Password:	
<u>lok</u>	
	<u>.</u>
Done Done	🔮 änternet

如果驗證成功,則出現此視窗。



必須使用應用的代理ACL配置RADIUS伺服器。在此範例中,將套用這些ACL專案。這允許PC連線 到任何裝置。

permit tcp host 192.168.10.200 any permit udp host 192.168.10.200 any permit icmp host 192.168.10.200 any 此Cisco ACS視窗顯示代理ACL的輸入位置。

Crown Sotun

CISCO SYSTEMS Group Setup		
	Jump To Access Restrictions	
User Setup Group Setup Setup Shared Profile Components Network Configuration	Unlisted arguments O Permit O Deny	
Interface Configuration Administration Control External User Databases Reports and Activity	Cisco IOS/PIX RADIUS Attributes	R
Unline Documentation	□ [009\102] cisco-h323-credit-time □ [009\103] cisco-h323-return-code □ [009\103] cisco-h323-return-code	<u> </u>

註:有關如何配置RADIUS/TACACS+伺服器的詳細資訊,請參閱<u>配置身份驗證代理</u>。

驗證

本節提供的資訊可用於確認您的組態是否正常運作。

- show ip access-lists 顯示防火牆上配置的標準型和延伸型ACL(包括動態ACL條目)。動態 ACL條目將根據使用者是否進行身份驗證定期新增和刪除。
- show ip auth-proxy cache 顯示驗證代理條目或執行中的驗證代理配置。cache關鍵字,用於列出主機IP地址、源埠號、身份驗證代理的超時值和使用身份驗證代理的連線狀態。如果身份驗證代理狀態為HTTP_ESTAB,則使用者身份驗證成功。

<u>疑難排解</u>

0

本節提供的資訊可用於對組態進行疑難排解。

如需這些命令以及其他疑難排解資訊,請參閱<u>驗證代理疑難排解</u>。

附註:使用 debug 指令之前,請先參閱<u>有關 Debug 指令的重要資訊</u>。

相關資訊

- IOS防火牆支援頁面
- TACACS/TACACS+ 支援頁面
- IOS 文件中的 TACACS+
- RADIUS 支援頁面
- IOS檔案中的RADIUS
- <u>要求建議 (RFC)</u>
- <u>技術支援與文件 Cisco Systems</u>