



Contents

CHAPTER 1

About the Cisco Security Packet Analyzer 2400 Series Appliance	1-1
Cisco Security Packet Analyzer 2400 Appliance Views and LEDs	1-2
Input/Output Ports and Connectors	1-4
Packet Analyzer Management Port (LAN 1)	1-4
Serial (Console) Port Connector and Cable	1-5
Small Form-Factor Pluggable (SFP) Modules	1-5
KVM Console	1-6
AC Power Supplies	1-6
Summary of Appliance Features	1-7
Cisco Security Packet Analyzer 2400 Feature	1-7

CHAPTER 2

Requirements and Restrictions	2-2
Installation Process Summary	2-2
Unpack and Inspect the Appliance	2-4
Cisco Cisco Security Packet Analyzer 2400 Appliance Packing List	2-5
Install the Appliance in a Rack	2-5
Install the Transceiver Modules	2-6
Connect the Power	2-7
Connect the Appliance Cables	2-8
Connect the Management Port	2-8
Connect the Monitoring Ports	2-9
Direct Connections	2-9
Optical Tap Connections	2-9
Connect a Console Terminal	2-11
Connect a Monitor to the Appliance	2-12
Power Up the Appliance	2-12

CHAPTER 3

Logging In For the First Time	3-1
Changing the Root Password	3-2
Examples	3-3
Changing the Packet Analyzer Root Password: Example	3-3
Verifying the Packet Analyzer Root Password: Example	3-3

- Resetting the Packet Analyzer Root Password to the Default Value 3-3
- Establishing Network Connectivity 3-4
- Checking Your Configuration 3-5
- Enabling the Cisco Security Packet Analyzer Web Server 3-6
- Verifying System Status 3-8
- Configuring a Monitored Device 3-10
 - Configuring a Monitored Device Interface 3-10
 - Creating a SPAN Session 3-10
- Opening and Closing a Telnet or SSH Session to the Packet Analyzer 3-11
 - Examples 3-12
- Setting up the CIMC 3-13
 - Setting up Serial Console Connection 3-14
 - Setting up Serial Console Access through External RJ-45 Port 3-14
- Shutting Down and Starting Up the Appliance 3-14

CHAPTER 4

- Configuring the iSCSI Array 4-1
- Locating the Packet Analyzer IQN 4-2
- Connecting the Storage Array 4-2

CHAPTER 5

- General Maintenance Guidelines 5-1
- Reading the LEDs 5-1
 - Cisco Packet Analyzer 2400 LEDs 5-2
 - Cisco Security Packet Analyzer 2400 5-2
 - Reading the Cisco Security Packet Analyzer 2400 Rear-Panel LEDs 5-4
 - Reading the NIC LEDs 5-5
 - Reading the AC Power Supply LED 5-6
- Replacing Appliance Components 5-7
 - Installing or Removing a UCS PCIe NIC Card 5-7
 - Replacing Transceiver Modules 5-7
 - Removing and Replacing a Hard Disk Drive 5-8
 - Installing or Replacing a Power Supply. 5-8
- Removing or Replacing the Cisco Security Packet Analyzer 2400 Series Appliances 5-8

CHAPTER 6

- Backing Up Your Configuration 6-1
- Restoring Your Configuration 6-2
- Upgrading Your Software 6-2
- Recovery Installation 6-3

APPENDIX A**Troubleshooting A-1**

- Troubleshooting Guidelines A-1
- Troubleshooting Appliance Problems A-2
- Serial Number Locations A-5

APPENDIX B**Safety Guidelines B-1**

- General Precautions B-1
- Safety with Equipment B-2
- Safety with Electricity B-3
- Preventing Electrostatic Discharge Damage B-4
- Lifting Guidelines B-5

APPENDIX C**Technical Specifications C-1**

- Cisco Security Packet Analyzer2400 Technical Specifications C-1
- SFP Port Cable Specifications C-1
- Optical Tap Devices C-1

APPENDIX D**Sample Site Log and Preinstallation Task Checklist D-1**

- Sample Site Log D-1
- Sample Preinstallation Task Checklist D-3

APPENDIX E**Helper Utility E-1**

- Helper Utility Menu Summary E-2
- Option n - Configure Network E-2
- Option 1 - Download Application Image and Write to HDD E-3
- Option 2 - Download Application Image and Reformat HDD E-4
- Option 3 - Install Application Image from CD E-4
- Option 4 - Display Software Versions E-4
- Option 5 - Reset Application Image CLI Passwords to Default E-5
- Option 6- Send Ping E-5
- Option 7 - Configure Capture RAID Settings E-5
- Option 8 - Install Application Image From Flash and Reformat HDD E-6
- Option f - Check For and Fix Filesystem Errors on Local Disk E-6
- Option s - Show Upgrade Log E-6
- Option r - Exit and Reset Services Engine E-6
- Option h - Exit and Shutdown Services Engine E-6

