



Show Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

- [show accounting](#), page 18-4
- [show arp](#), page 18-5
- [show authentication](#), page 18-6
- [show boot](#), page 18-7
- [show callhome](#), page 18-8
- [show cdp](#), page 18-10
- [show clock](#), page 18-14
- [show cores](#), page 18-15
- [show environment](#), page 18-16
- [show fc2](#), page 18-18
- [show fcalias](#), page 18-21
- [show fcanalyzer](#), page 18-22
- [show fcc](#), page 18-23
- [show fcdomain](#), page 18-24
- [show fcdroplateny](#), page 18-26
- [show fcflow stats](#), page 18-27
- [show fcfwd](#), page 18-28
- [show fcip profile](#), page 18-29
- [show fctimer](#), page 18-30
- [show fcns database](#), page 18-31
- [show fcns statistics](#), page 18-32
- [show fcroute](#), page 18-33
- [show fcs](#), page 18-36
- [show file](#), page 18-40
- [show flash](#), page 18-41

Send documentation comments to mdsfeedback-doc@cisco.com.

- [show flogi database](#), page 18-42
- [show fspf](#), page 18-44
- [show hardware](#), page 18-47
- [show hosts](#), page 18-49
- [show interface](#), page 18-51
- [show ip route](#), page 18-57
- [show ip routing](#), page 18-58
- [show ips arp](#), page 18-59
- [show ips ip route](#), page 18-60
- [show ips stats](#), page 18-61
- [show ips status](#), page 18-64
- [show iscsi global](#), page 18-65
- [show iscsi initiator](#), page 18-66
- [show iscsi session](#), page 18-69
- [show iscsi stats](#), page 18-71
- [show iscsi virtual-target](#), page 18-75
- [show kernel core](#), page 18-76
- [show logging](#), page 18-77
- [show module](#), page 18-82
- [show ntp](#), page 18-84
- [show port-channel](#), page 18-86
- [show processes](#), page 18-88
- [show qos statistics](#), page 18-91
- [show radius-server](#), page 18-92
- [show role](#), page 18-93
- [show rscn](#), page 18-94
- [show running-config](#), page 18-96
- [show scsi-target](#), page 18-97
- [show snmp](#), page 18-100
- [show span session](#), page 18-102
- [show sprom](#), page 18-104
- [show ssh](#), page 18-107
- [show startup-config](#), page 18-109
- [show switchname](#), page 18-112
- [show system](#), page 18-113
- [show system switchover impact](#), page 18-115
- [show tech-support](#), page 18-117
- [show telnet server](#), page 18-119

Send documentation comments to mdsfeedback-doc@cisco.com.

- [show terminal](#), page 18-120
- [show trunk protocol](#), page 18-123
- [show user-account](#), page 18-124
- [show users](#), page 18-125
- [show version](#), page 18-126
- [show version compatibility](#), page 18-128
- [show vrrp](#), page 18-129
- [show vsan](#), page 18-131
- [show wwn](#), page 18-133
- [show zone](#), page 18-134
- [show zoneset](#), page 18-137

Send documentation comments to mdsfeedback-doc@cisco.com.

show accounting

To display configured accounting information, use the **show accounting** command.

show accounting {config | log | logsize}

Syntax Description	config	Shows RADIUS accounting configuration information.
	log	Shows accounting log.
	logsize	Shows local accounting log file size.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples To display configured accounting parameters.

```
switch# show accounting config
RADIUS accounting not enabled
local accounting enabled
```

To display configured log size.

```
switch# show accounting logsize
maximum local accounting log size:29000
```

To display the entire log file.

```
switch# show accounting log
2002:stop:snmp_1033151784_171.71.49.83:admin:
Fri Sep 27 18:36:24 2002:start:_1033151784:root
Fri Sep 27 18:36:28 2002:update:::fcc configuration requested
Fri Sep 27 18:36:33 2002:start:snmp_1033151793_171.71.49.83:admin
Fri Sep 27 18:36:33 2002:stop:snmp_1033151793_171.71.49.83:admin:
Fri Sep 27 18:39:28 2002:start:snmp_1033151968_171.71.49.96:admin
Fri Sep 27 18:39:28 2002:stop:snmp_1033151968_171.71.49.96:admin:
Fri Sep 27 18:39:28 2002:start:_1033151968:root
Fri Sep 27 18:39:31 2002:update:::fcc configuration requested
Fri Sep 27 18:39:37 2002:start:snmp_1033151977_171.71.49.96:admin
Fri Sep 27 18:39:37 2002:stop:snmp_1033151977_171.71.49.96:admin:
Fri Sep 27 18:39:37 2002:start:snmp_1033151977_171.71.49.96:admin
Fri Sep 27 18:42:12 2002:start:snmp_1033152132_171.71.49.96:admin
Fri Sep 27 18:42:12 2002:stop:snmp_1033152132_171.71.49.96:admin:
Fri Sep 27 18:42:12 2002:start:snmp_1033152132_171.71.49.96:admin
Fri Sep 27 18:42:40 2002:start:snmp_1033152160_171.71.49.96:admin
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show arp

To view Address Resolution Protocol (ARP) entries, use the **show arp** command.

show arp

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples This displays the ARP table.

```
switch# show arp
Protocol Address          Age (min)  Hardware Addr  Type  Interface
Internet  171.1.1.1              0          0006.5bec.699c  ARPA  mgmt0
Internet  172.2.0.1              4          0000.0c07.ac01  ARPA  mgmt0
```

Related Commands	Command	Description
	clear arp-cache	Clears the arp-cache table entries.

Send documentation comments to mdsfeedback-doc@cisco.com.

show authentication

To display the configured authentication methods, use the **show authentication** command.

show authentication

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays authentication information.

```
switch# show authentication
authentication method:none
    console:not enabled
    telnet/ssh:not enabled
authentication method:radius
    console:not enabled
    telnet/ssh:not enabled
authentication method:local
    console:enabled
    telnet/ssh:enabled
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show boot

To display the boot variables, use the **show boot** command.

show boot [sup-1 | sup-2]

Syntax Description	show boot	Displays the boot variables in any Cisco MDS 9000 Family switch.
	sup-1	Displays the boot variables for the active supervisor module in any Cisco MDS 9500 Series switch.
	sup-2	Displays the boot variables for the standby supervisor module in any Cisco MDS 9500 Series switch.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2) and modified in Release 1.0(3).

Usage Guidelines None.

Examples To display the current contents of the boot variable, enter the following command at the switch prompt:

```
switch# show boot
sup-1
KICKSTART variable = bootflash:/kickstart-image
SYSTEM variable = bootflash:/system-image;
sup-2
KICKSTART variable = bootflash:/kickstart-image
SYSTEM variable = bootflash:/system-image;
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show callhome

To display related Call Home information configured on a switch, use the **show callhome** command.

show callhome [**destination-profile** *profile*] [**transport-email**]

Syntax Description	destination-profile <i>profile</i>	Shows callhome destination profile information for the specified profile.
	transport-email	Shows callhome email transport information.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

The following example displays configured callhome information.

```
switch# show callhome
callhome enabled
Callhome Information:
contact person name:who@where
contact person's email:person@place.com
contact person's phone number:310-408-4000
street addr:1234 Picaboo Street, Any city, Any state, 12345
site id:Site1ManhattanNewYork
customer id:Customer1234
contract id:Andiamo1234
switch priority:0
```

The following example displays destination profile information.

```
switch# show callhome destination-profile
XML destination profile information
maximum message size:250000
email addresses configured:
findout@.cisco.com

Short-txt destination profile information
maximum message size:4000
email addresses configured:
person1@epage.company.com

full-txt destination profile information
maximum message size:250000
email addresses configured:
person2@company2.com
```


Send documentation comments to mdsfeedback-doc@cisco.com.

The following example displays the full-text profile.

```
switch# show callhome destination-profile profile full-txt-destination
full-txt destination profile information
maximum message size:250000
email addresses configured:
person2@company2.com
```

The following example displays the short-text profile.

```
switch# show callhome destination-profile profile short-txt-destination
Short-txt destination profile information
maximum message size:4000
email addresses configured:
person2@company2.com
```

The following example displays the XML destination profile.

```
switch# show callhome destination-profile profile XML-destination
XML destination profile information
maximum message size:250000
email addresses configured:
findout@.cisco.com
```

The following example displays e-mail and SMTP information.

```
switch# show callhome transport-email
from email addr:user@company1.com
reply to email addr:pointer@company.com
return receipt email addr:user@company1.com
smtp server:server.company.com
smtp server port:25
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show cdp

To display CDP parameters configured globally or for a specific interface, use the **show cdp** command.

```
show cdp { all | entry [ all | name cdp-name ] | global | interface [ gigabitethernet slot-port | mgmt
0 ] | neighbors [ detail | interface (gigabitethernet slot-port | mgmt 0 )] | traffic interface [
gigabitethernet slot-port | mgmt 0 ] }
```

Syntax Description.		
all		Displays all enabled CDP interfaces.
entry		Displays CDP database entries.
all		Displays all CDP entries in the database
name		Displays CDP entries that match a specified name.
<i>cdp-name</i>		Specifies the name matching a CDP entry (restricted to 256 characters).
global		Displays global CDP parameters.
interface		Displays CDP parameters for an interface.
gigabitethernet		Specifies the Gigabit Ethernet interface.
<i>slot-port</i>		Specifies the slot number and port number separated by a slash (/).
mgmt 0		Specifies the Ethernet management interface.
neighbors		Displays all CDP neighbors.
detail		Displays detailed information for all CDP neighbors
interface		Displays CDP information for neighbors on a specified interface.
traffic		Displays CDP traffic statistics for an interface.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines This command is allowed only on the active supervisor module in the Cisco MDS 9500 Series.

Examples The following example displays all CDP capable interfaces and parameters.

```
switch# show cdp all
GigabitEthernet4/1 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
GigabitEthernet4/8 is down
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
mgmt0 is up
  CDP enabled on interface
  Sending CDP packets every 100 seconds
  Holdtime is 200 seconds
```

The following example displays all CDP neighbor entries.

```
switch# show cdp entry all
-----
Device ID:069038747(Kiowa3)
Entry address(es):
  IP Address: 172.22.92.5
Platform: WS-C5500, Capabilities: Trans-Bridge Switch
Interface: mgmt0, Port ID (outgoing port): 5/22
Holdtime: 136 sec

Version:
WS-C5500 Software, Version McpSW: 2.4(3) NmpSW: 2.4(3)
Copyright (c) 1995-1997 by Cisco Systems
```

```
Advertisement Version: 1
```

The following example displays the specified CDP neighbor.

```
switch# show cdp entry name 0
-----
Device ID:0
Entry address(es):
  IP Address: 0.0.0.0
Platform: DS-X9530-SF1-K9, Capabilities: Host
Interface: GigabitEthernet4/1, Port ID (outgoing port): GigabitEthernet4/1
Holdtime: 144 sec

Version:
1.1(0.144)
```

```
Advertisement Version: 2
```

```
Duplex: full
```

The following example displays global CDP parameters.

```
switch# show cdp global
Global CDP information:
  CDP enabled globally
  Sending CDP packets every 60 seconds
  Sending a holdtime value of 180 seconds
  Sending CDPv2 advertisements is enabled
```

The following example displays CDP parameters for the management interface.

```
switch# show cdp interface mgmt 0
mgmt0 is up
  CDP enabled on interface
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

The following example displays CDP parameters for the Gigabit Ethernet interface.

```
switch# show cdp interface gigabitethernet 4/1
GigabitEthernet4/1 is up
  CDP enabled on interface
  Sending CDP packets every 80 seconds
  Holdtime is 200 seconds
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example displays CDP Neighbors (brief).

```
switch# show cdp neighbors
Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

Device ID          Local Intrfce  Hldtme  Capability  Platform  Port ID
0                  Gig4/1        135     H           DS-X9530-SF1-  Gig4/1
069038732(Kiowa2  mgmt0        132     T S         WS-C5500      8/11
069038747(Kiowa3  mgmt0        156     T S         WS-C5500      6/20
069038747(Kiowa3  mgmt0        158     T S         WS-C5500      5/22
```

The following example displays CDP neighbors (detail).

```
switch# show CDP neighbor detail
-----
Device ID:0
Entry address(es):
  IP Address: 0.0.0.0
Platform: DS-X9530-SF1-K9, Capabilities: Host
Interface: GigabitEthernet4/1, Port ID (outgoing port): GigabitEthernet4/1
Holdtime: 162 sec

Version:
1.1(0.144)

Advertisement Version: 2
Duplex: full
-----
Device ID:069038732(Kiowa2)
Entry address(es):
  IP Address: 172.22.91.5
Platform: WS-C5500, Capabilities: Trans-Bridge Switch
Interface: mgmt0, Port ID (outgoing port): 8/11
Holdtime: 132 sec

Version:
WS-C5500 Software, Version McpSW: 2.4(3) NmpSW: 2.4(3)
Copyright (c) 1995-1997 by Cisco Systems

Advertisement Version: 1
```

The following example displays the specified CDP neighbor (detail).

```
switch# show CDP neighbors interface gigabitethernet 4/1 detail
-----
Device ID:0
Entry address(es):
  IP Address: 0.0.0.0
Platform: DS-X9530-SF1-K9, Capabilities: Host
Interface: GigabitEthernet4/1, Port ID (outgoing port): GigabitEthernet4/1
Holdtime: 144 sec

Version:
1.1(0.144)

Advertisement Version: 2
Duplex: full
```

The following example displays CDP traffic statistics for the management interface.

```
switch# show cdp traffic interface mgmt 0
-----
Traffic statistics for mgmt0
Input Statistics:
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Total Packets: 1148
Valid CDP Packets: 1148
  CDP v1 Packets: 1148
  CDP v2 Packets: 0
Invalid CDP Packets: 0
  Unsupported Version: 0
  Checksum Errors: 0
  Malformed Packets: 0
```

```
Output Statistics:
  Total Packets: 2329
  CDP v1 Packets: 1164
  CDP v2 Packets: 1165
  Send Errors: 0
```

The following example displays CDP traffic statistics for the Gigabit Ethernet interface

```
switch# show cdp traffic interface gigabitethernet 4/1
-----
Traffic statistics for GigabitEthernet4/1
Input Statistics:
  Total Packets: 674
  Valid CDP Packets: 674
    CDP v1 Packets: 0
    CDP v2 Packets: 674
  Invalid CDP Packets: 0
    Unsupported Version: 0
    Checksum Errors: 0
    Malformed Packets: 0

Output Statistics:
  Total Packets: 674
    CDP v1 Packets: 0
    CDP v2 Packets: 674
  Send Errors: 0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show clock

To show the system date and time and verify the time zone configuration., use the **show clock** command.

show clock

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show clock
Fri Mar 14 01:31:48 UTC 2003
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show cores

To shows all the cores presently available for upload from active sup, use the **show cores** command.

show cores

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples In the following example, an FSPF core was generated on the active supervisor (slot 5), an FCC core on the standby supervisor (slot 6) and acltcam and fib on module (slot 8).

```
switch# show cores

Module-num      Process-name      PID      Core-create-time
-----
5                fspf              1524     Jan 9 03:11
6                fcc                919     Jan 9 03:09
8                acltcam           285     Jan 9 03:09
8                fib                283     Jan 9 03:08
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show environment

To display all environment-related switch information (status of chassis clock, chassis fan modules, power supply modules, power supply redundancy mode and power usage summary, module temperature thresholds and alarm status, use the **show environment** command.

show environment [clock | fan | power | temperature]

Syntax Description		
	clock	Display status of chassis clock modules
	fan	Display status of chassis fan modules
	power	Display status of power supply modules, power supply redundancy mode and power usage summary.
	temperature	Display module temperature thresholds and alarm status of temperature sensors.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the status and alarm states of the clock, fan, power supply and temperature sensors.

```
switch# show environment
switch-180# show env
Clock:
-----
Clock          Model          Hw          Status
-----
A              DS-C9500-CL   0.0        ok/active
B              DS-C9500-CL   0.0        ok/standby

Fan:
-----
Fan           Model          Hw          Status
-----
Chassis      WS-9SLOT-FAN   0.0        ok
PS-1         --             --          ok
PS-2         --             --          ok

Temperature:
```


Send documentation comments to mdsfeedback-doc@cisco.com.

```

-----
Module   Sensor   MajorThresh  MinorThres  CurTemp     Status
         (Celsius) (Celsius)    (Celsius)
-----
1        Outlet   75           60          38          ok
1        Intake   65           50          35          ok

5        Outlet   75           60          36          ok
5        Intake   65           50          36          ok

6        Outlet   75           60          40          ok
6        Intake   65           50          33          ok

9        Outlet   75           60          28          ok
9        Intake   65           50          40          ok

```

Power Supply:

```

-----
PS  Model                Power    Power    Status
    (Watts)  (Amp @42V)
-----
1   DS-CAC-2500W        1153.32  27.46   ok
2   WS-CAC-2500W        1153.32  27.46   ok

```

```

-----
Mod Model                Power    Power    Power    Power    Status
    Requested Requested Allocated Allocated
    (Watts)  (Amp @42V) (Watts)  (Amp @42V)
-----
1   DS-X9016            220.08  5.24    220.08  5.24    powered-up
5   DS-X9530-SF1-K9    220.08  5.24    220.08  5.24    powered-up
6   DS-X9530-SF1-K9    220.08  5.24    220.08  5.24    powered-up
9   DS-X9016            220.08  5.24    220.08  5.24    powered-up

```

Power Usage Summary:

```

-----
Power Supply redundancy mode:                non-redundant (combined)

Total Power Capacity                        2306.64 W

Power reserved for Supervisor(s) [-]        440.16 W
Power reserved for Fan Module(s) [-]        210.00 W
Power currently used by Modules[-]          440.16 W

-----
Total Power Available                        1216.32 W
-----

```

Related Commands

Command	Description
show hardware	Displays all hardware components on a system.

Send documentation comments to mdsfeedback-doc@cisco.com.

show fc2

To display fc2 information, use the **show fc2** command.

```
show fc2 {bind | classf | exchange | exchresp | flogi | nport | plogi | plogi_pwwn | port | port brief
          | socket | sockexch | socknotify | socknport | vsan}
```

Syntax	Description
bind	Shows fc2 socket bindings.
classf	Shows fc2 classf sessions.
exchange	Shows fc2 active exchanges.
exchresp	Shows fc2 active responder exchanges.
flogi	Shows fc2 flogi table.
nport	Shows fc2 local Nports.
plogi	Shows fc2 plogi sessions.
plogi_pwwn	Shows fc2 plogi pwwn entries.
port brief	Shows fc2 physical port table.
socket	Shows fc2 active sockets.
sockexch	Shows fc2 active exchanges for each socket.
socknotify	Shows fc2 local nport plogi/logo notifications per each socket.
socknport	Shows fc2 local nports per each socket.
vsan	Shows fc2 vsan table.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fc2 socket
SOCKET  REF CNT  PROTOCOL  PID  RCVBUF  RMEM_USED  QLEN  NOTSK
b2a64b20      2      0      1421  65535      0      0      0
b2a647e0      3      0      1418  262142     0      0      0
b2a644a0      3      0      1417  65535      0      0      0
b2a64160      3      0      1417  262142     0      0      0
b294b180      3      0      1411  65535      0      0      0
b294ae40      3      0      1411  65535      0      0      0
b294a7c0      3      0      1410  65535      0      0      0
b294a480      2      7      1410  65535      0      0      0
b294a140      3      0      1409  262142     0      0      0
b278bb20      3      0      1409  262142     0      0      0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

b278b4a0      3      0      1407      65535      0      0      0
b278b160      3      0      1407      256000     0      0      0
b278ae20      3      0      1407      65535      0      0      0
b1435b00      3      0      1408      65535      0      0      0
b1434e00      3      0      1406      65535      0      0      0
b1434ac0      3      0      1406      131072     0      0      0
b1434780      3      0      1406      65535      0      0      0
b1434440      2      0      1405      131072     0      0      0
b1434100      3      0      1405      262142     0      0      b1434440
b22e2420      2      0      1372      65535      0      0      0
...
switch# show fc2 bind
      SOCKET RULE  SINDE X  VSAN  D_ID  MASK TYPE  SUBTYPE M_VALUES
b23ba0c0    16  6081000  1      0      0      0 00:00:00 00:00:00:00:00:00:00
b2a647e0    7  ffffffff 65535  fffffd ffffff 22 03:01:00 14:15:16:00:00:00:00
b294b180    7  ffffffff 65535  fffffd ffffff 1  02:01:00 61:62:00:00:00:00:00
b294ae40    7  ffffffff 65535  fffc00 ffff00 22 01:01:00 1b:00:00:00:00:00:00
b294a7c0    7  ffffffff 65535  fffffd ffffff 1  01:01:00 10:00:00:00:00:00:00
...
switch# show fc2 nport
REF  VSAN  D_ID  MASK  FL  ST  IFINDEX  CF  TC  2-SO  IC  RC  RS  CS
EE  3-SO  IC  RC  RS  CS  EE
1  65535 fffffd ffffff 3  0  ffffffff c800 0128 8000 0000 0000 2112 0064 0
008 8000 0000 0000 2112 0064 0000
6  65535 fffc00 ffff00 18b 0  ffffffff c800 0128 8000 0000 0000 2112 0064 0
008 8000 0000 0000 2112 0064 0000
2  65535 fffffa ffffff 3  0  ffffffff c800 0128 8000 0000 0000 2112 0064 0
008 8000 0000 0000 2112 0064 0000
1  65535 fffffc ffffff 3  0  ffffffff c800 0128 8000 0000 0000 2112 0064 0
008 8000 0000 0000 2112 0064 0000
...
switch# show fc2 plogi
HIX ADDRESS VSAN S_ID D_ID IFINDEX FL STATE CF TC 2-SO IC RC
RS CS EE 3-SO IC RC RS CS EE EECNT TCCNT 2CNT 3CNT REFCNT
2157 af364064 1 fffc6c 123400 ffffffff 0000 0 0000 0001 8000 0000 2000
0256 0001 0001 8000 0000 2000 0256 0001 0000 0 0 0 0 1
...
switch# show fc2 port
IX ST MODE EMUL TXPKTS TXDROP TXERR RXPKTS RXDROP R_A_TOV E_D_TOV
F-SO RC RS CS EE 2-SO RS 3-SO RS
0 D 1 0 0 0 0 0 0 0 10000 2000
8000 0000 2112 0001 0001 8000 0256 8000 0256
1 D 1 0 0 0 0 0 0 0 10000 2000
8000 0000 2112 0001 0001 8000 0256 8000 0256
2 D 1 0 0 0 0 0 0 0 10000 2000
8000 0000 2112 0001 0001 8000 0256 8000 0256
3 D 1 0 0 0 0 0 0 0 10000 2000
8000 0000 2112 0001 0001 8000 0256 8000 0256
4 D 1 0 0 0 0 0 0 0 10000 2000
8000 0000 2112 0001 0001 8000 0256 8000 0256
...
switch# show fc2 socknotify
      SOCKET ADDRESS REF  VSAN  D_ID  MASK  FL  ST  IFINDEX
b2a64160 b27f01e4 6  65535 fffc00 ffff00 18b 0  ffffffff
b294a7c0 b27f01e4 6  65535 fffc00 ffff00 18b 0  ffffffff
af8a3a60 b27f01e4 6  65535 fffc00 ffff00 18b 0  ffffffff
...
switch# show fc2 socknport
      SOCKET ADDRESS REF  VSAN  D_ID  MASK  FL  ST  IFINDEX
b2a64160 b27f01e4 6  65535 fffc00 ffff00 18b 0  ffffffff
b294b180 b27f0294 1  65535 fffffd ffffff 3  0  ffffffff
b294a7c0 b27f01e4 6  65535 fffc00 ffff00 18b 0  ffffffff

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

b278ae20 b27f0134 2 65535 fffffa ffffff 3 0 ffffffff
b1434e00 b27f0134 2 65535 fffffa ffffff 3 0 ffffffff
b1434780 b27f0084 1 65535 fffffc ffffff 3 0 ffffffff
af8a3a60 b27f01e4 6 65535 fffc00 ffff00 18b 0 ffffffff

```

```

switch# show fc2 vsan
  VSAN      X_ID  E_D_TOV  R_A_TOV                               WWN
  1          4      2000     10000  20:01:00:05:30:00:58:1f
  2          1      2000     10000  20:02:00:05:30:00:58:1f
  3          1      2000     10000  20:03:00:05:30:00:58:1f
  4          1      2000     10000  20:04:00:05:30:00:58:1f
  5          1      2000     10000  20:05:00:05:30:00:58:1f
  6          1      2000     10000  20:06:00:05:30:00:58:1f
  7          1      2000     10000  20:07:00:05:30:00:58:1f
  8          1      2000     10000  20:08:00:05:30:00:58:1f
  9          1      2000     10000  20:09:00:05:30:00:58:1f
 10         1      2000     10000  20:0a:00:05:30:00:58:1f
 11         1      2000     10000  20:0b:00:05:30:00:58:1f
 12         1      2000     10000  20:0c:00:05:30:00:58:1f
 13         1      2000     10000  20:0d:00:05:30:00:58:1f
 14         1      2000     10000  20:0e:00:05:30:00:58:1f
 15         1      2000     10000  20:0f:00:05:30:00:58:1f
 16         1      2000     10000  20:10:00:05:30:00:58:1f
 17         1      2000     10000  20:11:00:05:30:00:58:1f
 18         1      2000     10000  20:12:00:05:30:00:58:1f
.....

```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcalias

Use the **show fcalias** command to display fcalias configuration.

```
show fcalias [name string] [active] [vsan vsan-range]
```

Syntax Description	name <i>string</i>	Shows members of a specified fcalias
	active	Shows aliases which are part of active zoneset
	vsan <i>vsan-range</i>	Shows aliases belonging to the specified VSAN range. The VSAN ID range is from 1 to 4093.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays fcalias configuration.

```
switch# show fcalias vsan 1
fcalias name Alias2 vsan 1

fcalias name Alias1 vsan 1
  pwn 21:00:00:20:37:6f:db:dd
  pwn 21:00:00:20:37:9c:48:e5
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcanalyzer

Use the **show fcanalyzer** command to display the list of hosts configured for a remote capture.

show fcanalyzer

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The `DEFAULT` keyword shown with an `ActiveClient` entry specifies that the default port is used in attempting the connection to the client.

Examples Displays Configured Hosts

```
switch# show fcanalyzer
PassiveClient = 10.21.0.3
PassiveClient = 10.21.0.3
ActiveClient = 10.21.0.3, DEFAULT
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcc

Use the **show fcc** commands to view FCC settings.

show fcc

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	<p>Displays Configured FCC Information</p> <pre>switch# show fcc fcc is disabled fcc is applied to frames with priority up to 4</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcdomain

To show the fcdomain information, use the **show fcdomain** command.

```
show fcdomain {address-allocation [cache] | domain-list | fcid persistent | statistics | interface
| vsan [vsan-id / vsan-range]}
```

Syntax Description		
	address-allocation	Shows statistics for the fcid allocation
	cache	The cache is used by the principle switch to reassign the FC IDs for a device (disk or host) that exited and reentered the fabric. In the cache content, VSAN refers to the VSAN that contains the device, WWN refers to the device that owned the FC IDs, and mask refers to a single or entire area of FC IDs.
	domain-list	Shows list of domain ids granted by the principal sw
	fcid persistent	Shows persistent FCIDs (across reboot)
	statistics interface	Shows the statistics of fcdomain
	vsan vsan-id / vsan-range	The ID or range of the VSAN (from 1 to 4093).

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines Issuing the **show fcdomain** with no arguments shows all VSANs. The VSANs should be active or you will get an error.

Examples

```
switch# show fcdomain vsan 1
```

The local switch is a Subordinated Switch.

```
Local switch run time information:
  State: Stable
  Local switch WWN:      20:01:00:05:30:00:51:1f
  Running fabric name:  10:00:00:60:69:22:32:91
  Running priority:    128
  Current domain ID:   0x64(100)  ß verify domain id
```

```
Local switch configuration information:
  State: Enabled
  Auto-reconfiguration: Disabled
  Contiguous-allocation: Disabled
  Configured fabric name: 41:6e:64:69:61:6d:6f:21
  Configured priority: 128
```


Send documentation comments to mdsfeedback-doc@cisco.com.

Configured domain ID: 0x64(100) (preferred)

Principal switch run time information:

Running priority: 2

Interface	Role	RCF-reject
fc2/1	Downstream	Disabled
fc2/2	Downstream	Disabled
fc2/7	Upstream	Disabled

switch# **show fcdomain domain-list vsan 1**

Number of domains: 5

Domain ID	WWN
0x61(97)	10:00:00:60:69:50:0c:fe
0x62(98)	20:01:00:05:30:00:47:9f
0x63(99)	10:00:00:60:69:c0:0c:1d
0x64(100)	20:01:00:05:30:00:51:1f [Local]
0x65(101)	10:00:00:60:69:22:32:91 [Principal]

switch# **show fcdomain vsan 1**

The local switch is a Subordinated Switch.

Local switch run time information:

State: Stable
 Local switch WWN: 20:01:00:05:30:00:47:9f
 Running fabric name: 10:00:00:60:69:22:32:91
 Running priority: 128
 Current domain ID: 0x62(98) & verify domain

Local switch configuration information:

State: Enabled
 Auto-reconfiguration: Disabled
 Contiguous-allocation: Disabled
 Configured fabric name: 41:6e:64:69:61:6d:6f:21
 Configured priority: 128
 Configured domain ID: 0x62(98) (preferred)

Principal switch run time information:

Running priority: 2

Interface	Role	RCF-reject
fc1/1	Upstream	Disabled
fc1/3	Non-principal	Disabled
fc1/6	Non-principal	Disabled

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcdroplateny

To view the configured latency parameters, use the **show fcdroplateny** command.

show fcdroplateny [**network** | **switch**]

Syntax Description	network	Network latency in milliseconds.
	switch	Switch latency in milliseconds.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fcdroplateny
switch latency value:4000 milliseconds
network latency value:5000 milliseconds
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcflow stats

To view the configured fcflow information, use the **show fcflow stats** command.

show fcflow stats

Syntax Description		
	aggregated	Shows aggregated fcflow statistics.
	module <i>module-number</i>	Shows fcflow statistics for a specified module. The module number is a number from 1-9.
	usage	Shows flow index usage

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays aggregated fcflow details for the specified module.

```
switch# show fcflow stats aggregated module 2
Idx  VSAN # frames # bytes
-----
0000 4    387,653  674,235,875
0001 6    34,402   2,896,628
```

The following example displays fcflow details for the specified module.

```
switch# show fcflow stats module 2
Idx  VSAN D ID          S ID          mask          # frames # bytes
-----
0000 4    032.001.002 007.081.012 ff.ff.ff      387,653  674,235,875
0001 6    004.002.001 019.002.004 ff.00.00      34,402   2,896,628
```

The following example displays fcflow index usage for the specified module.

```
switch# show fcflow stats usage module 2
2 flows configured
configured flow : 3,7
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcfwd

To view the configured fcfwd tables and statistics, use the **show fcfwd** command.

```
show fcfwd {idxmap [interface-toport | port-to-interface | statistics] | pemap [interface] |sfib
[multicast | statistics | unicast] | spanmap [rx | tx]}
```

Syntax Description		
	idxmap	Shows FC fwd index tables.
	interface-to-port	Shows interface index to port index table.
	port-to-interface	Shows port index to interface index table.
	statistics	Shows index table statistics.
	pemap	Shows FC fwd PortChannel table.
	interface	Shows PortChannel table for an interface.
	sfib	Shows software forwarding tables.
	multicast	Shows multicast software forwarding tables.
	statistics	Shows software forwarding statistics.
	unicast	Shows unicast software forwarding tables.
	spanmap	Shows spanmap tables.
	rx	Shows spanmap table in ingress -rx direction.
	tx	Shows spanmap table in egress -tx direction.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fcfwd spanmap rx
SPAN source information: size [c8]
dir source                vsan    bit    drop_thresh destination
```

```
switch# show fcfwd idxmap statistics
idxmap statistics:
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcip profile

You can check the status of an interface at any time by using the **show interface** command.

show fcip profile [*profile-id*]

Syntax Description	fcip profile	Show the information for all FCIP profiles.
	<i>profile-id</i>	Show the information for the specified profile from 1 to 255.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None

Examples The following example displays all FCIP profiles.

```
switch# show fcip profile
-----
ProfileId      Ipaddr          TcpPort
-----
1              41.1.1.2        3225
2              10.10.100.154   3225
3              43.1.1.2        3225
4              44.1.1.100      3225
6              46.1.1.2        3225
7              47.1.1.2        3225
```

The following example displays information for a specified FCIP profile.

```
switch# show fcip profile 7
FCIP Profile 7
  Internet Address is 47.1.1.2 (interface GigabitEthernet4/7)
  Listen Port is 3225
  TCP parameters
    SACK is disabled
    PMTU discovery is enabled, reset timeout is 3600 sec
    Keep alive is 60 sec
    Minimum retransmission timeout is 300 ms
    Maximum number of re-transmissions is 4
    Send buffer size is 0 KB
    Maximum allowed bandwidth is 1000000 kbps
    Minimum available bandwidth is 15000 kbps
    Estimated round trip time is 1000 usec
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fctimer

To view the Fibre Channel timers, use the **show fctimer** command.

```
show fctimer [D_S_TOV | E_D_TOV | F_S_TOV | R_A_TOV]
```

Syntax Description	D_S_TOV	D_S_TOV in milliseconds
	E_D_TOV	E_D_TOV in milliseconds
	F_S_TOV	F_S_TOV in milliseconds
	R_A_TOV	R_A_TOV in milliseconds

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fctimer
F_S_TOV : 5000 milliseconds
D_S_TOV : 5000 milliseconds
E_D_TOV : 2000 milliseconds
R_A_TOV : 10000 milliseconds
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcns database

Use the **show fcns database** command to display the results of the discovery, or to display the name server database for a specified VSAN or for all VSANs.

show fcns database {**detail** [**vsan** *vsan-id*] | **domain** *domain-id* [**detail**] **vsan** *vsan-range* | *fcid* *fcid-id* | *local* [**detail**]*vsan* *vsan-range*] | *vsan* *vsan-id*}

Syntax Description		
detail		Shows all objects in each entry.
vsan <i>vsan-id</i>		Shows entries for a specified VSAN or VSANs (from 1 to 4093.).
domain <i>domain-id</i>		Shows entries in a domain.
fcid <i>fcid-id</i>		Shows entry for the given port.
local		Shows local entries.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The discovery can take several minutes to complete, especially if the fabric is large fabric or if several devices are slow to respond.

Examples

```
switch# show fcns database
VSAN 1:
-----
FCID          TYPE  PWWN                               (VENDOR)          FC4-TYPE:FEATURE
-----
0x9c0000      N     21:00:00:e0:8b:08:96:22 (Company 1)       scsi-fcp:init
0x9c0100      N     10:00:00:05:30:00:59:1f (Company 2)       ipfc
0x9c0200      N     21:00:00:e0:8b:07:91:36 (Company 3)       scsi-fcp:init
0x9c03d6      NL    21:00:00:20:37:46:78:97 (Company 4)       scsi-fcp:target
0x9c03d9      NL    21:00:00:20:37:5b:cf:b9 (Company 4)       scsi-fcp:target
0x9c03da      NL    21:00:00:20:37:18:6f:90 (Company 4)       scsi-fcp:target
0x9c03dc      NL    21:00:00:20:37:5a:5b:27 (Company 4)       scsi-fcp:target
0x9c03e0      NL    21:00:00:20:37:36:0b:4d (Company 4)       scsi-fcp:target
0x9c03e1      NL    21:00:00:20:37:39:90:6a (Company 4)       scsi-fcp:target
0x9c03e2      NL    21:00:00:20:37:18:d2:45 (Company 4)       scsi-fcp:target
0x9c03e4      NL    21:00:00:20:37:6b:d7:18 (Company 4)       scsi-fcp:target
0x9c03e8      NL    21:00:00:20:37:38:a7:c1 (Company 4)       scsi-fcp:target
0x9c03ef      NL    21:00:00:20:37:18:17:d2 (Company 4)       scsi-fcp:target

Total number of entries = 13
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcns statistics

Use the **show fcns statistics** command to display the statistical information for a specified VSAN or for all VSANs.

show fcns statistics [detail] vsan *vsan-range*

Syntax Description	detail	Shows detailed statistics.
	vsan <i>vsan-range</i>	Shows statistics for the specified VSAN or VSANs (from 1 to 4093).

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fcns statistics
registration requests received = 27
deregistration requests received = 0
queries received = 57
queries sent = 10
reject responses sent = 14
RSCNs received = 0
RSCNs sent = 0
switch#
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show fcroute

Use the **show fcroute** command to view specific information about existing Fibre Channel and FSPF configurations.

```
show fcroute [distance | label [label] vsan vsan-id / multicast vsan vsan-id /summary vsan
vsan-id / unicast fc-id vsan vsan-id / unicast vsan vsan-id]
```

distance	Shows FC route preference.
label	Shows label routes.
multicast	Shows FC multicast routes.
summary	Shows FC routes summary.
unicast	Shows FC unicast routes.
vsan <i>vsan-id</i>	The ID of the VSAN (from 1 to 4093).
<i>fcid-id</i>	The Fibre Channel ID.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines When the number of routes are displayed in the command output, both visible and hidden routes are included in the total number of routes.

Examples The following example displays administrative distance.

```
switch# show fcroute distance

      Route
  UUID  Distance      Name
  ----  -
  10     20             RIB
  22     40             FCDOMAIN
  39     80             RIB-CONFIG
  12    100             FSPF
  17    120             FLOGI
  21    140             TLPM
  14    180             MCAST
  64    200             RIB-TEST
```

The following example displays multicast routing information.

```
switch# show fcroute multicast
VSAN FC ID # Interfaces
-----
 1  0xffffffff 0
 2  0xffffffff 1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

3    0xffffffff 1
4    0xffffffff 0
5    0xffffffff 0
6    0xffffffff 0
7    0xffffffff 0
8    0xffffffff 0
9    0xffffffff 0
10   0xffffffff 0

```

The following example displays FCID information for a specified VSAN.

```
switch# show fcroute multicast vsan 3
```

```

VSAN FC ID    # Interfaces
---- -
3    0xffffffff 1

```

The following example displays FCID and interface information for a specified VSAN.

```
switch# show fcroute multicast 0xffffffff vsan 2
```

```

VSAN FC ID    # Interfaces
---- -
2    0xffffffff 1
     fc1/1

```

The following example displays unicast routing information.

```
switch# show fcroute unicast
```

```

D:direct R:remote P:permanent V:volatile A:active N:non-active
# Next
Protocol VSAN    FC ID/Mask      Rctl/Mask  Flags Hops  Cost
-----
static   1    0x010101 0xffffffff 0x00 0x00 D P A 1    10
static   2    0x111211 0xffffffff 0x00 0x00 R P A 1    10
fspf     2    0x730000 0xff0000 0x00 0x00 D P A 4    500
fspf     3    0x610000 0xff0000 0x00 0x00 D P A 4    500
static   4    0x040101 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040102 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040103 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040104 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x111211 0xffffffff 0x00 0x00 D P A 1    10

```

The following example displays unicast routing information for a specified VSAN.

```
switch# show fcroute unicast vsan 4
```

```

D:direct R:remote P:permanent V:volatile A:active N:non-active
# Next
Protocol VSAN    FC ID/Mask      Rctl/Mask  Flags Hops  Cost
-----
static   4    0x040101 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040102 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040103 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x040104 0xffffffff 0x00 0x00 R P A 1    103
static   4    0x111211 0xffffffff 0x00 0x00 D P A 1    10

```

The following example displays unicast routing information for a specified FCID.

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch# show fcroute unicast 0x040101 0xffffffff vsan 4

D:direct R:remote P:permanent V:volatile A:active N:non-active
# Next
Protocol VSAN    FC ID/Mask      Rctl/Mask  Flags Hops  Cost
-----
static   4      0x040101 0xffffffff 0x00 0x00 R P A 1    103
      fc1/2 Domain 0xa6(166)
```

The following example displays route database information.

```
switch# show fcroute summary

FC route database created Tue Oct 29 01:24:23 2002
VSAN    Ucast    Mcast    Label    Last Modified Time
-----
1       2        1        0        Tue Oct 29 18:07:02 2002
2       3        1        0        Tue Oct 29 18:33:24 2002
3       2        1        0        Tue Oct 29 18:10:07 2002
4       6        1        0        Tue Oct 29 18:31:16 2002
5       1        1        0        Tue Oct 29 01:34:39 2002
6       1        1        0        Tue Oct 29 01:34:39 2002
7       1        1        0        Tue Oct 29 01:34:39 2002
8       1        1        0        Tue Oct 29 01:34:39 2002
9       1        1        0        Tue Oct 29 01:34:39 2002
10      1        1        0        Tue Oct 29 01:34:39 2002
Total   19       10       0
```

The following example displays route database information for a specified VSAN.

```
switch# show fcroute summary vsan 4

FC route database created Tue Oct 29 01:24:23 2002
VSAN    Ucast    Mcast    Label    Last Modified Time
-----
4       6        1        0        Tue Oct 29 18:31:16 2002
Total   6        1        0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show fcs

Use the **show fcs** commands to display the status of the fabric configuration.

```
show fcs {database vsan vsan-range | ie [nwwn wwn vsan vsan-range / vsan vsan-range] |
platform [name string vsan vsan-range / vsan vsan-range] / port [pwwn wwn vsan
vsan-range / vsan vsan-range] / statistics vsan vsan-range / vsan}
```

Syntax Description		
database	Shows local database of FCS.	
ie	Shows Interconnect Element Objects Information.	
platform	Shows Platform Objects Information.	
port	Shows Port Objects Information.	
statistics	Shows statistics for FCS packets.	
vsan	Shows list of all the VSANs and plat-check-mode for each.	
<i>vsan-range</i>	Range of the required VSANs (from 1 to 4093)	

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays FCS database information.

```
switch# show fcs database

FCS Local Database in VSAN: 1
-----
Switch WWN                : 20:01:00:05:30:00:16:df
Switch Domain Id          : 0x7f(127)
Switch Mgmt-Addresses     : snmp://172.22.92.58/eth-ip
                          : http://172.22.92.58/eth-ip
Fabric-Name                : 20:01:00:05:30:00:16:df
Switch Logical-Name       : 172.22.92.58
Switch Information List   : [Cisco Systems*DS-C9509*0*20:00:00:05:30:00
Switch Ports:
-----
Interface  pWWN                Type      Attached-pWWNs
-----
fc2/1      20:41:00:05:30:00:16:de    TE        20:01:00:05:30:00:20:de
fc2/2      20:42:00:05:30:00:16:de    Unknown   None
fc2/17     20:51:00:05:30:00:16:de    TE        20:0a:00:05:30:00:20:de

FCS Local Database in VSAN: 5
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

-----
Switch WWN                : 20:05:00:05:30:00:12:5f
Switch Domain Id         : 0xef(239)
Switch Mgmt-Addresses    : http://172.22.90.171/eth-ip
                        : snmp://172.22.90.171/eth-ip
                        : http://10.10.15.10/vsan-ip
                        : snmp://10.10.15.10/vsan-ip
Fabric-Name              : 20:05:00:05:30:00:12:5f
Switch Logical-Name      : 172.22.90.171
Switch Information List   : [Cisco Systems*DS-C9509**20:00:00:05:30:00:12:5e]
Switch Ports:
-----
Interface  pWWN                Type      Attached-pWWNs
-----
fc3/1      20:81:00:05:30:00:12:5e  TE        22:01:00:05:30:00:12:9e
fc3/2      20:82:00:05:30:00:12:5e  TE        22:02:00:05:30:00:12:9e
fc3/3      20:83:00:05:30:00:12:5e  TE        22:03:00:05:30:00:12:9e

```

The following example displays Interconnect Element object information for a specific VSAN.

```

switch# show fcs ie vsan 1

IE List for VSAN: 1
-----
IE-WWN                IE-Type                Mgmt-Id
-----
20:01:00:05:30:00:16:df  Switch (Local)         0xffffc7f
20:01:00:05:30:00:20:df  Switch (Adjacent)     0xffffc64
[Total 2 IEs in Fabric]

```

This command displays Interconnect Element object information for a specific WWN.

```

switch# show fcs ie nwwn 20:01:00:05:30:00:16:df vsan 1
IE Attributes
-----
Domain-Id = 0x7f(127)
Management-Id = 0xffffc7f
Fabric-Name = 20:01:00:05:30:00:16:df
Logical-Name = 172.22.92.58
Management Address List =
    snmp://172.22.92.58/eth-ip
    http://172.22.92.58/eth-ip
Information List:
    Vendor-Name = Cisco Systems
    Model Name/Number = DS-C9509
    Release-Code = 0

```

This command displays platform information.

```

switch# show fcs platform name SamplePlatform vsan 1
Platform Attributes
-----
Platform Node Names:
    11:22:33:44:55:66:77:88
Platform Type = Gateway
Platform Management Addresses:
    1.1.1.1

```

Send documentation comments to mdsfeedback-doc@cisco.com.

This command displays platform information within a specified VSAN.

```
switch# show fcs platform vsan 1
Platform List for VSAN: 1
Platform-Names
-----
SamplePlatform
[Total 1 Platforms in Fabric]
```

This command displays FCS port information within a specified VSAN.

```
switch# show fcs port vsan 24
Port List in VSAN: 24
-- IE WWN: 20:18:00:05:30:00:16:df --
-----
Port-WWN                Type      Module-Type      Tx-Type
-----
20:41:00:05:30:00:16:de  TE_Port   SFP with Serial Id  Shortwave Laser
20:51:00:05:30:00:16:de  TE_Port   SFP with Serial Id  Shortwave Laser

[Total 2 switch-ports in IE]
-- IE WWN: 20:18:00:05:30:00:20:df --
-----
Port-WWN                Type      Module-Type      Tx-Type
-----
20:01:00:05:30:00:20:de  TE_Port   SFP with Serial Id  Shortwave Laser
20:0a:00:05:30:00:20:de  TE_Port   SFP with Serial Id  Shortwave Laser

[Total 2 switch-ports in IE]
```

This command displays ports within a specified WWN.

```
switch# show fcs port pwn 20:51:00:05:30:00:16:de vsan 24
Port Attributes
-----
Port Type = TE_Port
Port Number = 0x1090000
Attached-Port-WWNs:
    20:0a:00:05:30:00:20:de
Port State = Online
```

This command displays FCS statistics.

```
switch# show fcs statistics

FCS Statistics for VSAN: 1
-----
FCS Rx Get Reqs   :2
FCS Tx Get Reqs   :7
FCS Rx Reg Reqs   :0
FCS Tx Reg Reqs   :0
FCS Rx Dereg Reqs :0
FCS Tx Dereg Reqs :0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
FCS Rx RSCNs      :0
FCS Tx RSCNs      :3
FCS Rx RJTs       :3
FCS Tx RJTs       :0
FCS Rx ACCs       :4
FCS Tx ACCs       :2
FCS No Response   :0
FCS Retransmit    :0

FCS Statistics for VSAN: 30
-----
FCS Rx Get Reqs   :2
FCS Tx Get Reqs   :2
FCS Rx Reg Reqs   :0
FCS Tx Reg Reqs   :0
FCS Rx Dereg Reqs :0
FCS Tx Dereg Reqs :0
FCS Rx RSCNs      :0
FCS Tx RSCNs      :0
FCS Rx RJTs       :0
FCS Tx RJTs       :0
FCS Rx ACCs       :2
FCS Tx ACCs       :2
FCS No Response   :0
FCS Retransmit    :0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show file

To display the contents of a specified file in the file system, use the **show file** command.

show file *filename*

Syntax Description	<i>filename</i>	The name of the file for which you want to display contents.
---------------------------	-----------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Usage Guidelines	None.
-------------------------	-------

Examples	The following example displays the contents of the test file that resides in the slot0 directory.
-----------------	---

```
switch# show file slot0:test
config t
Int fc1/1
no shut
end
show int
```

The following example displays the contents of a file residing in the current directory.

```
switch# show file myfile
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show flash

To display the flash usage, use the **show flash** command.

show flash

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	The show flash command displays the disk usage of various devices. <pre>switch# show flash</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show flogi database

To list all the flogi sessions through all interfaces across all vsans, use the **show flogi database** command.

show flogi database [**fcid** *fcid-id* | **interface** *interface* | **vsan** *vsan-id*]

Syntax Description	Parameter	Description
	fcid	Optional - filters flogi based on the fcid allocated.
	interface	Optional - filters flogi based on the logged in interface.
	vsan	Optional - filters flogi based on the vsan.
	<i>vsan-id</i>	The ID of the VSAN is from 1 to 4093.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines Output of this command is first sorted on interface and then on vsans.

In a Fibre Channel fabric, each host or disk requires an FC ID. Use the **show flogi** command to verify if a storage device is displayed in the Fabric login (FLOGI) table as in the examples below. If the required device is displayed in the FLOGI table, the fabric login is successful. Examine the flogi database on a switch that is directly connected to the host HBA and connected ports.

Examples This command displays details on the FLOGI database.

```
switch# show flogi database
-----
INTERFACE  VSAN    FCID          PORT NAME          NODE NAME
-----
sup-fc0    2       0xb30100     10:00:00:05:30:00:49:63  20:00:00:05:30:00:49:5e
fc9/13     1       0xb200e2     21:00:00:04:cf:27:25:2c  20:00:00:04:cf:27:25:2c
fc9/13     1       0xb200e1     21:00:00:04:cf:4c:18:61  20:00:00:04:cf:4c:18:61
fc9/13     1       0xb200d1     21:00:00:04:cf:4c:18:64  20:00:00:04:cf:4c:18:64
fc9/13     1       0xb200ce     21:00:00:04:cf:4c:16:fb  20:00:00:04:cf:4c:16:fb
fc9/13     1       0xb200cd     21:00:00:04:cf:4c:18:f7  20:00:00:04:cf:4c:18:f7

Total number of flogi = 6.
```

This command displays the FLOGI interface.

```
switch# show flogi database interface fc1/11
-----
INTERFACE  VSAN    FCID          PORT NAME          NODE NAME
-----
fc9/13     1 0xa002ef 21:00:00:20:37:18:17:d2  20:00:00:20:37:18:17:d2
fc9/13     1 0xa002e8 21:00:00:20:37:38:a7:c1  20:00:00:20:37:38:a7:c1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
fc9/13    1 0xa002e4 21:00:00:20:37:6b:d7:18 20:00:00:20:37:6b:d7:18
fc9/13    1 0xa002e2 21:00:00:20:37:18:d2:45 20:00:00:20:37:18:d2:45
fc9/13    1 0xa002e1 21:00:00:20:37:39:90:6a 20:00:00:20:37:39:90:6a
fc9/13    1 0xa002e0 21:00:00:20:37:36:0b:4d 20:00:00:20:37:36:0b:4d
fc9/13    1 0xa002dc 21:00:00:20:37:5a:5b:27 20:00:00:20:37:5a:5b:27
fc9/13    1 0xa002da 21:00:00:20:37:18:6f:90 20:00:00:20:37:18:6f:90
fc9/13    1 0xa002d9 21:00:00:20:37:5b:cf:b9 20:00:00:20:37:5b:cf:b9
fc9/13    1 0xa002d6 21:00:00:20:37:46:78:97 20:00:00:20:37:46:78:97
```

Total number of flogi = 10.

This command displays the FLOGI VSAN.

```
switch# show flogi database vsan 1
```

```
-----
INTERFACE  VSAN    FCID          PORT NAME          NODE NAME
-----
fc9/13     1       0xef02ef     22:00:00:20:37:18:17:d2 20:00:00:20:37:18:17:d2
fc9/13     1       0xef02e8     22:00:00:20:37:38:a7:c1 20:00:00:20:37:38:a7:c1
fc9/13     1       0xef02e4     22:00:00:20:37:6b:d7:18 20:00:00:20:37:6b:d7:18
fc9/13     1       0xef02e2     22:00:00:20:37:18:d2:45 20:00:00:20:37:18:d2:45
fc9/13     1       0xef02e1     22:00:00:20:37:39:90:6a 20:00:00:20:37:39:90:6a
fc9/13     1       0xef02e0     22:00:00:20:37:36:0b:4d 20:00:00:20:37:36:0b:4d
fc9/13     1       0xef02dc     22:00:00:20:37:5a:5b:27 20:00:00:20:37:5a:5b:27
fc9/13     1       0xef02da     22:00:00:20:37:18:6f:90 20:00:00:20:37:18:6f:90
fc9/13     1       0xef02d9     22:00:00:20:37:5b:cf:b9 20:00:00:20:37:5b:cf:b9
fc9/13     1       0xef02d6     22:00:00:20:37:46:78:97 20:00:00:20:37:46:78:97
```

Total number of flogi = 10.

This command displays the FLOGI FCID.

```
switch# show flogi database fcid 0xef02e2
```

```
-----
INTERFACE  VSAN    FCID          PORT NAME          NODE NAME
-----
fc9/13     1       0xef02e2     22:00:00:20:37:18:d2:45 20:00:00:20:37:18:d2:45
```

Total number of flogi = 1.

Related Commands

Command	Description
show fcns database	Shows all the local and remote name server entries

[Send documentation comments to mdsfeedback-doc@cisco.com.](mailto:mdsfeedback-doc@cisco.com)

show fspf

To display global FSPF information, use the **show fspf** command. This information includes:

- the domain number of the switch
- the autonomous region for the switch
- Min_LS_arrival: the minimum time that must elapse before the switch accepts LSR updates
- Min_LS_interval: the minimum time that must elapse before the switch can transmit an LSR
- LS_refresh_time: the interval lapse between refresh LSR transmissions
- Max_age: the maximum time aa LSR can stay before being deleted

```
show fspf database [vsan vsan-id] [domain domain-id [detail]]
```

```
show fspf interface
```

```
show fspf [vsan vsan-id] [interface [interface range]]
```

Syntax Description		
database	To display information of fspf database for a VSAN. If no other parameters are given all the LSRs in the database are displayed. If more specific information is required then the domain number of the owner of the LSR may be given. Detail gives more detailed information on each LSR.	
domain <i>domain-id</i>	The domain of the database. The parameter <i>domain_num</i> is unsigned integers in the range 0-255.	
interface <i>interface</i>	Display FSPF interface information for a given VSAN. If the interface number is specified information on the neighbor on that interface is displayed. If no interface is specified information on all interfaces are displayed. The parameter <i>interface_range</i> is of the format fcslot/port - fcslot/port	
vsan	Specifies the VSAN.	
<i>vsan-id</i>	The ID of the VSAN is from 1 to 4093.	

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show fspf vsan 1 interface fc 2/14
FSPF interface fc2/14 in VSAN 1
FSPF routing administrative state is active
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Interface cost is 500
Timer intervals configured, Hello 20 s, Dead 80 s, Retransmit 5 s
FSPF State is FULL
Neighbor Domain Id is 0x03(3), Neighbor Interface index is 0x0001060d

Statistics counters :
  Number of packets received :LSU 184 LSA 184 Hello 5477 Error packets 0
  Number of packets transmitted :LSU 184 LSA 184 Hello 5478 Retransmitted
LSU 0
  Number of times inactivity timer expired for the interface = 0
```

The following example displays FSPF interface information.

```
switch# show fspf interface vsan 1 fc1/1
FSPF interface fc1/1 in VSAN 1
FSPF routing administrative state is active
Interface cost is 500
Timer intervals configured, Hello 20 s, Dead 80 s, Retransmit 5 s
FSPF State is FULL
Neighbor Domain Id is 0x0c(12), Neighbor Interface index is 0x0f100000

Statistics counters :
  Number of packets received : LSU 8 LSA 8 Hello 118 Error packets 0
  Number of packets transmitted : LSU 8 LSA 8 Hello 119 Retransmitted LSU
0
  Number of times inactivity timer expired for the interface = 0
```

The following example displays FSPF database information.

```
switch# show fspf database vsan 1

FSPF Link State Database for VSAN 1 Domain 0x0c(12)
LSR Type = 1
Advertising domain ID = 0x0c(12)
LSR Age = 1686
LSR Incarnation number = 0x80000024
LSR Checksum = 0x3caf
Number of links = 2
  NbrDomainId      IfIndex      NbrIfIndex      Link Type      Cost
-----
  0x65(101) 0x0000100e    0x00001081          1          500
  0x65(101) 0x0000100f    0x00001080          1          500

FSPF Link State Database for VSAN 1 Domain 0x65(101)
LSR Type = 1
Advertising domain ID = 0x65(101)
LSR Age = 1685
LSR Incarnation number = 0x80000028
LSR Checksum = 0x8443
Number of links = 6
  NbrDomainId      IfIndex      NbrIfIndex      Link Type      Cost
-----
  0xc3(195) 0x00001085    0x00001095          1          500
  0xc3(195) 0x00001086    0x00001096          1          500
  0xc3(195) 0x00001087    0x00001097          1          500
  0xc3(195) 0x00001084    0x00001094          1          500
  0x0c(12) 0x00001081    0x0000100e          1          500
  0x0c(12) 0x00001080    0x0000100f          1          500

FSPF Link State Database for VSAN 1 Domain 0xc3(195)
LSR Type = 1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Advertising domain ID = 0xc3(195)
LSR Age = 1686
LSR Incarnation number = 0x80000033
LSR Checksum = 0x6799
Number of links = 4
  NbrDomainId      IfIndex    NbrIfIndex    Link Type      Cost
-----
  0x65(101) 0x00001095    0x00001085      1             500
  0x65(101) 0x00001096    0x00001086      1             500
  0x65(101) 0x00001097    0x00001087      1             500
  0x65(101) 0x00001094    0x00001084      1             500
```

This command displays FSPF information for a specified VSAN.

```
switch# show fspf vsan 1
FSPF routing for VSAN 1
FSPF routing administration status is enabled
FSPF routing operational status is UP
It is an intra-domain router
Autonomous region is 0
SPF hold time is 0 msec
MinLsArrival = 1000 msec , MinLsInterval = 5000 msec
Local Domain is 0x65(101)
Number of LSRs = 3, Total Checksum = 0x0001288b

Protocol constants :
  LS_REFRESH_TIME = 1800 sec
  MAX_AGE          = 3600 sec

Statistics counters :
  Number of LSR that reached MaxAge = 0
  Number of SPF computations = 7
  Number of Checksum Errors = 0
  Number of Transmitted packets : LSU 65 LSA 55 Hello 474 Retranmsitted LSU 0
  Number of received packets : LSU 55 LSA 60 Hello 464 Error packets 10
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show hardware

Use the **show hardware** command to display switch hardware inventory details.

show hardware

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	<pre>switch# sho hardware Cisco Storage Area Networking Operating System (SAN-OS) Software TAC support:http://www.cisco.com/tac Copyright (c) 1986-2002 by cisco Systems, Inc. All rights reserved. The copyright for certain works contained herein are owned by Andiamo Systems, Inc. and/or other third parties and are used and distributed under license. Software BIOS: version 0.0.0 loader: version 1.0(0.259) kickstart:version 1.0(2) [build 1.0(0.280)] system: version 1.0(2) [build 1.0(0.280)] BIOS compile time: 10/10/02 kickstart image file is:bootflash:/boot-280 kickstart compile time: 11/20/2002 6:00:00 system image file is: isan-280 system compile time: 11/20/2002 6:00:00 Hardware RAM 963108 kB bootflash:503808 blocks (block size 512b) slot0: 0 blocks (block size 512b) 172.22.92.28 uptime is 0 days 0 hour 31 minute(s) 23 second(s) Last reset Reason:Watchdog Timeout/External Reset System version:1.0(2)</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

```
This supervisor carries Pentium processor with 963108 kB of memory
Intel(R) Pentium(R) III CPU at 800MHz with 512 KB L2 Cache
Rev:Family 6, Model 11 stepping 1
```

```
512K bytes of non-volatile memory.
503808 blocks of internal bootflash (block size 512b)
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show hosts

Use the **show hosts** command to display configured DNS host configuration details details.

show hosts

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	<p>The following example displays the configured hosts including the default domain, domain list, and name servers.</p> <pre>switch# show hosts Default domain is cisco.com Domain list: ucsc.edu harvard.edu yale.edu stanford.edu Name/address lookup uses domain service Name servers are 15.1.0.1 15.2.0.0</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show in-order-gaurantee

Use the **show in-order-gaurantee** command to display the present configured state of the in-order delivery feature.

show in-order-gaurantee

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the present configuration status of the in-order delivery feature.

```
switch# show in-order-guarantee  
inorder delivery is not guaranteed
```

[Send documentation comments to mdsfeedback-doc@cisco.com.](mailto:mdsfeedback-doc@cisco.com)

show interface

You can check the status of an interface at any time by using the **show interface** command.

```
show interface [brief | counters | description | fc | fc-link link-id | fcip interface-number |
gigabitethernet | iscsi | mgmt| port-channel | sup-fc | transceiver | trunk vsan [vsan-id] |
vsan vsan-id [interface range]
```

Syntax	Description
<i>interface range</i>	Displays the interfaces in the specified range.
brief	Show brief info of interface.
counters	Show counters of interface.
description	Show description of interface.
fc	Fibre Channel interface.
fc-link <i>link-id</i>	Show description of the specified FCIP link from 1 to 4095.
fcip <i>interface-number</i>	Show description of the specified FCIP interface from 1 to 255.
gigabitethernet <i>slot/port</i>	Show description of the Gigabit Ethernet interface in the specified slot/ port.
iscsi <i>slot/port</i>	Show description of the iSCSI interface in the specified slot/ port.
mgmt	Show description of the management interface.
port-channel	Show description of the PortChannel interface.
sup-fc	Inband interface
transceiver	Show transceiver information for interface.
trunk vsan	Show the trunking status of all VSANs.
<i>vsan-id</i>	Show the trunking status of the specified VSANs.
vsan <i>vsan-id</i>	Show the VSAN interface (brief, counters, or description for a specified interface or a range of interfaces)

Defaults None

Command Modes EXEC

Command History This command was modified in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None

Examples

```
switch# show interface fc1/1
fc1/1 is up
  Hardware is Fibre Channel, 20:01:ac:16:5e:4a:00:00
  vsan is 1
  Port mode is E
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Speed is 1 Gbps
Beacon is turned off
FCID is 0x0b0100
  0 frames input, 0 bytes, 0 discards
  0 runts, 0 jabber, 0 too long, 0 too short
  0 input errors, 0 CRC, 0 invalid transmission words
  0 address id, 0 delimiter
  0 EOF abort, 0 fragmented, 0 unknown class
  0 frames output, 0 bytes, 0 discards
Received 0 OLS, 0 LRR, 0 NOS, 0 loop inits
Transmitted 0 OLS, 0 LRR, 0 NOS, 0 loop inits
```

```
switch# show int sup-fc0
sup-fc0 is up
  Hardware is FastEthernet, address is 0000.0000.0000
  MTU 2596 bytes, BW 1000000 Kbit
  66 packets input, 7316 bytes
  Received 0 multicast frames, 0 compressed
  0 input errors, 0 frame, 0 overrun 0 fifo
  64 packets output, 28068 bytes, 0 underruns
  0 output errors, 0 collisions, 0 fifo
  0 carrier errors
```

```
switch# show int vsan 2
vsan2 is up, line protocol is up
  WWPN is 10:00:00:05:30:00:59:1f, FCID is 0xb90100
  Internet address is 10.1.1.1/24
  MTU 1500 bytes, BW 1000000 Kbit
  0 packets input, 0 bytes, 0 errors, 0 multicast
  0 packets output, 0 bytes, 0 errors, 0 dropped
```

```
switch# show interface description
fc1/1
  no description
fc1/2
  no description
fc1/15
fcAn1

sup-fc0 is up

mgmt0 is up

vsan1 - IPFC interface

port-channel 15
no description

port-channel 98
no description
```

```
switch# show interface fc2/1 - 5 brief
show int brief
```

```
-----
Interface  Vsan   Admin  Admin  Status           Oper  Oper  Port-channel
              Mode   Trunk
-----
```

Send documentation comments to mdsfeedback-doc@cisco.com.

				Mode	(Gbps)		
fc1/1	1	auto	on	down	--	--	--
fc1/2	1	auto	on	fcotAbsent	--	--	--
fc1/3	1	F	--	notConnected	--	--	--
fc1/4	1	auto	on	fcotAbsent	--	--	--
fc1/5	1	F	--	up	F	2	--
fc1/6	1	auto	on	fcotAbsent	--	--	--
fc1/7	1	auto	on	down	--	--	--
fc1/8	1	auto	on	fcotAbsent	--	--	--
fc1/9	1	auto	on	fcotAbsent	--	--	--
fc1/10	1	auto	on	fcotAbsent	--	--	--
fc1/11	1	auto	on	down	--	--	--
fc1/12	1	auto	on	fcotAbsent	--	--	--
fc1/13	1	auto	on	down	--	--	--
fc1/14	1	auto	on	fcotAbsent	--	--	--
fc1/15	1	auto	on	down	--	--	--
fc1/16	1	auto	on	fcotAbsent	--	--	--

Interface	Status	IP Address	Speed	MTU
sup-fc0	up	--	1 Gbps	2596

Interface	Status	IP Address	Speed	MTU
mgmt0	up	173.95.112/24	100 Mbps	1500

Interface	Status	IP Address	Speed	MTU
vsan1	up	10.1.1.1/24	1 Gbps	1500

switch# **show interface fcip 3 counters**

fcip3

TCP Connection Information

2 Active TCP connections

Control connection: Local 43.1.1.2:3225, Remote 43.1.1.1:65532

Data connection: Local 43.1.1.2:3225, Remote 43.1.1.1:65534

30 Attempts for active connections, 0 close of connections

TCP Parameters

Path MTU 1500 bytes

Current retransmission timeout is 300 ms

Round trip time: Smoothed 10 ms, Variance: 5

Advertized window: Current: 122 KB, Maximum: 122 KB, Scale: 1

Peer receive window: Current: 114 KB, Maximum: 114 KB, Scale: 1

Congestion window: Current: 2 KB, Slow start threshold: 1048560 KB

5 minutes input rate 64 bits/sec, 8 bytes/sec, 0 frames/sec

5 minutes output rate 64 bits/sec, 8 bytes/sec, 0 frames/sec

910 frames input, 84652 bytes

910 Class F frames input, 84652 bytes

0 Class 2/3 frames input, 0 bytes

0 Error frames timestamp error 0

908 frames output, 84096 bytes

908 Class F frames output, 84096 bytes

0 Class 2/3 frames output, 0 bytes

0 Error frames 0 reass frames

switch# **show interface counters brief**

switch# show interface counters b

Interface	Input (rate is 5 min avg)		Output (rate is 5 min avg)	
	Rate	Total	Rate	Total

Send documentation comments to mdsfeedback-doc@cisco.com.

```

-----
                MB/s      Frames                MB/s      Frames
-----
fc9/1             0          0             0          0
fc9/2             0          0             0          0
fc9/3             0          0             0          0
fc9/4             0          0             0          0
...

```

```

-----
Interface          Input (rate is 5 min avg)      Output (rate is 5 min avg)
-----
                Rate      Total                Rate      Total
                MB/s      Frames                MB/s      Frames
-----
iscsi4/1           0          0             0          0
iscsi4/2           0          0             0          0
iscsi4/3           0          0             0          0
iscsi4/4           0          0             0          0
...

```

```

vsan10 is up, line protocol is up
  WWPN is 10:00:00:05:30:00:07:23, FCID is 0xee0001
  Internet address is 10.1.1.5/24
  MTU 1500 bytes, BW 1000000 Kbit
  0 packets input, 0 bytes, 0 errors, 0 multicast
  0 packets output, 0 bytes, 0 errors, 0 dropped

```

```

-----
Interface          Input (rate is 5 min avg)      Output (rate is 5 min avg)
-----
                Rate      Total                Rate      Total
                MB/s      Frames                MB/s      Frames
-----
port-channel 100  0          0             0          0

```

```

-----
Interface          Input (rate is 5 min avg)      Output (rate is 5 min avg)
-----
                Rate      Total                Rate      Total
                Mbits/s  Frames                Mbits/s  Frames
-----
fcip2              0          0             0          0
fcip3              9          0             9          0

fcip6              8          0             8          0
fcip7              8          0             8          0

```

```

switch# show interface fcip 3
fcip3 is trunking
  Hardware is GigabitEthernet
  Port WWN is 20:ca:00:05:30:00:07:1e
  Peer port WWN is 20:ca:00:00:53:00:18:1e
  Admin port mode is auto, trunk mode is on
  Port mode is TE
  vsan is 1
  Trunk vsans (allowed active) (1,10)
  Trunk vsans (operational) (1)
  Trunk vsans (up) (1)
  Trunk vsans (isolated) (10)
  Trunk vsans (initializing) ()
  Using Profile id 3 (interface GigabitEthernet4/3)
  Peer Information
    Peer Internet address is 43.1.1.1 and port is 3225

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

Special Frame is disabled
Maximum number of TCP connections is 2
Time Stamp is disabled
B-port mode disabled
TCP Connection Information
  2 Active TCP connections
    Control connection: Local 43.1.1.2:3225, Remote 43.1.1.1:65532
    Data connection: Local 43.1.1.2:3225, Remote 43.1.1.1:65534
  30 Attempts for active connections, 0 close of connections
TCP Parameters
  Path MTU 1500 bytes
  Current retransmission timeout is 300 ms
  Round trip time: Smoothed 10 ms, Variance: 5
  Advertized window: Current: 122 KB, Maximum: 122 KB, Scale: 1
  Peer receive window: Current: 114 KB, Maximum: 114 KB, Scale: 1
  Congestion window: Current: 2 KB, Slow start threshold: 1048560 KB
  5 minutes input rate 64 bits/sec, 8 bytes/sec, 0 frames/sec
  5 minutes output rate 64 bits/sec, 8 bytes/sec, 0 frames/sec
  866 frames input, 80604 bytes
    866 Class F frames input, 80604 bytes
    0 Class 2/3 frames input, 0 bytes
    0 Error frames timestamp error 0
  864 frames output, 80048 bytes
    864 Class F frames output, 80048 bytes
    0 Class 2/3 frames output, 0 bytes
    0 Error frames 0 reass frames

```

```

switch# show interface gigabitethernet 4/1
GigabitEthernet4/1 is up
  Hardware is GigabitEthernet, address is 0005.3000.2e12
  Internet address is 100.1.1.2/24
  MTU 1500 bytes, BW 1000000 Kbit
  Port mode is IPS
  Speed is 1 Gbps
  Beacon is turned off
  5 minutes input rate 32 bits/sec, 4 bytes/sec, 0 frames/sec
  5 minutes output rate 88 bits/sec, 11 bytes/sec, 0 frames/sec
  637 packets input, 49950 bytes
    0 multicast frames, 0 compressed
    0 input errors, 0 frame, 0 overrun 0 fifo
  659 packets output, 101474 bytes, 0 underruns
    0 output errors, 0 collisions, 0 fifo
    0 carrier errors

```

```

switch# show interface iscsi 2/1
iscsi2/1 is up
  Hardware is GigabitEthernet
  Port WWN is 20:41:00:05:30:00:50:de
  Admin port mode is ISCSI
  Port mode is ISCSI
  Speed is 1 Gbps
  iSCSI initiator is identified by name
  Number of iSCSI session: 7, Number of TCP connection: 7
  Configured TCP parameters
    Local Port is 3260
    PMTU discover is disabled
    Keepalive-timeout is 1 sec
    Minimum-retransmit-time is 300 ms
    Max-retransmissions 8
    Sack is disabled
    Minimum available bandwidth is 0 kbps
    Estimated round trip time is 0 usec
  5 minutes input rate 265184 bits/sec, 33148 bytes/sec, 690 frames/sec
  5 minutes output rate 375002168 bits/sec, 46875271 bytes/sec, 33833 frames/sec

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

iSCSI statistics
  6202235 packets input, 299732864 bytes
    Command 6189718 pdus, Data-out 1937 pdus, 1983488 bytes, 0 fragments
  146738794 packets output, 196613551108 bytes
    Response 6184282 pdus (with sense 4), R2T 547 pdus
    Data-in 140543388 pdus, 189570075420 bytes

switch# show interface transceiver
fc1/1 fcot is present but not supported
  name is IBM
  part number is IBM42P21SNY
  revision is AA20
  serial number is 53P148700109D
  vendor specific data (bytes 96-127)
    0x49 0x42 0x4D 0x20 0x53 0x46 0x50 0x53
    0x20 0x41 0x52 0x45 0x20 0x43 0x4C 0x41
    0x53 0x53 0x20 0x31 0x20 0x4C 0x41 0x53
    0x45 0x52 0x20 0x53 0x41 0x46 0x45 0x20
fc1/2 fcot not present
fc1/3 fcot is present but not supported
  name is IBM
  part number is IBM42P21SNY
  revision is AA20
  serial number is 53P1487000ZXR
  vendor specific data (bytes 96-127)
    0x49 0x42 0x4D 0x20 0x53 0x46 0x50 0x53
    0x20 0x41 0x52 0x45 0x20 0x43 0x4C 0x41
    0x53 0x53 0x20 0x31 0x20 0x4C 0x41 0x53
    0x45 0x52 0x20 0x53 0x41 0x46 0x45 0x20

```


Send documentation comments to mdsfeedback-doc@cisco.com.

show ip route

To display the ip routes currently active, use the **show ip route** command.

show ip route

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show ip route

Codes: C - connected, S - static

Default gateway is 172.22.95.1

C 10.0.0.0/24 is directly connected, vsan1
C 172.22.95.0/24 is directly connected, mgmt0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show ip routing

To display the ip routing state, use the **show ip routing** command.

show ip routing

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples

```
switch# show ip routing
ip routing is disabled
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show ips arp

You can check the status of an interface at any time by using the **show ips arp** command.

show ips arp interface gigabitethernet slot-number

Syntax Description		
ips	Displays the information for all IP storage configurations.	
arp	Displays the ARP table.	
interface gigabitethernet	Specifies the interface type	
<i>slot-number</i>	Specifies the slot number and port number of the required interface.	

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines Use the **show ips arp interface gigabitethernet** command to display the ARP cache on the Gigabit Ethernet interfaces. This command takes the main Ethernet interface and as a parameter and returns the ARP cache for that interface.

Examples The following example displays ARP caches in the specified interface:

```
switch# show ips arp interface gigabitethernet 4/4
Protocol      Address      Age (min)   Hardware Addr  Type   Interface
Protocol      Address      Age (min)   Hardware Addr  Type   Interface
Internet      172.22.91.1  2    -    00:00:0c:07:ac:01  ARPA   GigabitEthernet4/4
Internet      172.22.91.2  0    -    00:02:7e:6b:a8:08  ARPA   GigabitEthernet4/4
Internet      172.22.91.17 0    -    00:e0:81:20:45:f5  ARPA   GigabitEthernet4/4
Internet      172.22.91.18 0    -    00:e0:81:05:f7:64  ARPA   GigabitEthernet4/4
Internet      172.22.91.30 0    -    00:e0:18:2e:9d:19  ARPA   GigabitEthernet4/4
...
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show ips ip route

You can check the status of an interface at any time by using the **show ips ip route** command.

```
show ips ip route interface gigabitethernet slot-number
```

Syntax Description	ips	Displays the information for all IP storage configurations.
	ip route	Displays the IP route table.
	interface gigabitethernet	Specifies the interface type
	<i>slot-number</i>	Specifies the slot number and port number of the required interface.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None

Examples The following example displays all FCIP profiles.

```
switch# show ips ip route interface gigabitethernet 8/1
Codes: C - connected, S - static

No default gateway

C 10.1.3.0/24 is directly connected, GigabitEthernet8/1
```

[Send documentation comments to mdsfeedback-doc@cisco.com.](mailto:mdsfeedback-doc@cisco.com)

show ips stats

You can check the status of an interface at any time by using the **show ips stats** command.

```
show ips stats [buffer | dma-bridge | icmp | ip | mac | tcp (detail) ] interface gigabitethernet
slot-number
```

Syntax Description	
ips	Displays the information for all IP storage configurations.
stats	Displays IP storage statistics for the specified interface.
buffer	Displays IP storage buffer information.
dma-bridge	Displays the direct memory access (DMA) statistics.
icmp	Displays ICMP statistics.
ip	Displays IP statistics.
mac	Displays MAC statistics,
tcp	Displays TCP statistics
detail	Displays all statistical information maintained by the interface.
interface gigabitethernet	Specifies the interface type
<i>slot-number</i>	Specifies the slot number and port number of the required interface.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines

Use the **show ips stats icmp interface gigabitethernet** command to obtain ICMP statistics for the selected interface.

Use the **show IPS stats IP interface gigabitethernet 2/1** command to obtain IP statistics for the selected interface.

Use the **show ips stats mac interface gigabitethernet** command to obtain Ethernet statistics for the selected interface.

Use the **show ips stats tcp interface gigabitethernet** command to obtain TCP stats along with the connection list and TCP state or the selected interface.

Examples The following example displays iSCSI buffer statistics.

```
switch# show ips stats buffer interface gigabitethernet 8/1
```

The following example displays ICMP statistics.

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch# show ips stats icmp interface gigabitethernet 8/1
ICMP Statistics for port GigabitEthernet8/1
  2 ICMP messages received
  0 ICMP messages dropped due to errors
ICMP input histogram
  2 echo request
ICMP output histogram
  2 echo reply
```

The following example displays IP statistics.

```
switch# show ips stats ip interface gigabitethernet 8/1
Internet Protocol Statistics for port GigabitEthernet8/1
  22511807 total received, 22509468 good, 2459 error
  0 reassembly required, 0 reassembled ok, 0 dropped after timeout
  27935633 packets sent, 0 outgoing dropped, 0 dropped no route
  0 fragments created, 0 cannot fragment
```

The following example displays MAC statistics.

```
switch# show ips stats mac interface gigabitethernet 8/1
Ethernet MAC Statistics for port GigabitEthernet8/1
Hardware Transmit Counters
  28335543 frame 37251751286 bytes
  0 collisions, 0 late collisions, 0 excess collisions
  0 bad frames, 0 FCS error, 0 abort, 0 runt, 0 oversize
Hardware Receive Counters
  18992406778 bytes, 22835370 frames, 0 multicasts, 2584 broadcasts
  0 bad, 0 runt, 0 CRC error, 0 length error
  0 code error, 0 align error, 0 oversize error
Software Counters
  22835370 received frames, 28335543 transmit frames
  0 frames soft queued, 0 current queue, 0 max queue
  0 dropped, 0 low memory
```

The following example displays TCP statistics.

```
switch# show ips stats tcp interface gigabitethernet 8/1
TCP Statistics for port GigabitEthernet8/1
Connection Stats
  0 active openings, 0 accepts
  0 failed attempts, 0 reset received, 0 established
Segment stats
  23657893 received, 29361174 sent, 0 retransmitted
  0 bad segments received, 0 reset sent

TCP Active Connections
Local Address      Remote Address    State    Send-Q  Recv-Q
10.1.3.3:3260     10.1.3.106:51935 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51936 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51937 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51938 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51939 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51940 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51941 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51942 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51943 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.106:51944 ESTABLISH 0       0
10.1.3.3:3260     10.1.3.115:1026  ESTABLISH 0       0
10.1.3.3:3260     10.1.3.115:1027  ESTABLISH 0       0
10.1.3.3:3260     10.1.3.115:1028  ESTABLISH 0       0
10.1.3.3:3260     10.1.3.115:1029  ESTABLISH 0       0
10.1.3.3:3260     10.1.3.115:1030  ESTABLISH 48      0
10.1.3.3:3260     10.1.3.115:1031  ESTABLISH 48      0
10.1.3.3:3260     10.1.3.115:1032  ESTABLISH 0       0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

10.1.3.3:3260	10.1.3.115:1033	ESTABLISH	0	0
10.1.3.3:3260	10.1.3.115:1034	ESTABLISH	0	0
0.0.0.0:3260	0.0.0.0:0	LISTEN	0	0

Send documentation comments to mdsfeedback-doc@cisco.com.

show ips status

You can check the status of an interface at any time by using the **show ips status** command.

show ips status [**module** *slot-number*]

Syntax Description	Command	Description
	ips	Displays the information for all IP storage configurations.
	status	Displays the ARP table.
	module <i>slot-number</i>	Identifies the module in the specified slot.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None

Examples The following example displays all FCIP profiles.

```
switch# show ips status
      Port 8/1 READY
      Port 8/2 READY
      Port 8/3 READY
      Port 8/4 READY
      Port 8/5 READY
      Port 8/6 READY
      Port 8/7 READY
      Port 8/8 READY

switch# show ips status module 9
      Port 9/1 READY
      Port 98/2 READY
      Port 9/3 READY
      Port 9/4 READY
      Port 9/5 READY
      Port 9/6 READY
      Port 9/7 READY
      Port 9/8 READY

...
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show iscsi global

The **show iscsi global** command shows all the iSCSI initiators that are configured by the user.

show iscsi global

Syntax Description	iscsi global Displays information for all configured iSCSI initiators.
Defaults	None
Command Modes	EXEC
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).
Usage Guidelines	None.
Examples	<p>The following example displays all configured iSCSI initiators</p> <pre>switch# show iscsi global iSCSI Global information Authentication:CHAP, NONE Import FC Target:Enabled Number of target nodes:11 Number of portals:8 Number of sessions:10 Failed sessions:9, Last failed initiator name:iqn.1987-05.com.cisco:02.0163c91bbc28.host1</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show iscsi initiator

The **show iscsi initiator** commands shows all the iSCSI nodes that are remote to the switch.

show iscsi initiator [configured | detail | fcp-session | iscsi-session]

Syntax Description		
	iscsi initiator	Displays iSCSI information for the initiators.
	configured	Displays the configured information for the iSCSI initiator.
	detail	Displays detailed iSCSI initiator information.
	fcp-session	Specifies the Fibre Channel session details.
	iscsi-session	Specifies iSCSI session details.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines If no parameter is provided the command lists all the active iSCSI virtual-targets. If the iSCSI node name is provided then the command lists the details of that iscsi virtual-target.

Examples The following example displays all iSCSI initiators

```
switch# show iscsi initiator
iSCSI Node name is iqn.1987-05.com.cisco.01.15cee6e7925087abc82ed96377653c8
  iSCSI alias name: iscsi7-lnx
  Node WWN is 23:10:00:05:30:00:7e:a0 (dynamic)
  Member of vsans: 1
  Number of Virtual n_ports: 1
  Virtual Port WWN is 23:12:00:05:30:00:7e:a0 (dynamic)
    Interface iSCSI 8/3, Portal group tag: 0x382
      VSAN ID 1, FCID 0xdc0100

iSCSI Node name is iqn.1987-05.com.cisco.02.91b0ee2e8aa1.iscsi16-w2k
  iSCSI alias name: ISCSI16-W2K
  Node WWN is 23:1f:00:05:30:00:7e:a0 (dynamic)
  Member of vsans: 1
  Number of Virtual n_ports: 1
  Virtual Port WWN is 23:28:00:05:30:00:7e:a0 (dynamic)
    Interface iSCSI 8/3, Portal group tag: 0x382
      VSAN ID 1, FCID 0xdc0101

iSCSI Node name is iqn.1987-05.com.cisco.01.b6ca466f8b4d8e848ab17e92f24bf9cc
  iSCSI alias name: iscsi6-lnx
  Node WWN is 23:29:00:05:30:00:7e:a0 (dynamic)
  Member of vsans: 1, 2, 3, 4
  Number of Virtual n_ports: 1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Virtual Port WWN is 23:2a:00:05:30:00:7e:a0 (dynamic)
Interface iSCSI 8/3, Portal group tag: 0x382
VSAN ID 4, FCID 0xee0000
VSAN ID 3, FCID 0xee0100
VSAN ID 2, FCID 0xee0000
VSAN ID 1, FCID 0xdc0102
...
```

The following example displays detailed Information for all iSCSI initiators

```
switch# show iscsi initiator detail
iSCSI Node name is iqn.1987-05.com.cisco.01.15cee6e7925087abc82ed96377653c8
iSCSI alias name: iscsi7-lnx
Node WWN is 23:10:00:05:30:00:7e:a0 (dynamic)
Member of vsans: 1
Number of Virtual n_ports: 1

Virtual Port WWN is 23:10:00:05:30:00:7e:a0 (dynamic)
Interface iSCSI 8/3, Portal group tag is 0x382
VSAN ID 1, FCID 0xdc0100
No. of FC sessions: 3
No. of iSCSI sessions: 2

iSCSI session details

Target node: iqn.com.domainname.172.22.93.143.08-03.gw.22000020374b5247
Statistics:
PDU: Command: 0, Response: 0
Bytes: TX: 0, RX: 0
Number of connection: 1
TCP parameters
Connection Local 10.1.3.3:3260, Remote 10.1.3.107:34112
Path MTU 1500 bytes
Current retransmission timeout is 300 ms
Round trip time: Smoothed 2 ms, Variance: 1
Advertised window: Current: 6 KB, Maximum: 6 KB, Scale: 3
Peer receive window: Current: 250 KB, Maximum: 250 KB, Scale: 2
Congestion window: Current: 8 KB

Target node: iqn.com.domainname.172.22.93.143.08-03.gw.22000020374b5247
Statistics:
PDU: Command: 0, Response: 0
Bytes: TX: 0, RX: 0
Number of connection: 1
TCP parameters
Connection Local 10.1.3.3:3260, Remote 10.1.3.107:34112
Path MTU 1500 bytes
Current retransmission timeout is 300 ms
Round trip time: Smoothed 2 ms, Variance: 1
Advertised window: Current: 6 KB, Maximum: 6 KB, Scale: 3
Peer receive window: Current: 250 KB, Maximum: 250 KB, Scale: 2
Congestion window: Current: 8 KB
...
```

The following example displays the iSCSI initiator information

```
switch# show iscsi initiator
iSCSI Node name is iqn.1987-05.com.cisco.01.15cee6e7925087abc82ed9637
iSCSI alias name: iscsi7-lnx
Node WWN is 23:10:00:05:30:00:7e:a0 (dynamic)
Member of vsans: 1
Number of Virtual n_ports: 1
Virtual Port WWN is 23:12:00:05:30:00:7e:a0 (dynamic)
Interface iSCSI 8/3, Portal group tag: 0x382
VSAN ID 1, FCID 0xdc0100
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
iSCSI Node name is iqn.1987-05.com.cisco:02.91b0ee2e8aa1.iscsi16-w2k
  iSCSI alias name: ISCSI16-W2K
  Node WWN is 23:1f:00:05:30:00:7e:a0 (dynamic)
  Member of vsans: 1
  Number of Virtual n_ports: 1
  Virtual Port WWN is 23:28:00:05:30:00:7e:a0 (dynamic)
    Interface iSCSI 8/3, Portal group tag: 0x382
      VSAN ID 1, FCID 0xdc0101

iSCSI Node name is iqn.1987-05.com.cisco.01.b6ca466f8b4d8e848ab17e92f
  iSCSI alias name: iscsi6-lnx
  Node WWN is 23:29:00:05:30:00:7e:a0 (dynamic)
  Member of vsans: 1, 2, 3, 4
  Number of Virtual n_ports: 1
...
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show iscsi session

You can check the iSCSI port information by using the **show iscsi port** command.

show iscsi session [**detail** | **incoming** | **initiator** | **outgoing** | **target** *word*]

Syntax Description		
	iscsi session	Show the information for all iSCSI ports.
	detail	Show detailed iSCSI session information.
	incoming	Show incoming iscsi sessions
	initiator	Show specific iscsi initiator's session information
	outgoing	Show outgoing iscsi sessions
	target	Show specific iscsi target's session information
	<i>word</i>	Specify an existing target name from 1 to 80 characters.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines All the parameters are optional in the **show iscsi session** commands. If no parameter is provided the command lists all the active iSCSI initiator or target sessions. If the IP address or iSCSI node name is provided, then the command lists details of all sessions from that initiator or to that target.

Examples The following command displays the iSCSI Session.

```
switch# show iscsi session
Initiator iqn.1987-05.com.cisco.01.15cee6e7925087abc82ed96377653c8
  Session #1
    Target iqn.com.domainname.172.22.93.143.08-03.gw.22000020374b5247
    VSAN 1, ISID 000000000000, Status active, no reservation

  Session #2
    Target iqn.com.domainname.172.22.93.143.08-03.gw.220000203738e77d
    VSAN 1, ISID 000000000000, Status active, no reservation

Initiator iqn.1987-05.com.cisco:02.91b0ee2e8aa1.iscsi16-w2k
  Session #1
    Discovery session, ISID 00023d00022f, Status active

  Session #2
    Target iqn.com.domainname.172.22.93.143.08-03.gw.2200002037388bc2
    VSAN 1, ISID 00023d000230, Status active, no reservation
...
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following command displays the Specified iSCSI Target.

```
switch# show iscsi session target
iqn.com.domainname.172.22.93.143.08-03.gw.220000203738e77d
Initiator iqn.1987-05.com.cisco.01.15cee6e7925087abc82ed96377653c8
  Session #1
    Target iqn.com.domainname.172.22.93.143.08-03.gw.220000203738e77d
    VSAN 1, ISID 000000000000, Status active, no reservation
```



Note

On the IPS module, you can verify what iSCSI initiator iqn has been assigned which pWWN when it logs in by using the **show zone active vsan vsan-no** command.

```
switch# zone name iscsi_16_A vsan 16
* fcid 0x7700d4 [pwwn 21:00:00:20:37:c5:2d:6d]
* fcid 0x7700d5 [pwwn 21:00:00:20:37:c5:2e:2e]
* fcid 0x770100 [symbolic-nodename
iqn.1987-05.com.cisco.02.BC3FEEFC431B199F81F33E97E2809C14.NUYEAR]
```

The following command displays the Specified iSCSI Initiator.

```
switch# show iscsi session initiator iqn.1987-05.com.cisco:02.91b0ee2e8aa1.iscsi16-w2k
Initiator iqn.1987-05.com.cisco:02.91b0ee2e8aa1.iscsi16-w2k
  Session #1
    Discovery session, ISID 00023d00022f, Status active

  Session #2
    Target iqn.com.domainname.172.22.93.143.08-03.gw.2200002037388bc2
    VSAN 1, ISID 00023d000230, Status active, no reservation

  Session #3
    Target iqn.com.domainname.172.22.93.143.08-03.gw.210000203739ad7f
    VSAN 1, ISID 00023d000235, Status active, no reservation

  Session #4
    Target iqn.com.domainname.172.22.93.143.08-03.gw.210000203739aa3a
    VSAN 1, ISID 00023d000236, Status active, no reservation

  Session #5
    Target iqn.com.domainname.172.22.93.143.08-03.gw.210000203739ada7
    VSAN 1, ISID 00023d000237, Status active, no reservation

  Session #6
    Target iqn.com.domainname.172.22.93.143.08-03.gw.2200002037381ccb
    VSAN 1, ISID 00023d000370, Status active, no reservation

  Session #7
    Target iqn.com.domainname.172.22.93.143.08-03.gw.2200002037388b54
    VSAN 1, ISID 00023d000371, Status active, no reservation

  Session #8
    Target iqn.com.domainname.172.22.93.143.08-03.gw.220000203738a194
    VSAN 1, ISID 00023d000372, Status active, no reservation

  Session #9
    Target iqn.com.domainname.172.22.93.143.08-03.gw.2200002037360053
    VSAN 1, ISID 00023d000373, Status active, no reservation
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show iscsi stats

You can check the iSCSI port information by using the **show iscsi port** command.

show iscsi stats [clear| detail | iscsi]

Syntax Description		
	iscsi stats	Show iSCSI statistics.
	clear	Show <i>????</i>
	detail	Show detailed iSCSI statistics.
	iscsi	Show statistics for the specified iSCSI interface.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None

Examples The following command displays brief iSCSI statistics.

```
switch# show iscsi stats
iscsi8/1
  5 minutes input rate 23334800 bits/sec, 2916850 bytes/sec, 2841 frames/sec
  5 minutes output rate 45318424 bits/sec, 5664803 bytes/sec, 4170 frames/sec
  iSCSI statistics
    86382665 packets input, 2689441036 bytes
      3916933 Command pdus, 82463404 Data-out pdus, 2837976576 Data-out bytes,
0 fragments
    131109319 packets output, 2091677936 bytes
      3916876 Response pdus (with sense 0), 1289224 R2T pdus
      125900891 Data-in pdus, 93381152 Data-in bytes

iscsi8/2
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  iSCSI statistics
    0 packets input, 0 bytes
      0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
    0 packets output, 0 bytes
      0 Response pdus (with sense 0), 0 R2T pdus
      0 Data-in pdus, 0 Data-in bytes

iscsi8/3
  5 minutes input rate 272 bits/sec, 34 bytes/sec, 0 frames/sec
  5 minutes output rate 40 bits/sec, 5 bytes/sec, 0 frames/sec
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

iSCSI statistics
  30 packets input, 10228 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  30 packets output, 1744 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

iscsi8/4
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

iscsi8/5
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

iscsi8/6
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

iscsi8/7
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

iscsi8/8
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes

```

The following command displays detailed iSCSI statistics.

```

switch# show iscsi stats detail
iscsi8/1
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics

```


Send documentation comments to mdsfeedback-doc@cisco.com.

```

    0 packets input, 0 bytes
      0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
    0 packets output, 0 bytes
      0 Response pdus (with sense 0), 0 R2T pdus
      0 Data-in pdus, 0 Data-in bytes
iSCSI Forward:
  Command: 0 PDUs (Received: 0)
  Data-Out (Write): 0 PDUs (Received 0), 0 fragments, 0 bytes
FCP Forward:
  Xfer_rdy: 0 (Received: 0)
  Data-In: 0 (Received: 0), 0 bytes
  Response: 0 (Received: 0), with sense 0
  TMF Resp: 0

iSCSI Stats:
  Login: attempt: 0, succeed: 0, fail: 0, authen fail: 0
  Rcvd: NOP-Out: 0, Sent: NOP-In: 0
        NOP-In: 0, Sent: NOP-Out: 0
        TMF-REQ: 0, Sent: TMF-RESP: 0
        Text-REQ: 0, Sent: Text-RESP: 0
        SNACK: 0
        Unrecognized Opcode: 0, Bad header digest: 0
        Command in window but not next: 0, exceed wait queue limit: 0
        Received PDU in wrong phase: 0
FCP Stats:
  Total: Sent: 0
        Received: 0 (Error: 0, Unknown: 0)
  Sent: PLOGI: 0, Rcvd: PLOGI_ACC: 0, PLOGI_RJT: 0
        PRLI: 0, Rcvd: PRLI_ACC: 0, PRLI_RJT: 0, Error resp: 0
        LOGO: 0, Rcvd: LOGO_ACC: 0, LOGO_RJT: 0
        ABTS: 0, Rcvd: ABTS_ACC: 0
        TMF REQ: 0
        Self orig command: 0, Rcvd: data: 0, resp: 0
  Rcvd: PLOGI: 0, Sent: PLOGI_ACC: 0
        LOGO: 0, Sent: LOGO_ACC: 0
        PRLI: 0, Sent: PRLI_ACC: 0
        ABTS: 0

iSCSI Drop:
  Command: Target down 0, Task in progress 0, LUN map fail 0
          CmdSeqNo not in window 0, No Exchange ID 0, Reject 0
          Persistent Resv 0   Data-Out: 0, TMF-Req: 0
FCP Drop:
  Xfer_rdy: 0, Data-In: 0, Response: 0

Buffer Stats:
  Buffer less than header size: 0, Partial: 0, Split: 0
  Pullup give new buf: 0, Out of contiguous buf: 0, Unaligned m_data: 0

iscsi8/2
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
iSCSI statistics
  0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
  0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes
iSCSI Forward:
  Command: 0 PDUs (Received: 0)
  Data-Out (Write): 0 PDUs (Received 0), 0 fragments, 0 bytes
FCP Forward:
  Xfer_rdy: 0 (Received: 0)
  Data-In: 0 (Received: 0), 0 bytes

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Response: 0 (Received: 0), with sense 0
...
```

The following command displays detailed statistics for the specified iSCSI interface.

```
switch# show iscsi stats iscsi 8/1
iscsi8/1
  5 minutes input rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  5 minutes output rate 0 bits/sec, 0 bytes/sec, 0 frames/sec
  iSCSI statistics
    0 packets input, 0 bytes
    0 Command pdus, 0 Data-out pdus, 0 Data-out bytes, 0 fragments
    0 packets output, 0 bytes
    0 Response pdus (with sense 0), 0 R2T pdus
    0 Data-in pdus, 0 Data-in bytes
```

The following command displays detailed iSCSI statistics.

```
switch# show iscsi stats clear
iSCSI 2/1 (ifindex 0xb080000)
  iSCSI Forward:
    Command: 538 PDUs (Received: 538)
    Data-Out (Write): 0 PDUs (Received 0), 0 fragments, 0 bytes
  FCP Forward:
    Xfer_rdy: 0 (Received: 0)
    Data-In: 458 (Received: 473), 139928 bytes
    Response: 538 (Received: 556), with sense 0
    TMF Resp: 0

iSCSI 2/2 (ifindex 0xb081000)
  iSCSI Forward:
    Command: 14380 PDUs (Received: 14380)
    Data-Out (Write): 0 PDUs (Received 0), 0 fragments, 0 bytes
  FCP Forward:
    Xfer_rdy: 0 (Received: 0)
    Data-In: 670244 (Received: 670250), 914727320 bytes
    Response: 14380 (Received: 14386), with sense 0
    TMF Resp: 0
...
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show iscsi virtual-target

The **show iscsi virtual-target** command shows all the iSCSI nodes that are local to the switch.

show iscsi virtual-target [*name*]

Syntax Description	iscsi virtual-target	Show the information for all iSCSI ports.
	<i>name</i>	Show iSCSI information for the specified virtual-target.

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines If no parameter is provided the command lists all the active iSCSI virtual-targets. If the iSCSI node name is provided then the command lists the details of that iSCSI virtual-target.

Examples The following example displays the local iSCSI node.

```
switch# show iscsi virtual-target
target: abc
  Port WWN 00:00:00:00:00:00:00:00
  Configured node
target: abc1
  Port WWN 21:00:00:20:37:a6:b0:bf
  Configured node
target: iqn.com.domainname.172.22.93.143.08-03.gw.22000020374b5247
  Port WWN 22:00:00:20:37:4b:52:47 , VSAN 1
  Auto-created node
target: iqn.com.domainname.172.22.93.143.08-03.gw.220000203738e77d
  Port WWN 22:00:00:20:37:38:e7:7d , VSAN 1
  Auto-created node
target: iqn.com.domainname.172.22.93.143.08-03.gw.220000203700cede
  Port WWN 22:00:00:20:37:00:ce:de , VSAN 1
  Auto-created node
...
target: iqn.com.domainname.172.22.93.143.08-03.gw.210000203739aa39
  Port WWN 21:00:00:20:37:39:aa:39 , VSAN 1
  Auto-created node
```

The following example displays a specified local iSCSI node

```
switch# show iscsi virtual-target
iqn.com.domainname.172.22.93.143.08-03.gw.210000203739a95b
target: iqn.com.domainname.172.22.93.143.08-03.gw.210000203739a95b
  Port WWN 21:00:00:20:37:39:a9:5b , VSAN 1
  Auto-created node
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show kernel core

To display kernel core configurations, use the **show kernel core** command.

show kernel core detailed

Syntax Description.	show install impact	Upgrades the BIOS for a supervisor or switching module.
	bootflash:	Source or destination location for internal bootflash memory
	slot0:	Source or destination location for the CompactFlash memory or PCMCIA card.
	volatile:	Source or destination location for the volatile directory.
	<i>image-filename</i>	The name of the system or kickstart image.
	detailed	Compares the image to the current running system image instead of the system.bin image

Defaults None

Command Modes EXEC

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines None.

Examples The following examples display kernel core settings.

```
switch# show kernel core limit
2

switch# show kernel core target
10.50.5.5

switch# show kernel core module 5
module 5 core is enabled
        level is header
        dst_ip is 10.50.5.5
        src_port is 6671
        dst_port is 6666
        dump_dev_name is eth1
        dst_mac_addr is 00:00:0C:07:AC:01
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show logging

Use the **show logging** command to display the current system message logging configuration.

```
show logging [console | level [auth | authpriv | callhome | cron | daemon | ftp | kernel | localn
| lpr | mail | news | security | syslog | user | uucp | vsan] | info | last lines | logfile | module |
monitor | nvram | server servername ]
```

Syntax Description		
	console	Shows console logging configuration.
	info	Shows logging configuration.
	last	Shows last few lines of logfile.
	level	Shows last few lines of logfile.
	logfile	Shows contents of logfile.
	module	Shows module logging configuration.
	monitor	Shows monitor logging configuration.
	nvr am	Shows NVRAM log.
	server <i>servername</i>	Shows server logging configuration.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays current system message logging.

```
switch# show logging

Logging console:                enabled (Severity: notifications)
Logging monitor:                enabled (Severity: information)
Logging linecard:              enabled (Severity: debugging)
Logging server:                 enabled
{172.22.0.0}
  server severity:              debugging
  server facility:              local7
{172.22.0.0}
  server severity:              debugging
  server facility:              local7
Logging logfile:                enabled
  Name - external/sampleLogFile: Severity - notifications Size - 3000000

syslog_get_levels :: Error(-1) querying severity values for fcmpls at SAP 30
syslog_get_levels :: Error(-1) querying severity values for fcfwd at SAP 38
```

Send documentation comments to mdsfeedback-doc@cisco.com.

Facility	Default Severity	Current Session Severity
-----	-----	-----
kern	6	4
user	3	3
mail	3	3
daemon	7	7
auth	0	0
syslog	3	3
lpr	3	3
news	3	3
uucp	3	3
cron	3	3
authpriv	3	3
ftp	3	3
local0	3	3
local1	3	3
local2	3	3
local3	3	3
local4	3	3
local5	3	3
local6	3	3
local7	3	3
fspf	3	3
fcdomain	2	2
module	5	5
zone	2	2
vni	2	2
ipconf	2	2
ipfc	2	2
xbar	3	3
fcns	2	2
fcs	2	2
acl	2	2
tlport	2	2
port	5	5
port_channel	5	5
fcmpls	0	0
wwn	3	3
fcc	2	2
qos	3	3
vrrp_cfg	2	2
fcfwd	0	0
ntp	2	2
platform	5	5
vrrp_eng	2	2
callhome	2	2
mcast	2	2
rscn	2	2
securityd	2	2
vhbad	2	2
rib	2	2
vshd	5	5

0 (emergencies)

1 (alerts)

2 (critical)

3 (errors)

4 (warnings)

5 (notifications)

6 (information)

7 (debugging)

Nov 8 16:48:04 excal-113 %LOG_VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from pts/1 (171.71.58.56)

Nov 8 17:44:09 excal-113 %LOG_VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from pts/0 (171.71.58.72)

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example displays console logging status.

```
switch# show logging console
Logging console:                enabled (Severity: notifications)
```

The following example displays logging facility status.

```
switch# show logging facility
syslog_get_levels :: Error(-1) querying severity values for fcmls at SAP 30
syslog_get_levels :: Error(-1) querying severity values for fcfwd at SAP 38
Facility           Default Severity      Current Session Severity
-----
kern                6                      4
user               3                      3
mail               3                      3
daemon             7                      7
auth               0                      0
syslog             3                      3
lpr                3                      3
news               3                      3
uucp               3                      3
cron               3                      3
authpriv           3                      3
ftp                3                      3
local0             3                      3
local1             3                      3
local2             3                      3
local3             3                      3
local4             3                      3
local5             3                      3
local6             3                      3
local7             3                      3
fspf               3                      3
fcdomain           2                      2
module             5                      5
zone               2                      2
vni                2                      2
ipconf             2                      2
ipfc               2                      2
xbar               3                      3
fcns               2                      2
fcs                2                      2
acl                2                      2
tlport            2                      2
port               5                      5
port_channel       5                      5
fcmls              0                      0
wn                 3                      3
fcc                2                      2
qos                3                      3
vrrp_cfg           2                      2
fcfwd              0                      0
ntp                2                      2
platform           5                      5
vrrp_eng           2                      2
callhome           2                      2
mcast              2                      2
rscn               2                      2
securityd          2                      2
vhbad              2                      2
rib                2                      2
vshd               5                      5
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
0 (emergencies)          1 (alerts)           2 (critical)
3 (errors)               4 (warnings)        5 (notifications)
6 (information)          7 (debugging)
```

The following example displays logging information.

```
switch# show logging info

Logging console:          enabled (Severity: notifications)
Logging monitor:         enabled (Severity: information)
Logging linecard:        enabled (Severity: debugging)
Logging server:          enabled
{172.22.95.167}
  server severity:       debugging
  server facility:       local7
{172.22.92.58}
  server severity:       debugging
  server facility:       local7
Logging logfile:         enabled
  Name - external/sampleLogFile: Severity - notifications Size - 3000000

syslog_get_levels :: Error(-1) querying severity values for fcmps at SAP 30
syslog_get_levels :: Error(-1) querying severity values for fcfd at SAP 38
Facility                Default Severity      Current Session Severity
-----                -
kern                    6                      4
user                    3                      3
mail                    3                      3
daemon                  7                      7
auth                    0                      0
syslog                  3                      3
lpr                     3                      3
news                    3                      3
uucp                    3                      3
cron                    3                      3
authpriv                3                      3
ftp                     3                      3
local0                  3                      3
local1                  3                      3
local2                  3                      3
local3                  3                      3
local4                  3                      3
local5                  3                      3
local6                  3                      3
local7                  3                      3
fspf                    3                      3
fcdomain                2                      2
module                  5                      5
zone                    2                      2
vni                     2                      2
ipconf                  2                      2
ipfc                    2                      2
xbar                    3                      3
fcns                    2                      2
fcs                     2                      2
acl                     2                      2
tlport                 2                      2
port                    5                      5
port_channel            5                      5
fcmps                   0                      0
wwn                     3                      3
fcc                     2                      2
```


Send documentation comments to mdsfeedback-doc@cisco.com.

```

qos                3                3
vrrp_cfg           2                2
fcfwd              0                0
ntp                2                2
platform           5                5
vrrp_eng           2                2
callhome           2                2
mcast              2                2
rscn               2                2
securityd          2                2
vhbad              2                2
rib                2                2
vshd               5                5

0 (emergencies)    1 (alerts)        2 (critical)
3 (errors)         4 (warnings)      5 (notifications)
6 (information)    7 (debugging)

```

The following example displays last few lines of a log file.

```

switch# show logging last 2
Nov  8 16:48:04 excal-113 %LOG_VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console
from pts/1 (171.71.58.56)
Nov  8 17:44:09 excal-113 %LOG_VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console
from pts/0 (171.71.58.72)

```

The following example displays switching module logging status.

```

switch# show logging module
Logging linecard:                enabled (Severity: debugging)

```

The following example displays monitor logging status.

```

switch# show logging monitor
Logging monitor:                enabled (Severity: information)

```

The following example displays server information.

```

switch# show logging server
Logging server:                enabled
{172.22.95.167}
  server severity:             debugging
  server facility:             local7
{172.22.92.58}
  server severity:             debugging
  server facility:             local7

```

Send documentation comments to mdsfeedback-doc@cisco.com.

show module

To verify the status of a module, use the **show module** command.

show module [**diag** | *slot*]

Syntax Description	diag	Shows module-related information.
	<i>slot</i>	Slot number for the required module (1 - 9 for the MDS 9500 Series switch and 1 - 2 for the MDS 9200 Series switch).

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines If your chassis has more than one switching module, you will see the progress check if you issue the show module command several times and view the status column each time.

The switching module goes through a testing and an initializing stage before displaying an `ok` status.

The following table describes the possible states in which a module can exist.

show module Output	Description
<code>powered up</code>	The hardware has electrical power. When the hardware is powered up, the software begins booting.
<code>testing</code>	The module has established connection with the supervisor and the switching module is performing bootup diagnostics.
<code>initializing</code>	The diagnostics have passed and the configuration is being downloaded.
<code>failure</code>	The switch detects a switching module failure on initialization and automatically attempts to power-cycle the module three (3) times. After the third attempt it continues to display a failed state.
<code>ok</code>	The switch is ready to be configured.
<code>power-denied</code>	The switch detects insufficient power for a switching module to power up. In this case, issue a show environment power command to determine power consumption issues (refer to the <i>Cisco MDS 9000 Family Configuration Guide</i>).
<code>active</code>	This module is the active supervisor module and the switch is ready to be configured.

Send documentation comments to mdsfeedback-doc@cisco.com.

show module Output	Description
HA-standby	This module is the standby supervisor module and that the HA switchover mechanism is enabled (refer to the <i>Cisco MDS 9000 Family Configuration Guide</i>).
standby	This module is the standby supervisor module and the warm switchover mechanism is enabled (refer to the <i>Cisco MDS 9000 Family Configuration Guide</i>).

Examples

```
switch# show module
Mod  Ports  Module-Type                Model                Status
---  ---
1    16     1/2 Gbps FC Module         DS-X9016             ok
5    0      Supervisor/Fabric-1       DS-X9530-SF1-K9     active *
6    0      Supervisor/Fabric-1       DS-X9530-SF1-K9     ha-standby
9    16     1/2 Gbps FC Module         DS-X9016             ok

Mod  Sw          Hw          World-Wide-Name(s) (WWN)
---  ---
1    1.0(2.34)   0.3         20:01:00:05:30:00:13:9e to 20:10:00:05:30:00:13:9e
5    1.0(2.34)   0.602      --
6    1.0(2.34)   0.0        --
9    1.0(2.34)   0.0        22:01:00:05:30:00:13:9e to 22:10:00:05:30:00:13:9e

Mod  MAC-Address(es)                Serial-Num
---  ---
1    00-05-30-00-81-6e to 00-05-30-00-81-72  jab063908gj
5    00-05-30-00-84-1a to 00-05-30-00-84-1e  jab063909cv
6    00-05-30-00-2c-5e to 00-05-30-00-2c-62
9    00-05-30-00-03-0c to 00-05-30-00-03-10  123

* this terminal session

switch# show module diag

Diag status for module 2 (. = PASS, F = FAIL, N = N/A)
CPU          .
SPROM        .
ASICS        .

Diag status for module 4 (. = PASS, F = FAIL, N = N/A)
CPU          .
SPROM        .
ASICS        .
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show ntp

To display the configured server and peer associations, use the **show ntp** command.

show ntp peers | statistics [io | local | memory | peer (ipaddr | name)] | timestamp-status

Syntax Description	
peers	Shows all the peers.
statistics	Shows the NTP statistics
io	Shows the input-output statistics.
local	Shows the counters maintained by the local NTP.
memory	Shows the statistics counters related to memory code.
peer	Shows the per-peer statistics counter of a peer.
ipaddr	Shows the peer statistics for the specified IP address.
name	Shows the peer statistics for the specified peer name.
timestamp-status	Shows if the timestamp check is enabled.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following examples display the NTP information.

```
switch# show ntp peers
-----
Peer IP Address          Serv/Peer
-----
10.20.10.2              Server
10.20.10.0              Peer

switch# show ntp statistics io
time since reset:      11152
receive buffers:      9
free receive buffers: 9
used receive buffers: 9
low water refills:    0
dropped packets:      0
ignored packets:      0
received packets:     3
packets sent:         2
packets not sent:     0
interrupts handled:   3
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
received by int:      3

switch# show ntp statistics local
system uptime:      11166
time since reset:   11166
bad stratum in packet: 0
old version packets: 4
new version packets: 0
unknown version number: 0
bad packet format: 0
packets processed: 0
bad authentication: 0

switch# show ntp statistics memory
time since reset:   11475
total peer memory: 15
free peer memory:  15
calls to findpeer: 0
new peer allocations: 0
peer demobilizations: 0
hash table counts: 0 0 0 0 0 0 0 0
                   0 0 0 0 0 0 0 0
                   0 0 0 0 0 0 0 0
                   0 0 0 0 0 0 0 0

switch# show ntp statistics peer ipaddr 10.1.1.1

switch# show ntp statistics peer name Peer1

switch# show ntp timestamp-status
Linecard 9 does not support Timestamp check.
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show port-channel

Use the **show port-channel** command to view information about existing PortChannel configurations

show port-channel compatibility-parameters

show port-channel consistency

show port-channel consistency detail

show port-channel database

show port-channel database interface port-channel *port channel number*

show port-channel summary

show port-channel usage

Syntax Description	
compatibility-parameters	Shows compatibility parameters.
consistency	Verify database consistency of all modules.
detail	Shows port channel database information for all modules.
database	Shows port-channel database.
interface port-channel <i>port channel number</i>	Port channel number (1-128)
summary	Shows port-channel summary.
usage	Shows port-channel number usage.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the PortChannel summary.

```
switch# show port-channel summary
NEW
```

The following example displays the PortChannel compatibility.

```
switch# show port-channel compatibility-parameters
  physical port layer          fibre channel or ethernet
  port mode                    E/TE/AUTO only
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
trunk mode
speed
port VSAN
port allowed VSAN list
```

The following example shows the PortChannel database.

```
switch# show port-channel database
port-channel 2
  Administrative channel mode is on
  Operational channel mode is on
  Last membership update succeeded
  First operational port is fc2/2
  1 port in total, 1 port up
  Ports:  fc2/2    [up]
```

The **show port-channel consistency** command has two options—without detail **and detail**.

Command Without Details

```
switch# show port-channel consistency
Database is consistent
switch#
```

Command With Details

```
switch# show port-channel consistency detail
Authoritative port-channel database:
=====
totally 1 port-channels
port-channel 2:
  1 ports, first operational port is fc2/2
  fc2/2    [up]
=====
database 1: from module 5
=====
totally 1 port-channels

port-channel 2:
  1 ports, first operational port is fc2/2
  fc2/2    [up]
=====
database 2: from module 2
=====
totally 1 port-channels
port-channel 2:
  1 ports, first operational port is fc2/2
  fc2/2    [up]
=====
```

The **show port-channel usage** command displays details of the used and unused PortChannel numbers.

PortChannel Usage

```
switch# show port-channel usage
Totally 2 port-channel numbers used
=====
Used   :    3, 9
Unused:  1-2, 4-8, 10-128
switch#
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show processes

To show general information about all the processes, use the show processes command.

show processes [cpu | log [details | pid *process-id* | memory]

Syntax Description	cpu	Shows processes CPU Info
	log	Shows information about process logs
	memory	Shows processes Memory Info

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following examples displays general information about system processes.

```
switch# show process
PID      State  PC          Start_cnt  TTY  Process
-----  -----  -----
 868     S    2ae4f33e          1    -   snmpd
 869     S    2acee33e          1    -   rscn
 870     S    2ac36c24          1    -   qos
 871     S    2ac44c24          1    -   port-channel
 872     S    2ac7a33e          1    -   ntp
-        ER          -          1    -   mdog
-        NR          -          0    -   vbuilder
```

PID: process ID.

State: process state

```

D  uninterruptible sleep (usually IO)
R  runnable (on run queue)
S  sleeping
T  traced or stopped
Z  a defunct ("zombie") process
```

NR not-running

ER should be running but currently not-running

PC: Current program counter in hex format

Start_cnt: how many times a process has been started.

Send documentation comments to mdsfeedback-doc@cisco.com.

TTY: Terminal that controls the process. A "-" usually means a daemon not running on any particular tty.

Process: name of the process.

=====

2. show processes cpu (new output)

Description: show cpu utilization information about the processes.

switch# **show processes cpu**

PID	Runtime(ms)	Invoked	uSecs	1Sec	Process
842	3807	137001	27	0.0	sysmgr
1112	1220	67974	17	0.0	syslogd
1269	220	13568	16	0.0	fcfwd
1276	2901	15419	188	0.0	zone
1277	738	21010	35	0.0	xbar_client
1278	1159	6789	170	0.0	wnn
1279	515	67617	7	0.0	vsan

Runtime(ms): cpu time the process has used, expressed in milliseconds

Invoked: Number of times the process has been invoked.

uSecs: Microseconds of CPU time in average for each process invocation.

1Sec: CPU utilization in percentage for the last 1 second.

=====

3. show processes mem

Description: show memory information about the processes.

PID	MemAlloc	StackBase/Ptr	Process
1277	120632	7ffffcd0/7ffffefe4	xbar_client
1278	56800	7ffffce0/7ffffb5c	wnn
1279	1210220	7ffffce0/7ffffbac	vsan
1293	386144	7ffffcf0/7ffffbd4	span
1294	1396892	7ffffce0/7ffffdf4	snmpd
1295	214528	7ffffcf0/7ffff904	rscn
1296	42064	7ffffce0/7ffffb5c	qos

MemAlloc: total memory allocated by the process.

StackBase/Ptr: process stack base and current stack pointer in hex format

=====

3. show processes log

Description: list all the process logs

switch# **show processes log**

Process	PID	Normal-exit	Stack-trace	Core	Log-create-time
fspf	1339	N	Y	N	Jan 5 04:25
lcm	1559	N	Y	N	Jan 2 04:49
rib	1741	N	Y	N	Jan 1 06:05

Normal-exit: whether or not the process exited normally.

Stack-trace: whether or not there is a stack trace in the log.

Core: whether or not there exists a core file.

Log-create-time: when the log file got generated.

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example displays the detail log information about a particular process.

```
switch# show processes log pid 1339
Service: fspf
Description: FSPF Routing Protocol Application

Started at Sat Jan  5 03:23:44 1980 (545631 us)
Stopped at Sat Jan  5 04:25:57 1980 (819598 us)
Uptime: 1 hours 2 minutes 2 seconds

Start type: SRV_OPTION_RESTART_STATELESS (23)
Death reason: SYSMGR_DEATH_REASON_FAILURE_SIGNAL (2)
Exit code: signal 9 (no core)
CWD: /var/sysmgr/work

Virtual Memory:

      CODE      08048000 - 0809A100
      DATA      0809B100 - 0809B65C
      BRK        0809D988 - 080CD000
      STACK      7FFFFFFD20
      TOTAL      23764 KB

Register Set:

      EBX 00000005      ECX 7FFFFFF8CC      EDX 00000000
      ESI 00000000      EDI 7FFFFFF6CC      EBP 7FFFFFF95C
      EAX FFFFFFFDFE    XDS 8010002B      XES 0000002B
      EAX 0000008E (orig) EIP 2ACE133E      XCS 00000023
      EFL 00000207      ESP 7FFFFFF654      XSS 0000002B

Stack: 1740 bytes. ESP 7FFFFFF654, TOP 7FFFFFFD20

0x7FFFFFF654: 00000000 00000008 00000003 08051E95 .....
0x7FFFFFF664: 00000005 7FFFFFF8CC 00000000 00000000 .....
0x7FFFFFF674: 7FFFFFF6CC 00000001 7FFFFFF95C 080522CD .....\"..
0x7FFFFFF684: 7FFFFFF9A4 00000008 7FFFC34 2AC1F18C .....4.....*
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show qos statistics

To display the current QoS settings along with a the number of frames marked high priority, use the **show qos statistics** command.

show qos statistics

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	<p>The following example displays configures QoS statistics.</p> <pre>switch# show qos statistics Total number of FC frames transmitted from the Supervisor= 15767 Number of highest-priority FC frames transmitted = 8224 Current priority of FC control frames = 0 (0 = lowest; 7 = highest)</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show radius-server

To display all configured RADIUS server parameters, use the **show radius-server** command.

show radius-server

Syntax Description	This command has no keywords or arguments.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	Only administrators can view the RADIUS pre-shared key.

Examples

```
switch# show radius-server
Global RADIUS shared secret:Myxggc
retransmission count:5
timeout value:10

following RADIUS servers are configured:
  myradius.cisco.users.com:
    available for authentication on port:1812
    available for accounting on port:1813
  172.22.91.37:
    available for authentication on port:1812
    available for accounting on port:1813
    RADIUS shared secret:23MHcUnD
  10.10.0.0:
    available for authentication on port:1812
    available for accounting on port:1813
    RADIUS shared secret:hostkey----> for administrators only
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show role

To display rules (and their associated rules) configured on the switch, including those roles that have not yet been committed to persistent storage, use the **show role** command.

show role [*name string*]

Syntax Description	name string The name of the role for which you want to display information.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	The rules are displayed by rule number and are based on each role. All roles are displayed even if role name is not specified. Only network-admin role can access this command.

Examples

```
switch# show role
Role: network-admin
Description: Predefined Network Admin group. This role cannot be modified
Access to all the switch commands

Role: network-operator
Description: Predefined Network Operator group. This role cannot be modified
Access to Show commands and selected Exec commands

Role: sangroup
Description: SAN management group
-----
Rule   Type   Command-type   Feature
-----
1.    permit  config         *
2.     deny   config         fspf
3.    permit  debug         zone
4.    permit  exec          fcping
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show rscn

To display RSCN information, use the **show rscn** command.

```
show rscn [scr-table vsan vsan-range | statistics vsan vsan-range]
```

Syntax Description	scr-table	Shows State Change Registration table.
	statistics	Shows RSCN statistics.
	vsan <i>vsan-range</i>	Range of the required VSANs (from 1 to 4093).
Defaults	None.	
Command Modes	EXEC mode.	
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).	
Usage Guidelines	The SCR table cannot be configured, it is only populated if one or more Nx ports send SCR frames to register for RSCN information. If the show rscn scr-table command does not return any entries, no Nx port is interested in receiving RSCN information.	

Examples The following examples display RSCN information.

```
switch# show rscn scr-table vsan 1
SCR table for VSAN: 1
-----
FC-ID          REGISTERED FOR
-----
0x1b0300      fabric detected rscns

Total number of entries = 1

switch# show rscn statistics vsan 1

Statistics for VSAN: 1
-----

Number of SCR received           = 0
Number of SCR ACC sent           = 0
Number of SCR RJT sent           = 0
Number of RSCN received          = 0
Number of RSCN sent              = 0
Number of RSCN ACC received      = 0
Number of RSCN ACC sent          = 0
Number of RSCN RJT received      = 0
Number of RSCN RJT sent          = 0
Number of SW-RSCN received       = 0
Number of SW-RSCN sent           = 0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Number of SW-RSCN ACC received = 0
Number of SW-RSCN ACC sent      = 0
Number of SW-RSCN RJT received = 0
Number of SW-RSCN RJT sent      = 0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show running-config

To view the running configuration file, use the **show running-config** command

show running-config [diff]

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines If the running configuration is different from the startup configuration, issue the **show startup-config** command to view the ASCII version of the current startup configuration that was used to boot the switch.

Examples The following example displays the configuration currently running on the switch.

```
switch# show running-config
Building Configuration ...
  interface fc1/1
  interface fc1/2
  interface fc1/3
  interface fc1/4
  interface mgmt0
ip address 172.22.95.112 255.255.255.0
no shutdown
vsan database
boot system bootflash:isan-237; sup-1
boot kickstart bootflash:boot-237 sup-1
callhome
ip default-gateway 172.22.95.1
switchname switch
trunk protocol enable
username admin password 5 /AFDAMD4B2xK2 role network-admin
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show scsi-target

Use the **show scsi target** command to view specific information about existing SCSI configurations.

```
show scsi target {devices [vsan vsan-range | fcid fcid-id] | disk [vsan vsan-range | fcid fcid-id] |
lun [vsan vsan-range | fcid fcid-id] | status | tape [vsan vsan-range | fcid fcid-id]}
```

Syntax Description	
devices	Shows discovered scsi-target devices information
disk	Shows discovered disk information.
lun	Shows discovered SCSI target LUN information.
vsan <i>vsan-range</i>	Specifies the VSAN ID or VSAN range (from 1 to 4093).
fcid <i>fcid-id</i>	Specifies the FCID of the SCSI target to display.
status	Shows SCSI target discovery status.
tape	Shows discovered tape information

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the status of a SCSI discovery.

```
switch# show scsi-target status
discovery completed
```

The following example displays discovered disk information.

```
switch# show scsi-target disk
```

VSAN	FCID	PWWN	VENDOR	MODEL	REV
1	0x9c03d6	21:00:00:20:37:46:78:97	Company 4	ST318203FC	0004
1	0x9c03d9	21:00:00:20:37:5b:cf:b9	Company 4	ST318203FC	0004
1	0x9c03da	21:00:00:20:37:18:6f:90	Company 4	ST318203FC	0004
1	0x9c03dc	21:00:00:20:37:5a:5b:27	Company 4	ST318203FC	0004
1	0x9c03e0	21:00:00:20:37:36:0b:4d	Company 4	ST318203FC	0004
1	0x9c03e1	21:00:00:20:37:39:90:6a	Company 4	ST318203 CLAR18	3844
1	0x9c03e2	21:00:00:20:37:18:d2:45	Company 4	ST318203 CLAR18	3844
1	0x9c03e4	21:00:00:20:37:6b:d7:18	Company 4	ST318203 CLAR18	3844
1	0x9c03e8	21:00:00:20:37:38:a7:c1	Company 4	ST318203FC	0004
1	0x9c03ef	21:00:00:20:37:18:17:d2	Company 4	ST318203FC	0004

The following example displays the discovered LUNs.

```
show scsi-target
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch# show scsi-target lun
- ST318203FC          from Company 4  (Rev 0004)
  FCID is 0x9c03d6 in VSAN 1, PWWN is 21:00:00:20:37:46:78:97
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LRA2510000007027 C:1 A:0 T:3 20:00:00:20:37:46:78:97
- ST318203FC          from Company 4  (Rev 0004)
  FCID is 0x9c03d9 in VSAN 1, PWWN is 21:00:00:20:37:5b:cf:b9
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LR94873000007029 C:1 A:0 T:3 20:00:00:20:37:5b:cf:b9
- ST318203FC          from Company 4  (Rev 0004)
  FCID is 0x9c03da in VSAN 1, PWWN is 21:00:00:20:37:18:6f:90
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LR18591800001004 C:1 A:0 T:3 20:00:00:20:37:18:6f:90
- ST318203FC          from Company 4  (Rev 0004)
  FCID is 0x9c03dc in VSAN 1, PWWN is 21:00:00:20:37:5a:5b:27
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LRC4498200007031 C:1 A:0 T:3 20:00:00:20:37:5a:5b:27
- ST318203FC          from Company 4  (Rev 0004)
  FCID is 0x9c03e0 in VSAN 1, PWWN is 21:00:00:20:37:36:0b:4d
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LR18184700007024 C:1 A:0 T:3 20:00:00:20:37:36:0b:4d
- ST318203 CLAR18    from Company 4  (Rev 3844)
  FCID is 0x9c03e1 in VSAN 1, PWWN is 21:00:00:20:37:39:90:6a
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18200      Online LR64147100001017 C:1 A:0 T:3 20:00:00:20:37:39:90:6a
- ST318203 CLAR18    from Company 2  (Rev 3844)
  FCID is 0x9c03e2 in VSAN 1, PWWN is 21:00:00:20:37:18:d2:45
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18200      Online LR28349500001952 C:1 A:0 T:3 20:00:00:20:37:18:d2:45
- ST318203 CLAR18    from Company 2  (Rev 3844)
  FCID is 0x9c03e4 in VSAN 1, PWWN is 21:00:00:20:37:6b:d7:18
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18200      Online LRF7150500001041 C:1 A:0 T:3 20:00:00:20:37:6b:d7:18
- ST318203FC          from Company 2  (Rev 0004)
  FCID is 0x9c03e8 in VSAN 1, PWWN is 21:00:00:20:37:38:a7:c1
-----
LUN      Capacity  Status Serial Number  Device-Id
      (MB)
-----
0x0      18210      Online LR43588300001011 C:1 A:0 T:3 20:00:00:20:37:38:a7:c1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
- ST318203FC          from Company 2 (Rev 0004)
  FCID is 0x9c03ef in VSAN 1, PWWN is 21:00:00:20:37:18:17:d2
-----
LUN      Capacity   Status Serial Number   Device-Id
      (MB)
-----
0x0      18210      Online LR06903200001949 C:1 A:0 T:3 20:00:00:20:37:18:17:d2
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show snmp

The **show snmp** command displays the count information for all SNMP settings.

show snmp [community | host [user]]

Syntax Description	community	Shows SNMP community strings.
	host	Shows snmp hosts.
	user	Shows SNMPv3 users.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays SNMP information.

```
switch# show snmp
sys contact:
sys location:

1631 SNMP packets input
    0 Bad SNMP versions
    0 Unknown community name
    0 Illegal operation for community name supplied
    0 Encoding errors
    64294 Number of requested variables
    1 Number of altered variables
    1628 Get-request PDUs
    0 Get-next PDUs
    1 Set-request PDUs
152725 SNMP packets output
    0 Too big errors
    1 No such name errors
    0 Bad values errors
    0 General errors

Community                Access
-----                -
public                    rw

User                      Group                Auth  Priv
-----                -
admin                    network-admin        md5   no
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example displays SNMP user details.

```
switch# show snmp user
User                               Group                               Auth  Priv
-----                               -----                               -
steve                               network-admin                       md5   des
sadmin                              network-admin                       md5   des
stever                               network-operator                     md5   des
```

The following example displays SNMP community information.

```
switch# show snmp community
Community                           Access
-----                           -
private                              rw
public                               ro
v93RACqPNH                           ro
```

The following example displays SNMP host information.

```
switch# show snmp host
Host                                Port  Version  Level  Type  SecName
-----                                -
171.16.126.34                       2162  v2c      noauth trap  public
171.16.75.106                        2162  v2c      noauth trap  public
171.31.124.81                        2162  v2c      noauth trap  public
171.31.157.193                       2162  v2c      noauth trap  public
171.31.157.98                        2162  v2c      noauth trap  public
171.31.49.25                         2162  v2c      noauth trap  public
171.31.49.32                         2188  v2c      noauth trap  public
171.31.49.49                         2162  v2c      noauth trap  public
171.31.49.49                         3514  v2c      noauth trap  public
171.31.49.54                         2162  v2c      noauth trap  public
171.31.58.54                         2162  v2c      noauth trap  public
171.31.58.81                         2162  v2c      noauth trap  public
171.31.58.97                         1635  v2c      noauth trap  public
171.31.58.97                         2162  v2c      auth   trap   public
171.31.58.97                         3545  v2c      auth   trap   public
172.22.00.43                         2162  v2c      noauth trap  public
172.22.00.65                         2162  v2c      noauth trap  public
172.22.05.234                       2162  v2c      noauth trap  public
172.22.05.98                         1050  v2c      noauth trap  public
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show span session

Use the **show span session** command to view specific information about a SPAN session.

show span session [*session-id* [**brief**] | **brief**]

Syntax Description	session	Shows SPAN session configuration.
	<i>session-id</i>	SPAN session ID (1-16).
	brief	Shows SPAN session configuration in brief format.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays SPAN sessions in a brief format.

```
switch# show span session brief
-----
Session  Admin          Oper          Destination
         State           State         Interface
-----
 7         no suspend    active        fc2/7
```

The following example displays a specific SPAN session details.

```
switch# show span session 7
Session 7 (active)
  Destination is fc2/7
  No session filters configured
  No ingress (rx) sources
  Egress (tx) sources are
    port-channel 7,
```

The following example displays ALL SPAN sessions.

```
switch# show span session
Session 1 (inactive as no destination)
Destination is not specified
  Session filter vsans are 1
  No ingress (rx) sources
  No egress (tx) sources

Session 2 (active)
  Destination is fc9/5
  No session filters configured
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
Ingress (rx) sources are
  vsans 1
  sup-fc0,
Egress (tx) sources are
  sup-fc0,
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show sprom

To show vendor ID, product's component attributes, serial number information that can be used to track field replaceable units, use the **show sprom** command.

show sprom sup

show sprom clock *clock-module-index*

show sprom backplane *backplane-index*

show sprom module *module-number sprom-index*

show sprom fan

show sprom powersupply *powersupply-index*

show sprom mgmt-module

Syntax	Description
sup	Display Vendor ID, product's component attributes for the current supervisor module
module <i>module-number</i> <i>sprom-index</i>	Display Vendor ID, product's component attributes for the given switching module. There can be up to 4 sub-components in a module. Each of them will have a SPROM associated with it.
clock clock-module-index>	Display attributes of the clock module. There are two clock modules in a switch. This module is absent in MDS9216 type switch.
backplane <backplane-index>	Display attributes that can be used to uniquely identify a switch.
powersupply <powersupply-index>	Displays attributes of the first or the second power-supply. This contains information about the powersupply capacity in watts when it is used in 110Volts and 220Volts respectively. This information is used for power-budget allocation.
fan	Display attributes that uniquely identified fan.
mgmt-module	Display attributes of management module. This module is only present in MDS9216 type switch.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Send documentation comments to mdsfeedback-doc@cisco.com.

Usage Guidelines

Use the **show sprom** command to get unique information about a specific module, supervisor module, switch, power-supply module, or a fan module. If the customer needs to report a problem with a module, supervisor module, switch, power-supply module, or a fan module and does not have access to management station, then he can extract serial number information from **show sprom**.

Examples

The following example displays management module information. This module and command are specific to the Cisco MDS 9216 switch.

```
switch# show sprom mgmt-module
DISPLAY SAM sprom contents:
Common block:
  Block Signature :0xabab
  Block Version   :2
  Block Length    :156
  Block Checksum  :0x1295
  EEPROM Size     :0
  Block Count     :2
  FRU Major Type  :0x0
  FRU Minor Type  :0x0
  OEM String      :Cisco Systems Inc
  Product Number  :SAM SMITH
  Serial Number   :12345678901
  Part Number     :SAM-SMITH-06
  Part Revision   :A0
  Mfg Deviation   :
  H/W Version     :1.0
  Mfg Bits        :1
  Engineer Use    :0
  snmpOID         :0.0.0.0.0.0.0.0
  Power Consump   :-200
  RMA Code        :0-0-0-0
Linecard Module specific block:
  Block Signature :0x6003
  Block Version   :2
  Block Length    :103
  Block Checksum  :0x3c7
  Feature Bits    :0x0
  HW Changes Bits :0x0
  Card Index      :9009
  MAC Addresses   :00-12-34-56-78-90
  Number of MACs  :4
  Number of EOBC links :4
  Number of EPLD  :0
  Port Type-Num   :200-16
  SRAM size       :0
  Sensor #1       :0,0
  Sensor #2       :0,0
  Sensor #3       :0,0
  Sensor #4       :0,0
  Sensor #5       :0,0
  Sensor #6       :0,0
  Sensor #7       :0,0
  Sensor #8       :0,0
```

The following command displays supervisor module information.

```
switch# show sprom sup
DISPLAY supervisor sprom contents:
Common block:
  Block Signature : 0xabab
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

Block Version      : 2
Block Length      : 156
Block Checksum    : 0x10a8
EEPROM Size       : 512
Block Count       : 2
FRU Major Type    : 0x6002
FRU Minor Type    : 0x7d0
OEM String        : Cisco Systems
Product Number    : DS-X9530-SF1-K9
Serial Number     : abcdefgh
Part Number       : 73-7523-06
Part Revision     : 0.0
Mfg Deviation     : 0.0
H/W Version       : 0.0
Mfg Bits          : 0
Engineer Use      : 0
snmpOID           : 9.5.1.3.1.1.2.2000
Power Consump     : -524
RMA Code          : 0-0-0-0
Supervisor Module specific block:
Block Signature   : 0x6002
Block Version     : 2
Block Length      : 103
Block Checksum    : 0x927
Feature Bits      : 0x0
HW Changes Bits   : 0x0
Card Index        : 9003
MAC Addresses     : 00-05-30-00-18-be
Number of MACs    : 4
Number of EPLD   : 1
EPLD A           : 0x0
Sensor #1         : 75,60
Sensor #2         : 60,55
Sensor #3         : -127,-127
Sensor #4         : -127,-127
Sensor #5         : -128,-128
Sensor #6         : -128,-128
Sensor #7         : -128,-128
Sensor #8         : -128,-128

```

Related Commands

Command	Description
show hardware	Displays brief information about the list of field replacable units in the switch.

Send documentation comments to mdsfeedback-doc@cisco.com.

show ssh

Use the **show ssh key** command to display the host key pair details for the specified key or for all keys, if no key is specified. Use the **show ssh server** command to display the status of the SSH protocol (enabled or disabled) and the versions that are enabled for that switch. `show ssh key`

show ssh [key [dsa | rsa | rsa1] | server]

Syntax Description	key	Shows ssh keys.
	server	Shows whether ssh server is enabled or not.
	dsa	Shows dsa ssh keys.
	rsa	Shows rsa ssh keys.
	rsa1	Shows rsa1 ssh keys.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays SSH protocol status.

```
switch# show ssh server
ssh is enabled
version 1 enabled
version 2 enabled
```

The following example displays Host Key Pair details.

```
switch# show ssh key
rsa1 Keys generated:Sun Jan 13 07:16:26 1980

1024 35

fingerprint:
1024 67:76:02:bd:3e:8d:f5:ad:59:5a:1e:c4:5e:44:03:07

could not retrieve rsa key information

dsa Keys generated:Sun Jan 13 07:40:08 1980

ssh-dss AAAAB3NzaC1kc3MAAABBAJTTCRQOydNRel2v7uiO6Fix+OTn8eGdnnDVxw5eJs50cOEXOyjaW
cMMYsEgxc9ada1NElp8Wy7GPMWGOQYj9CU0AAAAVAMCcWhNN18zFNOIPo7cU3t7d0iEbAAAAQbdQ8UAO
i/Cti84qFb3kTqXlS9mEhdQUo0lHcH5bw5PKFj2Y/dLR437zCBKXetPj4p7mhQ6Fq5os8RZtJEyOsNsA
AABAA0oxZbPyWeR5NHATXiyXdPI7j9i8fgyn9FNipMkOF2Mn75Mi/lqQ4NIq0gQNvQOx27uCeQlRts/Q
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
wI4q68/eaw==
```

```
fingerprint:
```

```
512 f7:cc:90:3d:f5:8a:a9:ca:48:76:9f:f8:6e:71:d4:ae
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show startup-config

To view the startup configuration file, use the **show startup-config** command

show startup-config [log]

Syntax Description	log Displays execution log of last used ascii startup configuration.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	The following example displays the switch configuration at startup.

```
switch# show startup-config
vsan database
vsan 2
vsan 3
vsan 4
vsan 5
vsan 31
vsan 32 suspend
vsan 100
vsan 300

interface port-channel 1
switchport mode E
switchport trunk mode off

interface port-channel 2
fspf cost 100 vsan 2
switchport mode E
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-99
switchport trunk allowed vsan add 101-4093

interface port-channel 3
switchport mode E
switchport trunk mode off

interface port-channel 4
switchport mode E
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-99
switchport trunk allowed vsan add 101-4093
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

interface port-channel 5
switchport mode E
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-10
interface port-channel 5
switchport mode E
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-10

interface port-channel 8
switchport mode E

interface vsan1

no shutdown

snmp-server community public rw
snmp-server user admin network-admin auth md5 0xe84b06201ae3bfb726a2eab9f485eb57
  localizedkey
snmp-server host 171.69.126.34 traps version 2c public udp-port 2162
snmp-server host 171.69.75.106 traps version 2c public udp-port 2162
vsan database
vsan 3 interface fc2/9
vsan 3 interface fc2/14
vsan 5 interface fc9/11
vsan 2 interface fc9/12
vsan 3 interface port-channel 3
vsan 3 interface port-channel 4
vsan 100 interface port-channel 8

boot system bootflash:/isan-8b-u sup-1
boot kickstart bootflash:/boot-3b sup-1
boot system bootflash:/isan-8b-u sup-2
boot kickstart bootflash:/boot-3b sup-2

ip default-gateway 172.22.90.1
power redundancy-mode combined force

username admin password 5 HyLyYqb4.q74Y role network-admin
zone name Z1 vsan 1
  member pwnn 10:00:00:00:77:99:60:2c
  member pwnn 21:00:00:20:37:a6:be:14

zone default-zone permit vsan 1
zoneset distribute full vsan 51-58

zoneset name ZS1 vsan 1
  member Z1

zoneset activate name ZS1 vsan 1

interface fc2/1
switchport mode E
switchport trunk mode off
no shutdown

interface fc2/2

interface fc2/3
channel-group 1 force
no shutdown

interface fc2/6
channel-group 2 force
no shutdown

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
interface fc2/7
switchport mode E
no shutdown
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-25

interface fc2/9
switchport mode E
switchport trunk mode off
no shutdown

interface fc2/10
channel-group 3 force
no shutdown

interface fc2/12
channel-group 4 force
no shutdown

interface fc2/14
switchport mode E
no shutdown
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-99
switchport trunk allowed vsan add 101-4093

interface fc2/15
channel-group 6 force
no shutdown

interface fc2/16
channel-group 6 force
no shutdown
.
.
.
interface fc9/10
switchport mode F
no shutdown

interface fc9/11
switchport trunk mode off
no shutdown

interface fc9/12
switchport mode E
switchport speed 1000
switchport trunk mode off
no shutdown

interface fc9/15
no shutdown
no switchport trunk allowed vsan all
switchport trunk allowed vsan add 1-99
switchport trunk allowed vsan add 101-4093

interface fc9/16
switchport mode FL
no shutdown

interface mgmt0
ip address 172.22.90.38 255.255.255.0
no shutdown
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show switchname

To view the switch's network name, use the **show switchname** command.

show switchname

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the name of the switch.

```
switch# show switchname  
switch-123
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show system

To show the system information use the **show system** command.

show system autosync | cores | default switchport | directory information | error-id [list | hex] | exception-info | health | redundancy status | reset-reason [module number] | resources | uptime

Syntax Description		
	autosync	Shows image autosync status.
	cores	Displays core transfer option.
	default switchport	Shows system default values.
	directory information	Directory information of System Manager.
	error-id	Shows description about errors.
	exception-info	Shows last exception log information.
	health	Shows dta to reflect the health of the system.
	redundancy status	Redundancy status.
	reset-reason	Shows the last four reset reason codes.
	module number	Specifies the module number to display the reset-reason codes.
	resources	Show the CPU and memory statistics.
	uptime	Shows how long the system has been up and running.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines Use the **show system redundancy status** command to ensure that the system is ready to accept a switchover.

Examples The following example displays the system redundancy status.

```
switch# show system redundancy status
This supervisor
-----
Redundancy state:   Active
Supervisor state:  Active
Internal state:    Active with no standby

Other supervisor
-----
Redundancy state:  Initializing
```

The following example displays the default switch port states.

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch# show system default switchport
System default port state is down
System default trunk mode is on
```

The following example displays error information for a specified ID.

```
switch# show system error-id 0x401D0019
Error Facility: module
Error Description: Failed to stop Linecard Async Notification.
```

The following example displays the system health information.

```
switch# show system health
System Health Services iteration frequency 5 seconds
Active SUP arbiter is Working
Active SUP bootflash is Working
```

The following example displays the system reset information.

```
switch# show system reset reason
1) No time
   Reason: Watchdog Timeout
   Service:
   Version: 1.0(0.253e)
2) At 125982 usecs after Tue Jan  1 06:45:55 1980
   Reason: Reset Requested CLI command reload
   Service:
   Version: 1.0(0.253e)
```

The following example displays system-related CPU and memory statistics.

```
switch# show system resources
Load average:  1 minute: 0.43  5 minutes: 0.17  15 minutes: 0.11
Processes   :  100 total, 2 running
CPU states  :  0.0% user,  0.0% kernel,  100.0% idle
Memory usage: 1027628K total,  313424K used,  714204K free
              3620K buffers,  22278K cache
```

The following example displays the system uptime.

```
switch# show system uptime
Start Time: Sun Oct 13 18:09:23 2030
Up Time:    0 days, 9 hours, 46 minutes, 26 seconds
```

Use the **show system cores** command to display the currently configured scheme for copying cores.

```
switch# show system cores
Transfer of cores is enabled
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show system switchover impact

To compare the image files between kickstart, system, and module images, use the **show system switchover** command.

```
show system switchover impact [bootflash: |slot0: | volatile:] image-filename [bootflash: |slot0: | volatile:] image-filename
```

Syntax Description.	show system switchover impact	Upgrades the BIOS for a supervisor or switching module.
	bootflash:	Source or destination location for internal bootflash memory
	slot0:	Source or destination location for the CompactFlash memory or PCMCIA card.
	volatile:	Source location for the volatile file system.
	<i>image-filename</i>	The name of the system or kickstart image.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(3).

Usage Guidelines None.

Examples This command shows the output if this command is issued on a single supervisor switch:

```
switch# show system switchover impact
No standby supervisor present.
```

This command shows the effects of the switchover assuming that the standby supervisor module is running 1.0(2) and the active supervisor module is running 1.0(2) system image.

```
switch# show system switchover impact
Effects of switching-over to m9500-sflek9-mz.1.0.2.bin from m9500-sflek9-mz.1.0.1.bin
Switchover type:                HA
Impact on modules:              modules 1, 2 will reset
```

Per module compatibility with system image 1.0(2) running on the standby supervisor

```
Module Compatibility check
1    Module running version 1.0(2): not compatible
2    Module running version 1.0(2): not compatible
7    Module running version 1.0(2): compatible
```

If a switchover is issue to sup 6 (new active), switching modules 1 and 2 will reset, switching module 7 will remain active after the switchover.

Send documentation comments to mdsfeedback-doc@cisco.com.

This command shows the effects of the switchover assuming that standby supervisor module has a new_system.bin, and is running 1.0(2) image.

```
switch# show system switchover impact bootflash:new_system.bin
Effects of switching-over to m9500-sf1ek9-mz.1.0.2.bin from m9500-sf1ek9-mz.1.0.1.bin
Switchover type:                HA
Impact on modules:              modules 1, 2 will reset

Per module compatibility with system image 1.0(2) running on the standby supervisor
Module Compatibility check
1      Module running version 1.0(2): not compatible
2      Module running version 1.0(2): not compatible
7      Module running version 1.0(2): compatible
```

This command shows the effects of the switchover to view the effects of a matrix between two images, instead of comparing it to running images.

```
switch# show system switchover impact bootflash:new_system.bin bootflash:old_system.bin
Effects of switching-over to m9500-sf1ek9-mz.1.0.2.bin from m9500-sf1ek9-mz.1.0.1.bin
Switchover type:                HA
Impact on modules:              module(s) will reset

Per module compatibility with system image 1.0(2) running on the standby supervisor
Module Compatibility check
-      Module running version 1.0(2): not compatible
```

This command shows the effects of the switchover if the parameters in the above display are swapped.

```
switch# show system switchover impact bootflash:old_system.bin bootflash:new_system.bin
Effects of switching-over to m9500-sf1ek9-mz.1.0.1.bin from m9500-sf1ek9-mz.1.0.2.bin
Switchover type:                warm
Impact on modules:              module(s) will reset

Per module compatibility with system image 1.0(2) running on the standby supervisor
Module Compatibility check
-      Module running version 1.0(2): not compatible
```

This displays shows that a warm switchover is possible and a HA switchover is not possible because image 1.0(2) is superseded by 1.0(2).

Send documentation comments to mdsfeedback-doc@cisco.com.

show tech-support

To display relevant information about entities like modules, interfaces that can be provided to technical support, use the **show tech-support** command.

show tech-support [interface | module | vsan vsan-id]

Syntax Description		
interface	Display interface status and configuration information	
module	Display module status information	
vsan	Display vsan status and configuration information	
<i>vsan-id</i>	The ID of the VSAN is from 1 to 4093.	

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The 'show tech-support internal' option provides internal information relevant to troubleshooting problems associated with modules, interfaces and VSANs that can be provided to technical support personnel.

Examples switch# **sho tech-support module 1**

```
'terminal length 0'

'show module '
Mod  Ports  Module-Type                Model                Status
---  ---
1    16     1/2 Gbps FC/Supervisor     DS-X9216-K9-SUP     active *
2    32     1/2 Gbps FC Module         DS-X9032             ok

Mod  Sw          Hw          World-Wide-Name(s) (WWN)
---  ---
1    1.0(0.271)  0.0         20:01:00:05:30:00:21:9e to 20:10:00:05:30:00:21:9e
2    1.0(0.271)  0.0         20:41:00:05:30:00:21:9e to 20:60:00:05:30:00:21:9e

Mod  MAC-Address(es)                Serial-Num
---  ---
1    00-05-30-00-40-b6 to 00-05-30-00-40-ba
2    00-05-30-00-11-22 to 00-05-30-00-11-26

* this terminal session

'show environment '
Clock:
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

-----
Clock          Model          Hw          Status
-----
A              Clock Module   --         ok/active
B              Clock Module   --         ok/standby

```

Fan:

```

-----
Fan           Model          Hw          Status
-----
Chassis      DS-2SLOT-FAN   0.0        ok
PS-1         --             --          ok
PS-2         --             --          absent

```

Temperature:

```

-----
Module  Sensor  MajorThresh  MinorThres  CurTemp  Status
        (Celsius)  (Celsius)  (Celsius)
-----
1       1       75           60          30       ok
1       2       65           50          28       ok
1       3       -127        -127        40       ok
1       4       -127        -127        36       ok

2       1       75           60          32       ok
2       2       65           50          26       ok
2       3       -127        -127        41       ok
2       4       -127        -127        31       ok

```

Power Supply:

```

-----
PS  Model          Power      Power      Status
    (Watts)      (Amp @42V)
-----
1   WS-CAC-950W    919.38    21.89     ok
2   --             --         --         absent

```

```

-----
Mod Model          Power      Power      Power      Power      Status
    Requested Requested Requested  Requested
    (Watts)   (Amp @42V) (Watts)   (Amp @42V)
-----
1   DS-X9216-K9-SUP 220.08    5.24      220.08    5.24      powered-up
2   DS-X9032        199.92    4.76      199.92    4.76      powered-up

```

Power Usage Summary:

```

-----
Power Supply redundancy mode:                redundant

Total Power Capacity                          919.38  W

Power reserved for Supervisor(s) [-]         220.08  W
Power reserved for Fan Module(s) [-]         47.88   W
Power currently used by Modules[-]           199.92  W

-----
Total Power Available                          451.50

```

Send documentation comments to mdsfeedback-doc@cisco.com.

show telnet server

The **show telnet server** command displays the state of the Telnet access configuration.

show telnet server

Syntax Description	This command has no arguments or keywords.
Defaults	None.
Command Modes	EXEC mode.
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
Usage Guidelines	None.
Examples	<pre>switch# show telnet server telnet service enabled</pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

show terminal

To view the terminal information, use the **show terminal** command

show terminal

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays terminal information.

```
switch# show terminal
TTY: Type: "vt100"
Length: 25 lines, Width: 80 columns
Session Timeout: 30 minutes
```


[Send documentation comments to mdsfeedback-doc@cisco.com.](mailto:mdsfeedback-doc@cisco.com)

show tlport

To view configured TL port information, use the **show tlport** command

```
show tlport {discapp [fcid fcid-id / verbose / vsan vsan-id] | interface [all | private | proxied | topology | unsupported] | list [vsan vsan-id]}
```

Syntax Description		
discapp		Shows private N port parameters.
fcid <i>fcid-id</i>		Specifies the FCID of the N port.
verbose		Specifies the verbose mode.
vsan <i>vsan-id</i>		Specifies the N port VSAN.
interface		Shows TL ports in the selected interface.
all		Shows all proxied & private devices on this TL Port.
private		Shows all private devices on this TL Port.
proxied		Shows all proxied devices on this TL Port.
topology		Shows loop topology for this TL Port.
unsupported		Shows all unsupported devices on this TL Port.
list		Shows TL ports in all VSANs.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The **show tlport** command displays the TL port interface configurations. This command provides a list of all TL ports configured on a box and shows the associated VSAN, the FC ID for the port (only domain and area are valid), and the current operational state of the TL port (up or initializing).

Examples The following example displays the TL ports in all VSANs

```
switch# show tlport list
-----
Interface Vsan FC-ID   State
-----
fc1/16    1    0x420000 Init
fc2/26    1    0x150000 Up
```

The following example displays the detailed information for a specific TL port

```
switch# show tlport interface fc1/16 all
fc1/16 is up, vsan 1, FCID 0x420000
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
-----
alpha pWWN                nWWN                SCSI Type Device  FC-ID
-----
0x01 20:10:00:05:30:00:4a:de 20:00:00:05:30:00:4a:de Initiator Proxied 0xffffc42
0x73 22:00:00:20:37:39:ae:54 20:00:00:20:37:39:ae:54 Target    Private 0x420073
0xef 20:10:00:05:30:00:4a:de 20:00:00:05:30:00:4a:de Initiator Switch 0x0000ef
```

The following example displays TL port information for private devices

```
switch# show tlport int fc1/16 pri
fc1/16 is up, vsan 1, FCID 0x420000
```

```
-----
alpha pWWN                nWWN                SCSI Type FC-ID
-----
0x73 22:00:00:20:37:39:ae:54 20:00:00:20:37:39:ae:54 Target    0x420073
0x74 22:00:00:20:37:38:d3:de 20:00:00:20:37:38:d3:de Target    0x420074
```

The following example displays TL port information for proxied devices

```
switch# show tlport int fc1/16 prox
fc1/16 is up, vsan 1, FCID 0x420000
```

```
-----
alpha pWWN                nWWN                SCSI Type FC-ID
-----
0x01 20:10:00:05:30:00:4a:de 20:00:00:05:30:00:4a:de Initiator 0xffffc42
0x02 21:00:00:e0:8b:01:95:e7 20:00:00:e0:8b:01:95:e7 Initiator 0x420100
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show trunk protocol

To show trunk protocol information, use the **show trunk protocol** command.

show trunk protocol

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays trunk protocol

```
switch# show trunk protocol  
Trunk protocol is enabled
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show user-account

Use the **show user-account** command to display configured information about user accounts.

show user-account [*user-name*]

Syntax	<i>user-name</i>	Displays the user account information for the specified user name.
Description		
Defaults	None.	
Command Modes	EXEC mode.	
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).	
Usage Guidelines	None.	
Examples	The following example displays information for a specified user.	

```
switch# show user-account user1
user:user1
    this user account has no expiry date
    roles:network-operator
no password set. Local login not allowed
Remote login through RADIUS is possible
```

The following example displays information for all users.

```
switch# show user-account
show user-account
user:admin
    this user account has no expiry date
    roles:network-admin

user:usam
    expires on Sat May 31 00:00:00 2003
    roles:network-admin network-operator

user:msam
    this user account has no expiry date
    roles:network-operator

user:user1
    this user account has no expiry date
    roles:network-operator
no password set. local login not allowed
Remote login through RADIUS is possible
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show users

The **show users** command displays all users currently accessing the switch.

show users

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays all users.

```
switch# show users
switch# show users
admin pts/7 Jan 12 20:56 (10.77.202.149)
admin pts/9 Jan 12 23:29 (modena.cisco.com)
admin pts/10 Jan 13 03:05 (dhcp-171-71-58-120.cisco.com)
admin pts/11 Jan 13 01:53 (dhcp-171-71-49-49.cisco.com)
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show version

To show the version of system software that is currently running on the switch, use the **show version** command.

show version {detail | image [bootflash: | slot0:]image-filename | [module module-number]}

Syntax Description	Parameter	Description
	detail	Shows the software version.
	image	Shows the software version of a given image.
	bootflash:	Source location for internal bootflash memory
	slot0:	Source location for the CompactFlash memory or PCMCIA card.
	<i>image-filename</i>	The name of the system or kickstart image.
	module	Shows the software version of a module.
	<i>module-number</i>	Slot number in which the required module resides.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2) and modified in Release 1.0(3).

Usage Guidelines Use the **show version image** command to verify the integrity of the image before loading the images. This command can be used for both the system and kickstart images.

Use the **show version** command to verify the version on the active and standby supervisor modules before and after an upgrade.

Examples The following examples depict version of the system, kickstart, and failed images.

```
switch(boot)# show version image bootflash:system_image <-----system image
image name: m9500-sflek9-mz.1.0.3.bin
system:      version 1.0(3)
compiled:    10/25/2010 12:00:00
```

```
switch(boot)# show version image bootflash:kickstart_image <-----kickstart image
image name: m9500-sflek9-kickstart-mz.1.0.3.upg.bin
kickstart:   version 1.0(3)
loader:      version 1.0(3)
compiled:    10/25/2010 12:00:00
```

```
switch# show version image bootflash:bad_image <-----failure case
Md5 Verification Failed
Image integrity check failed
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following examples provide a before and after comparison scenario after the loader version is updated.

```
switch# show version
Cisco Storage Area Networking Operating System (SAN-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2003 by Cisco Systems, Inc. All rights reserved.
The copyright for certain works contained herein are owned by
Andiamo Systems, Inc. and/or other third parties and are used and
distributed under license.
Software
  BIOS:      version 1.0(3)
  loader:    version 1.0(2) <-----existing version
  kickstart: version 1.0(3)
  system:    version 1.0(3)
  BIOS compile time:      11/18/02
  kickstart image file is: bootflash:/kickstart_image
  kickstart compile time: 1/20/2003 12:00:00
  system image file is:   bootflash:/system_image
  system compile time:    1/20/2003 12:00:00
```

```
switch# show version
Cisco Storage Area Networking Operating System (SAN-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2003 by Cisco Systems, Inc. All rights reserved.
The copyright for certain works contained herein are owned by
Andiamo Systems, Inc. and/or other third parties and are used and
distributed under license.
Software
  BIOS:      version 1.0(3)
  loader:    version 1.0(3) <-----new version
  . . . . .
```

The following example show the version details for a specified module.

```
switch# show ver mod 4
Mod No  Mod Type      SW Version      SW Interim Version
4       LC              1.0(3)          1.0(3)
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show version compatibility

To show the software compatibility matrix of a specific image, use the **show version compatibility** command.

show version compatibility [**bootflash:** | **slot0:**] *image-filename*

Syntax Description		
	bootflash:	Source location for internal bootflash memory
	slot0:	Source location for the CompactFlash memory or PCMCIA card.
	<i>image-filename</i>	The name of the system or kickstart image.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples Use the **show version compatibility** command to view the effect of updating the system from the running image to another specified image.

```
switch# show version compatibility bootflash:system_image
Version comparison between /bootflash/system_image and running-image:
Mod No   Mod Type   SRG Compare Result
1        LC         Linecard version is compatible
2        LC         Linecard version is compatible
3        LC         Linecard version is compatible
4        LC         Linecard version is compatible
6        SUP       Non-Disruptive upgrade is possible
7        LC         Linecard version is compatible
8        LC         Linecard version is compatible
9        LC         Linecard version is compatible
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show vrrp

Use the **show vrrp vr** command to display the VRRP configuration information

```
show vrrp [statistics | vr [integer interface group]
```

Syntax Description		
	statistics	Shows cumulative vrrp statistics for this machine.
	vr	Shows virtual router information.
	group	The ID of the group (1-255).
	interface	Enter mgmt for management interface, or VSAN for the IPFC VSAN interface.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays VRRP configured information.

```
switch# show vrrp vr 7 interface vsan 2 configuration
vr id 7 configuration
admin state down
priority 100
no authentication
advertisement-Interval 1
preempt yes
tracking interface vsan1 priority 2
protocol IP
```

The following example displays VRRP status information.

```
switch# show vrrp vr 7 interface vsan 2 status
vr id 7 status
MAC address 00:00:5e:00:01:07
Operational state: init
```

The following example displays VRRP statistics

```
switch# show vrrp vr 7 interface vsan 2 statistics
vr id 7 statistics
Become master 0
Advertisement 0
Advertisement Interval Error 0
Authentication Failure 0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
TTL Error 0
Priority 0 Received 0
Priority 0 Sent 0
Invalid Type 0
Mismatch Address List 0
Invalid Authentication Type 0
Mismatch Authentication 0
Invalid Packet Length 0
```

The following example displays VRRP cumulative statistics.

```
switch# show vrrp statistics
Invalid checksum 0
Invalid version 0
Invalid VR ID 0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show vsan

Use the **show vsan** command to display information about configured VSAN.

show vsan [vsan-range] | [membership interface vsan-range] | usage]]

Syntax Description	vsan <i>vsan-range</i>	The VSAN ID range (from 1 to 4093).
	membership	Shows membership information.
	usage	Shows VSNA usage in the system.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines For the **show vsan membership interface** command, interface information is not displayed if interfaces are not configured on this VSAN.

Examples The following examples displays configured VSAN information.

```
switch# show vsan 1
vsan 1 information
  name:VSAN0001 state:active
  interoperability mode:yes & verify mode
  loadbalancing:src-id/dst-id/oxid
  operational state:up

switch# show vsan usage
4 vsan configured
configured vsans:1-4
vsans available for configuration:5-4093

switch# show vsan
switch# show vsan
vsan 1 information
  name:VSAN0001 state:active
  in-order guarantee:no interoperability mode:no
  loadbalancing:src-id/dst-id/oxid
vsan 2 information
  name:VSAN0002 state:active
  in-order guarantee:no interoperability mode:no
  loadbalancing:src-id/dst-id/oxid
vsan 7 information
  name:VSAN0007 state:active
  in-order guarantee:no interoperability mode:no
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

        loadbalancing:src-id/dst-id/oxid
vsan 100 information
        name:VSAN0100 state:active
        in-order guarantee:no interoperability mode:no
        loadbalancing:src-id/dst-id/oxid
vsan 4094:isolated vsan

```

```

switch # show vsan 1 membership
vsan 1 interfaces:
        fc1/1  fc1/2  fc1/3  fc1/4  fc1/5  fc1/6  fc1/7  fc1/9
        fc1/10 fc1/11 fc1/12 fc1/13 fc1/14 fc1/15 fc1/16 port-channel 99

```

The following example displays membership information for all VSANs

```

switch # show vsan membership
vsan 1 interfaces:
        fc2/16 fc2/15 fc2/14 fc2/13 fc2/12 fc2/11 fc2/10 fc2/9
        fc2/8  fc2/7  fc2/6  fc2/5  fc2/4  fc2/3  fc2/2  fc2/1
        fc1/16 fc1/15 fc1/14 fc1/13 fc1/12 fc1/11 fc1/10 fc1/9
        fc1/7  fc1/6  fc1/5  fc1/4  fc1/3  fc1/2  fc1/1
vsan 2 interfaces:
vsan 7 interfaces:
        fc1/8
vsan 100 interfaces:
vsan 4094(isolated vsan) interfaces:

```

The following example displays membership information for a specified interface.

```

switch # show vsan membership interface fc1/1
fc1/1
        vsan:1
        allowed list:1-4093

```

Send documentation comments to mdsfeedback-doc@cisco.com.

show wwn

Use the **show wwn** commands to display the status of the WWN configuration.

show wwn [**status** *block-id number* | **switch**]

Syntax Description	
status	Shows overall WWN Usage and Alarm Status
switch	Shows switch WWN.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays the WWN of VSAN 1.

```
switch# show wwn vsan 1
VSAN WWN of VSAN# 1 is 20:01:ac:16:5e:52:00:01
```

Send documentation comments to mdsfeedback-doc@cisco.com.

show zone

To display zone information, use the **show zone** command.

show zone [**active**]

show zone [**change** [**event-history**] [**vsan** *vsan-range*]

show zone [**member** [[**fcalias** *alias-name*] [**active**] [**vsan** *vsan-range*] | [**fcid** *fcid-id*] [**active**] [**vsan** *vsan-range*] | **pwwn** *wwn* [**active**] [**vsan** *vsan-range*]]

show zone [**merge**] [**event-history**] [**interface** *interface* **vsan** *vsan-id*]

show zone [**name** *string* **active** **vsan** *vsan-range*]

show zone [**statistics** **vsan** *vsan-range*]

show zone [**status** **vsan** *vsan-range*]

Syntax Description		
active	Shows zones which are part of active zoneset.	
change	Shows log transaction changes.	
member	Shows all zones in which the given member is part of.	
merge	Shows log transaction merges.	
name	Shows members of a specified zone.	
statistics	Shows zone server statistics.	
status	Shows zone server current status.	
vsan	Shows zones belonging to the specified VSAN.	
<i>vsan-range</i>	Range of the required VSANs (from 1 to 4093).	

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays configured zone information.

```
switch(config)# show zone
zone name Zone3 vsan 1
  pwwn 21:00:00:20:37:6f:db:dd
  pwwn 21:00:00:20:37:9c:48:e5
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
zone name Zone2 vsan 2
  fwwn 20:41:00:05:30:00:2a:1e
  fwwn 20:42:00:05:30:00:2a:1e
  fwwn 20:43:00:05:30:00:2a:1e

zone name Zone1 vsan 1
  pwwn 21:00:00:20:37:6f:db:dd
  pwwn 21:00:00:20:37:a6:be:2f
  pwwn 21:00:00:20:37:9c:48:e5
  fcalias Alias1
```

Use the **show zone vsan** command to display zone information for a specific VSAN.

```
switch(config)# show zone vsan 1
zone name Zone3 vsan 1
  pwwn 21:00:00:20:37:6f:db:dd
  pwwn 21:00:00:20:37:9c:48:e5

zone name Zone2 vsan 1
  fwwn 20:41:00:05:30:00:2a:1e
  fwwn 20:42:00:05:30:00:2a:1e
  fwwn 20:43:00:05:30:00:2a:1e
  fwwn 20:44:00:05:30:00:2a:1e
  fwwn 20:45:00:05:30:00:2a:1e
  fwwn 20:46:00:05:30:00:2a:1e
  fwwn 20:47:00:05:30:00:2a:1e
  fwwn 20:48:00:05:30:00:2a:1e
  fwwn 20:49:00:05:30:00:2a:1e
  fwwn 20:4a:00:05:30:00:2a:1e
  fwwn 20:4b:00:05:30:00:2a:1e
  fwwn 20:4c:00:05:30:00:2a:1e
  fwwn 20:4d:00:05:30:00:2a:1e
  fwwn 20:4e:00:05:30:00:2a:1e
  fwwn 20:4f:00:05:30:00:2a:1e
  fwwn 20:50:00:05:30:00:2a:1e
  fwwn 20:51:00:05:30:00:2a:1e
  fwwn 20:52:00:05:30:00:2a:1e
  fwwn 20:53:00:05:30:00:2a:1e
  fwwn 20:54:00:05:30:00:2a:1e
  fwwn 20:55:00:05:30:00:2a:1e
  fwwn 20:56:00:05:30:00:2a:1e
  fwwn 20:57:00:05:30:00:2a:1e
  fwwn 20:58:00:05:30:00:2a:1e
  fwwn 20:59:00:05:30:00:2a:1e
  fwwn 20:5a:00:05:30:00:2a:1e
  fwwn 20:5b:00:05:30:00:2a:1e
  fwwn 20:5c:00:05:30:00:2a:1e
  fwwn 20:5d:00:05:30:00:2a:1e
  fwwn 20:5e:00:05:30:00:2a:1e
  fwwn 20:5f:00:05:30:00:2a:1e
  fwwn 20:60:00:05:30:00:2a:1e

zone name Zone1 vsan 1
  pwwn 21:00:00:20:37:6f:db:dd
  pwwn 21:00:00:20:37:a6:be:2f
  pwwn 21:00:00:20:37:9c:48:e5
  fcalias Alias1
```

Use the **show zone name** command to display members of a specific zone.

```
switch# show zone name Zone1
zone name Zone1 vsan 1
  pwwn 21:00:00:20:37:6f:db:dd
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
pwwn 21:00:00:20:37:a6:be:2f
pwwn 21:00:00:20:37:9c:48:e5
fcalias Alias1
```

Use the **show zone member** command to display all zones to which a member belongs using the FC ID.

```
@switch# show zone member pwwn 21:00:00:20:37:9c:48:e5
          VSAN: 1
zone Zone3
zone Zone1
fcalias Alias1
```

Use the **show zone statistics** command to display the number of control frames exchanged with other switches.

```
switch# show zone statistics
Statistics For VSAN: 1
*****
Number of Merge Requests Sent: 24
Number of Merge Requests Recvd: 25
Number of Merge Accepts Sent: 25
Number of Merge Accepts Recvd: 25
Number of Merge Rejects Sent: 0
Number of Merge Rejects Recvd: 0
Number of Change Requests Sent: 0
Number of Change Requests Recvd: 0
Number of Change Rejects Sent: 0
Number of Change Rejects Recvd: 0
Number of GS Requests Recvd: 0
Number of GS Requests Rejected: 0
Statistics For VSAN: 2
*****
Number of Merge Requests Sent: 4
Number of Merge Requests Recvd: 4
Number of Merge Accepts Sent: 4
Number of Merge Accepts Recvd: 4
Number of Merge Rejects Sent: 0
Number of Merge Rejects Recvd: 0
Number of Change Requests Sent: 0
Number of Change Requests Recvd: 0
Number of Change Rejects Sent: 0
Number of Change Rejects Recvd: 0
Number of GS Requests Recvd: 0
Number of GS Requests Rejected: 0
```


Send documentation comments to mdsfeedback-doc@cisco.com.

show zoneset

Use the **show zoneset** command to view the configured zone sets.

show zoneset [**name** | **brief** | **active** | **vsan** *vsan-id*]

Syntax Description	
active	Shows only active zonesets.
brief	Shows members in brief mode.
name	Shows members of a specified zoneset.
vsan	Shows zonesets belonging to the specified VSAN.
<i>vsan-id</i>	The ID of the VSAN is from 1 to 4093.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example displays configured zoneset information.

```
switch# show zoneset vsan 1
zoneset name ZoneSet2 vsan 1
  zone name Zone2 vsan 1
    fwwn 20:4e:00:05:30:00:2a:1e
    fwwn 20:4f:00:05:30:00:2a:1e
    fwwn 20:50:00:05:30:00:2a:1e
    fwwn 20:51:00:05:30:00:2a:1e
    fwwn 20:52:00:05:30:00:2a:1e

  zone name Zone1 vsan 1
    pwwn 21:00:00:20:37:6f:db:dd
    pwwn 21:00:00:20:37:a6:be:2f
    pwwn 21:00:00:20:37:9c:48:e5
    fcalias Alias1

zoneset name ZoneSet1 vsan 1
  zone name Zone1 vsan 1
    pwwn 21:00:00:20:37:6f:db:dd
    pwwn 21:00:00:20:37:a6:be:2f
    pwwn 21:00:00:20:37:9c:48:e5
    fcalias Alias1
```

The following example displays configured zone set information for a specific VSAN.

Send documentation comments to mdsfeedback-doc@cisco.com.

```
switch# show zoneset vsan 2-3
zoneset name ZoneSet2 vsan 1
  zone name Zone2 vsan 1
    fwwn 20:52:00:05:30:00:2a:1e
    fwwn 20:53:00:05:30:00:2a:1e
    fwwn 20:54:00:05:30:00:2a:1e
    fwwn 20:55:00:05:30:00:2a:1e
    fwwn 20:56:00:05:30:00:2a:1e

  zone name Zone1 vsan 1
    pwwn 21:00:00:20:37:6f:db:dd
    pwwn 21:00:00:20:37:a6:be:2f
    pwwn 21:00:00:20:37:9c:48:e5
    fcalias Alias1

zoneset name ZoneSet1 vsan 1
  zone name Zone1 vsan 1
    pwwn 21:00:00:20:37:6f:db:dd
    pwwn 21:00:00:20:37:a6:be:2f
    pwwn 21:00:00:20:37:9c:48:e5
    fcalias Alias1
```