

Initial Switch Configuration

This chapter provides instructions for setting up the hardware, connecting to the console port, and initially configuring the switch.

This chapter includes the following sections:

- [Preparing for Network Connections, page 2-1](#)
- [Connecting the Console Port, page 2-2](#)
- [Connecting the 10/100 Ethernet Management Port, page 2-4](#)
- [Connecting to the MGMT 10/100/1000 Ethernet Port, page 2-5](#)
- [Using the Switch Setup Utility, page 2-5](#)
- [Verifying the Module Status, page 2-9](#)

Preparing for Network Connections

When preparing your site for network connections to the Andiamo 9500 switch, consider the following for each type of interface:

- Cabling required for each interface type
- Distance limitations for each signal type
- Additional interface equipment needed

Before installing the device, have all additional external equipment and cables available.

Configuration Prerequisites

Before you configure a switch in the Cisco MDS 9000 Family for the first time, make sure you have the following information:

- Administrator password.
- Switch name—This is also used as your switch prompt.
- IP address for the switch's management interface.
- Subnet mask for the switch's management interface.
- IP address of the default gateway.

■ **Connecting the Console Port**

Send documentation comments to mdsfeedback-doc@cisco.com


Connecting the Console Port

This section describes how to connect the RS-232 console port to a PC. The console port allows you to perform the following functions:

- Configure the switch from the CLI.
- Monitor network statistics and errors.
- Configure SNMP agent parameters.
- Manage downloading software updates (through the Ethernet management interface) or distributing software images residing in Flash memory to attached devices.


[Figure 2-1](#), [Figure 2-3](#), [Figure 2-4](#), and [Figure 2-4](#) show the console port and the management port, located on a Cisco MDS 9500 series supervisor-1 module, Cisco MDS 9500 series supervisor-2 module, a Cisco MDS 9200 Series supervisor module, and Cisco MDS 9100 Series supervisor module.

Figure 2-1 Cisco MDS 9500 Series Supervisor-1 Module



1	Console port
2	MGMT 10/100 Ethernet port (with integrated link and activity LEDs)


Figure 2-2 Cisco MDS 9500 Series Supervisor-2 Module



1	Status, System, Active, and Pwr Mgmt LEDs
4	MGMT 10/100/1000 Ethernet port (with integrated Link and Activity LEDs)


Send documentation comments to mdsfeedback-doc@cisco.com

Figure 2-3 Connecting the Console Cable to a Cisco MDS 9200 Series Switch



1	Console port
2	MGMT 10/100 Ethernet port (with integrated link and activity LEDs)

Figure 2-4 Connecting the Console Cable to a Cisco MDS 9100 Series Switch



1	Console port
2	MGMT 10/100 Ethernet port (with integrated link and activity LEDs)

Send documentation comments to mdsfeedback-doc@cisco.com

Connecting the Console Port to a PC

You can connect the console port to a PC serial port for local administrative access to the Andiamo 9500 switch.



Note The PC must support VT100 terminal emulation. The terminal emulation software—frequently a PC application such as HyperTerminal Plus—makes communication between the Andiamo 9500 switch and your PC possible during setup and configuration.

To connect the console port to a PC, follow these steps:

Step 1 Configure the baud rate and character format of the PC terminal emulation program to match the following management port default characteristics:

- 9600 baud
- 8 data bits
- 1 stop bit
- No parity



Note On Cisco terminal servers, issue the following commands starting in EXEC mode:

```
switch# config t
switch(config)# no flush-at-activation
switch(config)# exit
switch# copy running-config startup-config
```

This configuration ensures that the MDS switch does not receive random characters that might cause it to hang.

Step 2 Connect the supplied RJ-45 to DB-9 female adapter or RJ-45 to DB-25 female adapter (depending on your PC connection) to the PC serial port.

Step 3 Connect one end of the supplied console cable (a rollover RJ-45 to RJ-45 cable) to the console port. (See [Figure 2-4](#).) Connect the other end to the RJ-45 to DB-9 (or RJ-45 to DB-25) adapter at the PC serial port.



Note If you are using a Cisco MDS 9500 Series switch that has multiple supervisor modules, connect the console port to the “active” supervisor. The active supervisor is the module with the green Active LED.

Connecting the 10/100 Ethernet Management Port

The autosensing 10/100 Ethernet management port is located on the left side of the front panel (labeled 10/100 MGMT), to the right of the Console port (see [Figure 2-1](#), [Figure 2-4](#), and [Figure 2-4](#)). This port is used for out-of-band management of the Cisco MDS 9000 Family switches.

Send documentation comments to mdsfeedback-doc@cisco.com

Make sure to connect the Ethernet management ports of both supervisor modules on an MDS 9500 Series switch. Even though there are two Ethernet connections, only one management IP address is required for a switch with dual supervisors.



Tip

The two Ethernet connections should be connected to ports in different slots on the same LAN switch, or should be split between two different LAN switches.

If only the active supervisor module is connected to the LAN and an event occurs that causes a system switchover (such as a software upgrade), the switch becomes unmanageable through the Ethernet port after the active supervisor reboots and the standby supervisor becomes the active supervisor.

Use modular, RJ-45 cables to connect the 10/100 Ethernet management port to external hubs and switches.

Connecting to the MGMT 10/100/1000 Ethernet Port

The Supervisor-2 module supports an autosensing MGMT 10/100/1000 Ethernet port (labeled “MGMT 10/100/1000”) and has an RJ-45 interface. You can use this port to access and manage the switch by IP address, such as through Cisco Fabric Manager.

Use a modular, RJ-45, straight-through UTP cable to connect the MGMT 10/100/1000 Ethernet port to an Ethernet switch port or hub.

Using the Switch Setup Utility

The switch setup utility helps you configure the switch. To configure the switch, follow these steps:

Step 1

Verify the following physical connections for the new Cisco MDS 9000 Family switch (see [Figure 2-4](#)):

- The console port is physically connected to a computer terminal (or terminal server).
- The 10/100/1000 Ethernet management port (mgmt0) is connected to an external hub, switch, or router.

Refer to the hardware installation guide for your specific product.



Tip

Save the host ID information for future use (for example, to enable licensed features). The host ID information is provided in the Proof of Purchase document that accompanies the switch.

Step 2

Verify that the default console port parameters are identical to those of the computer terminal (or terminal server) attached to the switch console port (see the “[Connecting the Console Port to a PC](#)” section on page [2-4](#)).

Step 3

Power on the switch. The switch boots automatically.



Note

If the switch boots to the `loader>` or `switch(boot)` prompts, contact your storage vendor support organization for technical assistance.

After powering on the switch, you see the following output:

Send documentation comments to mdsfeedback-doc@cisco.com

*Note: setup is mainly used for configuring the system initially, when no configuration is present. So setup always assumes system defaults and not the current system configuration values.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): **yes**

The switch setup utility guides you through the basic configuration process. Press **Ctrl-C** at any prompt to end the configuration process.

- Step 6** Enter **no** (no is the default) to not create any additional accounts.

Create another login account (yes/no) [n]: **no**

- Step 7** Enter **no** (no is the default) to not configure any read-only SNMP community strings.

Configure read-only SNMP community string (yes/no) [n]: **no**

- Step 8** Enter **no** (no is the default) to not configure any read-write SNMP community strings.

Configure read-write SNMP community string (yes/no) [n]: **no**

- Step 9** Enter a name for the switch.



Note The switch name is limited to 32 alphanumeric characters. The default is **switch**.

Enter the switch name: *switch_name*

- Step 10** Enter **yes** (yes is the default) to configure the out-of-band management configuration.

Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: **yes**

- a. Enter the IP address for the mgmt0 interface.

Mgmt0 IP address : *mgmt_IP_address*

- b. Enter the netmask for the mgmt0 interface in the xxx.xxx.xxx.xxx format.

Mgmt0 IP netmask : *xxx.xxx.xxx.xxx*

- Step 11** Enter **yes** (yes is the default) to configure the default gateway (recommended).

Configure the default-gateway: (yes/no) [y]: **yes**

- a. Enter the default gateway IP address.

IP address of the default-gateway: *default_gateway*

- Step 12** Enter **no** (no is the default) to configure advanced IP options such as in-band management, static routes, default network, DNS, and domain name.

Configure Advanced IP options (yes/no) ? [n]: **no**

- Step 13** Enter **yes** (yes is the default) to enable Telnet service.

Enable the telnet service? (yes/no) [y]: **yes**

- Step 14** Enter **no** (no is the default) to not enable the SSH service.

Enable the ssh service? (yes/no) [n]: **no**

- Step 15** Enter **no** (no is the default) to not configure the NTP server.

Send documentation comments to mdsfeedback-doc@cisco.com

```
Configure the ntp server? (yes/no) [n]: no
```

- Step 16** Enter **noshut** (shut is the default) to configure the default switch port interface to the noshut state.

```
Configure default switchport interface state (shut/noshut) [shut]: noshut
```

- Step 17** Enter **on** (on is the default) to configure the switch port trunk mode.

```
Configure default switchport trunk mode (on/off/auto) [on]: on
```

- Step 18** Enter **deny** (deny is the default) to configure a default zone policy configuration.

```
Configure default zone policy (permit/deny) [deny]: deny
```

Denies the traffic to flow for all members of the default zone.

- Step 19** Enter **yes** (no is the default) to enable a full zone set distribution (refer to the *Cisco MDS 9000 Family CLI Configuration Guide*).

```
Enable full zoneset distribution (yes/no) [n]: yes
```

You see the new configuration. Review and edit the configuration that you have just entered.

- Step 20** Enter **no** (no is the default) if you are satisfied with the configuration.

The following configuration will be applied:

```
switchname switch_name
interface mgmt0
    ip address mgmt_IP_address
    subnetmask mgmt0_ip_netmask
    no shutdown
    ip default-gateway default_gateway
    telnet server enable
    no ssh server enable
    no system default switchport shutdown
    system default switchport trunk mode on
    no zone default-zone permit vsan 1-4093
    zoneset distribute full vsan 1-4093
Would you like to edit the configuration? (yes/no) [n]: no
```

- Step 21** Enter **yes** (yes is default) to use and save this configuration.

```
Use this configuration and save it? (yes/no) [y]: yes
```



Caution

If you do not save the configuration at this point, none of your changes are updated the next time the switch is rebooted. Type **yes** to save the new configuration. This ensures that the kickstart and system images are also automatically configured.

Send documentation comments to mdsfeedback-doc@cisco.com

Verifying the Module Status

Before you proceed with any further configuration of the switch, you need to ensure that the modules in the chassis are functioning as designed. To verify the status of a module at any time, issue the **show module** command. All the hardware that was physically installed should be displayed.

A sample output of the **show module** command follows:

```
switch# show module
Mod Ports Module-Type Model Status
--- -----
2 32 1/2 Gbps FC Module DS-X9032 ok
3 16 1/2 Gbps FC Module DS-X9016 ok
4 8 IP Storage Services Module DS-X9308-SMIP ok
5 0 Supervisor/Fabric-1 DS-X9530-SF1-K9 active *
6 0 Supervisor/Fabric-1 DS-X9530-SF1-K9 ha-standby
7 0 Caching Services Module DS-X9560-SMAP ok
9 32 Advanced Services Module DS-X9032-SMV ok

Mod Sw Hw World-Wide-Name(s) (WWN)
--- -----
2 2.1(1a) 1.1 20:41:00:05:30:00:86:9e to 20:60:00:05:30:00:86:9e
3 2.1(1a) 3.0 20:81:00:05:30:00:86:9e to 20:90:00:05:30:00:86:9e
4 2.1(1a) 4.0 20:c1:00:05:30:00:86:9e to 20:c8:00:05:30:00:86:9e
5 2.1(1a) 4.0 --
6 2.1(1a) 4.0 --
7 2.1(1a) 0.702 --
9 2.1(1a) 0.502 22:01:00:05:30:00:86:9e to 22:20:00:05:30:00:86:9e

Mod Application Image Description Application Image Version
--- -----
7 svc-node1 1.3 (5m)
7 svc-node2 1.3 (5m)
9 SSI linecard image 2.1(1)

Mod MAC-Address(es) Serial-Num
--- -----
2 00-0c-30-d9-eb-60 to 00-0c-30-d9-eb-64 JAB074704EJ
3 00-0c-30-0d-27-54 to 00-0c-30-0d-27-58 JAB074004RR
4 00-0c-30-da-92-88 to 00-0c-30-da-92-94 JAB075204ZN
5 00-0c-30-d9-dc-d0 to 00-0c-30-d9-dc-d4 JAB074504RC
6 00-0c-30-d9-ef-80 to 00-0c-30-d9-ef-84 JAB0747055Y
7 00-0d-bc-2f-bc-b8 to 00-0d-bc-2f-bd-3c JAB073907DK
9 00-05-30-00-ad-4e to 00-05-30-00-ad-52 JAB070605QV
```

* this terminal session



Note

If you do not see all the installed hardware, call your storage vendor support organization for further assistance.

■ Verifying the Module Status

Send documentation comments to mdsfeedback-doc@cisco.com