



CHAPTER 43

Configuring Ethernet OAM, CFM, and E-LMI

Ethernet Operations, Administration, and Maintenance (OAM) is a protocol for installing, monitoring, and troubleshooting Ethernet networks to increase management capability within the context of the overall Ethernet infrastructure. The Cisco ME 3800X and ME 3600X switch supports IEEE 802.1ag Connectivity Fault Management (CFM), Ethernet Local Management Interface (E-LMI), and IEEE 802.3ah Ethernet OAM discovery, link monitoring, remote fault detection, and remote loopback. It also supports IP Service Level Agreements (SLAs) for CFM.

This chapter provides information about configuring CFM, E-LMI, and the Ethernet OAM protocol.

For complete command and configuration information for Ethernet OAM, CFM, and E-LMI, see the *Cisco IOS Carrier Ethernet Configuration Guide*.

For complete syntax of the commands used in this chapter, see the command reference for this release and the *Cisco IOS Carrier Ethernet Command Reference* at this URL:

http://www.cisco.com/en/US/docs/ios/cether/command/reference/ce_book.html

This chapter contains these sections:

- [Understanding Ethernet CFM, page 43-1](#)
- [Configuring Ethernet CFM, page 43-7](#)
- [Managing and Displaying Ethernet CFM Information, page 43-23](#)
- [Understanding the Ethernet OAM Protocol, page 43-25](#)
- [Setting Up and Configuring Ethernet OAM, page 43-26](#)
- [Displaying Ethernet OAM Protocol Information, page 43-35](#)
- [Understanding E-LMI, page 43-35](#)
- [Configuring E-LMI, page 43-36](#)
- [Displaying E-LMI, page 43-38](#)
- [Ethernet CFM and Ethernet OAM Interaction, page 43-38](#)

Understanding Ethernet CFM

Ethernet CFM is an end-to-end per VLAN Ethernet layer OAM protocol that includes proactive connectivity monitoring, fault verification, and fault isolation. End-to-end can be provider-edge-to-provider-edge (PE-to-PE) device or customer-edge-to-customer-edge (CE-to-CE) device. Ethernet CFM, as specified by IEEE 802.1ag, is the standard for Layer 2 ping, Layer 2 traceroute, and end-to-end connectivity check of the Ethernet network.

The switch does not support:

- CFM on VFI interfaces
- Provider-edge E-LMI
- CFM on SVI based xconnect
- CFM on port based xconnect

**Note**

CFM is supported on EVC BD, EVC xconnect, EFP xconnect and CFM transparencies.



These sections contain conceptual information about Ethernet CFM:

- [CFM Domain, page 43-2](#)
- [Maintenance Associations and Maintenance Points, page 43-3](#)
- [CFM Messages, page 43-4](#)
- [Crosscheck Function and Static Remote MEPs, page 43-5](#)
- [SNMP Traps and Fault Alarms, page 43-5](#)
- [Configuration Error List, page 43-5](#)
- [IP SLAs Support for CFM, page 43-6](#)
- [CFM on EVC Bridge Domains and EVC Cross-Connect Interfaces, page 43-6](#)

CFM Domain

A CFM maintenance domain is a management space on a network that is owned and operated by a single entity and defined by a set of ports internal to it, but at its boundary. You assign a unique maintenance level (from 0 to 7) to define the hierarchical relationship between domains. The larger the domain, the higher the level. For example, as shown in [Figure 43-1](#), a service-provider domain would be larger than an operator domain and might have a maintenance level of 6, while the operator domain maintenance level is 3 or 4.

As shown in [Figure 43-2](#), domains cannot intersect or overlap because that would require management by more than one entity, which is not allowed. Domains can touch or nest (if the outer domain has a higher maintenance level than the nested domain). Nesting domains is useful when a service provider contracts with one or more operators to provide Ethernet service. Each operator has its own maintenance domain and the service provider domain is a superset of the operator domains. Maintenance levels of nesting domains should be communicated among the administering organizations. CFM exchanges messages and performs operations on a per-domain basis.

Figure 43-1 CFM Maintenance Domains**Figure 43-2** Allowed Domain Relationships

Maintenance Associations and Maintenance Points

A maintenance association (MA) identifies a service that can be uniquely identified within the maintenance domain. The CFM protocol runs within a maintenance association. A maintenance point is a demarcation point on an interface that participates in CFM within a maintenance domain. Maintenance points drop all lower-level frames and forward all higher-level frames. There are two types of maintenance points:

- Maintenance end points (MEPs) are points at the edge of the domain that define the boundaries and confine CFM messages within these boundaries. *Outward facing* or *Down* MEPs communicate through the wire side (connected to the port). *Inward facing* or *Up* MEPs communicate through the relay function side, not the wire side.

CFM 802.1ag supports up and down per-VLAN MEPs, as well as port MEPs, which are untagged down MEPs that are not associated with a VLAN. Port MEPs are configured to protect a single hop and used to monitor link state through CFM. If a port MEP is not receiving continuity check messages from its peer (static remote MEP), for a specified interval, the port is put into an operational down state in which only CFM and OAM packets pass through, and all other data and control packets are dropped.

- An up MEP sends and receives CFM frames through the relay function. It drops all CFM frames at its level or lower that come from the wire side, except traffic going to the down MEP. For CFM frames from the relay side, it processes the frames at its level and drops frames at a lower level. The MEP transparently forwards all CFM frames at a higher level, regardless of whether they are received from the relay or wire side. If the port on which MEP is configured is blocked by STP, the MEP can still send or receive CFM messages through the relay function. CFM runs at the provider maintenance level (UPE-to-UPE), specifically with up MEPs at the user network interface (UNI).

**Note**

The switch rate-limits all incoming CFM messages at a fixed rate of 500 frames per second.

- A down MEP sends and receives CFM frames through the wire connected to the port on which the MEP is configured. It drops all CFM frames at its level or lower that come from the relay side. For CFM frames from the wire side, it processes all CFM frames at its level and drops CFM frames at lower levels except traffic going to the other lower-level down MEP. The MEP transparently forwards all CFM frames at a higher level, regardless of whether they are received from the relay or through the wire.
- Maintenance intermediate points (MIPs) are internal to a domain, not at the boundary, and respond to CFM only when triggered by traceroute and loopback messages. They forward CFM frames received from MEPs and other MIPs, drop all CFM frames at a lower level (unless MIP filtering is enabled), and forward all CFM frames at a higher level and at a lower level and regardless of whether they are received from the relay or wire side. When MIP filtering is enabled, the MIP drops CFM frames at a lower level. MIPs also catalog and forward continuity check messages (CCMs), but do not respond to them.

MIP filtering is disabled by default, and you can configure it to be enabled or disabled. When MIP filtering is disabled, all CFM frames are forwarded.

You can manually configure a MIP or configure the switch to automatically create a MIP. You can configure a MEP without a MIP. In case of a configuration conflict, manually created MIPs take precedence over automatically created MIPs.

If port on which the MEP is configured is blocked by Spanning-Tree Protocol (STP), the MIP can receive and might respond to CFM messages from both the wire and relay side, but cannot forward any CFM messages.

CFM Messages

CFM uses standard Ethernet frames distinguished by EtherType or (for multicast messages) by MAC address. All CFM messages are confined to a maintenance domain and to a service-provider VLAN (S-VLAN). These CFM messages are supported:

- Continuity Check (CC) messages—multicast heartbeat messages exchanged periodically between MEPs that allow MEPs to discover other MEPs within a domain and allow MIPs to discover MEPs. CC messages are configured to a domain or VLAN. Enter the **continuity-check** Ethernet service configuration command to enable CCM.

The default continuity check message (CCM) interval on the switch is 10 seconds. You can set it to be 100 ms, 1 second, 1 minute, or 10 minutes by entering the **continuity-check interval** Ethernet service mode command. Because faster CCM rates are more CPU intensive, we do not recommend configuring a large number of MEPs running at 100 ms intervals.

- Loopback messages—unicast or multicast frames transmitted by a MEP at administrator request to verify connectivity to a particular maintenance point, indicating if a destination is reachable. A loopback message is similar to an Internet Control Message Protocol (ICMP) ping message. Refer to the **ping ethernet** privileged EXEC command.
- Traceroute messages—multicast frames transmitted by a MEP at administrator request to track the path (hop-by-hop) to a destination MEP. Traceroute messages are similar in concept to UDP traceroute messages. Refer to the **traceroute ethernet** privileged EXEC command.

Crosscheck Function and Static Remote MEPs

The crosscheck function is a timer-driven post-provisioning service verification between dynamically configured MEPs (using crosscheck messages) and expected MEPs (by configuration) for a service. It verifies that all endpoints of a multipoint service are operational. The crosscheck function is performed only one time and is initiated from the command-line interface (CLI).

CFM 802.1ag also supports static remote MEPs or static RMEP check. Unlike the crosscheck function, which is performed only once, configured static RMEP checks run continuously. To configure static RMEP check, enter the **continuity-check static rmeip** Ethernet CFM service mode command.

SNMP Traps and Fault Alarms

The MEPs generate two types of SNMP traps: CC traps and crosscheck traps. Supported CC traps are MEP up, MEP down, cross-connect (a service ID does not match the VLAN), loop, and configuration error. The crosscheck traps are service up, MEP missing (an expected MEP is down), and unknown MEP.

Fault alarms are unsolicited notifications sent to alert the system administrator when CFM detects a fault. You can configure the priority level of alarms that trigger an SNMP trap or syslog message. You can also configure a delay period before a fault alarm is sent and the time before the alarm is reset.

Configuration Error List

CFM configuration errors in CFM 802.1ag can be misconfigurations or extra configuration commands detected during MEP configuration. They can be caused by overlapping maintenance associations. For example, if you create a maintenance association with a VLAN list and a MEP on an interface, a potential leak error could occur if other maintenance associations associated with the same VLAN exist at a higher level without any MEPs configured. You can display the configuration error list, which is informational only, by entering the **show ethernet cfm errors configuration** privileged EXEC command.

IP SLAs Support for CFM

The switch supports CFM with IP Service Level Agreements (SLAs), which provides the ability to gather Ethernet layer network performance metrics. Available statistical measurements for the IP SLAs CFM operation include round-trip time, jitter (interpacket delay variance), and packet loss. You can schedule multiple IP SLAs operations and use Simple Network Management Protocol (SNMP) trap notifications and syslog messages for proactive threshold violation monitoring.

For more information about IP SLAs, see [Chapter 42, “Configuring Cisco IOS IP SLAs Operations.”](#)

IP SLAs integration with CFM gathers Ethernet layer statistical measurements by sending and receiving Ethernet data frames between CFM MEPs. Performance is measured between the source MEP and the destination MEP. Unlike other IP SLAs operations that provide performance metrics for only the IP layer, IP SLAs with CFM provides performance metrics for Layer 2.

You can manually configure individual Ethernet ping or jitter operations. You can also configure an IP SLAs automatic Ethernet operation that queries the CFM database for all MEPs in a given maintenance domain and VLAN. The operation then automatically creates individual Ethernet ping or jitter operations based on the discovered MEPs.

For more information about IP SLAs operation with CFM, see the *IP SLAs for Metro-Ethernet* feature module.

CFM on EVC Bridge Domains and EVC Cross-Connect Interfaces

CFM is supported on EVC bridge domains and EVC cross-connect interfaces. EVC interfaces can be used to connect UNI interfaces so that VLAN IDs can be mapped to bridge domains.

CFM is supported on the following types of EVCs:

- Default
- Tagged
- Untagged
- Single-dot1q tagged
- QinQ

CFM over pseudowires allows service providers to manage access-side, end-to-end connectivity over an MPLS core.

CFM packets can be forwarded over:

- SVI Pseudo-wire
- VPLS Pseudo-wire
- EVC Xconnect Pseudo-wire
- Bridge-domain
- VLAN

The following CFM features are supported on the Cisco ME3600/ME3800 switches:

- CFM transparency on SVI PW / VPLS PW / EVC xconnect PW
- CFM Up MEP on EVC Xconnect and Port-Channel EVC Xconnect
- CFM Down MEP on EVC BD and Port-Channel EVC Xconnect
- CFM Up MEP on EVC BD and Port-Channel EVC Xconnect

- MIP support
- CFM IEEE MIB (EVC BD, EVC Xconnect)
- ELMI PE and CE support
- CFM ELMI Interworking
- CFM and 802.3ah interworking
- SYSLOG
- 802.3AH SNMP MIB

The following asymmetric configurations are not supported on the Cisco ME3600/ME3800 switches:

- efps with 1 tag & no rewrite
- efps with 2 tags & pop 1
- efps with 2 tags and no rewrite

The following asymmetric configurations are supported on the Cisco ME3600/ME3800 switches:

- efps with no tag & no rewrite
- efps with 1 tag & pop 1
- efps with 2 tag & pop 2

Configuring Ethernet CFM

Configuring Ethernet CFM requires configuring the CFM domain. You can optionally configure and enable other CFM features such as crosschecking, remote MEP, port MEPs, SNMP traps, and fault alarms.

- [Default Ethernet CFM Configuration, page 43-7](#)
- [Ethernet CFM Configuration Guidelines, page 43-8](#)
- [Configuring the CFM Domain, page 43-8](#)
- [Configuring Ethernet CFM Crosscheck, page 43-11](#)
- [Configuring Static Remote MEP, page 43-13](#)
- [Configuring a Port MEP, page 43-14](#)
- [Configuring SNMP Traps, page 43-15](#)
- [Configuring Fault Alarms, page 43-16](#)
- [Configuring IP SLAs CFM Operation, page 43-17](#)
- [Configuring CFM on EVC Bridge Domains and EVC Cross-Connect Interfaces, page 43-21](#)

Default Ethernet CFM Configuration

CFM is globally disabled.

CFM is enabled on all interfaces when CFM is globally enabled.

A port can be configured as a flow point (MIP/MEP), a transparent port, or disabled (CFM disabled). By default, ports are transparent ports until configured as MEP, MIP, or disabled.

There are no MEPs or MIPs configured.

When configuring a MEP service, if you do not configure direction, the default is up (inward facing).

Ethernet CFM Configuration Guidelines

- CFM is not supported on and cannot be configured on routed ports or on Layer 3 EtherChannels.
- CFM is supported on EtherChannel port channels. You can configure an EtherChannel port channel as MEP or MIP. However, CFM is not supported on individual ports that belong to an EtherChannel and you cannot add a CFM port to an EtherChannel group.
- Port MEP is not supported on Layer 2 EtherChannels, or on ports that belong to an EtherChannel.
- CFM is supported on VLAN interfaces and on service instances (bridge domains).
- CFM is supported on trunk ports and access ports with these exceptions:
 - Trunk ports configured as MEPs must belong to allowed VLANs
 - Access ports configured as MEPs must belong to the native VLAN.
- A REP port or FlexLink port can also be a service (VLAN) MEP or MIP, but it cannot be a port MEP.
- CFM is supported on ports running STP.
- You must configure a port MEP at a lower level than any service (VLAN) MEPs on an interface.
- You cannot configure tunnel mode by using the native VLAN as the S-VLAN or the C-VLAN.
- Do not configure double-tagged 802.1ag CFM packets entering a trunk port.

Configuring the CFM Domain

Beginning in privileged EXEC mode, follow these steps to configure the Ethernet CFM domain, configure a service to connect the domain to a VLAN, or configure a port to act as a MEP. You can also enter the optional commands to configure other parameters, such as continuity checks.

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet cfm ieee	Configure the CFM version as IEEE 802.1ag.
Step 3	ethernet cfm global	Globally enable Ethernet CFM on the switch.
Step 4	ethernet cfm traceroute cache [<i>size entries</i> <i>hold-time minutes</i>]	(Optional) Configure the CFM traceroute cache. You can set a maximum cache size or hold time. <ul style="list-style-type: none"> (Optional) For size, enter the cache size in number of entry lines. The range is from 1 to 4095; the default is 100 lines. (Optional) For hold-time, enter the maximum cache hold time in minutes. The range is from 1 to 65535; the default is 100 minutes.

	Command	Purpose
Step 5	ethernet cfm mip auto-create level <i>level-id</i> vlan <i>vlan-id</i>	(Optional) Configure the switch to automatically create MIPs for VLAN IDS that are not associated with specific maintenance associations at the specified level. The level range is 0 to 7. Note Configure MIP auto-creation only for VLANs that MIPs should monitor. Configuring for all VLANs can be CPU and memory-intensive.
Step 6	ethernet cfm mip filter	(Optional) Enable MIP filtering, which means that all CFM frames at a lower level are dropped. The default is disabled.
Step 7	ethernet cfm domain <i>domain-name</i> level <i>level-id</i>	Define a CFM domain, set the domain level, and enter ethernet-cfm configuration mode for the domain. The maintenance level number range is 0 to 7.
Step 8	id { <i>mac-address domain_number</i> dns name null }	(Optional) Assign a maintenance domain identifier. <ul style="list-style-type: none"> <i>mac-address domain_number</i>—Enter the MAC address and a domain number. The number can be from 0 to 65535. dns name—Enter a DNS name string. The name can be a maximum of 43 characters. null—Assign no domain name.
Step 9	service { <i>ma-name</i> <i>ma-number</i> <i>vpn-id vpn</i> } { evc <i>evc-id</i> } { vlan <i>vlan-id</i> [direction down] port }	Define a customer service maintenance association (MA) name or number or VPN ID to be associated with the domain, a VLAN ID or port MEP, and enter ethernet-cfm-service configuration mode. <ul style="list-style-type: none"> <i>ma-name</i>—a string of no more than 100 characters that identifies the MAID. <i>ma-number</i>—a value from 0 to 65535. <i>vpn-id vpn</i>—enter a VPN ID as the <i>ma-name</i>. vlan <i>vlan-id</i>—VLAN range is from 1 to 4094. You cannot use the same VLAN ID for more than one domain at the same level. evc <i>evc-id</i>—enter an EVC name. (Optional) direction down—specify the service direction as down. port—Configure port MEP, a down MEP that is untagged and not associated with a VLAN.
Step 10	continuity-check	Enable sending and receiving of continuity check messages.
Step 11	continuity-check interval <i>value</i>	(Optional) Set the interval at which continuity check messages are sent. The available values are 100 ms, 1 second, 10 seconds, 1 minute and 10 minutes. The default is 10 seconds. Note Because faster CCM rates are more CPU-intensive, we do not recommend configuring a large number of MEPs running at 100 ms intervals.

	Command	Purpose
Step 12	continuity-check loss-threshold <i>threshold-value</i>	(Optional) Set the number of continuity check messages to be missed before declaring that an MEP is down. The range is 2 to 255; the default is 3.
Step 13	maximum meps <i>value</i>	(Optional) Configure the maximum number of MEPS allowed across the network. The range is from 1 to 65535. The default is 100.
Step 14	sender-id { chassis none }	(Optional) Include the sender ID TLVs, attributes containing type, length, and values for neighbor devices. <ul style="list-style-type: none"> • chassis—Send the chassis ID (host name). • none—Do not include information in the sender ID.
Step 15	mip auto-create [lower-mep-only none]	(Optional) Configure auto creation of MIPs for the service. <ul style="list-style-type: none"> • lower-mep-only—Create a MIP only if there is a MEP for the service in another domain at the next lower active level. • none—No MIP auto-create.
Step 16	exit	Return to ethernet-cfm configuration mode.
Step 17	mip auto-create [lower-mep-only]	(Optional) Configure auto creation of MIPs for the domain. <ul style="list-style-type: none"> • lower-mep-only—Create a MIP only if there is a MEP for the service in another domain at the next lower active level.
Step 18	mep archive-hold-time <i>minutes</i>	(Optional) Set the number of minutes that data from a missing maintenance end point is kept before it is purged. The range is 1 to 65535; the default is 100 minutes.
Step 19	exit	Return to global configuration mode.
Step 20	interface <i>interface-id</i>	Specify an interface to configure, and enter interface configuration mode.
Step 21	switchport mode trunk	(Optional) Configure the port as a trunk port.
Step 22	ethernet cfm mip level <i>level-id</i>	(Optional) Configure a customer level or service-provider level maintenance intermediate point (MIP) for the interface. The MIP level range is 0 to 7. <p>Note This step is not required if you have entered the ethernet cfm mip auto-create global configuration command or the mip auto-create ethernet-cfm or ethernet-cfm-srv configuration mode.</p>

	Command	Purpose
Step 23	ethernet cfm mep domain <i>domain-name</i> mpid identifier { vlan <i>vlan-id</i> port }	Configure maintenance end points for the domain, and enter ethernet cfm mep mode. <ul style="list-style-type: none"> • domain <i>domain-name</i>—Specify the name of the created domain. • mpid identifier—Enter a maintenance end point identifier. The identifier must be unique for each VLAN. The range is 1 to 4094. • vlan <i>vlan-id</i>—Enter the service provider VLAN ID or IDs as a VLAN-ID (1 to 4094), a range of VLAN-IDs separated by a hyphen, or a series of VLAN IDs separated by comma. • port—Configure port MEP.
Step 24	cos <i>value</i>	(Optional) Specify the class of service (CoS) value to be sent with the messages. The range is 0 to 7.
Step 25	end	Return to privileged EXEC mode.
Step 26	show ethernet cfm maintenance-points { local remote }	Verify the configuration.
Step 27	show ethernet cfm errors [configuration]	(Optional) Display the configuration error list.
Step 28	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** versions of the commands to remove the configuration or return to the default configurations.

This is an example of the basic CFM configuration:

```
Switch(config)# ethernet cfm ieee
Switch(config)# ethernet cfm global
Switch(config)# ethernet cfm domain abc level 3
Switch(config-ecfm)# service test vlan 5
Switch(config-ecfm-srv)# continuity-check
Switch(config-ecfm-srv)# exit
Switch(config-ecfm)# exit
Switch(config)# interface gigabitethernet0/2
Switch(config-if)# ethernet cfm mep domain abc mpid 222 vlan 5
Switch(config-if-ecfm-mep)# exit
```

Configuring Ethernet CFM Crosscheck

Beginning in privileged EXEC mode, follow these steps to configure Ethernet CFM crosscheck:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet cfm mep crosscheck start-delay <i>delay</i>	Configure the number of seconds that the device waits for remote MEPs to come up before the crosscheck is started. The range is 1 to 65535; the default is 30 seconds.
Step 3	ethernet cfm domain <i>domain-name</i> level <i>level-id</i>	Define a CFM domain, set the domain level, and enter ethernet-cfm configuration mode for the domain. The maintenance level number range is 0 to 7.

	Command	Purpose
Step 4	service { <i>ma-name</i> <i>ma-number</i> <i>vpn-id</i> <i>vpn</i> } { evc <i>evc-id</i> } { vlan <i>vlan-id</i> }	<p>Define a customer service maintenance association name or number or VPN ID to be associated with the domain, and a VLAN ID, and enter ethernet-cfm-service configuration mode.</p> <ul style="list-style-type: none"> • <i>ma-name</i>—a string of no more than 100 characters that identifies the MAID. • <i>ma-number</i>—a value from 0 to 65535. • <i>vpn-id</i> <i>vpn</i>—enter a VPN ID as the <i>ma-name</i>. • vlan <i>vlan-id</i>—VLAN range is from 1 to 4094. You cannot use the same VLAN ID for more than one domain at the same level. • evc <i>evc-id</i>—enter and EVC name.
Step 5	mep <i>mpid identifier</i>	Define the MEP maintenance end point identifier in the domain and service. The range is 1 to 4094.
Step 6	end	Return to privileged EXEC mode.
Step 7	ethernet cfm mep crosscheck { enable disable } domain <i>domain-name</i> { vlan { <i>vlan-id</i> any } port }	<p>Enable or disable CFM crosscheck for one or more VLANs or a port MEP in the domain.</p> <ul style="list-style-type: none"> • domain <i>domain-name</i>—Specify the name of the created domain. • vlan {<i>vlan-id</i> any}—Enter the service provider VLAN ID or IDs as a VLAN-ID (1 to 4094), a range of VLAN-IDs separated by a hyphen, or a series of VLAN IDs separated by comma. Enter any for any VLAN. • port—Identify a port MEP.
Step 8	show ethernet cfm maintenance-points remote crosscheck	Verify the configuration.
Step 9	show ethernet cfm errors [configuration]	Enter this command after you enable CFM crosscheck to display the results of the crosscheck operation. Enter the configuration keyword to display the configuration error list.
Step 10	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** form of each command to remove a configuration or to return to the default settings.

Configuring Static Remote MEP

Beginning in privileged EXEC mode, follow these steps to configure Ethernet CFM static remote MEP:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet cfm domain <i>domain-name</i> level <i>level-id</i>	Define a CFM domain, set the domain level, and enter ethernet-cfm configuration mode for the domain. The maintenance level number range is 0 to 7.
Step 3	service { <i>ma-name</i> <i>ma-number</i> <i>vpn-id</i> <i>vpn</i> } { evc <i>evc-id</i> } { vlan <i>vlan-id</i> [direction down] port }	Define a customer service maintenance association name or number or a VPN ID to be associated with the domain, and a VLAN ID or peer MEP, and enter ethernet-cfm-service configuration mode. <ul style="list-style-type: none"> • <i>ma-name</i>—a string of no more than 100 characters that identifies the MAID. • <i>ma-number</i>—a value from 0 to 65535. • <i>vpn-id</i>—enter a VPN ID as the <i>ma-name</i>. • vlan <i>vlan-id</i>—VLAN range is from 1 to 4094. You cannot use the same VLAN ID for more than one domain at the same level. • (Optional) direction down—specify the service direction as down. • port—Configure port MEP, a down MEP that is untagged and not associated with a VLAN.
Step 4	continuity-check	Enable sending and receiving of continuity check messages.
Step 5	mep mpid <i>identifier</i>	Define the static remote maintenance end point identifier. The range is 1 to 4094.
Step 6	continuity-check static rmep	Enable checking of the incoming continuity check message from a remote MEP that is configured in the MEP list.
Step 7	end	Return to privileged EXEC mode.
Step 8	show ethernet cfm maintenance-points remote static	Verify the configuration.
Step 9	show ethernet cfm errors [configuration]	Enter this command after you enable CFM crosscheck to display the results of the crosscheck operation. Enter the configuration keyword to display the configuration error list.
Step 10	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** form of each command to remove a configuration or to return to the default settings.

Configuring a Port MEP

A port MEP is a down MEP that is not associated with a VLAN and that uses untagged frames to carry CFM messages. You configure port MEPs on two connected interfaces. Port MEPs are always configured at a lower domain level than native VLAN MEPs.

Beginning in privileged EXEC mode, follow these steps to configure Ethernet CFM port MEPs:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet cfm domain <i>domain-name</i> level <i>level-id</i>	Define a CFM domain, set the domain level, and enter ethernet-cfm configuration mode for the domain. The maintenance level number range is 0 to 7.
Step 3	service { <i>ma-name</i> <i>ma-number</i> <i>vpn-id</i> } port	Define a customer service maintenance association name or number or VPN ID to be associated with the domain, define a port MEP, and enter ethernet-cfm-service configuration mode. <ul style="list-style-type: none"> • <i>ma-name</i>—a string of no more than 100 characters that identifies the MAID. • <i>ma-number</i>—a value from 0 to 65535. • <i>vpn-id</i> <i>vpn</i>—enter a VPN ID as the <i>ma-name</i>.
Step 4	mep mpid <i>identifier</i>	Define the static remote maintenance end point identifier in the domain and service. The range is 1 to 4094.
Step 5	continuity-check	Enable sending and receiving of continuity check messages.
Step 6	continuity-check interval <i>value</i>	(Optional) Set the interval at which continuity check messages are sent. The available values are 100 ms, 1 second, 10 seconds, 1 minute and 10 minutes. The default is 10 seconds. Note Because faster CCM rates are more CPU-intensive, we do not recommend configuring a large number of MEPs running at 100 ms intervals.
Step 7	continuity-check loss-threshold <i>threshold-value</i>	(Optional) Set the number of continuity check messages to be missed before declaring that an MEP is down. The range is 2 to 255; the default is 3.
Step 8	continuity-check static rmp	Enable checking of the incoming continuity check message from a remote MEP that is configured in the MEP list.
Step 9	exit	Return to ethernet-cfm configuration mode.
Step 10	exit	Return to global configuration mode.
Step 11	interface <i>interface-id</i>	Identify the port MEP interface and enter interface configuration mode.

	Command	Purpose
Step 12	ethernet cfm mep domain <i>domain-name</i> mpid identifier port	Configure the interface as a port MEP for the domain. <ul style="list-style-type: none"> domain <i>domain-name</i>—Specify the name of the created domain. mpid identifier—Enter a maintenance end point identifier. The identifier must be unique for each VLAN. The range is 1 to 4094.
Step 13	end	Return to privileged EXEC mode.
Step 14	show ethernet cfm maintenance-points remote static	Verify the configuration.
Step 15	show ethernet cfm errors [configuration]	Enter this command after you enable CFM crosscheck to display the results of the crosscheck operation. Enter the configuration keyword to display the configuration error list.
Step 16	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** form of each command to remove a configuration or to return to the default settings.

This is a sample configuration for a port MEP:

```
Switch(config)# ethernet cfm domain abc level 3
Switch(config-ecfm)# service PORTMEP port
Switch(config-ecfm-srv)# mep mpid 222
Switch(config-ecfm-srv)# continuity-check
Switch(config-ecfm-srv)# continuity-check static rmep
Switch(config-ecfm-srv)# exit
Switch(config-ecfm)# exit
Switch(config)# interface gigabitethernet0/1
Switch(config-if)# ethernet cfm mep domain abc mpid 111 port
Switch(config-if)# end
```

Configuring SNMP Traps

Beginning in privileged EXEC mode, follow these steps to configure traps for Ethernet CFM:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	snmp-server enable traps ethernet cfm cc [mep-up] [mep-down] [config] [loop] [cross-connect]	(Optional) Enable Ethernet CFM continuity check traps.
Step 3	snmp-server enable traps ethernet cfm crosscheck [mep-unknown] [mep-missing] [service-up]	(Optional) Enable Ethernet CFM crosscheck traps.
Step 4	end	Return to privileged EXEC mode.
Step 5	show running-config	Verify your entries.
Step 6	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** form of each command to remove a configuration or to return to the default settings.

Configuring Fault Alarms

Beginning in privileged EXEC mode, follow these steps to configure Ethernet CFM fault alarms. Note that you can configure fault alarms in either global configuration mode or Ethernet CFM interface MEP mode. In case of conflict, the interface MEP mode configuration takes precedence.

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet cfm alarm notification {all error-xcon mac-remote-error-xcon none remote-error-xcon xcon}	Globally enable Ethernet CFM fault alarm notification for the specified defects: <ul style="list-style-type: none"> • all—report all defects. • error-xcon—Report only error and connection defects. • mac-remote-error-xcon—Report only MAC-address, remote, error, and connection defects. • none—Report no defects. • remote-error-xcon—Report only remote, error, and connection defects. • xcon—Report only connection defects.
Step 3	ethernet cfm alarm delay value	(Optional) Set a delay period before a CFM fault alarm is sent. The range is 2500 to 10000 milliseconds (ms). The default is 2500 ms.
Step 4	ethernet cfm alarm reset value	(Optional) Specify the time period before the CFM fault alarm is reset. The range is 2500 to 10000 milliseconds (ms). The default is 10000 ms.
Step 5	ethernet cfm logging alarm ieee	Configure the switch to generate system logging messages for the alarms.
Step 6	interface interface-id	(Optional) Specify an interface to configure, and enter interface configuration mode.
Step 7	ethernet cfm mep domain domain-name mpid identifier vlan vlan-id	Configure maintenance end points for the domain, and enter ethernet cfm interface mep mode. <ul style="list-style-type: none"> • domain domain-name—Specify the name of the created domain. • mpid identifier—Enter a maintenance end point identifier. The identifier must be unique for each VLAN. The range is 1 to 4094. • vlan vlan-id—Enter the service provider VLAN ID or IDs as a VLAN-ID (1 to 4094), a range of VLAN-IDs separated by a hyphen, or a series of VLAN IDs separated by comma.

	Command	Purpose
Step 8	ethernet cfm alarm notification { all error-xcon mac-remote-error-xcon none remote-error-xcon xcon }	(Optional) Enable Ethernet CFM fault alarm notification for the specified defects on the interface. Note The Ethernet CFM interface MEP alarm configuration takes precedence over the global configuration.
Step 9	ethernet cfm alarm { delay <i>value</i> reset <i>value</i> }	(Optional) Set an alarm delay period or a reset period. Note The Ethernet CFM interface MEP alarm configuration takes precedence over the global configuration.
Step 10	end	Return to privileged EXEC mode.
Step 11	show running-config	Verify your entries.
Step 12	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no** form of each command to remove a configuration or to return to the default settings.

Configuring IP SLAs CFM Operation

You can manually configure an individual IP SLAs Ethernet ping or jitter echo operation or you can configure IP SLAs Ethernet operation with endpoint discovery. You can also configure multiple operation scheduling. For accurate one-way delay statistics, the clocks on the endpoint switches must be synchronized. You can configure the endpoint switches with Network Time Protocol (NTP) so that the switches are synchronized to the same clock source.

For more information about configuring IP SLAs Ethernet operation, see the *IP SLAs for Metro-Ethernet*.

For detailed information about configuring IP SLAs operations, see the *Cisco IOS IP SLAs Configuration Guide*.

For detailed information about IP SLAs commands, see the command reference at this URL:
http://www.cisco.com/en/US/docs/ios/ipsla/command/reference/sla_book.html

This section includes these procedures:

- [Manually Configuring an IP SLAs CFM Probe or Jitter Operation, page 43-17](#)
- [Configuring an IP SLAs Operation with Endpoint Discovery, page 43-19](#)

Manually Configuring an IP SLAs CFM Probe or Jitter Operation

Beginning in privileged EXEC mode, follow these steps to manually configure an IP SLAs Ethernet echo (ping) or jitter operation:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ip sla operation-number	Create an IP SLAs operation, and enter IP SLAs configuration mode.

	Command	Purpose
Step 3	ethernet echo mpid <i>identifier</i> domain <i>domain-name</i> vlan <i>vlan-id</i> or ethernet jitter mpid <i>identifier</i> domain <i>domain-name</i> vlan <i>vlan-id</i> [interval <i>interpacket-interval</i>] [num-frames <i>number-of frames transmitted</i>]	Configure the IP SLAs operation as an echo (ping) or jitter operation, and enter IP SLAs Ethernet echo configuration mode. <ul style="list-style-type: none"> Enter echo for a ping operation or jitter for a jitter operation. For mpid <i>identifier</i>, enter a maintenance endpoint identifier. The identifier must be unique for each VLAN. The range is 1 to 4094. For domain <i>domain-name</i>, enter the CFM domain name. For vlan <i>vlan-id</i>, the VLAN range is from 1 to 4095. (Optional—for jitter only) Enter the interval between sending of jitter packets. (Optional—for jitter only) Enter the num-frames and the number of frames to be sent.
Step 4	cos <i>cos-value</i>	(Optional) Set a class of service value for the operation.
Step 5	frequency <i>seconds</i>	(Optional) Set the rate at which the IP SLAs operation repeats. The range is from 1 to 604800 seconds; the default is 60 seconds.
Step 6	history <i>history-parameter</i>	(Optional) Specify parameters for gathering statistical history information for the IP SLAs operation.
Step 7	owner <i>owner-id</i>	(Optional) Configure the SNMP owner of the IP SLAs operation.
Step 8	request-data-size <i>bytes</i>	(Optional) Specify the protocol data size for an IP SLAs request packet. The range is from 0 to the maximum size allowed by the protocol being used; the default is 66 bytes.
Step 9	tag <i>text</i>	(Optional) Create a user-specified identifier for an IP SLAs operation.
Step 10	threshold <i>milliseconds</i>	(Optional) Specify the upper threshold value in milliseconds (ms0 for calculating network monitoring statistics. The range is 0 to 2147483647; the default is 5000.
Step 11	timeout <i>milliseconds</i>	(Optional) Specify the amount of time in ms that the IP SLAs operation waits for a response from its request packet. The range is 0 to 604800000; the default value is 5000.
Step 12	exit	Return to global configuration mode.

	Command	Purpose
Step 13	ip sla schedule <i>operation-number</i> [ageout <i>seconds</i>] [life { forever <i>seconds</i> }] [recurring] [start-time { <i>hh:mm</i> { <i>:ss</i> } [<i>month day</i> <i>day month</i>] pending now after <i>hh:mm:ss</i> }]	<p>Schedule the time parameters for the IP SLAs operation.</p> <ul style="list-style-type: none"> <i>operation-number</i>—Enter the IP SLAs operation number. (Optional) ageout <i>seconds</i>—Enter the number of seconds to keep the operation in memory when it is not actively collecting information. The range is 0 to 2073600 seconds. The default is 0 seconds. (Optional) life—Set the operation to run indefinitely (forever) or for a specific number of <i>seconds</i>. The range is from 0 to 2147483647. The default is 3600 seconds (1 hour) (Optional) recurring—Set the probe to be automatically scheduled every day. (Optional) start-time—Enter the time for the operation to begin collecting information: <ul style="list-style-type: none"> To start at a specific time, enter the hour, minute, second (in 24-hour notation), and day of the month. Enter pending to select no information collection until a start time is selected. Enter now to start the operation immediately. Enter after <i>hh:mm:ss</i> to show that the operation should start after the entered time has elapsed.
Step 14	end	Return to privileged EXEC mode.
Step 15	show ip sla configuration [<i>operation-number</i>]	Show the configured IP SLAs operation.
Step 16	copy running-config startup-config	(Optional) Save your entries in the configuration file.

To remove an IP SLAs operation, enter the no **ip sla** *operation-number* global configuration command.

Configuring an IP SLAs Operation with Endpoint Discovery

Beginning in privileged EXEC mode, follow these steps to use IP SLAs to automatically discover the CFM endpoints for a domain and VLAN ID. You can configure ping or jitter operations to the discovered endpoints.

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ip sla ethernet-monitor <i>operation-number</i>	Begin configuration of an IP SLAs automatic Ethernet operation, and enter IP SLAs Ethernet monitor configuration mode.

	Command	Purpose
Step 3	type echo domain <i>domain-name</i> vlan <i>vlan-id</i> [exclude-mpids <i>mp-ids</i> or type jitter domain <i>domain-name</i> vlan <i>vlan-id</i> [exclude-mpids <i>mp-ids</i> [interval <i>interpacket-interval</i> [num-frames <i>number-of-frames</i> <i>transmitted</i>	Configure the automatic Ethernet operation to create echo (ping) or jitter operation and enter IP SLAs Ethernet echo configuration mode. <ul style="list-style-type: none"> Enter type echo for a ping operation or type jitter for a jitter operation. For mpid identifier, enter a maintenance endpoint identifier. The range is 1 to 4094. For domain <i>domain-name</i>, enter the CFM domain name. For vlan <i>vlan-id</i>, the VLAN range is from 1 to 4095. (Optional) Enter exclude-mpids <i>mp-ids</i> to exclude the specified maintenance endpoint identifiers. (Optional—for jitter only) Enter the interval between sending of jitter packets. (Optional—for jitter only) Enter the num-frames and the number of frames to be sent.
Step 4	cos <i>cos-value</i>	(Optional) Set a class of service value for the operation.
Step 5	owner <i>owner-id</i>	(Optional) Configure the SNMP owner of the IP SLAs operation.
Step 6	request-data-size <i>bytes</i>	(Optional) Specify the protocol data size for an IP SLAs request packet. The range is from 0 to the maximum size allowed by the protocol being used; the default is 66 bytes.
Step 7	tag <i>text</i>	(Optional) Create a user-specified identifier for an IP SLAs operation.
Step 8	threshold <i>milliseconds</i>	(Optional) Specify the upper threshold value in milliseconds for calculating network monitoring statistics. The range is 0 to 2147483647; the default is 5000.
Step 9	timeout <i>milliseconds</i>	(Optional) Specify the amount of time in milliseconds that the IP SLAs operation waits for a response from its request packet. The range is 0 to 604800000; the default value is 5000.
Step 10	exit	Return to global configuration mode.

	Command	Purpose
Step 11	<code>ip sla schedule operation-number [ageout seconds] [life {forever seconds}] [recurring] [start-time {hh:mm {:ss} [month day day month] pending now after hh:mm:ss}]</code>	<p>Schedule the time parameters for the IP SLAs operation.</p> <ul style="list-style-type: none"> <i>operation-number</i>—Enter the IP SLAs operation number. (Optional) ageout <i>seconds</i>—Enter the number of seconds to keep the operation in memory when it is not actively collecting information. The range is 0 to 2073600 seconds. The default is 0 seconds. (Optional) life—Set the operation to run indefinitely (forever) or for a specific number of <i>seconds</i>. The range is from 0 to 2147483647. The default is 3600 seconds (1 hour) (Optional) recurring—Set the probe to be automatically scheduled every day. (Optional) start-time—Enter the time for the operation to begin collecting information: <ul style="list-style-type: none"> To start at a specific time, enter the hour, minute, second (in 24-hour notation), and day of the month. Enter pending to select no information collection until a start time is selected. Enter now to start the operation immediately. Enter after <i>hh:mm:ss</i> to show that the operation should start after the entered time has elapsed.
Step 12	<code>end</code>	Return to privileged EXEC mode.
Step 13	<code>show ip sla configuration [operation-number]</code>	Show the configured IP SLAs operation.
Step 14	<code>copy running-config startup-config</code>	(Optional) Save your entries in the configuration file.

To remove an IP SLAs operation, enter the **no ip sla operation-number** global configuration command.

Configuring CFM on EVC Bridge Domains and EVC Cross-Connect Interfaces

The following examples show how to configure CFM on EVC.

Configuring CFM on EVC Commands

The following example shows the CLIs that are available for configuring CFM on EVC.

```

ethernet cfm ieee
ethernet cfm global
ethernet cfm domain L6 level 6
    service vlan100 evc evc100 direction down
        continuity-check
    service vlan200 evc evc200
        continuity-check
    service vlan200 evc evc300
        continuity-check

```

```

service xconn evc xconn direction down
continuity-check

```

Configuring CFM on an EVC Bridge Domain

The following example shows how to configure CFM on an EVC Bridge Domain.

```

interface GigabitEthernet2/0/0
  no ip address
  no mls qos trust
  service instance 1 ethernet evc100
    encapsulation dot1q 1000
    bridge-domain 1000
    cfm mep domain L6 mpid 99
  exit
  service instance 2 ethernet evc200
    encapsulation dot1q 2000
    bridge-domain 2000
    cfm mep domain L6 mpid 77
  exit
  service instance 3 ethernet evc300
    encapsulation dot1q 300
  xconnect 1.1.1.1 1 encap mpls
    cfm mep domain L6 mpid 88
  exit
end

```

Displaying CFM on EVC

The following example shows how to display CFM information.

```

Switch# show ethernet cfm ma local
Local MEPS:
-----
MPID Domain Name                               Lvl  MacAddress      Type  CC
      Domain Id                               Dir   Port          Id
      MA Name                                 SrvcInst
      EVC name
-----
 77   L6                                         6     000b.45e5.cb90  BD-V  Y
      L6                                         Up     Gi 0/2    2000
      vlan2000                                  2
      evc2000
 99   L6                                         6     00e0.aabb.cc00  BD-V  Y
      L6                                         Down   Gi 0/2    1000
      vlan1000                                  1
      evc1000
100   R3                                         3     00e0.aabb.cc0a  BD-V  Y
      R3                                         Down   Gi 0/10    10
      sr1                                         1
      er1
 2    eccm2                                     0     00e0.aabb.cc09  BD-V  I
      eccm2                                     Down   Gi /0/9    100
      ser2                                       N/A
      evc2

Total Local MEPS: 4
Local MIPs: None

```

Configuring CFM on an EVC with Cross-Connect

The following example shows how to configure CFM on EVC with cross-connect.

```
pseudowire-class vlan-xconnect
  encapsulation mpls
interface gigabit 1/1
  service instance 10 ethernet
  encapsulation dot1q 20
  xconnect 2.2.2.2 123 pw-class vlan-xconnect
  cfm mep domain Core mpid 100
```

Remote MEPs:

MPID	Domain Name	Lvl	MacAddress	Type	CC
	Domain Id	Dir	Port	Id	
	MA Name		SrvInst		
	EVC name				
7003	ofm_xcon	5	<port-mac>	XCONN	Y
	ofm_xcon	Down	Gi4/5	N/A	
	ofm_serv		xcon_evc_name		
	xcon_evc_name				
8103	ifm_xcon	5	<BRAIN-MAC>	XCONN	Y
	ifm_xcon	Up	(10.10.10.3, 81)	PW	
	ifm_serv		xcon_evc_name		
	xcon_evc_name				

Managing and Displaying Ethernet CFM Information

You can use the privileged EXEC commands in these tables to clear Ethernet CFM information.

Table 43-1 Clearing CFM Information

Command	Purpose
clear ethernet cfm ais domain <i>domain-name</i> mpid <i>id</i> [vlan <i>vlan-id</i> port]	Clear MEPs with matching domain and VLAN ID out of AIS defect condition.
clear ethernet cfm ais link-status interface <i>interface-id</i>	Clear a SMEP out of AIS defect condition.
clear ethernet cfm error	Clear all CFM error conditions, including AIS.

You can use the privileged EXEC commands in [Table 43-2](#) to display Ethernet CFM information.

Table 43-2 Displaying CFM Information

Command	Purpose
show ethernet cfm domain [brief]	Displays CFM domain information or brief domain information.
show ethernet cfm errors [configuration domain-id]	Displays CFM continuity check error conditions logged on a device since it was last reset or the log was last cleared. When CFM crosscheck is enabled, displays the results of the CFM crosscheck operation.

Table 43-2 **Displaying CFM Information (continued)**

Command	Purpose
show ethernet cfm maintenance-points local [detail domain interface level mep mip]	Displays maintenance points configured on a device.
show ethernet cfm maintenance-points remote [crosscheck detail domain static]	Displays information about a remote maintenance point domains or levels or details in the CFM database.
show ethernet cfm mpdb	Displays information about entries in the MIP continuity-check database.
show ethernet cfm smep [interface interface-id]	Displays Ethernet CFM SMEP information.
show ethernet cfm traceroute-cache	Displays the contents of the traceroute cache.
show platform cfm	Displays platform-independent CFM information.

This is an example of output from the **show ethernet cfm domain brief** command:

```
Switch# show ethernet cfm domain brief
Domain Name                               Index Level Services Archive(min)
level5                                    1      5      1      100
level3                                    2      3      1      100
test                                      3      3      3      100
name                                      4      3      1      100
test1                                     5      2      1      100
lck                                       6      1      1      100Total Services : 1
```

This is an example of output from the **show ethernet cfm errors** command:

```
Switch# show ethernet cfm errors
-----
MPID Domain Id                               Mac Address      Type   Id  Lvl
      MAName                               Reason           Age
-----
6307 level3                                0021.d7ee.fe80   Vlan   7   3
      vlan7                                Receive RDI      5s
```

This is an example of output from the **show ethernet cfm maintenance-points local detail** command:

```
Switch# show ethernet cfm maintenance-points local detail
Local MEPs:
-----
MPID: 7307
DomainName: level3
Level: 3
Direction: Up
Vlan: 7
Interface: Gi0/3
CC-Status: Enabled
CC Loss Threshold: 3
MAC: 0021.d7ef.0700
LCK-Status: Enabled
LCK Period: 60000(ms)
LCK Expiry Threshold: 3.5
Level to transmit LCK: Default
Defect Condition: No Defect
presentRDI: FALSE
AIS-Status: Enabled
AIS Period: 60000(ms)
AIS Expiry Threshold: 3.5
Level to transmit AIS: Default
Suppress Alarm configuration: Enabled
```

Suppressing Alarms: No

MIP Settings:

Local MIPs:

* = MIP Manually Configured

Level	Port	MacAddress	SrvcInst	Type	Id
*5	Gi0/3	0021.d7ef.0700	N/A	Vlan	2,7

This is an example of output from the **show ethernet cfm traceroute** command:

```
Switch# show ethernet cfm traceroute
Current Cache-size: 0 Hops
Max Cache-size: 100 Hops
Hold-time: 100 Minutes
```

You can use the privileged EXEC commands in [Table 43-3](#) to display IP SLAs Ethernet CFM information.

Table 43-3 *Displaying IP SLAs CFM Information*

Command	Purpose
show ip sla configuration [<i>entry-number</i>]	Displays configuration values including all defaults for all IP SLAs operations or a specific operation.
show ip sla ethernet-monitor configuration [<i>entry-number</i>]	Displays the configuration of the IP SLAs automatic Ethernet operation.
show ip sla statistics [<i>entry-number</i> aggregated details]	Display current or aggregated operational status and statistics.

Understanding the Ethernet OAM Protocol

The Ethernet OAM protocol for installing, monitoring, and troubleshooting Metro Ethernet networks and Ethernet WANs relies on an optional sublayer in the data link layer of the OSI model. Normal link operation does not require Ethernet OAM. You can implement Ethernet OAM on any full-duplex point-to-point or emulated point-to-point Ethernet link for a network or part of a network (specified interfaces).

OAM frames, called OAM protocol data units (OAM PDUs) use the slow protocol destination MAC address 0180.c200.0002. They are intercepted by the MAC sublayer and cannot propagate beyond a single hop within an Ethernet network. Ethernet OAM is a relatively slow protocol, with a maximum transmission rate of 10 frames per second, resulting in minor impact to normal operations. However, when you enable link monitoring, because the CPU must poll error counters frequently, the number of required CPU cycles is proportional to the number of interfaces that must be polled.

Ethernet OAM has two major components:

- The OAM client establishes and manages Ethernet OAM on a link and enables and configures the OAM sublayer. During the OAM discovery phase, the OAM client monitors OAM PDUs received from the remote peer and enables OAM functionality. After the discovery phase, it manages the rules of response to OAM PDUs and the OAM remote loopback mode.

- The OAM sublayer presents two standard IEEE 802.3 MAC service interfaces facing the superior and inferior MAC sublayers. It provides a dedicated interface for the OAM client to pass OAM control information and PDUs to and from the client. It includes these components:
 - The control block provides the interface between the OAM client and other OAM sublayer internal blocks.
 - The multiplexer manages frames from the MAC client, the control block, and the parser and passes OAM PDUs from the control block and loopback frames from the parser to the subordinate layer.
 - The parser classifies frames as OAM PDUs, MAC client frames, or loopback frames and sends them to the appropriate entity: OAM PDUs to the control block, MAC client frames to the superior sublayer, and loopback frames to the multiplexer.

OAM Features

These OAM features are defined by IEEE 802.3ah:

- Discovery identifies devices in the network and their OAM capabilities. It uses periodic OAM PDUs to advertise OAM mode, configuration, and capabilities; PDU configuration; and platform identity. An optional phase allows the local station to accept or reject the configuration of the peer OAM entity.
- Link monitoring detects and indicates link faults under a variety of conditions and uses the event notification OAM PDU to notify the remote OAM device when it detects problems on the link. Error events include when the number of symbol errors, the number of frame errors, the number of frame errors within a specified number of frames, or the number of error seconds within a specified period exceed a configured threshold.
- Remote failure indication conveys a slowly deteriorating quality of an OAM entity to its peers by communicating these conditions: Link Fault means a loss of signal, Dying Gasp means an unrecoverable condition, and Critical Event means an unspecified vendor-specific critical event. The switch can receive and process but not generate Link Fault or Critical Event OAM PDUs. It can generate Dying Gasp OAM PDUs to show when Ethernet OAM is disabled, the interface is shut down, the interface enters the error-disabled state, or the switch is reloading. It also supports Dying Gasp PDUs based on loss of power.
- Remote loopback mode to ensure link quality with a remote peer during installation or troubleshooting. In this mode, when the switch receives a frame that is not an OAM PDU or a pause frame, it sends it back on the same port. The link appears to the user to be in the up state. You can use the returned loopback acknowledgement to test delay, jitter, and throughput.

OAM Messages

Ethernet OAM messages or PDUs are standard length, untagged Ethernet frames between 64 and 1518 bytes. They do not go beyond a single hop and have a maximum transmission rate of 10 OAM PDUs per second. Message types are information, event notification, loopback control, or vendor-specific OAM PDUs.

Setting Up and Configuring Ethernet OAM

- [Default Ethernet OAM Configuration, page 43-27](#)

- [Ethernet OAM Configuration Guidelines, page 43-27](#)
- [Enabling Ethernet OAM on an Interface, page 43-27](#)
- [Enabling Ethernet OAM Remote Loopback, page 43-28](#)
- [Configuring Ethernet OAM Link Monitoring, page 43-29](#)
- [Configuring Ethernet OAM Remote Failure Indications, page 43-32](#)
- [Configuring Ethernet OAM Templates, page 43-32](#)

Default Ethernet OAM Configuration

Ethernet OAM is disabled on all interfaces.

When Ethernet OAM is enabled on an interface, link monitoring is automatically turned on.

Remote loopback is disabled.

No Ethernet OAM templates are configured.

Ethernet OAM Configuration Guidelines

- The switch does not support monitoring of egress frames sent with cyclic redundancy code (CRC) errors. The **ethernet oam link-monitor transmit crc** interface-configuration or template-configuration commands are visible but are not supported on the switch. The commands are accepted, but are not applied to an interface.
- For a remote failure indication, the switch does not generate Link Fault or Critical Event OAM PDUs. However, if these PDUs are received from a link partner, they are processed. The switch supports generating and receiving Dying Gasp OAM PDUs when Ethernet OAM is disabled, the interface is shut down, the interface enters the error-disabled state, or the switch is reloading. The switch can also generate and receive Dying Gasp PDUs based on loss of power. The PDU includes a reason code to indicate why it was sent.
- The switch does not support Ethernet OAM on ports that belong to an EtherChannel.

Enabling Ethernet OAM on an Interface

Beginning in privileged EXEC mode, follow these steps to enable Ethernet OAM on an interface:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	interface <i>interface-id</i>	Define an interface to configure as an OAM interface, and enter interface configuration mode.
Step 3	ethernet oam	Enable Ethernet OAM on the interface.

	Command	Purpose
Step 4	ethernet oam [max-rate <i>oampdus</i> min-rate <i>seconds</i> mode { active passive } timeout <i>seconds</i>]	<p>You can configure these optional OAM parameters:</p> <ul style="list-style-type: none"> (Optional) Enter max-rate <i>oampdus</i> to configure the maximum number of OAM PDUs sent per second. The range is from 1 to 10. (Optional) Enter min-rate <i>seconds</i> to configure the minimum transmission rate in seconds when one OAM PDU is sent per second. The range is from 1 to 10. (Optional) Enter mode active to set OAM client mode to active. (Optional) Enter mode passive to set OAM client mode to passive. <p>Note When Ethernet OAM mode is enabled on two interfaces passing traffic, at least one must be in the active mode.</p> <ul style="list-style-type: none"> (Optional) Enter timeout <i>seconds</i> to set a time for OAM client timeout. The range is from 2 to 30.
Step 5	end	Return to privileged EXEC mode.
Step 6	show ethernet oam status [interface <i>interface-id</i>]	Verify the configuration.
Step 7	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Enter the **no ethernet oam** interface configuration command to disable Ethernet OAM on the interface.

Enabling Ethernet OAM Remote Loopback

You must enable Ethernet OAM remote loopback on an interface for the local OAM client to initiate OAM remote loopback operations. Changing this setting causes the local OAM client to exchange configuration information with its remote peer. Remote loopback is disabled by default.

Remote loopback has these limitations:

- Internet Group Management Protocol (IGMP) packets are not looped back.
- You cannot configure Ethernet OAM remote loopback on ports that belong to an EtherChannel.

Beginning in privileged EXEC mode, follow these steps to enable Ethernet OAM remote loopback on an interface:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	interface <i>interface-id</i>	Define an interface to configure as an OAM interface, and enter interface configuration mode.

	Command	Purpose
Step 3	ethernet oam remote-loopback { supported timeout <i>seconds</i> }	Enable Ethernet remote loopback on the interface, or set a loopback timeout period. <ul style="list-style-type: none"> Enter supported to enable remote loopback. Enter timeout <i>seconds</i> to set a remote loopback timeout period. The range is from 1 to 10 seconds.
Step 4	end	Return to privileged EXEC mode.
Step 5	ethernet oam remote-loopback { start stop } { interface <i>interface-id</i> }	Turn on or turn off Ethernet OAM remote loopback on an interface.
Step 6	show ethernet oam status [interface <i>interface-id</i>]	Verify the configuration.
Step 7	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no ethernet oam remote-loopback** {**supported** | **timeout**} interface configuration command to disable remote loopback support or to remove the timeout setting.

Configuring Ethernet OAM Link Monitoring

You can configure high and low thresholds for link-monitoring features. If no high threshold is configured, the default is **none** —no high threshold is set. If you do not set a low threshold, it defaults to a value lower than the high threshold.

Beginning in privileged EXEC mode, follow these steps to configure Ethernet OAM link monitoring on an interface:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	interface <i>interface-id</i>	Define an interface, and enter interface configuration mode.
Step 3	ethernet oam link-monitor supported	Enable the interface to support link monitoring. This is the default. You need to enter this command only if it has been disabled by previously entering the no ethernet oam link-monitor supported command.

	Command	Purpose
Step 4	ethernet oam link-monitor symbol-period { threshold { high { high-symbols none } low { low-symbols } } window symbols } Note Repeat this step to configure both high and low thresholds.	(Optional) Configure high and low thresholds for an error-symbol period that trigger an error-symbol period link event. <ul style="list-style-type: none"> Enter threshold high high-symbols to set a high threshold in number of symbols. The range is 1 to 65535. The default is none. Enter threshold high none to disable the high threshold if it was set. This is the default. Enter threshold low low-symbols to set a low threshold in number of symbols. The range is 0 to 65535. It must be lower than the high threshold. Enter window symbols to set the window size (in number of symbols) of the polling period. The range is 1 to 65535 symbols.
Step 5	ethernet oam link-monitor frame { threshold { high { high-frames none } low { low-frames } } window milliseconds } Note Repeat this step to configure both high and low thresholds.	(Optional) Configure high and low thresholds for error frames that trigger an error-frame link event. <ul style="list-style-type: none"> Enter threshold high high-frames to set a high threshold in number of frames. The range is 1 to 65535. The default is none. Enter threshold high none to disable the high threshold if it was set. This is the default. Enter threshold low low-frames to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window milliseconds to set the a window and period of time during which error frames are counted. The range is 10 to 600 and represents the number of milliseconds in multiples of 100. The default is 100.
Step 6	ethernet oam link-monitor frame-period { threshold { high { high-frames none } low { low-frames } } window frames } Note Repeat this step to configure both high and low thresholds.	(Optional) Configure high and low thresholds for the error-frame period that triggers an error-frame-period link event. <ul style="list-style-type: none"> Enter threshold high high-frames to set a high threshold in number of frames. The range is 1 to 65535. The default is none. Enter threshold high none to disable the high threshold if it was set. This is the default. Enter threshold low low-frames to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window frames to set the a polling window size in number of frames. The range is 1 to 65535; each value is a multiple of 10000 frames. The default is 1000.

	Command	Purpose
Step 7	ethernet oam link-monitor frame-seconds {threshold {high {high-frames none} low {low-frames}} window milliseconds} Note Repeat this step to configure both high and low thresholds.	(Optional) Configure high and low thresholds for the frame-seconds error that triggers an error-frame-seconds link event. <ul style="list-style-type: none"> Enter threshold high high-frames to set a high error frame-seconds threshold in number of seconds. The range is 1 to 900. The default is none. Enter threshold high none to disable the high threshold if it was set. This is the default. Enter threshold low low-frames to set a low threshold in number of frames. The range is 1 to 900. The default is 1. Enter window frames to set the a polling window size in number of milliseconds. The range is 100 to 9000; each value is a multiple of 100 milliseconds. The default is 1000.
Step 8	ethernet oam link-monitor receive-crc {threshold {high {high-frames none} low {low-frames}} window milliseconds} Note Repeat this step to configure both high and low thresholds.	(Optional) Configure thresholds for monitoring ingress frames received with cyclic redundancy code (CRC) errors for a period of time. <ul style="list-style-type: none"> Enter threshold high high-frames to set a high threshold for the number of frames received with CRC errors. The range is 1 to 65535 frames. Enter threshold high none to disable the high threshold. Enter threshold low low-frames to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window milliseconds to set the a window and period of time during which frames with CRC errors are counted. The range is 10 to 1800 and represents the number of milliseconds in multiples of 100. The default is 100.
Step 9	[no] ethernet link-monitor on	(Optional) Start or stop (when the no keyword is entered) link-monitoring operations on the interface. Link monitoring operations start automatically when support is enabled.
Step 10	end	Return to privileged EXEC mode.
Step 11	show ethernet oam status [interface interface-id]	Verify the configuration.
Step 12	copy running-config startup-config	(Optional) Save your entries in the configuration file.

The **ethernet oam link-monitor transmit-crc {threshold {high {high-frames | none} | low {low-frames}} | window milliseconds}** command is visible on the switch and you are allowed to enter it, but it is not supported. Enter the **no** form of the commands to disable the configuration. Use the **no** form of each command to disable the threshold setting.

Configuring Ethernet OAM Remote Failure Indications

You can configure an error-disable action to occur on an interface if one of the high thresholds is exceeded, if the remote link goes down, if the remote device is rebooted, or if the remote device disables Ethernet OAM on the interface.

Beginning in privileged EXEC mode, follow these steps to enable Ethernet OAM remote-failure indication actions on an interface:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	interface <i>interface-id</i>	Define an interface, and enter interface configuration mode.
Step 3	ethernet oam remote-failure {critical-event dying-gasp link-fault} action error-disable-interface	Configure the Ethernet OAM remote-failure action on the interface. You can configure disabling the interface for one of these conditions: <ul style="list-style-type: none"> • Select critical-event to shut down the interface when an unspecified critical event has occurred. • Select dying-gasp to shut down the interface when Ethernet OAM is disabled or the interface enters the error-disabled state. • Select link-fault to shut down the interface when the receiver detects a loss of signal.
Step 4	end	Return to privileged EXEC mode.
Step 5	show ethernet oam status [interface <i>interface-id</i>]	Verify the configuration.
Step 6	copy running-config startup-config	(Optional) Save your entries in the configuration file.

The switch does not generate Link Fault or Critical Event OAM PDUs. However, if these PDUs are received from a link partner, they are processed. The switch supports sending and receiving Dying Gasp OAM PDUs with reason codes when Ethernet OAM is disabled, the interface is shut down, the interface enters the error-disabled state, or the switch is reloading. It can also respond to and generate, Dying Gasp PDUs based on loss of power. Enter the **no ethernet remote-failure {critical-event | dying-gasp | link-fault} action** command to disable the remote failure indication action.

Configuring Ethernet OAM Templates

You can create a template for configuring a common set of options on multiple Ethernet OAM interfaces. The template can be configured to monitor frame errors, frame-period errors, frame-second errors, received CRS errors, and symbol-period errors and thresholds. You can also set the template to put the interface in error-disabled state if any high thresholds are exceeded. These steps are optional and can be performed in any sequence or repeated to configure different options.

Beginning in privileged EXEC mode, follow these steps to configure an Ethernet OAM template and to associate it with an interface:

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	template <i>template-name</i>	Create a template, and enter template configuration mode.
Step 3	ethernet oam link-monitor receive-crc { threshold { high { <i>high-frames</i> none } low { <i>low-frames</i> } } window <i>milliseconds</i> }	<p>(Optional) Configure thresholds for monitoring ingress frames received with cyclic redundancy code (CRC) errors for a period of time.</p> <ul style="list-style-type: none"> Enter threshold high <i>high-frames</i> to set a high threshold for the number of frames received with CRC errors. The range is 1 to 65535 frames. Enter threshold high none to disable the high threshold. Enter threshold low <i>low-frames</i> to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window <i>milliseconds</i> to set the a window and period of time during which frames with CRC errors are counted. The range is 10 to 1800 and represents the number of milliseconds in multiples of 100. The default is 100.
Step 4	ethernet oam link-monitor symbol-period { threshold { high { <i>high symbols</i> none } low { <i>low-symbols</i> } } window <i>symbols</i> }	<p>(Optional) Configure high and low thresholds for an error-symbol period that triggers an error-symbol period link event.</p> <ul style="list-style-type: none"> Enter threshold high <i>high-symbols</i> to set a high threshold in number of symbols. The range is 1 to 65535. Enter threshold high none to disable the high threshold. Enter threshold low <i>low-symbols</i> to set a low threshold in number of symbols. The range is 0 to 65535. It must be lower than the high threshold. Enter window <i>symbols</i> to set the window size (in number of symbols) of the polling period. The range is 1 to 65535 symbols.

	Command	Purpose
Step 5	ethernet oam link-monitor frame { threshold { high { <i>high-frames</i> none } low { <i>low-frames</i> } } window <i>milliseconds</i> }	<p>(Optional) Configure high and low thresholds for error frames that trigger an error-frame link event.</p> <ul style="list-style-type: none"> Enter threshold high <i>high-frames</i> to set a high threshold in number of frames. The range is 1 to 65535. You must enter a high threshold. Enter threshold high none to disable the high threshold. Enter threshold low <i>low-frames</i> to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window <i>milliseconds</i> to set the a window and period of time during which error frames are counted. The range is 10 to 600 and represents the number of milliseconds in a multiple of 100. The default is 100.
Step 6	ethernet oam link-monitor frame-period { threshold { high { <i>high-frames</i> none } low { <i>low-frames</i> } } window <i>frames</i> }	<p>(Optional) Configure high and low thresholds for the error-frame period that triggers an error-frame-period link event.</p> <ul style="list-style-type: none"> Enter threshold high <i>high-frames</i> to set a high threshold in number of frames. The range is 1 to 65535. You must enter a high threshold. Enter threshold high none to disable the high threshold. Enter threshold low <i>low-frames</i> to set a low threshold in number of frames. The range is 0 to 65535. The default is 1. Enter window <i>frames</i> to set the a polling window size in number of frames. The range is 1 to 65535; each value is a multiple of 10000 frames. The default is 1000.
Step 7	ethernet oam link-monitor frame-seconds { threshold { high { <i>high-seconds</i> none } low { <i>low-seconds</i> } } window <i>milliseconds</i> }	<p>(Optional) Configure frame-seconds high and low thresholds for triggering an error-frame-seconds link event.</p> <ul style="list-style-type: none"> Enter threshold high <i>high-seconds</i> to set a high threshold in number of seconds. The range is 1 to 900. You must enter a high threshold. Enter threshold high none to disable the high threshold. Enter threshold low <i>low-frames</i> to set a low threshold in number of frames. The range is 1 to 900. The default is 1. Enter window <i>frames</i> to set the a polling window size in number of frames. The range is 100 to 9000; each value is a multiple of 100 milliseconds. The default is 1000.

	Command	Purpose
Step 8	ethernet oam link-monitor high threshold action error-disable-interface	(Optional) Configure the switch to put an interface in an error disabled state when a high threshold for an error is exceeded.
Step 9	exit	Return to global configuration mode.
Step 10	interface <i>interface-id</i>	Define an Ethernet OAM interface, and enter interface configuration mode.
Step 11	source-template <i>template-name</i>	Associate the template to apply the configured options to the interface.
Step 12	end	Return to privileged EXEC mode.
Step 13	show ethernet oam status [interface <i>interface-id</i>]	Verify the configuration.
Step 14	copy running-config startup-config	(Optional) Save your entries in the configuration file.

The switch does not support monitoring egress frames with CRC errors. The **ethernet oam link-monitor transmit-crc {threshold {high {high-frames | none} | low {low-frames}} | window milliseconds}** command is visible on the switch and you can enter it, but it is not supported. Use the **no** form of each command to remove the option from the template. Use the **no source-template** *template-name* to remove the source template association.

Displaying Ethernet OAM Protocol Information

You can use the privileged EXEC commands in [Table 43-4](#) to display Ethernet OAM protocol information.

Table 43-4 *Displaying Ethernet OAM Protocol Information*

Command	Purpose
show ethernet oam discovery [interface <i>interface-id</i>]	Displays discovery information for all Ethernet OAM interfaces or the specified interface.
show ethernet oam statistics [interface <i>interface-id</i>]	Displays detailed information about Ethernet OAM packets.
show ethernet oam status [interface <i>interface-id</i>]	Displays Ethernet OAM configuration for all interfaces or the specified interface.
show ethernet oam summary	Displays active Ethernet OAM sessions on the switch.

Understanding E-LMI

Ethernet Local Management Interface (E-LMI) is a protocol between the customer-edge (CE) device and the provider-edge (PE) device. It runs only on the PE-to-CE UNI link and notifies the CE device of connectivity status and configuration parameters of Ethernet services available on the CE port. E-LMI interoperates with an OAM protocol, such as CFM, that runs within the provider network to collect OAM status. CFM runs at the provider maintenance level (UPE to UPE with up MEPs at the UNI).

OAM manager, which streamlines interaction between any two OAM protocols, handles the interaction between CFM and E-LMI. This interaction is unidirectional, running only from OAM manager to E-LMI on the UPE side of the switch. Information is exchanged either as a result of a request from E-LMI or triggered by OAM when it received notification of a change from the OAM protocol. This type of information is relayed:

- Remote UNI name and status
- Remote UNI counts

The ME 3800X and ME 3600X switch can be only a customer-edge device.

Configuring E-LMI

Most E-LMI configuration occurs on the PE switch on the interfaces connected to the CE device. On the CE switch, you only need to enable E-LMI on the connecting interface.

The switch supports only E-LMI-CE configuration.

- [Default E-LMI Configuration, page 43-36](#)
- [E-LMI Configuration Guidelines, page 43-36](#)
- [Enabling E-LMI, page 43-37](#)
- [Enabling Ethernet OAM, page 43-39](#)
- [Ethernet OAM and CFM Configuration Example, page 43-39](#)

Default E-LMI Configuration

Ethernet LMI is globally disabled by default.

When you globally enable E-LMI by entering the **ethernet lmi global** global configuration command, it is automatically enabled on all interfaces. You can also enable or disable E-LMI per interface to override the global configuration. The E-LMI command that is given last is the command that has precedence.

There are no UNIs defined. UNI bundling service is bundling with multiplexing.

E-LMI Configuration Guidelines

The switch supports E-LMI only for the customer edge. The provider side of the connection must be running CFM and E-LMI.

- E-LMI is not supported on routed ports, EtherChannel port channels or ports that belong to an EtherChannel.
- You cannot configure E-LMI on VLAN interfaces.
- You must enter the **ethernet lmi ce** global configuration command to enable the switch or interface in customer-edge mode.

Enabling E-LMI

You can enable E-LMI globally or on an interface and configure the switch as a CE device. Beginning in privileged EXEC mode, follow these steps to enable for E-LMI on the switch or on an interface. Note that the order of the global and interface commands determines the configuration. The command that is entered last has precedence.

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	ethernet lmi global	Globally enable E-LMI on all interfaces.
Step 3	ethernet lmi ce	Configure the switch as an E-LMI CE device.
Step 4	interface <i>interface-id</i>	Define an interface to configure as an E-LMI interface, and enter interface configuration mode.
Step 5	ethernet lmi interface	Configure Ethernet LMI on the interface. If E-LMI is enabled globally, it is enabled on all interfaces unless you disable it on specific interfaces. If E-LMI is disabled globally, you can use this command to enable it on specified interfaces.
Step 6	ethernet lmi { <i>n391 value</i> <i>n393 value</i> <i>t391 value</i> <i>t392 value</i> }	<p>Configure E-LMI parameters for the UNI.</p> <p>The keywords have these meanings:</p> <ul style="list-style-type: none"> • <i>n391 value</i>—Set the event counter on the customer equipment. The counter polls the status of the UNIs. The range is from 1 to 65000; the default is 360. • <i>n393 value</i>—Set the event counter for the metro Ethernet network. The range is from 1 to 10; the default is 4. • <i>t391 value</i>—Set the polling timer on the customer equipment. A polling timer sends status enquiries and when status messages are not received, records errors. The range is from 5 to 30 seconds; the default is 10 seconds. • <i>t392 value</i>—Set the polling verification timer for the metro Ethernet network or the timer to verify received status inquiries. The range is from 5 to 30 seconds, or enter 0 to disable the timer. The default is 15 seconds. <p>Note The <i>t392</i> keyword is not supported when the switch is in CE mode.</p>
Step 7	end	Return to privileged EXEC mode.
Step 8	show ethernet lmi	Verify the configuration.
Step 9	copy running-config startup-config	(Optional) Save your entries in the configuration file.

Use the **no ethernet lmi** global configuration command to globally disable E-LMI. Use the **no** form of the **ethernet lmi** interface configuration command with keywords to disable E-LMI on the interface or to return the timers to the default settings.

Use the **show ethernet lmi** commands to display information that was sent to the CE from the status request poll. Use the **show ethernet service** commands to show current status on the device.

Customer-Edge Device Configuration

This example shows the commands necessary to configure E-LMI on the CE device. The switch can only be configured as the CE device. The example enables E-LMI globally, but you can also enable it only on a specific interface.

```
Switch# config t
Switch(config)# ethernet lmi global
Switch(config)# ethernet lmi ce
Switch(config)# exit
```



Note

For E-LMI to work, any VLANs used on the PE device must also be created on the CE device. Create a VLAN by entering the **vlan vlan-id** global configuration command on the CE device, where the *vlan-ids* match those on the PE device and configure these VLANs as allowed VLANs by entering the **switchport trunk allowed vlan vlan-ids** interface configuration command. Allowed VLANs can receive and send traffic on the interface in tagged format when in trunking mode.

Displaying E-LMI

You can use the privileged EXEC commands in [Table 43-5](#) to display E-LMI information.

Table 43-5 *Displaying E-LMI and OAM Manager Information*

Command	Purpose
show ethernet lmi statistics interface <i>interface-id</i>	Displays Ethernet LMI interface statistics sent to the CE from the status request poll.
show ethernet lmi uni map interface [<i>interface-id</i>]	Displays information about the E-LMI UNI VLAN map sent to the CE from the status request poll.

Ethernet CFM and Ethernet OAM Interaction

When the Ethernet OAM Protocol is running on an interface that has CFM MEPs configured, Ethernet OAM informs CFM of the state of the interface. Interaction is unidirectional from the Ethernet OAM to the CFM Protocol, and the only information exchanged is the user network interface port status.

The Ethernet OAM Protocol notifies CFM when these conditions occur:

- Error thresholds are crossed at the local interface.
CFM responds to the notification by sending a port status of *Local_Excessive_Errors* in the Port StatusType Length Value (TLV).
- Ethernet OAM receives an OAMPDU from the remote side showing that an error threshold is exceeded on the remote endpoint.
CFM responds to the notification by sending a port status of *Remote_Excessive_Errors* in the Port Status TLV.
- The local port is set into loopback mode.

CFM responds by sending a port status of Test in the Port Status TLV.

- The remote port is set into loopback mode.

CFM responds by sending a port status of Test in the Port Status TLV.

This section includes this information:

- [Enabling Ethernet OAM, page 43-39](#)
- [Ethernet OAM and CFM Configuration Example, page 43-39](#)

For more information about CFM and interaction with Ethernet OAM, see the Ethernet Connectivity Fault Management feature module.

Enabling Ethernet OAM

Beginning in privileged EXEC mode, follow these steps to enable Ethernet OAM on an interface.

	Command	Purpose
Step 1	configure terminal	Enter global configuration mode.
Step 2	interface <i>interface-id</i>	Define an interface to configure as an Ethernet OAM interface and enter interface configuration mode.
Step 3	ethernet oam [max-rate <i>oampdus</i> min-rate <i>seconds</i> mode { active passive } timeout <i>seconds</i>]	Enable Ethernet OAM on the interface <ul style="list-style-type: none"> • (Optional) Enter max-rate <i>oampdus</i> to set the maximum rate (per second) to send OAM PDUs. The range is 1 to 10 PDUs per second; the default is 10. • (Optional) Enter min-rate <i>seconds</i> to set the minimum rate in seconds. The range is 1 to 10 seconds. • (Optional) Set the OAM client mode as active or passive. The default is active. • (Optional) Enter timeout <i>seconds</i> to set the time after which a device declares the OAM peer to be nonoperational and resets its state machine. The range is 2 to 30 seconds; the default is 5 seconds.
Step 4	end	Return to privileged EXEC mode.
Step 5	copy running-config startup-config	(Optional) Save your entries in the configuration file.
Step 6	show ethernet cfm maintenance points remote	(Optional) Display the port states as reported by Ethernet OAM.

Ethernet OAM and CFM Configuration Example

These are example configurations of the interworking between Ethernet OAM and CFM in a sample service provider network with a provider-edge switch connected to a customer edge switch at each endpoint. You must configure CFM and Ethernet OAM between the customer edge and the provider edge switch.

Customer-edge switch 1 (CE1) configuration:

```
Switch# config t
Switch(config)# interface gigabitethernet0/1
```

```
Switch(config-if)# switchport trunk allowed vlan 10
Switch(config-if)# switchport mode trunk
Switch(config-if)# ethernet oam remote-loopback supported
Switch(config-if)# ethernet oam
Switch(config-if)# exit
```

Provider-edge switch 1 (PE1) configuration:

```
Switch# config t
Switch(config)# interface gigabitethernet0/5
Switch(config-if)# switchport trunk encapsulation dot1q
Switch(config-if)# switchport mode trunk
Switch(config-if)# ethernet cfm mip level 7
Switch(config-if)# ethernet cfm mep level 4 mpid 100 vlan 10
Switch(config-if)# ethernet uni id 2004-20
Switch(config-if)# ethernet oam remote-loopback supported
Switch(config-if)# ethernet oam
Switch(config-if-srv)# exit
```

Provider-edge switch 2 (PE2) configuration:

```
Switch# config t
Switch(config)# interface gigabitethernet1/20
Switch(config-if)# switchport mode trunk
Switch(config-if)# ethernet cfm mip level 7
Switch(config-if)# ethernet cfm mep level 4 mpid 101 vlan 10
Switch(config-if)# ethernet uni id 2004-20
Switch(config-if)# ethernet oam remote-loopback supported
Switch(config-if)# ethernet oam
Switch(config-if-srv)# exit
```

Customer-edge switch 2 (CE2) configuration:

```
Switch# config t
Switch(config)# interface gigabitethernet0/1
Switch(config-if)# switchport trunk allowed vlan 10
Switch(config-if)# switchport mode trunk
Switch(config-if)# ethernet oam remote-loopback supported
Switch(config-if)# ethernet oam
Switch(config-if)# exit
```

These are examples of the output showing provider-edge switch port status of the configuration. Port status shows as *UP* at both switches.

Switch PE1:

```
Switch# show ethernet cfm maintenance points remote
MPID  Level  Mac Address      Vlan  PortState  InGressPort  Age(sec)  Service  ID
101 * 4      0015.633f.6900  10    UP          Gi0/1       27       blue
```

Switch PE2:

```
Switch# show ethernet cfm maintenance points remote
MPID  Level  Mac Address      Vlan  PortState  InGressPort  Age(sec)  Service  ID
100 * 4      0012.00a3.3780  10    UP          Gi0/1       8        blue
Total Remote MEPs: 1
```

This example shows the outputs when you start remote loopback on CE1 (or PE1). The port state on the remote PE switch shows as *Test* and the remote CE switch goes into error-disable mode.

```
Switch# ethernet oam remote-loopback start interface gigabitEthernet 0/1
This is a intrusive loopback.
Therefore, while you test Ethernet OAM MAC connectivity,
you will be unable to pass traffic across that link.
Proceed with Remote Loopback? [confirm]
```

Switch PE1:

```
Switch# show ethernet cfm maintenance points remote
MPID  Level Mac Address      Vlan PortState IngressPort    Age(sec) Service ID
101 * 4      0015.633f.6900 10   UP          Gi0/1          27      blue
```

Switch PE2:

```
Switch# show ethernet cfm maintenance points remote
MPID  Level Mac Address      Vlan PortState IngressPort    Age(sec) Service ID
100 * 4      0012.00a3.3780 10   TEST        Gi1/1/1        8       blue
Total Remote MEPs: 1
```

In addition, if you shut down the CE1 interface that connects to PE1, the remote PE2 port will show a PortState of *Down*.

