# Preface

This preface describes the audience, organization, and conventions of the *Cisco Nexus 7000 Series NX-OS Security Command Reference*. It also provides information on how to obtain related documentation.

This chapter includes the following sections:

- Audience, page xvii
- Organization, page xvii
- Document Conventions, page xvii
- Related Documentation, page xviii
- Documentation Feedback, page xx
- Obtaining Documentation and Submitting a Service Request, page xx

## Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

## Organization

This reference is organized as follows:

| Chapter Title | Description |
|---|---|
| New and Changed Information | Describes the new and changed information for the new Cisco NX-OS software releases. |

## Document Conventions

Command descriptions use these conventions:

| Convention | Description |
|---|---|
| boldface font | Commands and keywords are in boldface. |

| italic font | Arguments for which you supply values are in italics. |
| [  ] | Elements in square brackets are optional. |
| [ x | y | z ] | Optional alternative keywords are grouped in brackets and separated by vertical bars. |
| string | A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks. |

Screen examples use these conventions:

| screen font | Terminal sessions and information that the switch displays are in screen font. |
| **boldface screen font** | Information you must enter is in boldface screen font. |
| *italic screen font* | Arguments for which you supply values are in italic screen font. |
| < > | Nonprinting characters, such as passwords, are in angle brackets. |
| [  ] | Default responses to system prompts are in square brackets. |
| !, # | An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line. |

This document uses the following conventions:

**Note** Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.

**Caution** Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

**Tip** Means *the following information will help you solve a problem.*

# Related Documentation

Cisco NX-OS includes the following documents:

**Release Notes**

*Cisco Nexus 7000 Series NX-OS Release Notes, Release 6.x*

**NX-OS Configuration Guides**

*Cisco Nexus 2000 Series Fabric Extender  Software Configuration Guide*
*Cisco Nexus 7000 Series NX-OS Configuration Examples*
*Cisco Nexus 7000 Series NX-OS FabricPath Configuration Guide*

*Configuring Feature Set for FabricPath*

*Cisco Nexus 7000 Series NX-OS Fundamentals Configuration Guide*

*Cisco Nexus 7000 Series NX-OS High Availability and Redundancy Guide*

*Cisco Nexus 7000 Series NX-OS Interfaces Configuration Guide*

Cisco Nexus 7000 Series NX-OS IP SLAs Configuration Guide

*Cisco Nexus 7000 Series NX-OS Layer 2 Switching Configuration Guide*

*Cisco Nexus 7000 Series NX-OS LISP Configuration Guide*

*Cisco Nexus 7000 Series NX-OS MPLS Configuration Guide*

*Cisco Nexus 7000 Series NX-OS Multicast Routing Configuration Guide*

*Cisco Nexus 7000 Series NX-OS OTV Configuration Guide*

*Cisco Nexus 7000 Series OTV Quick Start Guide*

*Cisco Nexus 7000 Series NX-OS Quality of Service Configuration Guide*

*Cisco Nexus 7000 Series NX-OS SAN Switching Configuration Guide*

*Cisco Nexus 7000 Series NX-OS Security Configuration Guide*

*Cisco Nexus 7000 Series NX-OS System Management Configuration Guide*

*Cisco Nexus 7000 Series NX-OS Unicast Routing Configuration Guide*

Cisco Nexus 7000 Series NX-OS Verified Scalability Guide

*Cisco Nexus 7000 Series NX-OS Virtual Device Context Configuration Guide*

*Cisco Nexus 7000 Series NX-OS Virtual Device Context Quick Start*

*Cisco NX-OS FCoE Configuration Guide for Cisco Nexus 7000 and Cisco MDS 9500*

**NX-OS Command References**

*Cisco Nexus 7000 Series NX-OS Command Reference Master Index*

*Cisco Nexus 7000 Series NX-OS FabricPath Command Reference*

*Cisco Nexus 7000 Series NX-OS Fundamentals Command Reference*

*Cisco Nexus 7000 Series NX-OS High Availability Command Reference*

*Cisco Nexus 7000 Series NX-OS Interfaces Command Reference*

Cisco Nexus 7000 Series NX-OS IP SLAs Command Reference

*Cisco Nexus 7000 Series NX-OS Layer 2 Switching Command Reference*

*Cisco Nexus 7000 Series NX-OS LISP Command Reference*

*Cisco Nexus 7000 Series NX-OS MPLS Command Reference*

*Cisco Nexus 7000 Series NX-OS Multicast Routing Command Reference*

*Cisco Nexus 7000 Series NX-OS OTV Command Reference*

*Cisco Nexus 7000 Series NX-OS Quality of Service Command Reference*

*Cisco Nexus 7000 Series NX-OS SAN Switching Command Reference*

*Cisco Nexus 7000 Series NX-OS Security Command Reference*

*Cisco Nexus 7000 Series NX-OS System Management Command Reference*

*Cisco Nexus 7000 Series NX-OS Unicast Routing Command Reference*

*Cisco Nexus 7000 Series NX-OS Virtual Device Context Command Reference*

*Cisco NX-OS FCoE Command Reference for Cisco Nexus 7000 and Cisco MDS 9500*

## Other Software Documents

*Cisco NX-OS Licensing Guide*

*Cisco Nexus 7000 Series NX-OS MIB Quick Reference*

*Cisco Nexus 7000 Series NX-OS Software Upgrade and Downgrade Guide*

*Cisco NX-OS System Messages Reference*

*Cisco NX-OS XML Interface User Guide*

# Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to nexus7k-docfeedback@cisco.com. We appreciate your feedback.

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation*.

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the What's New in Cisco Product Documentation RSS feed. The RSS feeds are a free service.