



## はじめに

### 目的

このマニュアルでは、Smart Install 用に作成されたコマンドの使用手順を説明します。他の標準の Cisco IOS Release 12.2 のコマンドまたは Cisco IOS Release 15.0 については、Cisco.com ホームページの [Products & Services] > [Cisco IOS/NX-OS Software] > [Cisco IOS] の Cisco IOS マニュアル集を参照してください。

表示されるシステム メッセージやデバイスのインストール方法などの説明は行いません。詳細については、デバイスのシステム メッセージ ガイドおよびハードウェア インストール ガイドを参照してください。

マニュアルのアップデートやその他の最新情報の詳細については、このリリースの特定のデバイスに関するリリース ノートを参照してください。

### 表記法

このマニュアルでは、次の表記法を使用して説明および情報を表示しています。

コマンドの説明では、次の表記法を使用しています。

- コマンドおよびキーワードは、**太字**で示しています。
- ユーザが値を指定する引数は、*イタリック体*で示しています。
- 角カッコ ([ ]) の中の要素は、省略可能です。
- 必ずいずれか 1 つを選択しなければならない要素は、波カッコ ({ }) で囲み、縦棒 (|) で区切って示しています。
- 任意で選択する要素の中で、必ずどれか 1 つを選択しなければならない要素は、角カッコと波カッコで囲み、縦棒で区切って ([{|}]) 示しています。

対話形式の例では、次の表記法を使用しています。

- 端末セッションおよびシステムの表示は、screen フォントで示しています。
- ユーザが入力する情報は、**太字の screen** フォントで示しています。
- パスワードやタブのように、出力されない文字は、山カッコ (<>) で囲んで示しています。

注釈および注意は、次の表記法を使用しています。



(注) 「注釈」です。役立つ情報や、このマニュアル以外の参照資料などを紹介しています。

**注意**

「**要注意**」の意味です。機器の損傷またはデータ損失を予防するための注意事項が記述されています。

## 関連資料

- Catalyst 6500 Supervisor Engine 2T-10GE  
[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)
- Catalyst 4500  
[http://www.cisco.com/en/US/products/hw/switches/ps4324/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps4324/tsd_products_support_series_home.html)
- Catalyst 3850  
[http://www.cisco.com/en/US/products/ps12686/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps12686/tsd_products_support_series_home.html)
- Catalyst 3750-X  
[http://www.cisco.com/en/US/products/ps10745/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps10745/tsd_products_support_series_home.html)
- Catalyst 3560-X  
[http://www.cisco.com/en/US/products/ps10744/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps10744/tsd_products_support_series_home.html)
- Catalyst 3750-E  
[http://www.cisco.com/en/US/products/ps7077/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps7077/tsd_products_support_series_home.html)
- Catalyst 3560-E  
[http://www.cisco.com/en/US/products/ps7078/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps7078/tsd_products_support_series_home.html)
- Catalyst 3750  
[http://www.cisco.com/en/US/products/hw/switches/ps5023/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps5023/tsd_products_support_series_home.html)
- Catalyst 3560  
[http://www.cisco.com/en/US/products/hw/switches/ps5528/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps5528/tsd_products_support_series_home.html)
- Catalyst 2975  
[http://www.cisco.com/en/US/products/ps10081/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps10081/tsd_products_support_series_home.html)
- Catalyst 2960 および Catalyst 2960-S  
[http://www.cisco.com/en/US/products/ps6406/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps6406/tsd_products_support_series_home.html)
- EtherSwitch ネットワーク モジュール  
[https://www.cisco.com/en/US/docs/ios/lanswitch/configuration/guide/lsw\\_enet\\_switch\\_net\\_external\\_docbase\\_0900e4b18090920b\\_4container\\_external\\_docbase\\_0900e4b18096f791.html](https://www.cisco.com/en/US/docs/ios/lanswitch/configuration/guide/lsw_enet_switch_net_external_docbase_0900e4b18090920b_4container_external_docbase_0900e4b18096f791.html)

## マニュアルの入手方法およびテクニカル サポート

マニュアルの入手方法、テクニカル サポート、その他の有用な情報について、次の URL で、毎月更新される『*What's New in Cisco Product Documentation*』を参照してください。シスコの新規および改訂版の技術マニュアルの一覧も示されています。

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

『*What's New in Cisco Product Documentation*』は RSS フィードとして購読できます。また、リーダーアプリケーションを使用してコンテンツがデスクトップに直接配信されるように設定することもできます。RSS フィードは無料のサービスです。シスコは現在、RSS バージョン 2.0 をサポートしています。

