



A

adding
 devices [3-7](#)
 users [3-7](#)
administrative privileges [2-4](#)
admin password
 adding during installation [2-9](#)
 changing [4-5](#)
admin user
 adding info to profile [3-6](#)
Adobe Reader
 requirement [2-2](#)
 version [2-2](#)
alert view [1-5](#)
authentication methods [3-4](#)

B

backing up [4-2](#)
before you begin [3-1](#)

C

cautions
 significance of [viii](#)
certificate file
 setting installation default [2-13](#)
Cisco.com [A-2](#)
 registering [3-1](#)
Cisco IOS dependencies, see your device
 documentation [2-3](#)
client software

 requirements [2-3](#)
clm_backup.bat [4-2](#)
clm_export.bat [4-4](#)
clm_import.bat [4-3](#)
clm_installer.bat [2-5](#)
clm_restore.bat [4-3](#)
clm_updatedb.bat [4-6](#)
CLMServer.exe [4-5](#)
command line
 installing [2-12](#)
configure
 admin user profile [3-1](#)
conventions [vii](#)

D

deploying licenses [3-14](#)
device
 configuration for CLM [2-3, 3-1](#)
 discovery [3-7](#)
 pane [1-4](#)
device authentication [4-6](#)
device inventory, changing authentication data [4-6](#)
device notification [3-1](#)
device protocol
 reconfiguring [4-5](#)
discovering devices [3-7](#)
DNS requirement [3-1](#)
documentation
 conventions [vii](#)

E

editing

- user/password pairs [4-6](#)

- edit password list [3-9](#)

- email server [A-1](#)

email service

- installation default [2-13](#)

- reconfiguring [4-5](#)

- server installation question about [2-9](#)

exporting

- device and license data [4-4](#)

- examples of [4-4](#)

F

- features [1-1](#)

flowchart

- getting started [3-3](#)

- quick start [3-2](#)

- frequently asked questions [A-1](#)

G

- getting started flowchart [3-3](#)

- graphical user interface (GUI) [1-2](#)

I

- icon descriptions [1-3](#)

- icons, location [2-7](#)

importing

- devices and license objects [4-3](#)

- examples of [4-4](#)

- install.properties file [2-12](#)

installation

- command line [2-12](#)

- considerations [2-1](#)

- customized install file [2-12](#)

- default directory [2-7](#)

- no firewalls [2-1](#)

- options [2-1](#)

- quick [2-4](#)

- required preparations [2-4](#)

- step-by-step [2-5](#)

- verifying [2-14](#)

- ip http authentication [3-4](#)

J

- java library files [2-4](#)

- JAVA requirements [2-4](#)

L

- license agent notify [3-4](#)

licenses

- deploying [3-14](#)

- obtaining [3-12](#)

- location of product icons [2-7](#)

- logging in [3-4](#)

M

- menu bar [1-3](#)

N

- network and port requirements [2-3](#)

- new users, adding [3-7](#)

O

- obtaining licenses [3-12](#)

P

package options [2-1](#)

PAKs

- adding to existing folders [3-10](#)
- explorer pane [1-4](#)
- retrieving information [3-11](#)

password

- changing [4-5](#)

poll licenses [3-9, 3-10](#)

port

- installation default [2-12](#)
- reconfiguring [4-5](#)
- requirements [2-3](#)

ports

- default [2-8](#)

preparations [3-1](#)

properties pane [1-5](#)

Q

quick start flowchart [3-2](#)

R

register on Cisco.com [3-1](#)

reinstalling [2-16](#)

requirements

- Cisco IOS (see your device documentation) [2-3](#)
- client [2-3](#)
- JAVA [2-4](#)
- network and port [2-3](#)
- server [2-2](#)
- software [2-2](#)

restoring [4-2](#)

rmiregistry.exe [4-5](#)

runsetup.bat [4-5](#)

S

security agent, disabling [A-3](#)

selecting

- objects in PAK and Device panes [1-5](#)

server

- stopping [4-5](#)

server software

- installation defaults [2-12](#)

setup program, running [4-5](#)

SMTP e-mail server [2-9](#)

SMTP server [A-1](#)

software requirements

- client [2-3](#)
- server [2-2](#)

SSL devices

- setting in installation [2-12](#)

status

- and log view pane [1-5](#)

stopping the server [4-5](#)

system requirements [2-2](#)

T

toolbar [1-3](#)

troubleshooting tips [A-2](#)

U

uninstalling [2-14](#)

user/password pairs list [3-9](#)

user profiles, managing [3-5](#)

users, adding [3-7](#)

V

verifying installation [2-14](#)

W

Windows Registry keys [A-1](#)

Windows XP, version [2-2](#)