



INDEX WEBSITE

A

Archival Jobs

See Configuration Change Management

Archival Settings

See Configuration Change Management

Auto-Synchronization with Devices

deleting events data [15-6](#)

description [15-1](#)

poller interval [4-14](#), [15-4](#)

purging data automatically [15-6](#)

purging data now [15-8](#)

starting and stopping a poller [15-4](#)

synchronizing with a device [15-5](#)

C

chassis

environmental status [11-3](#)

events [11-5](#)

hardware details [11-3](#)

memory utilization [11-4](#)

software details [11-3](#)

Cisco NX-OS

configuration requirements [1-5](#)

logging requirements [1-6](#)

preparing for management [1-5](#)

Configuration Change Management

archival history [14-5](#)

Archival Jobs [14-14](#)

Archival Settings [14-18](#)

archival status [14-5](#)

archiving a running configuration [14-6](#)

browsing versions [14-6](#)

commenting on a version [14-6](#)

comparing versions [14-8](#)

comparison tools [14-9](#)

configuring an archival job [14-14](#)

deleting an archival job [14-16](#)

deleting archived configurations [14-13](#)

description [14-1](#)

diff tools [14-9](#)

enabling or disabling an archival job [14-16](#)

history settings [14-18](#)

merging differences [14-11](#)

performing a rollback [14-12](#)

rollback server settings [14-19](#)

Version Browser [14-4](#)

version settings [14-18](#)

viewing an archival job [14-17](#)

viewing archival job history [14-17](#)

viewing a version [14-7](#)

viewing rollback history [14-13](#)

D

database

backing up [18-3](#)

cleaning [18-5](#)

guidelines [18-3](#)

maintenance [18-1](#)

restoring [18-6](#)

DCNM

deploying [1-4](#)

description [1-1](#)

DCNM client

Send document comments to nexus7k-docfeedback@cisco.com

downloading [3-2](#)

installation prerequisites [3-1](#)

Java [3-1](#)

licensed features [3-1](#)

operating systems [3-1](#)

password, default [3-2](#)

reinstalling the client [3-4](#)

uninstalling the client [3-4](#)

DCNM Enterprise LAN License

adding a device to a license [8-3](#)

installing [2-7](#)

removing a device from a license [8-4](#)

DCNM license

See DCNM Enterprise LAN License

DCNM server

adding a device to a license [8-3](#)

downloading [2-2](#)

installing [2-3](#)

installing a license [2-7](#)

reinstalling [2-10](#)

removing a device from a license [8-4](#)

starting [2-6, 2-7](#)

stopping [2-14](#)

deployment

how to [1-4](#)

Device Discovery

description [6-1](#)

discovering a device [6-4](#)

rediscovering a device [6-6](#)

Device OS Management

adding or changing comments [13-11](#)

changing file server [13-14](#)

changing installation options [13-12](#)

configuring a file server [13-13](#)

creating a software installation job [13-7](#)

creating or editing a software installation job [13-8](#)

deleting a file server [13-15](#)

deleting a software installation job [13-11](#)

deleting startup configuration [13-12](#)

description [13-1](#)

editing a software installation job [13-7](#)

File Servers [13-13](#)

installing software [13-5](#)

overview [13-1](#)

rescheduling a software installation job [13-10](#)

saving running configuration [13-12](#)

Software Image Management [13-4, 13-6](#)

viewing device image details [13-5](#)

viewing software installation job details [13-7](#)

viewing status [13-7](#)

Devices and Credentials

adding a device [7-4](#)

configuring default credentials [7-6](#)

deleting a device [7-6](#)

description [7-1](#)

discovering a device [7-5](#)

unmanaging a device [7-5](#)

documentation

additional publications [iv-xxi](#)

E

Events Browser

adding a note [10-7](#)

changing event status [10-7](#)

configuring maximum event age [4-15](#)

deleting an event [10-8](#)

description [10-1](#)

filtering events [10-5](#)

viewing events [10-3](#)

Events tab

adding a note [10-7](#)

changing event status [10-7](#)

configuring maximum event age [4-15](#)

deleting an event [10-8](#)

description [10-1](#)

viewing events [10-5](#)

Send document comments to nexus7k-docfeedback@cisco.com

F

fabric module

- details [11-6](#)
- environmental status [11-7](#)
- events [11-8](#)

fan tray

- details [11-10](#)
- events [11-11](#)

File Servers

See Device OS Management

G

Global preferences

- events preference [4-15](#)
- monitoring preference [4-14](#)
- overview [4-14](#)
- preprovisioning preference [4-15](#)

H

high availability

- SPAN [12-4](#)

I

I/O module

- details [11-6](#)
- environmental status [11-7](#)
- events [11-8](#)

installation

- prerequisites [3-1](#)
- requirements [2-1](#)

inventory information

- chassis
 - detail [11-3](#)
 - environmental status [11-3](#)

- events [11-5](#)
- memory utilization [11-4](#)
- summary [11-2](#)

fan tray

- details [11-10](#)
- events [11-11](#)
- summary [11-10](#)

module

- details [11-6](#)
- environmental status [11-7](#)
- events [11-8](#)
- summary [11-6](#)

power supply

- details [11-9](#)
- events [11-9](#)
- summary [11-8](#)

L

license

See DCNM Enterprise LAN License

licensing requirements

- SPAN [12-4](#)

M

module

- details [11-6](#)
- environmental status [11-7](#)
- events [11-8](#)

monitoring

- stopping and starting [4-10, 4-11](#)

N

NX-OS

See Cisco NX-OS

Send document comments to nexus7k-docfeedback@cisco.com

P

power supply

- details [11-9](#)
- events [11-9](#)
- redundancy [11-3](#)
- usage [11-3, 11-7](#)

R

- related documents [iv-xxi](#)

S

Server Log Settings

- configuring the default logging level [17-3](#)
- description [17-1](#)

Software Image Management

- See Device OS Management

software installation job

- See Device OS Management

SPAN

- configuring an RSPAN VLAN [12-9](#)
- configuring a session [12-6](#)
- configuring a virtual SPAN session [12-7](#)
- description [12-1](#)
- destination field descriptions (table) [12-10](#)
- enabling a session [12-9](#)
- guidelines [12-5](#)
- high availability [12-4](#)
- licensing requirements [12-4](#)
- limitations [12-5](#)
- multiple sessions [12-4](#)
- prerequisites [12-4](#)
- session destinations [12-6](#)
- session field descriptions (table) [12-10](#)
- sessions [12-2](#)
- session sources [12-6](#)
- shutting down a session [12-9](#)

- source field descriptions (table) [12-10](#)

- virtualization support [12-4](#)

- virtual SPAN sessions [12-3](#)

Statistical Data Collection

- deleting a collection [16-5](#)
- deleting data from a collection [16-4](#)
- deleting data from the statistics database [16-5](#)
- description [16-1](#)
- purging data automatically [16-6](#)
- purging data now [16-8](#)
- Statistics tab [4-10, 4-11](#)
- stopping and starting data collection [16-4](#)

Statistics tab

- stopping and starting monitoring [4-10, 4-11](#)

supervisor module

- details [11-6](#)
- environmental status [11-7](#)
- events [11-8](#)
- redundancy information [11-3](#)

switched port analyzer. See SPAN

T

Topology

- accessing other features [9-13](#)
- description [9-1](#)
- exporting as JPG image [9-16](#)
- layouts [9-5](#)
- legend [9-8](#)
- loading layouts [9-15, 9-16](#)
- managing a vPC [9-12](#)
- moving devices [9-14](#)
- opening the map [9-7](#)
- understanding icons and links [9-8](#)
- using viewing tools [9-9](#)
- views [9-2](#)
- vPC configuration inconsistency [9-13](#)

Send document comments to nexus7k-docfeedback@cisco.com

U

users

- adding a user [5-3](#)
- changing passwords [5-4](#)
- deleting [5-6](#)
- description [5-1](#)
- roles [5-1](#)

V

Version Browser

- See Configuration Change Management

Send document comments t o nexus7k-docfeedback@cisco.com