# تاعامتجالا مداخ ىلع LDAP يمدختسم نيوكت نم Cisco ربع API

# تايوتحملا

قمدق ملا قيس اس أل ا تابلطت ملا تابلطت ملا قمدختس مل ا تانوك ملا قيس اس أ تامول عم نيوكتل ا محال ص إو عاط خأل ا فاش كتس ا

#### ةمدقملا

نيوكت دنتسملا اذه فصي LDAP (نزولا فيفخ ليلدلا يل لوصول لوكوتورب) الدولات دنتسملا اذه فصي مداخ يلع (نزول في في ا نم تاعامتجالا قجمرب قوجاو) API (تاقيبطتلا قجمرب قوجاو).

ةيساسألا تابلطتملا

PostMan قىبطت

Cisco نم (CMS) تاعامتجالا مداخ

Microsoft Active Directory

# تابلطتملا

دنتسملا اذهل قصاخ تابلطتم دجوت ال.

# ةمدختسملا تانوكملا

Cisco نم تاعامتجالا مداخ

Microsoft Active Directory

## ةيساسأ تامولعم

.تاقيبطتلا ةجمرب ةهجاو ربع LDAP ةنمازمل يوتسملا يلاع نيوكت قفدت

حضوم وه امك (API) تاقيبطتال ةجمرب ةهجاو اللخ نم IdapServers/ قملعمال نيوكت .1 ةوطخالا هاندأ

- LDAP مداخ ناونع/ذفنم تامولعم .1
- مداخلا يل إلوصول رورملا مملكو مدختسملا مسا .2
- .نمالا ريغ LDAP لوكوتورب .3

وه امك (API) تاقيبطتالا ةجمرب ةهجاو اللخ نم IdapMappings/ قملعملا نيوكتب مق 2: ةوطخلا هاندأ حضوم


- ةقباطم مدختسم تانئاك ىلإ LDAP مدختسم صئاصخ تانئاك 1.
- 2. كل اثم يا CMS كل نيعيس jid كل انيعيس \$sAMAccountName\$@domain.com كل د كل د المو cms كل د كل النام .ك

حضوم وه امك (API) تاقيبطتالا قجمرب قهجاو ربع IdapSources/ تاملعم نيوكتب مق :3 قوطخالا نئاكو IdapMappings.

#### نيوكتلا

### ldapServers/ نيوكت .1 ةوطخلا


1. فرعم مدختسأ .ldapServers فرعم ءاشنإب موقيس يذلا ، ldapServers/ ل روشنم لاسرا نم ديزمل ديرفلا /ldapServers نيوكتلا




- 2. كل قباجتسالا عاجرا متيس <ldapServer id="7ca32cc4-389f-46f5a1b0-0a468af291a4">
- <u>CMS API عجرم ليلد</u> لكل LDAP مداخ فرعم ثيدحتل تامولعم هاندأ طاقتلاالا .3

Parameters	Type/Value	Description/Notes	
address *	String	The address of the LDAP server to connect to.	
portNumber *	Number	The TCP or TLS port number to connect to on the remote LDAP server.	
username	String	The username to use when retrieving information from the LDAP server.	
password	String	The password of the account associated with username.	
secure *	true false	Whether to make a secure connection to the LDAP server. If "true" then TLS will be used; if "false", TCP will be used.	

تاملعملا عم POST بولسأ جذومن .4



مت يتلاا تاملعملاا نم ققحتلل GET ءارجا اهنىوكت



ldapMappings/ نيوكت ،2 ةوطخلا


ال روشنم لاسراً .ldapMappings/ مدختسأ .ldapMappings/ فرعم ءاشنإل /ldapMappings/ لـ روشنم لاسراً .1 المراء التي ماندأ تاملعملا نيوكتب مقو.




<u>CMS API عجرم ليلد</u> لكل LDAP نييعت فرعم ثيدحتل تامولعم هاندأ طاقتلالا .2

Parameters	Type/Value	Description/Notes
jidMapping	String	The template for generating user JIDs from the associated LDAP server's entries, for instance \$sAMAccountName\$@example.com.
nameMapping	String	The template for generating user names from the associated LDAP server's entries; for instance "\$cn\$" to use the common name.
cdrTagMapping	String	The template for generating a users' cdrTag value. Can be set either to a fixed value or be constructed from other LDAP fields for that user. The user's cdrTag is used in callLegStart CDRs. See the Cisco Meeting Server CDR Reference for details.
authenticationIdMapping	String	The template for generating authentication IDs from the associated LDAP server"s entries, for instance "\$userPrincipalName\$".
coSpaceUriMapping	String	If these parameters are supplied, they ensure that each user account generated by this LDAP mapping has an associated personal coSpace. The user is automatically added as a member of the coSpace, with permissions defined above
coSpaceSecondaryUriMapping	String	In order for that coSpace to be set up as required, these parameters provide the template for setting the coSpaces' URI, displayed name and configured Call ID. For example, setting coSpaceNameMapping to "\$cn\$ personal coSpace" ensures that each user's coSpace is labelled with their name followed by "personal coSpace".
coSpaceNameMapping	String	Note that the generated coSpace will have its own cdrTag - and it will be the same as the user's cdrTag and cannot be changed other than by changing the cdrTagMapping above and resyncing. (The coSpace's cdrTag is used in the callStart CDR. See the Cisco Meeting Server CDR Reference for details.)
coSpaceCallIdMapping	String	Note that the normal uniqueness rules apply to the URI and Call IDs of coSpaces set up in this way: it is not valid to have the same URI or Call ID for more than one coSpace set up by a given LDAP mapping, nor is it valid for such a coSpace URI or Call ID to be the same as one currently in use elsewhere on the Meeting Server.

ل ەاندأ تاملعملا نيوكت .3 IdapMappings



مت يتلا تاملعملا نم ققحتلل GET ءارجإ .4 اەنيوكت.



ldapsources/ نيوكت .3 ةوطخلا

مقو Idapsources ID/ مدختسأ ldapsources/ فرعم ءاشنإل Idapsources/ لروشنم لاسرا تاملعملا نيوكتب ماندأ.



2. اندأ طاقت الله LDAP ع<u>جرم ليل</u>د لكل LDAP نييعت فرعم ثيدحتل تامولعم هاندأ طاقت الله <u>API</u>

Parameters	Type/Value	Description/Notes	
server*	ID	The ID of a previously-configured LDAP server (see above)	
mapping *	ID	The ID of a previously-configured LDAP mapping (see above)	
baseDn *	String	The distinguished name of the node in the LDAP server's tree from which users should be imported, for instance "cn=Use-ers,dc= <companyname>,dc=com"</companyname>	
filter	String	An LDAP filter string that records must satisfy in order to be imported as users, for instance "(objectClass=person)"	
tenant	ID	If supplied, the ID for the tenant to which the LDAP source should be asso- ciated. Users imported with this LDAP source will be associated with that tenant	
userProfile	ID	If supplied, this is the ID of the user profile to associate with users imported via this LDAP source. This parameter is present from version 2.0 onwards.	
nonMemberAccess	true  false	This parameter pre-configures newly created spaces to allow or disallow non-member access. Spaces existing before the LDAP sync are not affected.	
		true - no passcode is required to access the space and non-members are able to access the created spaces. This is the default setting and matches behavior before this parameter was introduced in version 2.0.	
		false - ensures the member must configure non-member access and set a passcode as part of the LDAP sync. This setting allows a company to enforce passcode protection for non-member access to all user spaces.	
		For more information, see Section 1.2.	


3. ل ەاندأ تاملعملا نيوكت IdapSources



نآلا ةلماك ةنمازم ءارجإ اننكمي .نيوكتلا لمتكا.

ةحصلا نم ققحتلا

ثادحألا تالجس نم قوّحتلاو API نم POST ل POST لاسرا .1 ةوطخلا



## لامتكا ةلاح يف ثادحألا تالجس صحفب مق .2 ةوطخلا قنمازملا.

10:50:41.225	Info	10.65.86.71: API user "admin" created new LDAP sync operation c02dbb2b-c63e-4bb8-a39f-bbee2cd9611f
10:50:41.225	Info	LDAP sync operation starting
10:50:41.269	Info	LDAP sync operation: finalising
10:50:41.650	Info	LDAP sync operation c02dbb2b-c63e-4bb8-a39f-bbee2cd9611f complete
10:50:55.705	Info	10.65.86.71: web user "admin" logged in
10:50:55.705	Info	web session 1 now in use for user "admin"
10:53:04.331	Info	1103 log messages cleared by "admin"
10:53:07.569	Info	10.65.86.71: web user "admin" created new LDAP sync operation 50c7034c-9aa7-4e81-a304-4113734ffc11
10:53:07.570	Info	LDAP sync operation starting
10:53:07.594	Info	LDAP sync operation: finalising
10:53:07.943	Info	LDAP sync operation complete

الردصم نم نيمدختسملاً ةنمازم نم قوحت .3 ةوطخلا ldap.

#### Users



اهحالصإو ءاطخألا فاشكتسا

.LDAP تامسو تاقيبطتالا ةجمرب ةهجاو تاملعم ةقد نم ققحت

.LDAP مادختساب ل.اصتال الكاشم ل.زع يف Bridge عاعدتسا نم مزحلا طاقتلا دعاسي للكاشم ل.زع يف المرابع ال

ةمجرتلا هذه لوح

تمهرت Cisco تا الرمستنع باستغام مهووة من التقن وات الآلية تالولية والرسبين في همود أنعاء الوالم والربشبين في هميد أنعاء الوالم والربشبين في هميو أنعاء الوالم والمتابين في المعارفة أن أفضل عمورت لن تكون عقوية كما باعلان مولية أن أفضل عمورت التوالية الربي وقعم مهرتم المعارفية التولي وقعمه المعارفية المعارفية المعارفية والمعارفية المعارفية المعارفية والمعارفية المعارفية والمعارفية والمعارفية المعارفية الم