

FTD تاهجاو ىلع لىكولل ARP لىطعت FlexConfig مادختساب

ةلأسم

تبات لكشب ةنيمعمل IP نيوانع مادختسا ىلع ةرداق ريغ FTD ةهجاو ىلع ةفيضملا ةزهجالا لىلحت فشكي 169.254.x.x نيوانع ىلإ عوجرلا لبق "رركم IP ناوع" ءاطخأ نع غالبال او هب صاخلا IP ناوع لىناجم (ARP Probe) ARP فيضملا لسري امدنع هنا مزحلا طاقتلل ا. حجائل تباتلل IP نيوعت عنمي امم ، اذه IP ناوع ةيكللمب ةبلاطم لل ةيامحل راج بيحتسي

ةئيبلا

- قيبطتلل لباق) 7.4.4 رادصالا ، FTD جم انرب لغشي يذلا Cisco Secure Firewall 2120 (زرطل او تارادصالا عيمج ىلع
- ةزهجالا ةرادال Cisco نم (FMC) نم آالا ةيامحل راج ةرادا زكرم
- .يضا رتفا لكشب FTD ىلع هنيممت مت لىكولل ARP

رارق

ةسايس مادختساب ةرثأتملا ةهجاو لىلع لىكولل ARP لىطعت قيرط نع ةلكشملا لىح متي ةباجتساللا نم ةيامحل راج عنمي اذهو . FMC لالخنم اهرشن متي يتل FlexConfig .حيرص لكشب اهكلممي ال يتل IP نيوانع ل ARP تانايبتسال

1: ARP لىطعتل ةديج FlexConfig ةسايس ئشنأو FMC في FlexConfig مسق ىلإ لقتنا :
نارخال Sysopt_noproxyYarp و Sysopt_noproxy_negate دعى . ةدحمل ةهجاو لىلع لىكولل
صصخملا مادختسالل امهسن نممي و FMC في نييضا رتفا نيئناك

| Name | Domain | Description |
|---------------------------------|--------|---|
| Netflow_Delete_Destination | Global | Delete a NetFlow export destination. |
| Netflow_Set_Parameters | Global | Set global parameters for NetFlow export. |
| NGFW_TCP_NORMALIZATION | Global | Configures the default TCP Normalization CLI on NGFW. |
| OSPF_Keychain | Global | |
| Policy_Based_Routing | Global | The template is an example of PBR policy configuration... |
| Policy_Based_Routing_Clear | Global | Clear configuration of Policy Based Routing. |
| Sysopt_AAA_radius | Global | Uses the sysopt command to provide the following exa... |
| Sysopt_AAA_radius_negate | Global | Negates CLI configured by Sysopt_AAA_radius. |
| Sysopt_basic | Global | Uses the sysopt command to provide the following exa... |
| Sysopt_basic_negate | Global | Negates CLI configured by Sysopt_basic. |
| Sysopt_clear_all | Global | Negates all the CLIs configured by Sysopt. |
| Sysopt_noproxyarp | Global | Uses the sysopt command to provide the following exa... |
| Sysopt_noproxyarp_negate | Global | Negates CLI configured by Sysopt_noproxyarp. |
| Sysopt_Preserve_Vpn_Flow | Global | Uses the sysopt command to configure sysopt preserve ... |
| Sysopt_Preserve_Vpn_Flow_Negate | Global | Negates the CLI pushed through Sysopt_Preserve_Vpn... |
| Sysopt_Reclassify_Vpn | Global | Uses the sysopt command to configure sysopt reclassif... |
| Sysopt_Reclassify_Vpn_Negate | Global | Negates CLI configured by Sysopt_Reclassify_Vpn Flex... |
| TCP_Embryonic_Conn_Limit | Global | TCP Embryonic Connection Settings |

inline_image_0.png

2: FlexConfig noproxy IFNAME: ةسايس ءم انرب ىلإ نىوكتلل رما فضا:

Edit FlexConfig Object

Name:
Sysopt_noproxyarp_DMZ_Gues...

Description:
Uses the sysopt command to provide the following

⚠ Copy-pasting any rich text might introduce line breaks while generating CLI. Please verify the CLI before deployment.

Insert **Deployment:** Once **Type:** Append

`sysopt noproxyarp DMZ_Guest-Wireless`

Variables

| Name | Dimension | Default Value | Property (Type:Name) | Override | Description |
|-----------------------|-----------|---------------|----------------------|----------|-------------|
| No records to display | | | | | |

Cancel Save

inline_image_1.png

رځ آ زاهج ةطساوب لعفلاب مادختسالال ديق بوغرملا

ةلصلال يذىوتحملال

• [Cisco نمتاليزنتلالاويينفلالا معدلا](#)

ةمچرتل هذه لوج

ةللأل تاي نقتل نمة ومة مادختساب دن تسمل اذة Cisco تمةرت
ملاعلاء انء مء مء نمة دختسمل معد و تمة مء دقتل ةر شبل او
امك ةق قء نوك ت نل ةللأل ةمچرت لصف أن ةظحال مء ءرء. ةصاأل مء تءل ب
Cisco ةللخت. فرتمة مچرت مء مء دقء ةللأل ةل فارتحال ةمچرتل عم لاعل او
ىل إأمءءاد ءوچرلاب ةصوء و تامةرتل هذه ةقء نء اهءل وئس م Cisco
Systems (رفوتم طبارل) ةلصلأل ةزءل ءن إل دن تسمل