VNF and VM Recovery Using the Portal

- VNF and VM Recovery Using the Portal, on page 1

VNF and VM Recovery Using the Portal

You can now perform manual recovery of VNFs and VM using the ESC portal:

Procedure

Step 1 Choose **Deployments**.

Step 2 Select a deployment in error state.

For VM level recovery, select a VM in error state from the View VNFs page.

Step 3 Click **Recover VNF** or **Monitor + Recover VNF**.

Step 4 Click **OK** to confirm.

Step 5 Select a **Recovery Action** from the Recovery Action dropdown and click **OK**.

The following recovery actions are available:

- Default—Triggers the recovery action that was defined in the datamodel.
- REBOOT_ONLY
- REDEPLOY_ONLY
- REBOOT_THEN_REDEPLOY

For more information on the recovery options, see Recovery Policy.

Important Points

1. Configurable manual recovery does not support the in-flight transaction behaviour. So if a failover happens during a configurable manual recovery, the manual recovery resumes with predefined recover action.

2. For deployment migration, use the default recovery policy. Cisco does not provide recovery action for VM/VNF manual recovery in LCS based recovery.