New and Changed Information

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 7000 Series NX-OS MPLS Command Reference*. The latest version of this document is available at the following Cisco website:

http://www.cisco.com/c/en/us/support/switches/nexus-7000-series-switches/products-command-reference-list.html

To check for additional information about this Cisco NX-OS Release, see the Cisco NX-OS Release Notes available at the following Cisco website:
http://www.cisco.com/c/en/us/support/switches/nexus-7000-series-switches/products-release-notes-list.html

The table below summarizes the new and changed features for the *Cisco Nexus 7000 Series NX-OS MPLS Command Reference*, and tells you where they are documented.

Table 1   New and Changed Features

Feature	Description	Changed in Release
A commands	allowas-in as-override autonomous-system	6.2(2)
B commands	bridge-domain	6.2(2)
C commands	control-word	6.2(2)
D commands	demand-circuit device ospf disable-peer-as-check	6.2(2)
E commands	echo revision echo vendor-extension encapsulation dot1q	6.2(2)
F commands	feature evc	6.2(2)
I commands	inherit port-profile internetworking interface pseudowire	6.2(2)

Table 1   ***New and Changed Features (continued)***

Feature	Description	Changed in Release
L commands	**l2vpn xconnect context** **l2vpn vfi context**	6.2(2)
M commands	**maximum-paths eibgp**	8.0(1)
	member encapsulation mpls **member** **member pseudowire** **member vfi** **mpls ldp graceful-restart**	6.2(2)
P commands	**port-profile type pseudowire**	6.2(2)
R commands	**redundancy** **remote link failure notification** **rewrite ingress tag push dot1q symmetric** **rewrite ingress tag translate 1-to-1 dot1q symmetric**	6.2(2)
S commands	**send-community extended** **signaling protocol none** **soo** **state enabled** **switchport allowed vlan**	6.2(2)
Show commands	**show bridge-domain** **show forwarding** **show ethernet service instance** **show ethernet service instance id interface ethernet** **show ethernet service instance interface ethernet** **show forwarding** **show l2vpn atom** **show l2vpn atom vc detail** **show l2vpn service xconnect all** **show l2vpn service vfi** **show l2vpn vfi** **show mpls ldp neighbor graceful-restart** **show run mpls ldp all**	6.2(2)
U commands	**update-source loopback**	6.2(2)
V commands	**vpn**	6.2(2)