



Numerics

- 19-inch rack [2-4](#)
 - mount unit [2-4](#)
- 6-second countdown [2-5, 2-7](#)
- 9-pin serial-port [2-1](#)

A

- ACT LED See LED indicators
- Administrator interface [1-2, 2-14](#)
- Advanced Configuration menu [2-8, 2-10, 2-12](#)
- architecture [1-6](#)
- audio
 - codecs [1-3](#)
- auto-boot [2-5](#)

B

- boot configuration menu [2-5](#)

C

- cables
 - RJ-45 8-pin IP network port [4-2](#)
 - RS-232 9-pin serial port [4-1](#)
- cascaded conferences [1-7](#)
- Certifications
 - EMC [7-1](#)
 - Telecom [7-2](#)
- chipset [5-1](#)
- codecs
 - audio transcoding [1-3](#)

- video [1-4](#)

- communication interfaces [5-1](#)
- communication settings [2-6](#)
- Conference Control interface [1-2](#)
- Configuration menu [2-5](#)
- Continuous Presence [1-4](#)

D

- data collaboration [1-4](#)
- DB-9 [2-2, 2-13](#)
- DTMF [1-4](#)
- dual-screen video [1-4](#)
- Duo Video [1-4](#)
- duplex parameters [2-9, 2-12](#)

E

- EMC [7-1](#)
- encryption [1-4](#)
- Ethernet
 - cable [2-3](#)
 - port [2-1](#)
 - speed [2-9, 2-12](#)

F

- failsafe [5-2](#)
- flat capacity [1-2](#)
- front panel [2-2](#)
 - components [2-2](#)

G

GK LED See LED indicators
 global user name [2-14](#)

H

H.235 [1-3](#)
 H.239 [1-3, 1-4](#)
 H.243 [1-4](#)
 High Definition [1-5](#)

I

initial configuration [2-5](#)
 initialization [2-5](#)
 installation procedures

- access administrator interface [2-14](#)
- change advanced configuration settings [2-12](#)
- change configuration software password [2-8, 2-10](#)
- change IP address [2-8](#)
- change LAN port settings [2-12](#)
- change password [2-7](#)
- change security level [2-11](#)
- change unit IP address [2-11](#)
- configure default network port values [2-7, 2-8](#)
- configure IP address for unit [2-6](#)
- configure IP address for video processing module [2-9](#)
- configure network security level [2-7, 2-8](#)
- configure web server [2-12](#)
- configure web server port [2-12](#)
- connect to the serial port [2-5](#)
- connect unit to the LAN [2-8](#)
- disable DSP reset [2-12](#)
- display Advanced Configuration menu [2-8](#)
- display advanced configuration menu [2-7](#)
- mount unit in a 19-inch rack [2-4](#)
- restore factory configuration [2-12](#)
- restore factory settings [2-12](#)

save network configuration settings [2-13](#)
 set default network properties [2-9](#)
 set duplex parameters [2-10, 2-12](#)
 set Ethernet speed [2-10, 2-12](#)
 installation requirements [2-2](#)
 interoperability [1-3](#)
 IP address

- change for unit [2-11](#)
- configure for unit [2-6](#)
- configure for video processing module [2-9](#)

 IVR [1-4](#)

L

LAN cable [2-3](#)
 layouts

- Continuous Presence [1-4](#)

 LED indicators [2-2, 5-1](#)
 local port monitoring [2-13](#)

M

Main menu [2-8, 2-11, 2-12](#)
 MC LED See LED indicators
 memory [5-2](#)
 multi-view See dual-screen video

N

Netscape Navigator [2-15](#)
 Network Configuration menu [2-7, 2-8, 2-10](#)

O

online help [2-15](#)

- Netscape Navigator [2-15](#)

 operating system [5-2](#)
 optional no self see [1-4](#)

P

- package contents [2-3](#)
- password
 - change configuration software password [2-10](#)
- pin-out configuration
 - RJ-45 IP network port [4-2](#)
 - RS-232 9-pin D-type serial port [4-1](#)
- ports
 - RJ-45 IP [4-2](#)
 - RS-232 9-pin serial [4-1](#)
- power supply [5-2](#)
- privacy [1-4](#)
- protocols [1-3](#)
- push buttons [5-1](#)

R

- remote control [1-4](#)
- remote management and monitoring [2-13](#)
- reset button [2-2](#)
- RJ-45 [2-2](#)
- RS-232 terminal cable [2-5](#)
- RST [2-2](#)
- RST button [5-1](#)

S

- Safety
 - compliance [7-1](#)
 - electrical [6-1](#)
 - ESD procedures [6-2](#)
- security [1-4](#)
 - change security level [2-11](#)
- self-view [1-4](#)
- serial connector [2-2](#)
- SNMP
 - agent [2-13](#)
- Software Upgrade Utility [2-14](#)

- software upgrade utility procedures
 - install and launch [3-1](#)
 - use utility [3-2](#)
- summary of features [1-2](#)

T

- T.120 [1-4](#)
- Telecom [7-2](#)
- terminal cable [2-5](#)
- topologies [1-7](#)
- transcoding [1-3](#)

U

- unit dimensions [5-1](#)
- upgrade software [3-1](#)
- user types [1-2](#)
 - administrators [1-2](#)
 - chair controllers [1-2](#)
 - conference participants [1-2](#)
 - operators [1-2](#)

V

- video
 - codec [1-4](#)
 - coding [1-4](#)
 - formats [1-4](#)
- video quality [1-2, 1-4](#)

W

- web-based management and control [1-3](#)
- web interface [2-14](#)

