



INDEX

A

Adding Alert Recipients [16-3](#)
Adding Auto-detect Access Information [16-8](#)
Adding Multipoint Processors [12-17](#)
Adding Services [12-18](#)
Adding Users [16-2](#)
Additional Cisco IOS H.323 Gatekeeper tabs [12-19](#)
Additional Endpoints tab [12-14](#)
Additional Gatekeeper tabs [12-9](#)
Address Book
 adding participant [11-6](#)
Add Service button [6-10](#)
ad-hoc
 participants [3-3](#)
Advanced Invitation tab [9-13](#)
Advanced Settings
 Default Meeting Settings tab [i-ii, 10-1](#)
 Default User Settings tab [i-ii, 10-1](#)
Alarms tab [15-1](#)
Alarms view [11-4](#)
 Alarms tab [12-5, 15-1](#)
Alert Recipients
 modifying [16-4](#)
All Meetings [9-1](#)
 Current tab [9-1, 9-2](#)
 Deployment [9-2](#)
 History tab [9-1](#)
 Status indicators [9-2](#)
 Upcoming tab [9-1](#)
Attendee Availability tab [11-6](#)
Attendees Settings tab [11-5](#)
audio

 enable for all participants [9-4](#)

authorization [6-5](#)

authorization connection [6-5](#)

Auto-Detect [11-3, 18-1](#)

auto-switching [9-9](#)

 Auto-switch interval [9-9](#)

B

Bandwidth

 Restricted Mode [6-10](#)

bandwidth [10-4](#)

billing [11-3](#)

billing contact [A-7, B-17](#)

Block Entry button [9-4](#)

C

Call Control Connection [6-5](#)

camera

 blocking [9-12](#)

cascading [3-3](#)

 dynamic [3-3](#)

CDR [B-14](#)

 file naming [B-14](#)

Centralized Log Management [11-4](#)

Children [12-12](#)

Cisco IOS H.323 Gatekeeper

 Bandwidth Rules [12-21](#)

 command [12-22](#)

 debug flags [12-22](#)

 local zones [12-19](#)

 Prefixes [12-20](#)

- remote zones [12-20](#)
 - Community access [12-8](#)
 - Conferences and Calls view
 - Calls tab [17-1](#)
 - Conferences tab [17-1](#)
 - Configuration Tool
 - billing contact [B-17](#)
 - CDR [B-14](#)
 - Database Settings tab [B-12](#)
 - e-mail server settings [B-4](#)
 - external terminals [B-19](#)
 - external users [B-19](#)
 - MCU command delay [B-6](#)
 - meeting settings [B-7](#)
 - meeting types [B-17](#)
 - passwords [B-6](#)
 - resource scheduling [B-22](#)
 - Configuration Utility
 - Database tab [E-2](#)
 - Mail Server tab [E-1](#)
 - Security tab [E-2](#)
 - Configuring
 - Cisco IOS H.323 Gatekeeper [12-8](#)
 - Gateway [12-8](#)
 - MCU [12-7](#)
 - Terminal managers [11-4](#)
 - Configuring Protocols [12-16](#)
 - connection
 - authorization of [6-5](#)
 - Gatekeeper/API [6-5](#)
 - SNMP [6-5](#)
 - Continuous Presence Mode [9-8](#)
 - Control Panel [9-5](#)
 - Custom views [18-4](#)
-
- Default User Settings
 - Look and Feel tab [10-1](#)
 - delay [10-4](#)
 - device controller
 - IP Topology [5-2](#)
 - device island [3-2](#)
 - adding [5-3](#)
 - connecting [5-3, 5-5](#)
 - deleting [5-3](#)
 - modifying [5-3](#)
 - network topology [5-3, 5-5](#)
 - reassigning [5-4](#)
 - viewing [5-2, 5-3](#)
 - dialing information
 - search by [6-15](#)
 - directory server
 - user provisioning via Configuration Tool [B-19](#)
 - distributed environment [3-3](#)
 - Download Meeting Types [7-5](#)
 - Download Meeting Types window [7-5](#)
 - Dual IP/ISDN terminal [11-5](#)
 - duration
 - extending [9-4](#)
 - meeting history [9-17](#)
 - of meeting [11-3](#)
 - dynamic cascading [3-3](#)
 - Dynamic Layout
 - enabling and disabling [9-10](#)

E

- E.164 [9-3](#)
- Element configuration [11-3](#)
- Element management [12-3, 13-1, 14-1](#)
- Element Managers
 - configuration [11-4](#)
- Elements
 - adding [18-2](#)
 - deleting [18-3](#)

D

- data collaboration [9-13](#)
- Default Dialing Mode [10-3](#)

- editing [18-3](#)
- finding [18-2](#)
- endpoint
 - unresponsive to connection request [B-5](#)
- Endpoint Management tab [16-7](#)
- error message
 - Reason Failed [9-17](#)
- Events view
 - Events tab [12-6](#)

F

- Filtering Traps [15-2](#)
- Finding a conference [12-6, 17-2](#)
- Finding Elements [18-2](#)

G

- Gatekeeper
 - supported models [6-1](#)
- Gatekeeper/SIP
 - searching for [6-5](#)
- Gatekeeper hierarchy
 - children [12-12](#)
 - neighbors [12-13](#)
 - parent [12-10](#)
- Gateway
 - adding [6-10](#)
 - additional phone numbers [6-10](#)
 - configuration [11-3](#)
- gateway
 - access to outside local line [6-10](#)
 - area code [6-10](#)
 - bandwidth [6-10](#)
 - deleting [6-11](#)
 - DID numbers [6-9](#)
 - IVR numbers [6-9](#)
 - modifying [6-4, 6-10](#)

- offline [6-11](#)
- out-of-area calls [6-10](#)
- ports
 - telephone number assignment [6-10](#)
 - service prefixes [6-10](#)
- Gateway tab [6-9](#)
- generating reports
 - cost code [9-18](#)
- groups
 - per user [8-4](#)

H

- host [9-15](#)

I

- icons
 - media [9-12](#)
- ID
 - meeting [9-15](#)
- In Meeting Control [10-5](#)
- in-meeting control
 - privileges [9-1](#)
- invalid prefix [7-5](#)
- Invite tab [11-4](#)
- IP Topology
 - device controller [5-2](#)
- IP Topology tab [5-1](#)
 - Bandwidth [5-2](#)
 - Distance [5-2](#)
- ISDN
 - cost of call [5-4](#)
- ISDN Network Topology
 - overview [3-3](#)

J

Join Data Collaboration button [9-4](#)

L

layout

 changing [9-10](#)

 dynamic [9-10](#)

Layouts display [11-5](#)

Least Cost Routing [3-2, 3-3](#)

locking

 image [9-14](#)

log

 Upload [7-7](#)

logging

 CDR [B-14](#)

logging in [4-2](#)

Logs

 Gateway [12-8](#)

 MCU [12-8](#)

loudspeakers

 muting and enabling [9-12](#)

M

Max Video Layout [7-3](#)

MCU

 command delay [B-6](#)

 configuration [11-3](#)

 local [10-4](#)

 modifying [6-7](#)

 searching for [6-9](#)

 service prefixes [6-7](#)

MCU access [17-2](#)

MCU tab

 Basic tab [6-7](#)

media

 status [9-12](#)

media icons [9-12](#)

meeting

 controlling [9-5](#)

 modifying [9-17](#)

 searching for [9-15](#)

meeting cascading

 selecting priority [6-5](#)

Meeting ID [9-15](#)

meeting room

 searching for [6-13](#)

Meeting Rooms tab [6-11, 6-12](#)

meetings

 alert before termination [11-7](#)

 default settings [10-2](#)

 monitoring [9-3](#)

 start when host joins [A-8](#)

Meeting Schedule button [10-5](#)

Meeting Scheduling [10-5](#)

 Ad-Hoc Meeting [11-1](#)

 Attendees Settings [11-5](#)

 Invite Attendees list [10-5](#)

 Meeting Attendees [10-5](#)

 Normal Meeting [11-1](#)

 One Button [10-5](#)

 password [11-7](#)

 Recurrence [10-5](#)

 Recurring Meeting [11-1](#)

 Reference Code [11-7](#)

Meeting tab [11-2](#)

meeting type

 deactivate [7-7](#)

 deleting [7-8](#)

 deploying [7-6](#)

 searching for [7-7](#)

Meeting Types

 Active Meeting Types tab [7-1](#)

 Inactive Meeting Types tab [7-1](#)

meeting types *see also* services

 Configuration Tool [B-17](#)

- groups [7-8](#)
- Mic. Enabled button [9-4](#)
- Modifying Auto-detect Access Information [16-8](#)
- Modifying users [16-2](#)
- monitor
 - enabling [9-12](#)
- muting
 - all participants [9-4](#)
- My Meetings
 - Current tab [9-2](#)

N

- Neighbors [12-13](#)
- Network Manager
 - overview [11-1](#)
- Network Map
 - navigating [14-2](#)
- Network Map view [14-1](#)
- Network Status [11-2](#)
- Network Table view [13-1](#)
- network topology [3-2](#)
- Network Tree view [12-1, 12-3](#)
 - Access tab [12-8](#)
 - Additional Cisco IOS H.323 Gatekeeper tabs [12-19](#)
 - Additional Endpoints tab [12-14](#)
 - Additional Gatekeeper tabs [12-9](#)
 - Calls tab [12-7](#)
 - Configure tab [12-7](#)
 - Elements tab [12-4](#)
 - Logs tab [12-8](#)
- Network Views [11-5](#)
- Non Video Conference [11-4](#)

O

- organization
 - default user settings [10-2](#)

- Outlook
 - Attendee Settings tab [A-6](#)
 - billing contact [A-7](#)
 - installation [A-2](#)
 - start meeting when host joins [A-8](#)
 - To field [A-5](#)

P

- Parent [12-10](#)
- Participant List tab [9-11](#)
- participants
 - changing view for [9-6](#)
 - deleting [9-4](#)
 - disconnecting [9-6](#)
 - enabling audio for [9-4](#)
 - inviting [9-10](#)
 - meeting control [11-5](#)
 - muting all [9-4](#)
 - reconnecting [9-4](#)
 - reconnecting all [9-6](#)
- password [8-2](#)
- PSTN/ISDN [10-3](#)

R

- rate-matching [7-3](#)
- Reconnect All button [9-4](#)
- Refresh button [9-4](#)
- Registering MPs [12-17](#)
- Regular User [8-2](#)
- report
 - information categories [9-16](#)
- reports
 - generating [9-16](#)
- Requirements
 - system [11-1](#)
- resources

additional [11-7](#)
 restarting [4-2](#)

S

scheduling meetings
 alert before termination [11-7](#)
 participant meeting control [11-5](#)
 resources via Configuration Tool [B-22](#)
 unresolved calls [11-7](#)

Security Settings tab [B-13](#)

service [4-2](#)

Services
 Gateway [12-18](#)
 MCU [12-18](#)
 viewing [12-3, 12-4](#)

services *see also* meeting types
 groups [7-8](#)

Settings view [16-1](#)
 Alarms tab [16-5](#)
 Alert Recipients tab [16-3](#)
 Auto-Detect tab [16-7](#)
 Cisco IOS H.323 Gatekeeper tab [16-9](#)
 Element Access tab [16-7](#)
 Element Logs tab [16-7](#)
 Endpoint Management tab [16-7](#)
 Logs tab [16-6](#)
 Network Subsets tab [16-5](#)
 Traps tab [16-4](#)
 Users tab [16-2](#)

SIP server
 SIP environment [6-6](#)
 supported models [6-1](#)

SNMP Connection [6-5](#)

starting [4-2](#)

Statistics tab [9-13](#)

sub-conference [9-7](#)

T

terminal
 adding [6-13](#)
 custom [11-5](#)
 deleting [6-15](#)
 display name [10-3](#)
 Dual IP/ISDN [11-5](#)
 modifying number [11-5](#)
 searching for [6-15](#)
 type of [6-13](#)

terminals
 external terminals via Configuration Tool [B-19](#)

Terminals tab [6-13](#)

terminating meeting [10-3](#)

U

unresolved calls [11-7](#)

Upcoming tab [9-15](#)

Upload Log [7-7](#)

user
 default settings [10-2](#)
 groups [8-4](#)
 provisioning via Configuration Tool [B-19](#)

User Access [16-2](#)

user ID [8-2](#)

User Management [8-1](#)
 Users tab [8-1](#)

users
 adding [8-2](#)

user types
 Regular User [8-2](#)

V

video frame [9-8](#)

Video Layout and Display area [9-8](#)

Video Layout area [9-5](#)

video output
 schemes [9-8](#)

view
 for participants [9-4](#)

Viewing conferences [11-2](#)

Viewing events [11-4](#)

Views
 Custom [18-4](#)
 Network Map [14-1](#)
 Network Table [13-1](#)
 Network Tree [12-1](#)
 Settings [16-1](#)

voice-activated frame [9-9](#)

X

XML

 CDR [B-14](#)
 CDR file naming [B-14](#)

Z

Zone management [12-2](#)

