



INDEX

A

- access lists [14](#)
- active calls
 - backup [57, 59](#)
- administrator
 - password [17](#)
 - user ID [17](#)

B

- backup
 - active calls [57, 59](#)
 - numbering scheme [57](#)
- backup category command [58](#)
- boot helper [39](#)

C

- call processing [14](#)
- Cisco Unified CME
 - Flash memory files [10](#)
 - IP path command [10, 11](#)
 - web administrator [12](#)
- Cisco Unified CME web page [10](#)
- Cisco Unified Communications Manager
 - CTI ports [13](#)
- Cisco Unity Express
 - software files [21, 27, 40](#)
- Cisco Unity Express software website [52](#)
- command
 - backup category [58](#)
 - continue [58](#)

- interface Service-Engine [19](#)
- ip address [19](#)
- IP path [10](#)
- ip unnumbered [19](#)
- offline [58, 59](#)
- reload [59](#)
- restore id [59](#)
- service-module [19](#)
- show backup history [58, 59](#)
- show backup server [59](#)
 - show backup server command [58](#)
- show software versions [35, 46](#)
- show software versions detail [35, 46](#)
- configuring
 - dial peer [11](#)
 - ephone-dn [10](#)
 - IP addresses [17](#)
- configuring IP connectivity [11](#)
- continue command [58](#)
- creating users and telephones [9](#)
- CTI ports [13](#)

D

- default gateway [18](#)
- Device option [13](#)
- dial peer [11](#)
- DNS server [17](#)
- downloading license files [52](#)

E

- ephone [10](#)

ephone-dn [10](#)
 Etherswitch module [11, 13](#)

F

factory-set system limits [4](#)
 FTP
 server [52](#)

G

G.711 ulaw [11](#)
 graceful shutdown [3](#)

I

installer file [52](#)
 installing
 software image [40](#)
 Interactive Voice-Mail license [49](#)
 interface Service-Engine command [19](#)
 IP
 addressing [17](#)
 IP address, Cisco Unity Express module [11, 13](#)
 ip address command [19](#)
 IP connectivity, configuring [11](#)
 IP path for Cisco Unified CME [10, 11](#)
 ip unnumbered command [19](#)
 IVR [49](#)
 License, changing [55](#)

J

JTAPI traffic, prioritizing [14](#)

L

Languages

 installing additional [20](#)
 removing [23](#)
 language upgrades [61](#)
 license files [52](#)
 downloading [52](#)
 installing [54](#)

M

maximum number of triggers [4](#)
 module IP address [11, 13](#)
 modules, network [4](#)

N

network modules [4](#)
 NTP server [17](#)
 numbering scheme, backup files [57](#)

O

offline command [58, 59](#)
 offline mode [57, 59](#)
 option
 Device [13](#)

P

Prerequisites
 Cisco Unified Communications Manager [12](#)
 Cisco Unified Communications Manager Express [9](#)

R

reload command [59](#)
 restore
 procedure [59](#)
 restore id command [59](#)

S

servers

DNS [17](#)NTP [17](#)service-module command [19](#)show backup history command [58, 59](#)show backup server command [59](#)show software versions command [35, 46](#)show software versions detail command [35, 46](#)SIP dial peer [11](#)SKUs [51](#)software files [21, 27, 40](#)installer [52](#)license [52](#)software image, installing [40](#)

system limits

factory set [4](#)

T

triggers

maximum number [4](#)

Uuninterruptible power supply [3](#)

Upgrades

types [2](#)

upgrading

languages [61](#)UPS [3](#)

VVLAN interface [11, 13](#)

Wweb administrator [12](#)

web page

Cisco Unified CME [10](#)

