# About this Guide

**Note** Control and User Plane Separation (CUPS) represents a significant architectural change in the way StarOS-based products are deployed in the 3G, 4G, and 5G networks. Unless otherwise specified, it should not be assumed that any constructs (including, but not limited to, commands, statistics, attributes, MIB objects, alarms, logs, services) referenced in this document imply functional parity with CUPS products. References to any CUPS products or features are for informational purposes only. Please contact your Cisco Account or Support representative for any questions about parity between this product and any CUPS products.

**Note** The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

**Note** The HA, HSGW, PDSN, and SecGW products have reached end of life and are not supported in this release. Any references to these products (specific or implied) their components or functions including CLI commands and parameters in this document are coincidental and are not supported. Full details on the end of life for these products are available at https://www.cisco.com/c/en/us/products/collateral/wireless/asr-5000-series/eos-eol-notice-c51-740422.html.

This preface describes the Serving Architecture Evolution Gateway (SAEGW) Administration Guide, how it is organized and its document conventions.

The SAEGW node is a combination of S-GW and P-GW nodes. SAEGW operates as a service on the StarOS and requires existing S-GW and P-GW services to be configured and mentioned inside an SAEGW service configuration. Existing standalone S-GW and P-GW services (when part of an SAEGW umbrella service) will work in tandem to present a single SAEGW node as a black-box view. This document contains feature descriptions, configuration procedures, and monitoring and troubleshooting information.


- Conventions Used, on page ii
- Supported Documents and Resources, on page iii

# Conventions Used

The following tables describe the conventions used throughout this documentation.

| Notice Type | Description |
|---|---|
| Information Note | Provides information about important features or instructions. |
| Caution | Alerts you of potential damage to a program, device, or system. |
| Warning | Alerts you of potential personal injury or fatality. May also alert you of potential electrical hazards. |

| Typeface Conventions | Description |
|---|---|
| Text represented as a `screen display` | This typeface represents displays that appear on your terminal screen, for example:<br>`Login:` |
| Text represented as **commands** | This typeface represents commands that you enter, for example:<br>**show ip access-list**<br>This document always gives the full form of a command in lowercase letters. Commands are not case sensitive. |
| Text represented as a **command** *variable* | This typeface represents a variable that is part of a command, for example:<br>**show card** *slot_number*<br>*slot_number* is a variable representing the desired chassis slot number. |
| Text represented as menu or sub-menu names | This typeface represents menus and sub-menus that you access within a software application, for example:<br>Click the **File** menu, then click **New** |

| Command Syntax Conventions | Description |
|---|---|
| **{ keyword** or *variable* **}** | Required keyword options and variables are those components that are required to be entered as part of the command syntax.<br>Required keyword options and variables are surrounded by grouped braces { }. For example:<br>**sctp-max-data-chunks { limit** *max_chunks* **\| mtu-limit }**<br>If a keyword or variable is not enclosed in braces or brackets, it is mandatory. For example:<br>**snmp trap link-status** |
| **[ keyword** or *variable* **]** | Optional keywords or variables, or those that a user may or may not choose to use, are surrounded by brackets. |
| \| | Some commands support multiple options. These are documented within braces or brackets by separating each option with a vertical bar.<br>These options can be used in conjunction with required or optional keywords or variables. For example:<br>**action activate-flow-detection { intitiation \| termination }**<br>or<br>**ip address [ count** *number_of_packets* **\| size** *number_of_bytes* **]** |

# Supported Documents and Resources

## Related Common Documentation

The most up-to-date information for this product is available in the product Release Notes provided with each product release.

The following common documents are available:

- AAA Interface Administration Reference
- Command Line Interface Reference
- GTPP Interface Administration Reference
- Hardware Installation Guide (hardware dependent)
- Release Change Reference
- Statistics and Counters Reference
- System Administration Guide (hardware dependent)

- Thresholding Configuration Guide

## Related Product Documentation

The following product documents are also available and work in conjunction with the SAEGW:

- ADC Administration Guide
- ECS Administration Guide
- GGSN Administration Guide
- MME Administration Guide
- NAT Administration Guide
- PSF Administration Guide
- P-GW Administration Guide
- S-GW Administration Guide

## Obtaining Documentation

The most current Cisco documentation is available on the following website:

http://www.cisco.com/cisco/web/psa/default.html

Use the following path selections to access the SAE-GW documentation:

Products > Wireless > Mobile Internet> Network Functions > Cisco SAEGW System Architecture Evolution Gateway

# Contacting Customer Support

Use the information in this section to contact customer support.

Refer to the support area of http://www.cisco.com for up-to-date product documentation or to submit a service request. A valid username and password are required to access this site. Please contact your Cisco sales or service representative for additional information.