

Cambio del Canal Inalámbrico en un Cisco Small Business VoIP Router

Contenido

[Introducción](#)

[¿Cómo puedo cambiar el canal usado por mi red inalámbrica en un router VoIP de la Pequeña empresa de Cisco?](#)

[Información Relacionada](#)

[Introducción](#)

Este artículo forma parte de una serie para ayudar con la configuración, el troubleshooting y el mantenimiento de productos para Pequeñas Empresas de Cisco.

Q. [¿Cómo puedo cambiar el canal usado por mi red inalámbrica en un router VoIP de la Pequeña empresa de Cisco?](#)

R.

Muchos productos de red inalámbrica en los E.E.U.U. se envían con un canal predeterminado de 6 como el router de la Pequeña empresa de Cisco. Si usted encuentra interferencia de los otros dispositivos, cambie los canales para conseguir alrededor de estas interferencias. Para cambiar el canal que su red inalámbrica está utilizando, que vaya a la página de configuración basada en web del router.

Cambie el canal del router

Paso 1:

Acceda la página de configuración basada en web del router. Para las instrucciones, haga clic [aquí](#).

Paso 2:

Cuando aparece la página de configuración basada en web del router, haga clic la **Tecnología inalámbrica**.

Paso 3:

Busque el **canal inalámbrico**, y cámbielo a su canal deseado. Los canales recomendados son **1, 6**, o **11** puesto que se consideran los canales sin traslapo.

The screenshot shows the Linksys web interface. At the top left is the Linksys logo with the text "LINKSYS® A Division of Cisco Systems, Inc.". Below the logo is a navigation bar with tabs: "Setup", "Wireless", "Security", "Access Restrictions", "Applications & Gaming", "Administration", "Status", and "Voice". The "Wireless" tab is selected. Below the navigation bar are sub-tabs: "Basic Wireless Settings", "Wireless Security", "Wireless MAC Filter", and "Advanced Wireless Settings". The "Basic Wireless Settings" sub-tab is active. The main content area is titled "Wireless Settings" and contains the following fields:

- Wireless Network Mode: Disabled (dropdown menu)
- Wireless Network Name (SSID): (text input field)
- Wireless Channel: 1 (dropdown menu)
- Wireless SSID Broadcast: Enable Disabled

Annotations include:

- A yellow box with the text "Click Wireless." and an arrow pointing to the "Wireless" tab.
- A yellow box with the text "Select 1, 6 or 11 then click Save Settings." and an arrow pointing to the "Wireless Channel" dropdown menu.

At the bottom of the page are two buttons: "Save Settings" and "Cancel Changes". On the right side, there is a "Basic Wireless Settings" sidebar with a description: "The Wireless screen allows you to customize data transmission settings. In most cases, the advanced settings on this screen should remain at their default values." and a "More..." link. The Cisco Systems logo is in the bottom right corner.

Paso 4:

Tecleo **Save Settings**.

Información Relacionada

- [Soporte Técnico y Documentación - Cisco Systems](#)