

ID de document : 12730

Mis à jour : DEC 14, 2006



[PDF de téléchargement](#)



[Copie](#)

[\[+\] Feedback](#)

## [Produits connexes](#)

- [Routeurs de la gamme Cisco 7200](#)

## Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Composants utilisés](#)

[Produits connexes](#)

[Conventions](#)

[Procédure pas à pas](#)

[Exemple de procédure de récupération de mot de passe](#)

[Informations connexes](#)

[Cisco relatif prennent en charge des discussions de la Communauté](#)

## [Introduction](#)

Ce document explique comment récupérer les mots de passe **enable password** et **enable secret password**. Ces mots de passe protègent l'accès aux modes privilégiés EXEC et de configuration. Le mot de passe **enable password** peut être récupéré, mais le mot de passe **enable secret password** est chiffré et doit être remplacé par un nouveau mot de passe. Utilisez la procédure décrite dans ce document pour remplacer le mot de passe **enable secret**.

## [Conditions préalables](#)

### [Conditions requises](#)

Aucune spécification déterminée n'est requise pour ce document.

### [Composants utilisés](#)

Les informations dans ce document sont basées sur le Routeurs de la gamme Cisco 7200.

Les informations contenues dans ce document ont été créées à partir des périphériques d'un

environnement de laboratoire spécifique. Tous les périphériques utilisés dans ce document ont démarré avec une configuration effacée (par défaut). Si votre réseau est opérationnel, assurez-vous que vous comprenez l'effet potentiel de toute commande.

## [Produits connexes](#)

Pour plus d'informations sur la façon de récupérer des mots de passe pour des produits connexes, reportez-vous aux [Procédures de récupération de mot de passe](#).

## [Conventions](#)

Pour plus d'informations sur les conventions utilisées dans ce document, reportez-vous à [Conventions relatives aux conseils techniques Cisco](#).

## [Procédure pas à pas](#)

Pour récupérer votre mot de passe, suivez les étapes suivantes :

1. Connectez un terminal ou un PC avec émulation de terminal au port pour console du routeur. Utilisez les paramètres de terminal suivants : Débit de 9 600 bauds, Aucune parité, 8 bits de données, 1 bit d'arrêt, Aucun contrôle de flux. Pour plus d'informations sur la façon de raccorder et de connecter un terminal au port pour console ou au port AUX, reportez-vous aux documents suivants : [Guide de raccordement de la console et des ports AUX](#), [Connexion d'un terminal au port pour console sur les commutateurs Catalyst](#), [Connecter un terminal aux commutateurs de la gamme Catalyst 2948G-L3 4908G-L3 et 4840G](#)
2. Si vous pouvez accéder au routeur, tapez **show version** à l'invite, puis enregistrez le paramètre de registre de configuration. Pour afficher la sortie de la commande **show version**, consultez [Exemple de procédure de récupération de mot de passe](#). **Remarque:** La valeur définie pour le registre de configuration est généralement 0x2102 ou 0x102. Si vous n'avez plus accès au routeur (mot de passe routeur ou mot de passe TACACS perdu), vous pouvez supposer en toute sécurité que votre registre de configuration contient la valeur 0x2102.
3. Arrêtez le routeur à l'aide du bouton d'alimentation, et rallumez-le. **Remarques importantes :** Pour simuler cette étape sur Cisco 6400, débranchez puis rebranchez la carte NRP (Node Route Processor) ou NSP (Node Switch Processor). Pour simuler cette étape sur Cisco 6x00 avec NI-2, débranchez puis rebranchez la carte NI-2.
4. Appuyez sur **Break** sur le clavier du terminal dans les 60 secondes de mise sous tension afin de mettre le routeur en ROMMON. Si la séquence d'arrêt ne fonctionne pas, reportez-vous à [Combinaisons de touches d'arrêt standard pendant la récupération d'un mot de passe](#) pour obtenir d'autres combinaisons de touches.
5. Tapez **confreg 0x2142** à l'invite rommon 1> pour démarrer à partir de la mémoire flash. Cette étape ignore la configuration de démarrage dans laquelle les mots de passe sont stockés.
6. Tapez **reset** à la suite de l'invite rommon 2>. Le routeur redémarre, mais ignore la configuration enregistrée.
7. Tapez **no** après chaque question de configuration, ou appuyez sur **Ctrl-C** pour ignorer la procédure de configuration initiale.
8. Tapez **enable** à la suite de l'invite Router>. Vous êtes en mode enable et devez voir l'invite Router#.
9. Tapez **configure memory** ou **copy startup-config running-config** pour copier la mémoire RAM

non volatile (NVRAM) dans la mémoire. **Important** : Ne tapez *pas* **copy running-config startup-config** ou **write**. Ces commandes effacent votre configuration de démarrage.

10. Tapez **show running-config**. La commande **show running-config** affiche la configuration du routeur. Dans cette configuration, la commande **shutdown** apparaît sous toutes les interfaces, ce qui indique que toutes les interfaces sont actuellement arrêtées. De plus, les mots de passe (enable password, enable secret, vty et de console) sont au format chiffré ou non chiffré. Vous pouvez réutiliser les mots de passe non chiffrés. Vous devez remplacer les mots de passe chiffrés par un nouveau mot de passe.
11. Tapez **configure terminal**. L'invite hostname(config)# s'affiche.
12. Tapez **enable secret <password>** pour modifier le mot de passe **enable secret password**.  
Exemple :hostname(config)#**enable secret** cisco
13. Émettez la commande **no shutdown** sur chaque interface que vous utilisez. Si vous émettez une commande **show ip interface brief**, chaque interface que vous voulez utiliser doit afficher *up up*.
14. Tapez **config-register <configuration\_register\_setting>**. Où **configuration\_register\_setting** est la valeur que vous avez enregistrée à l'étape 2 ou **0x2102**. Exemple  
:hostname(config)#**config-register** 0x2102
15. Appuyez sur **Ctrl-z** ou sur **end** pour quitter le mode de configuration. L'invite hostname# s'affiche.
16. Tapez **write memory** ou **copy running-config startup-config** pour valider les modifications apportées.

## [Exemple de procédure de récupération de mot de passe](#)

Cette section fournit un exemple de procédure de récupération de mot de passe. Cet exemple a été créé avec un routeur de la gamme Cisco 2600. Même si vous n'utilisez pas un routeur de la gamme Cisco 2600, cette sortie fournit un exemple de ce que vous devriez obtenir sur votre produit.

```
Router>enablePassword:Password:Password:% Bad secretsRouter>show versionCisco Internetwork
Operating System SoftwareIOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE
SOFTWARE (fc2)Copyright (c) 1986-1999 by cisco Systems, Inc.Compiled Tue 07-Dec-99 02:21 by
phanguyeImage text-base: 0x80008088, data-base: 0x80C524F8ROM: System Bootstrap, Version
11.3(2)XA4, RELEASE SOFTWARE (fc1)Router uptime is 3 minutesSystem returned to ROM by abort at
PC 0x802D0B60System image file is "flash:c2600-is-mz.120-7.T"cisco 2611 (MPC860) processor
(revision 0x202) with 26624K/6144K bytes of memory.Processor board ID JAB031202NK
(3878188963)M860 processor: part number 0, mask 49Bridging software.X.25 software, Version
3.0.0.Basic Rate ISDN software, Version 1.1.2 Ethernet/IEEE 802.3 interface(s)2
Serial(sync/async) network interface(s)1 ISDN Basic Rate interface(s)32K bytes of non-volatile
configuration memory.8192K bytes of processor board System flash partition 1 (Read/Write)8192K
bytes of processor board System flash partition 2 (Read/Write)Configuration register is
0x2102Router>!--- The router was just powercycled, and during bootup a!--- break sequence was
sent to the router.!*** System received an abort due to Break Key ***signal= 0x3, code= 0x500,
context= 0x813ac158PC = 0x802d0b60, Vector = 0x500, SP = 0x80006030rommon 1 > confreg 0x2142You
must reset or power cycle for new config to take effectrommon 2 > resetSystem Bootstrap, Version
11.3(2)XA4, RELEASE SOFTWARE (fc1)Copyright (c) 1999 by cisco Systems,
Inc.TAC:Home:SW:IOS:Specials for infoC2600 platform with 32768 Kbytes of main memoryprogram load
complete, entry point: 0x80008000, size: 0x6fdb4cSelf decompressing the image :
#####
#####
##### [OK] Restricted Rights LegendUse,
duplication, or disclosure by the Government issubject to restrictions as set forth in
subparagraph(c) of the Commercial Computer Software - RestrictedRights clause at FAR sec.
52.227-19 and subparagraph(c) (1) (ii) of the Rights in Technical Data and ComputerSoftware
```

```

clause at DFARS sec. 252.227-7013. cisco Systems, Inc. 170 West Tasman Drive San Jose,
California 95134-1706Cisco Internetwork Operating System SoftwareIOS (tm) C2600 Software (C2600-
IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)Copyright (c) 1986-1999 by cisco Systems,
Inc.Compiled Tue 07-Dec-99 02:21 by phanguyeImage text-base: 0x80008088, data-base:
0x80C524F8cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of
memory.Processor board ID JAB031202NK (3878188963)M860 processor: part number 0, mask 49Bridging
software.X.25 software, Version 3.0.0.Basic Rate ISDN software, Version 1.1.2 Ethernet/IEEE
802.3 interface(s)2 Serial(sync/async) network interface(s)1 ISDN Basic Rate interface(s)32K
bytes of non-volatile configuration memory.8192K bytes of processor board System flash partition
1 (Read/Write)8192K bytes of processor board System flash partition 2 (Read/Write) --- System
Configuration Dialog ---Would you like to enter the initial configuration dialog? [yes/no]:
nPress RETURN to get started!00:00:19: %LINK-3-UPDOWN: Interface BRI0/0, changed state to
up00:00:19: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to up00:00:19: %LINK-3-UPDOWN:
Interface Ethernet0/1, changed state to up00:00:19: %LINK-3-UPDOWN: Interface Serial0/0, changed
state to down00:00:19: %LINK-3-UPDOWN: Interface Serial0/1, changed state to down00:00:20:
%LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0, changed state to down00:00:20:
%LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0, changed state to upRouter>00:00:20:
%LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1, changed state to up00:00:20:
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0, changed state to down00:00:20:
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/1, changed state to down00:00:50: %SYS-
5-RESTART: System restarted --Cisco Internetwork Operating System SoftwareIOS (tm) C2600
Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)Copyright (c) 1986-1999 by cisco
Systems, Inc.Compiled Tue 07-Dec-99 02:21 by phanguye00:00:50: %LINK-5-CHANGED: Interface
BRI0/0, changed state to administratively down00:00:52: %LINK-5-CHANGED: Interface Ethernet0/0,
changed state to administratively down00:00:52: %LINK-5-CHANGED: Interface Serial0/0, changed
state to administratively down00:00:52: %LINK-5-CHANGED: Interface Ethernet0/1, changed state to
administratively down00:00:52: %LINK-5-CHANGED: Interface Serial0/1, changed state to
administratively down00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to down00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1,
changed state to downRouter>Router>enableRouter#copy startup-config running-configDestination
filename [running-config]?1324 bytes copied in 2.35 secs (662 bytes/sec)Router#00:01:24:
%LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:1, changed state to down00:01:24:
%LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:2, changed state to downRouter#configure
terminalEnter configuration commands, one per line. End with CNTL/Z.Router(config)#enable secret
< password >Router(config)#^Z00:01:54: %SYS-5-CONFIG_I: Configured from console by
consoleRouter#show ip interface briefInterface IP-Address OK? Method Status
ProtocolEthernet0/0 10.200.40.37 YES TFTP administratively down downSerial0/0
unassigned YES TFTP administratively down downBRI0/0 193.251.121.157 YES
unset administratively down downBRI0/0:1 unassigned YES unset administratively down
administratively down downBRI0/0:2 unassigned YES unset administratively down
downEthernet0/1 unassigned YES TFTP administratively down downSerial0/1
unassigned YES TFTP administratively down downLoopback0 193.251.121.157 YES
TFTP up upRouter#configure terminalEnter configuration commands, one
per line. End with CNTL/Z.Router(config)#interface Ethernet0/0Router(config-if)#no
shutdownRouter(config-if)#00:02:14: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to
up00:02:15: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0, changed state to
upRouter(config-if)#interface BRI0/0Router(config-if)#no shutdownRouter(config-if)#00:02:26:
%LINK-3-UPDOWN: Interface BRI0/0:1, changed state to down00:02:26: %LINK-3-UPDOWN: Interface
BRI0/0:2, changed state to down00:02:26: %LINK-3-UPDOWN: Interface BRI0/0, changed state to
up00:02:115964116991: %ISDN-6-LAYER2UP: Layer 2 for Interface BR0/0, TEI 68 changed to
upRouter(config-if)#^ZRouter#00:02:35: %SYS-5-CONFIG_I: Configured from console by
consoleRouter#copy running-config startup-configDestination filename [startup-config]?Building
configuration...[OK]Router#show versionCisco Internetwork Operating System SoftwareIOS (tm)
C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)Copyright (c) 1986-1999 by
cisco Systems, Inc.Compiled Tue 07-Dec-99 02:21 by phanguyeImage text-base: 0x80008088, data-
base: 0x80C524F8ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)Router uptime
is 3 minutesSystem returned to ROM by abort at PC 0x802D0B60System image file is "flash:c2600-
is-mz.120-7.T" cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of
memory.Processor board ID JAB031202NK (3878188963)M860 processor: part number 0, mask 49Bridging
software.X.25 software, Version 3.0.0.Basic Rate ISDN software, Version 1.1.2 Ethernet/IEEE
802.3 interface(s)2 Serial(sync/async) network interface(s)1 ISDN Basic Rate interface(s)32K
bytes of non-volatile configuration memory.8192K bytes of processor board System flash partition
1 (Read/Write)8192K bytes of processor board System flash partition 2 (Read/Write)Configuration
register is 0x2142Router#configure terminalEnter configuration commands, one per line. End with

```

```
CNTL/Z.Router(config)#config-register 0x2102Router(config)#^Z00:03:20: %SYS-5-CONFIG_I:
Configured from console by consoleRouter#show versionCisco Internetwork Operating System
SoftwareIOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)Copyright
(c) 1986-1999 by cisco Systems, Inc.Compiled Tue 07-Dec-99 02:21 by phanguyeImage text-base:
0x80008088, data-base: 0x80C524F8ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE
(fc1)Router uptime is 3 minutesSystem returned to ROM by abort at PC 0x802D0B60System image file
is "flash:c2600-is-mz.120-7.T"cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K
bytes of memory.Processor board ID JAB031202NK (3878188963)M860 processor: part number 0, mask
49Bridging software.X.25 software, Version 3.0.0.Basic Rate ISDN software, Version 1.1.2
Ethernet/IEEE 802.3 interface(s)2 Serial(sync/async) network interface(s)1 ISDN Basic Rate
interface(s)32K bytes of non-volatile configuration memory.8192K bytes of processor board System
flash partition 1 (Read/Write)8192K bytes of processor board System flash partition 2
(Read/Write)Configuration register is 0x2142 (will be 0x2102 at next reload)Router#
```

## [Informations connexes](#)

- [Procédures de récupération de mot de passe](#)
- [Guide de raccordement de la console et des ports AUX](#)
- [Connexion d'un terminal au port pour console sur les commutateurs Catalyst](#)
- [Connecter un terminal aux commutateurs de la gamme Catalyst 2948G-L3 4908G-L3 et 4840G](#)
- [Combinaisons de touches d'arrêt standard pendant la récupération d'un mot de passe](#)
- [Support technique - Cisco Systems](#)

Ce document était-il utile ? [Oui](#) [aucun](#)

Merci de votre feedback.

[Ouvrez une valise de support](#) (exige un [contrat de service Cisco](#).)

## Cisco relatif prennent en charge des discussions de la Communauté

[Cisco prennent en charge la Communauté](#) est un forum pour que vous posiez et pour répondez à des questions, des suggestions de partage, et collabore avec vos pairs.

Référez-vous au [Conventions relatives aux conseils techniques Cisco](#) pour les informations sur des conventions utilisées dans ce document.

Mis à jour : DEC 14, 2006

ID de document : 12730