

Configuration d'un serveur NTP sur SPA3102

Contenu

[Introduction](#)

[Comment placer le serveur de NTP sur SPA3102 ?](#)

[Informations connexes](#)

[Introduction](#)

Cet article en est un d'une série pour aider à l'installation, au dépannage, et à la maintenance des produits Cisco Small Business.

Q. [Comment placer le serveur de NTP sur SPA3102 ?](#)

R.

Installez un serveur de NTP sur SPA3102

Étape 1 :

Accédez à la page basée sur le WEB d'installation SPA3102. Pour des instructions, cliquez [ici](#).

Étape 2 :

Quand la page basée sur le WEB d'installation paraît, cliquez sur la **procédure de connexion d'admin**.



Étape 3 :

Installation blême de clic, alors avancée.

[Étape 4 :](#)

Sous le **serveur primaire de NTP**, introduisez l'adresse du serveur de NTP sur le champ approprié.

The screenshot shows the Linksys Phone Adapter Configuration interface. At the top left is the Linksys logo and the text "A Division of Cisco Systems, Inc.". The page title is "Linksys Phone Adapter Configuration". There are two yellow callout boxes: one pointing to the "Wan Setup" tab in the navigation menu with the text "Click Wan Setup.", and another pointing to the "advanced" link in the top right with the text "Click advanced.". The navigation menu includes "Status", "Wan Setup", "Lan Setup", and "Application". The "User Login" section has links for "basic" and "advanced". The main content area is titled "Internet Connection Settings" and includes sections for "Connection Type" (set to DHCP), "Static IP Settings", "PPPoE Settings", and "Optional Settings". The "Optional Settings" section has a yellow callout box pointing to the "Primary NTP Server" field with the text "Enter the Primary NTP Server here.".

Étape 5 :

Clic

Informations connexes

- [Support et documentation techniques - Cisco Systems](#)