

Cisco Small Business VoIP ルータのワイヤレス設定の設定

目次

概要

[どのように Cisco 小企業 VoIP ルータのワイヤレス設定を設定できますか。](#)

関連情報

概要

この記事は、Cisco Small Business 製品のセットアップ、トラブルシューティング、およびメンテナンスを支援する一連のドキュメントの 1 つです。

Q. [どのように Cisco 小企業 VoIP ルータのワイヤレス設定を設定できますか。](#)

A.

設定し、無線ネットワークの場合を改良するため、無線ネットワーク名前 (SSID) を変更するためおよび/または別のチャネルを使用することを試みるため。次の手順を実行します。

ルータの SSID を変更し、チャネリングして下さい

ステップ 1:

ルータの Web ベース セットアップ ページにアクセスします。手順については[ここ](#)をクリックしてください。

ステップ 2:

ルータの Web ベース セットアップ ページが開いたら [Wireless] をクリックします。

ステップ 3:

[Wireless Network Name (SSID)] を探します。それが「linksys」にそれでも設定される場合、ユニークな何かにそれを変更して下さい。そして**設定を『SAVE』**をクリックして下さい。

ステップ 4:

SSID を変更した後、チャネルを干渉を回避するために変更することを試みて下さい。使用に理想的なチャネルは、オーバーラップしないチャネルと考えられる、1、6、および 11 です。

The screenshot shows the Linksys web interface. At the top left is the Linksys logo with the text "A Division of Cisco Systems, Inc.". Below the logo is a navigation bar with tabs for "Setup", "Wireless", "Security", "Access Restrictions", "Applications & Gaming", "Administration", "Status", and "Voice". The "Wireless" tab is selected. Below the navigation bar are sub-tabs for "Basic Wireless Settings", "Wireless Security", "Wireless MAC Filter", and "Advanced Wireless Settings". The "Basic Wireless Settings" sub-tab is active, showing a form with the following fields: "Wireless Network Mode" (set to "Disabled"), "Wireless Network Name (SSID)" (set to "linksys"), "Wireless Channel" (set to "1"), and "Wireless SSID Broadcast" (with a "Disable" radio button). Annotations include a yellow box at the top pointing to the "Wireless" tab with the text "Click Wireless.", a yellow box pointing to the SSID field with the text "This is your SSID. If this is set to 'linksys,' change this to something unique.", and a yellow box pointing to the "Wireless Channel" dropdown with the text "Select 1, 6 or 11 then click Save Settings." At the bottom of the page are "Save Settings" and "Cancel Changes" buttons, and the Cisco Systems logo.

ステップ 5 :

をクリックします。 .

関連情報

- [テクニカルサポートとドキュメント - Cisco Systems](#)