



## Auto QoS コマンド

---

- [auto qos classify](#) (2 ページ)
- [auto qos trust](#) (5 ページ)
- [auto qos video](#) (13 ページ)
- [auto qos voip](#) (24 ページ)
- [debug auto qos](#) (38 ページ)
- [show auto qos](#) (39 ページ)

## auto qos classify

QoS ドメイン内で信頼できないデバイスの Quality of Service (QoS) の分類を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos classify** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

**auto qos classify [police]**  
**no auto qos classify [police]**

### 構文の説明

**police** (任意) 信頼できないデバイスの QoS ポリシングを設定します。

### コマンド デフォルト

auto-QoS 分類は、すべてのポートでディセーブルです。

### コマンド モード

インターフェイス コンフィギュレーション

### コマンド履歴

| リリース                            | 変更内容            |
|---------------------------------|-----------------|
| Cisco IOS XE Everest<br>16.5.1a | このコマンドが導入されました。 |

### 使用上のガイドライン

QoS ドメイン内の信頼インターフェイスに QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、デバイス、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。

auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。

auto-QoS は、デバイスが信頼インターフェイスと接続するように設定します。着信パケットの QoS ラベルは信頼されます。非ルーテッドポートの場合は、着信パケットの CoS 値が信頼されます。ルーテッドポートでは、着信パケットの DSCP 値が信頼されます。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できません。



- (注) デバイスは、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、auto-QoS によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、デバイスをリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシーマップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシーマップやポリサーを変更します。生成されたポリシーマップの代わりに新しいポリシーマップを使用するには、生成したポリシーマップをインターフェイスから削除して、新しいポリシーマップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。 **debug auto qos** 特権 EXEC コマンドを使用すると、auto-QoS のデバッグがイネーブルになります。

**auto qos classify** コマンドおよび **auto qos classify police** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ (**auto qos classify police** コマンドの場合) :

- AutoQos-4.0-Classify-Police-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavenger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの auto-QoS をディセーブルにするには、**no auto qos classify** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、auto-QoS によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。auto-QoS をイネーブルにした最後のポートで、**no auto qos classify** コマンドを入力すると、auto-QoS によって生成されたグローバルコンフィギュレーションコマンドが残っている場合でも、auto-QoS はディ

セーブルと見なされます（グローバルコンフィギュレーションによって影響を受ける他のポートでのトラフィックの中断を避けるため）。

#### 例

次の例では、信頼できないデバイスの auto-QoS 分類をイネーブルにし、トラフィックをポリシングする方法を示します。

設定を確認するには、**show auto qos interface *interface-id*** 特権 EXEC コマンドを入力します。

## auto qos trust

QoS ドメイン内の信頼インターフェイスの Quality of Service (QoS) を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos trust** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos trust {cos | dscp}
no auto qos trust {cos | dscp}
```

### 構文の説明

**cos** CoS パケット分類を信頼します。

**dscp** DSCP パケット分類を信頼します。

### コマンド デフォルト

auto-QoS 信頼は、すべてのポートでディセーブルです。

### コマンド モード

インターフェイス コンフィギュレーション

### コマンド履歴

| リリース                            | 変更内容            |
|---------------------------------|-----------------|
| Cisco IOS XE Everest<br>16.5.1a | このコマンドが導入されました。 |

### 使用上のガイドライン

QoS ドメイン内の信頼インターフェイスに QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、デバイス、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。

表 1: トラフィックタイプ、パケットラベル、およびキュー

|                   | VoIP データ<br>トラフィック | VOIP コントロール<br>トラフィック | ルーティングプロ<br>トコ<br>ラフィッ<br>ク | STP <sup>1</sup> BPDU <sup>2</sup> ト<br>ラフィック | リアルタイムビデオ<br>トラフィック | その他すべてのト<br>ラフィック |
|-------------------|--------------------|-----------------------|-----------------------------|---|---------------------|-------------------|
| DSCP <sup>3</sup> | 46                 | 24、26                 | 48                          | 56  | 34                  | –                 |
| CoS <sup>4</sup>  | 5                  | 3                     | 6                           | 7   | 3                   | –                 |

<sup>1</sup> STP = スパニング ツリー プロトコル

<sup>2</sup> BPDU = ブリッジプロトコル データ ユニット

<sup>3</sup> DSCP = DiffServ コードポイント

<sup>4</sup> CoS = サービスクラス



(注) デバイスは、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、**auto-QoS**によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、デバイスをリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

**auto-QoS**をイネーブルにした後、名前に *AutoQoS* を含むポリシーマップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシーマップやポリサーを変更します。生成されたポリシーマップの代わりに新しいポリシーマップを使用するには、生成したポリシーマップをインターフェイスから削除して、新しいポリシーマップを適用します。

**auto-QoS**がイネーブルのときに自動的に生成される QoS の設定を表示するには、**auto-QoS**をイネーブルにする前にデバッグをイネーブルにします。**debug auto qos** 特権 EXEC コマンドを使用すると、**auto-QoS**のデバッグがイネーブルになります。

**auto qos trust cos** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ：

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ：

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

**auto qos trust dscp** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ：

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの auto-QoS をディセーブルにするには、**no auto qos trust** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、auto-QoS によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。auto-QoS をイネーブルにした最後のポートで、**no auto qos trust** コマンドを入力すると、auto-QoS によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、auto-QoS はディセーブルと見なされます (グローバルコンフィギュレーションによって影響を受ける他のポートでのトラフィックの中断を避けるため)。

## 例

次に、特定の CoS 分類を持つ信頼できるインターフェイスの auto-QoS を有効にする方法を示します。

```
Device(config)# interface gigabitethernet1/0/17
Device(config-if)# auto qos trust cos
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/17

Gigabitethernet1/0/17

Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1
```

```
(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
Match: dscp cs4 (32) cs5 (40) ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 3
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10
```



```
Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 25%
  queue-buffers ratio 25
```

次に、特定の DSCP 分類を持つ信頼できるインターフェイスの auto-QoS を有効にする方法を示します。

```
Device(config)# interface gigabitethernet1/0/18
Device(config-if)# auto qos trust dscp
Device(config-if)# end
Device#show policy-map interface gigabitethernet1/0/18
Gigabitethernet1/0/18
```

```
Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
```

```
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
```

```
(bytes output) 0  
bandwidth remaining 25%  
queue-buffers ratio 25
```

設定を確認するには、**show auto qos interface *interface-id*** 特権 EXEC コマンドを入力します。

## auto qos video

QoS ドメイン内のビデオの Quality Of Service (QoS) を自動的に設定するには、インターフェイス コンフィギュレーションモードで **auto qos video** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos video { cts | ip-camera | media-player }
no auto qos video { cts | ip-camera | media-player }
```

### 構文の説明

|                     |   |
|---------------------|---|
| <b>cts</b>          | Cisco TelePresence System に接続されるポートを指定し、自動的にビデオの QoS を設定します。  |
| <b>ip-camera</b>    | Cisco IP カメラに接続されるポートを指定し、自動的にビデオの QoS を設定します。                |
| <b>media-player</b> | Cisco Digital Media Player に接続されるポートを指定し、自動的にビデオの QoS を設定します。 |

### コマンド デフォルト

Auto-QoS ビデオは、ポート上でディセーブルに設定されています。

### コマンド モード

インターフェイス コンフィギュレーション

### コマンド履歴

| リリース                            | 変更内容            |
|---------------------------------|-----------------|
| Cisco IOS XE Everest<br>16.5.1a | このコマンドが導入されました。 |

### 使用上のガイドライン

QoS ドメイン内のビデオトラフィックに適切な QoS を設定するには、このコマンドを使用します。QoS ドメインには、デバイス、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。詳細については、この項の最後にあるキューテーブルを参照してください。

auto-QoS は、Cisco TelePresence システム、Cisco IP カメラ、または Cisco Digital Media Player へのビデオ接続用にデバイスを設定します。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できます。

デバイスは、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、auto-QoS によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コ

ンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、デバイスをリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

これが **auto-QoS** をイネーブルにする最初のポートの場合は、**auto-QoS** によって生成されたグローバルコンフィギュレーションコマンドに続いてインターフェイスコンフィギュレーションコマンドが実行されます。別のポートで **auto-QoS** をイネーブルにすると、そのポートに対して **auto-QoS** によって生成されたインターフェイスコンフィギュレーションコマンドだけが実行されます。

**auto-QoS** をイネーブルにした後、名前に *AutoQoS* を含むポリシーマップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシーマップやポリサーを変更します。生成されたポリシーマップの代わりに新しいポリシーマップを使用するには、生成したポリシーマップをインターフェイスから削除して、新しいポリシーマップを適用します。

**auto-QoS** がイネーブルのときに自動的に生成される QoS の設定を表示するには、**auto-QoS** をイネーブルにする前にデバッグをイネーブルにします。**debug auto qos** 特権 EXEC コマンドを使用すると、**auto-QoS** のデバッグがイネーブルになります。

**auto qos video cts** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ：

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

**auto qos video ip-camera** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ：

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

**auto qos video media-player** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ :

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

ポートの **auto-QoS** をディisableにするには、**no auto qos video** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、**auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。**auto-QoS** をイネーブルにした最後のポートで、**no auto qos video** コマンドを入力すると、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、**auto-QoS** はディisableと見なされます (グローバルコンフィギュレーションによって影響を受ける他のポートでのトラフィックの中断を避けるため)。

表 2: トラフィックタイプ、パケットラベル、およびキュー

|                   | VoIP データ<br>トラフィック | VOIP コントロール<br>トラフィック | ルーティングプロ<br>トコ<br>ルトラ<br>フィッ<br>ク | STP <sup>5</sup> BPDU <sup>6</sup> ト<br>ラフィック | リアルタイムビ<br>デオト<br>ラフィッ<br>ク | その他すべてのト<br>ラフィック |
|-------------------|--------------------|-----------------------|-----------------------------------|---|-----------------------------|-------------------|
| DSCP <sup>7</sup> | 46                 | 24、26                 | 48                                | 56  | 34                          | –                 |
| CoS <sup>8</sup>  | 5                  | 3                     | 6                                 | 7   | 3                           | –                 |

<sup>5</sup> STP = スパニング ツリー プロトコル

<sup>6</sup> BPDU = ブリッジプロトコルデータ ユニット

<sup>7</sup> DSCP = DiffServ コードポイント

<sup>8</sup> CoS = サービスクラス

## 例

次に、**auto qos video cts** コマンドと、適用されるポリシーとクラスマップの例を示します。

```
Device(config)# interface gigabitethernet1/0/12
Device(config-if)# auto qos video cts
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/12
Gigabitethernet1/0/12

Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,
```



```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
```

```

(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次に、**auto qos video ip-camera** コマンドと、適用されるポリシーとクラスマップの例を示します。

```

Device(config)# interface gigabitethernet1/0/9
Device(config-if)# auto qos video ip-camera
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/9

Gigabitethernet1/0/9

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

```

```
queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```
(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

次に、**auto qos video media-player** コマンドと、適用されるポリシーとクラスマップの例を示します。

```
Device(config)# interface gigabitethernet1/0/7
```

```
Device(config-if)# auto qos video media-player
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/7

interface gigabitethernet1/0/7

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
Queueing
priority level 1

(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
Match: dscp cs4 (32) cs5 (40) ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 3
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
```

```
    5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
```

```
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

設定を確認するには、**show auto qos video interface *interface-id*** 特権 EXEC コマンドを入力します。

## auto qos voip

QoS ドメイン内の Voice over IP (VoIP) の Quality of Service (QoS) を自動的に設定するには、インターフェイス コンフィギュレーション モードで **auto qos voip** コマンドを使用します。デフォルト設定に戻すには、このコマンドの **no** 形式を使用します。

```
auto qos voip {cisco-phone | cisco-softphone | trust}
no auto qos voip {cisco-phone | cisco-softphone | trust}
```

### 構文の説明

|                        |   |
|------------------------|---|
| <b>cisco-phone</b>     | Cisco IP Phone に接続されるポートを指定し、自動的にビデオの VoIP を設定します。着信パケットの QoS ラベルが信頼されるのは、IP Phone が検知される場合に限りです。                                       |
| <b>cisco-softphone</b> | Cisco SoftPhone が動作している装置に接続されるポートを指定し、自動的にビデオの VoIP を設定します。  |
| <b>trust</b>           | 信頼できるデバイスに接続されるポートを指定し、自動的にビデオの VoIP を設定します。着信パケットの QoS ラベルは信頼されます。非ルーテッドポートの場合は、着信パケットの CoS 値が信頼されます。ルーテッドポートでは、着信パケットの DSCP 値が信頼されます。 |

### コマンド デフォルト

auto-QoS は、すべてのポートでディセーブルです。

auto-QoS がイネーブルの場合は、入力パケットのラベルを使用して、トラフィックの分類、パケットラベルの割り当て、および入力/出力キューの設定を行います。

### コマンド デフォルト

インターフェイス コンフィギュレーション

### コマンド履歴

| リリース                         | 変更内容            |
|------------------------------|-----------------|
| Cisco IOS XE Everest 16.5.1a | このコマンドが導入されました。 |

### 使用上のガイドライン

QoS ドメイン内の VoIP トラフィックに適切な QoS を設定する場合は、このコマンドを使用します。QoS ドメインには、デバイス、ネットワーク内部、QoS の着信トラフィックを分類することのできるエッジデバイスなどが含まれます。

Auto-QoS は、デバイスとルーテッドポート上の Cisco IP 電話を使用した VoIP と、Cisco SoftPhone アプリケーションが動作する装置に対してデバイスを設定します。これらのリリースは Cisco IP SoftPhone バージョン 1.3(3)以降だけをサポートします。接続される装置は Cisco Call Manager バージョン 4 以降を使用する必要があります。

auto-QoS のデフォルトを利用するには、auto-QoS をイネーブルにしてから、その他の QoS コマンドを設定する必要があります。auto-QoS をイネーブルにした後で、auto-QoS を調整できます。





(注) デバイスは、コマンドラインインターフェイス (CLI) からコマンドが入力された場合と同じように、**auto-QoS**によって生成されたコマンドを適用します。既存のユーザ設定では、生成されたコマンドの適用に失敗することがあります。また、生成されたコマンドで既存の設定が上書きされることもあります。これらのアクションは、警告を表示せずに実行されます。生成されたコマンドがすべて正常に適用された場合、上書きされなかったユーザ入力の設定は実行コンフィギュレーション内に残ります。上書きされたユーザ入力の設定は、現在の設定をメモリに保存せずに、デバイスをリロードすると復元できます。生成されたコマンドの適用に失敗した場合は、前の実行コンフィギュレーションが復元されます。

これが **auto-QoS** をイネーブルにする最初のポートの場合は、**auto-QoS** によって生成されたグローバル コンフィギュレーション コマンドに続いてインターフェイス コンフィギュレーション コマンドが実行されます。別のポートで **auto-QoS** をイネーブルにすると、そのポートに対して **auto-QoS** によって生成されたインターフェイス コンフィギュレーション コマンドだけが実行されます。

Cisco IP 電話に接続されたネットワークエッジのポートで **auto qos voip cisco-phone** インターフェイス コンフィギュレーション コマンドを入力すると、デバイスにより信頼境界の機能が有効になります。デバイスは、Cisco Discovery Protocol (CDP) を使用して、Cisco IP 電話の存在を検出します。Cisco IP Phone が検出されると、ポートの入力分類は、パケットで受け取った QoS ラベルを信頼するように設定されます。また、デバイスはポリシングを使用してパケットがプロファイル内か、プロファイル外かを判断し、パケットに対するアクションを指定します。パケットに 24、26、または 46 という DSCP 値がない場合、またはパケットがプロファイル外にある場合、デバイスは DSCP 値を 0 に変更します。Cisco IP Phone が存在しない場合、ポートの入力分類は、パケットで受け取った QoS ラベルを信頼しないように設定されます。ポリシングがポリシーマップ分類と一致したトラフィックに適用された後で、デバイスが信頼境界の機能をイネーブルにします。

- Cisco SoftPhone が動作するデバイスに接続されたネットワークエッジにあるポートに **auto qos voip cisco-softphone** インターフェイス コンフィギュレーション コマンドを入力した場合、デバイスはポリシングを使用してパケットがプロファイル内かプロファイル外かを判断し、パケットに対するアクションを指定します。パケットに 24、26、または 46 という DSCP 値がない場合、またはパケットがプロファイル外にある場合、デバイスは DSCP 値を 0 に変更します。
- ネットワーク内部に接続されたポート上で **auto qos voip trust** インターフェイス コンフィギュレーション コマンドを入力すると、非ルーテッドポートの場合は入力パケット内の CoS 値、ルーテッドポートの場合は入力パケット内の DSCP 値がデバイスで信頼されます (前提条件は、トラフィックがすでに他のエッジデバイスによって分類されていることです)。

スタティックポート、ダイナミックアクセスポート、音声 VLAN アクセスポート、およびトランクポートで **auto-QoS** をイネーブルにすることができます。ルーテッドポートで Cisco IP Phone の自動 QoS を有効にすると、スタティック IP アドレスを IP Phone に割り当てます。



(注) Cisco SoftPhone が稼働するデバイスがデバイスまたはルーテッドポートに接続されている場合、デバイスはポートごとに1つの Cisco SoftPhone アプリケーションだけをサポートします。

auto-QoS をイネーブルにした後、名前に *AutoQoS* を含むポリシーマップや集約ポリサーを変更しないでください。ポリシーマップや集約ポリサーを変更する必要がある場合、そのコピーを作成し、コピーしたポリシーマップやポリサーを変更します。生成されたポリシーマップの代わりに新しいポリシーマップを使用するには、生成したポリシーマップをインターフェイスから削除して、新しいポリシーマップを適用します。

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。 **debug auto qos** 特権 EXEC コマンドを使用すると、auto-QoS のデバッグがイネーブルになります。

**auto qos voip trust** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ :

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

**auto qos voip cisco-softphone** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ :

- AutoQos-4.0-CiscoSoftPhone-Input-Policy
- AutoQos-4.0-Output-Policy

クラスマップ :

- AutoQos-4.0-Voip-Data-Class (match-any)

- AutoQos-4.0-Voip-Signal-Class (match-any)
- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavenger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

**auto qos voip cisco-phone** コマンドを実行する場合、次のポリシーマップおよびクラスマップが作成され、適用されます。

ポリシーマップ :

- service-policy input AutoQos-4.0-CiscoPhone-Input-Policy
- service-policy output AutoQos-4.0-Output-Policy

クラスマップ :

- class AutoQos-4.0-Voip-Data-CiscoPhone-Class
- class AutoQos-4.0-Voip-Signal-CiscoPhone-Class
- class AutoQos-4.0-Default-Class

ポートの auto-QoS をディセーブルにするには、**no auto qos voip** インターフェイス コンフィギュレーション コマンドを使用します。このポートに対して、auto-QoS によって生成されたインターフェイス コンフィギュレーション コマンドだけが削除されます。auto-QoS をイネーブルにした最後のポートで、**no auto qos voip** コマンドを入力すると、auto-QoS によって生成されたグローバル コンフィギュレーション コマンドが残っている場合でも、auto-QoS はディセーブルと見なされます (グローバル コンフィギュレーション によって影響を受ける他のポートでのトラフィックの中断を避けるため)。

デバイスは、このテーブルの設定にしたがってポートの出力キューを設定します。

表 3: 出力キューに対する *auto-QoS* の設定

| 出力キュー           | キュー番号 | CoS からキューへのマッピング | キュー ウェイト (帯域幅) | ギガビット対応ポートのキュー (バッファ) サイズ | 10/100イーサネットポートのキュー (バッファ) サイズ |
|-----------------|-------|------------------|----------------|---------------------------|--------------------------------|
| プライオリティ (シェイプド) | 1     | 4、5              | 最大 100%        | 25%                       | 15%                            |
| SRR 共有          | 2     | 2、3、6、7          | 10%            | 25%                       | 25%                            |
| SRR 共有          | 3     | 0                | 60%            | 25%                       | 40%                            |
| SRR 共有          | 4     | 1                | 20%            | 25%                       | 20%                            |

例

次に、**auto qos voip trust** コマンドと、適用されるポリシーとクラスマップの例を示します。

```
Device(config)# interface gigabitethernet1/0/31
Device(config-if)# auto qos voip trust
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/31

Gigabitethernet1/0/31

Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,
```

```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 3
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
```

```

(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次に、**auto qos voip cisco-phone** コマンドと、適用されるポリシーとクラスマップの例を示します。

```

Device(config)# interface gigabitethernet1/0/5
Device(config-if)# auto qos voip cisco-phone
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/5

Gigabitethernet1/0/5

Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
 0 packets
Match: cos 5
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
 dscp ef
police:
  cir 128000 bps, bc 8000 bytes
  conformed 0 bytes; actions:

```

```
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
  0 packets
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
  police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
```



```

(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

次に、**auto qos voip cisco-softphone** コマンドと、適用されるポリシーとクラスマップの例を示します。

```

Device(config)# interface gigabitethernet1/0/20
Device(config-if)# auto qos voip cisco-softphone
Device(config-if)# end
Device# show policy-map interface gigabitethernet1/0/20

```

#### **Gigabitethernet1/0/20**

```
Service-policy input: AutoQos-4.0-CiscoSoftPhone-Input-Policy
```

```

Class-map: AutoQos-4.0-Voip-Data-Class (match-any)
 0 packets
Match: dscp ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp ef
police:
  cir 128000 bps, bc 8000 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    set-dscp-transmit dscp table policed-dscp
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-Class (match-any)
 0 packets
Match: dscp cs3 (24)
 0 packets, 0 bytes

```

```
    5 minute rate 0 bps
Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp cs3
police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Multimedia-Conf-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-MultiEnhanced-Conf
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af41
police:
    cir 5000000 bps, bc 156250 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Bulk-Data-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Bulk-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af11
police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Transaction-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Transactional-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
QoS Set
    dscp af21
police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Scavenger-Class (match-any)
    0 packets
Match: access-group name AutoQos-4.0-Acl-Scavenger
    0 packets, 0 bytes
    5 minute rate 0 bps
```

```
QoS Set
  dscp cs1
  police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Signaling-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Signaling
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
    police:
      cir 32000 bps, bc 8000 bytes
      conformed 0 bytes; actions:
        transmit
      exceeded 0 bytes; actions:
        drop
      conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default
    police:
      cir 10000000 bps, bc 312500 bytes
      conformed 0 bytes; actions:
        transmit
      exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
      conformed 0000 bps, exceed 0000 bps

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,
```

```
Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
```

```
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```

設定を確認するには、**show auto qos interface *interface-id*** 特権 EXEC コマンドを入力します。

## debug auto qos

Automatic Quality of Service (auto-QoS; 自動 QoS) 機能のデバッグをイネーブルにするには、特権 EXEC モードで **debug auto qos** コマンドを使用します。デバッグをディセーブルにする場合は、このコマンドの **no** 形式を使用します。

**debug auto qos**  
**no debug auto qos**

### 構文の説明

このコマンドには引数またはキーワードはありません。

### コマンド デフォルト

auto-QoS デバッグはディセーブルです。

### コマンド モード

特権 EXEC

### コマンド履歴

| リリース                         | 変更内容            |
|------------------------------|-----------------|
| Cisco IOS XE Everest 16.5.1a | このコマンドが導入されました。 |

### 使用上のガイドライン

auto-QoS がイネーブルのときに自動的に生成される QoS の設定を表示するには、auto-QoS をイネーブルにする前にデバッグをイネーブルにします。デバッグをイネーブルにするには、**debug auto qos** 特権 EXEC コマンドを入力します。

**undebug auto qos** コマンドは **no debug auto qos** コマンドと同じです。

ある device スタック上でデバッグをイネーブルにした場合、アクティブ device でのみイネーブルになります。スタック メンバのデバッグをイネーブルにする場合は、**session switch-number** 特権 EXEC コマンドでアクティブ device からセッションを開始してください。次に、スタック メンバのコマンドラインプロンプトで **debug** コマンドを入力します。最初にセッションを開始せずにメンバ device のデバッグをイネーブルにするには、アクティブ device 上で **remote command stack-member-number LINE** 特権 EXEC コマンドを使用することもできます。

### 例

次の例では、auto-QoS がイネーブルの場合に自動的に生成される QoS 設定を表示する方法を示します。

```

デバイス# debug auto qos
AutoQoS debugging is on
デバイス# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
デバイス(config)# interface gigabitethernet2/0/1
デバイス(config-if)# auto qos voip cisco-phone

```

## show auto qos

automatic QoS (auto-QoS) が有効になっているインターフェイスに入力された Quality of Service (QoS) コマンドを表示するには、特権 EXEC モードで **show auto qos** コマンドを使用します。

**show auto qos** [**interface** *interface-id*]

|         |                                      |   |
|---------|--------------------------------------|---|
| 構文の説明   | <b>interface</b> <i>interface-id</i> | (任意) 指定されたポートまたはすべてのポートの auto-QoS 情報を表示します。有効なインターフェイスには、物理ポートが含まれます。 |
| コマンドモード | ユーザ EXEC<br>特権 EXEC                  |   |
| コマンド履歴  | リリース                                 | 変更内容  |
|         | Cisco IOS XE Everest 16.5.1a         | このコマンドが導入されました。   |

**show auto qos** コマンド出力には、各インターフェイスに入力された **auto qos** コマンドだけが表示されます。**show auto qos interface interface-id** コマンド出力には、特定のインターフェイス上に入力された **auto qos** コマンドが表示されます。

auto-QoS 設定およびユーザ変更を表示する場合は、**show running-config** 特権 EXEC コマンドを使用します。

### 例

次の例では、**auto qos voip cisco-phone** および **auto qos voip cisco-softphone** インターフェイス コンフィギュレーション コマンドを入力した場合の **show auto qos** コマンドの出力を示します。

```
Device# show auto qos
GigabitEthernet 2/0/4
auto qos voip cisco-softphone
```

```
GigabitEthernet 2/0/5
auto qos voip cisco-phone
```

```
GigabitEthernet 2/0/6
auto qos voip cisco-phone
```

次に、**auto qos voip cisco-phone** インターフェイス コンフィギュレーション コマンドが入力された場合の **show auto qos interface interface-id** コマンドの出力例を示します。

```
Device# show auto qos interface GigabitEthernet 2/0/5
GigabitEthernet 2/0/5
auto qos voip cisco-phone
```

次の例では、auto-QoS がインターフェイスでディセーブルになっている場合の **show auto qos interface *interface-id*** コマンドの出力を示します。

```
Device# show auto qos interface GigabitEthernet 3/0/1
AutoQoS is disabled
```