



SEM 障害 Cisco UCS Manager

• [Cisco UCS の障害 \(1 ページ\)](#)

Cisco UCS の障害

fltFabricComputeSlotEpMisplacedInChassisSlot

障害コード : F0156

Message: Server, vendor([vendor]), model([model]), serial([serial]) in slot [chassisId]/[slotId] presence: [presence]

説明 :

通常、この障害は、シャーシスロット内のサーバが以前にスロットに搭載されていたものと一致していないことが Cisco UCS Manager によって検出された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 以前のサーバが意図的に取り外され、新しいサーバが取り付けられている場合は、サーバを再認識します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: server-moved
mibFaultCode: F0156
mibFaultName: fltFabricComputeSlotEpMisplacedInChassisSlot
moClass: fabric:ComputeSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]
```

fltFabricComputeSlotEpServerIdentificationProblem

障害コード : F0157

Message: Problem identifying server in slot [chassisId]/[slotId]

説明 :

通常、この障害は、シャーシスロット内のサーバの識別で Cisco UCS Manager に問題が発生した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバをいったん取り外し、取り付け直します。
2. サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: server-identification-problem
mibFaultCode: F0157
mibFaultName: fltFabricComputeSlotEpServerIdentificationProblem
moClass: fabric:ComputeSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]
```

fltVnicEtherConfig-failed

障害コード : F0169

Message: Eth vNIC [name], service profile [name] failed to apply configuration

説明 :

通常、この障害は、Cisco UCS Manager が vCon に vNIC を配置できなかった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバが正常に検出されたことを確認します。
2. 正しいタイプのアダプタがサーバにインストールされていることを確認します。
3. vCon の割り当てが正しいことを確認します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: minor
Cause: configuration-failed
mibFaultCode: F0169
mibFaultName: fltVnicEtherConfigFailed
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]

```

fltVnicFcConfig-failed

障害コード : F0170

Message: FC vHBA [name], service profile [name] failed to apply configuration

説明 :

通常、この障害は、Cisco UCS Manager が vCon に vHBA を配置できなかった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバが正常に検出されたことを確認します。
2. 正しいタイプのアダプタがサーバにインストールされていることを確認します。
3. vCon の割り当てが正しいことを確認します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: minor
Cause: configuration-failed
mibFaultCode: F0170
mibFaultName: fltVnicFcConfigFailed
moClass: vnic:Fc
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/fc-[name]
Affected MO: org-[name]/san-conn-pol-[name]/fc-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/fc-[name]

```

fltProcessorUnitInoperable

障害コード : F0174

Message: Processor [id] on server [chassisId]/[slotId] operability: [operability]Processor [id] on rack server [id] operability: [operability]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] operability: [operability]

説明 :

この障害は、プロセッサが動作不能になっているという、まれなイベントで発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 障害がブレードサーバのプロセッサに発生する場合は、サーバをシャーンからいったん取り外して取り付け直します。
2. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0174
mibFaultName: fltProcessorUnitInoperable
moClass: processor:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitThermalNonCritical

障害コード：F0175

Message: Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明：

この障害は、ブレードまたはラックサーバのプロセッサの温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。

2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: info
Cause: thermal-problem
mibFaultCode: F0175
mibFaultName:fltProcessorUnitThermalNonCritical
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitThermalThresholdCritical

障害コード : F0176

Message: Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラックサーバのプロセッサの温度が重大しきい値を超えている場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0176
mibFaultName: fltProcessorUnitThermalThresholdCritical
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitThermalThresholdNonRecoverable

障害コード：F0177

Message: Processor [id] on server [chassisId]/[slotId] temperature: [thermal]Processor [id] on server [id] temperature: [thermal]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明：

この障害は、ブレードまたはラックサーバのプロセッサの温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0177
mibFaultName:fltProcessorUnitThermalThresholdNonRecoverable
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitVoltageThresholdNonCritical

障害コード：F0178

Message: Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id]
voltage: [voltage]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明 :

この障害は、プロセッサの電圧が正常な動作範囲外にあるが、危険な段階にはまだ到達していない場合に発生します。通常、プロセッサはそれ自体でこの状況から回復します

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. これ以上の低下がないかどうかプロセッサをモニタします。
2. 障害がブレードサーバのプロセッサに発生する場合は、サーバをシャーシからいったん取り外して取り付け直します。
3. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: voltage-problem
mibFaultCode: F0178
mibFaultName: fltProcessorUnitVoltageThresholdNonCritical
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitVoltageThresholdCritical

障害コード : F0179

Message: Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id]
voltage: [voltage]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明 :

この障害は、プロセッサの電圧が指定したハードウェアの電圧定格を超えた場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害がブレードサーバのプロセッサに発生する場合は、サーバをシャーシからいったん取り外して取り付け直します。
2. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: voltage-problem
mibFaultCode: F0179
mibFaultName: fltProcessorUnitVoltageThresholdCritical
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltProcessorUnitVoltageThresholdNonRecoverable

障害コード : F0180

Message: Processor [id] on server [chassisId]/[slotId] voltage: [voltage]Processor [id] on server [id] voltage: [voltage]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明 :

この障害は、プロセッサの電圧が指定したハードウェアの電圧定格を超過し、プロセッサのハードウェアが損傷するか危険な状態になる可能性がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害がブレードサーバのプロセッサに発生する場合は、サーバをシャーシからいったん取り外して取り付け直します。
2. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: voltage-problem
mibFaultCode: F0180
mibFaultName: fltProcessorUnitVoltageThresholdNonRecoverable
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltStorageLocalDiskInoperable

障害コード : F0181

Message: Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on storage enclosure [id] operability: [operability]. Reason:

[operQualifierReason]Local disk [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

この障害は、ローカル ディスクが動作不能になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サポートされているスロットにディスクを挿入します。
2. ローカル ディスクをいったん取り外し、もう一度差し込みます。
3. 別のディスクがある場合は、ディスクを交換します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0181
mibFaultName: fltStorageLocalDiskInoperable
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltStorageItemCapacityExceeded

障害コード : F0182

Message: Disk usage for partition [name] on fabric interconnect [id] exceeded 70%

説明 :

この障害は、パーティションのディスク使用率が 70 % を超えているが 90 % 未満である場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 未使用のファイルと不要なファイルを削除して、パーティションのディスク使用率を 70% 未満に減らします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: capacity-exceeded
mibFaultCode: F0182
mibFaultName: fltStorageItemCapacityExceeded
moClass: storage:Item
Type: environmental
autoCleared: true
Affected MO: sys/switch-[id]/stor-part-[name]
```

fltStorageItemCapacityWarning

障害コード : F0183

Message: Disk usage for partition [name] on fabric interconnect [id] exceeded 90%

説明 :

この障害は、パーティションのディスク使用率が 90 % を超えている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 未使用のファイルと不要なファイルを削除して、パーティションのディスク使用率を 90% 未満に減らします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: capacity-exceeded
mibFaultCode: F0183
mibFaultName: fltStorageItemCapacityWarning
moClass: storage:Item
Type: environmental
autoCleared: true
Affected MO: sys/switch-[id]/stor-part-[name]
```

fltMemoryUnitDegraded

障害コード : F0184

Message: DIMM [location] on server [chassisId]/[slotId] operability: [operability]DIMM [location] on server [id] operability: [operability]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] operability: [operability]

説明 :

この障害は、DIMM が縮退運転状態である場合に発生します。通常、この状態は、DIMM での過剰な数の修正可能な ECC エラーが、サーバ BIOS によって報告されている場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager を使用して、縮退した DIMM のエラー統計情報をモニタします。相当数のエラーが解決しなかった場合は、DIMM が動作不能になっている可能性が高いです。
2. DIMM が動作不能になっている場合は、DIMM を交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: F0184
mibFaultName: fltMemoryUnitDegraded
moClass: memory:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryUnitInoperable

障害コード：F0185

Message: DIMM [location] on server [chassisId]/[slotId] operability: [operability]DIMM [location] on server [id] operability: [operability]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] operability: [operability]

説明：

通常、この障害は、しきい値を超える数の修正可能または修正不可能なエラーが DIMM で発生したために発生します。DIMM は動作不能になっている場合があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. SEL がイネーブルの場合は、DIMM の SEL 統計情報を確認して、しきい値を超えたかを判断します。
2. 必要な場合は、DIMM を交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: F0185
mibFaultName: fltMemoryUnitInoperable
moClass: memory:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]

```

fltMemoryUnitThermalThresholdNonCritical

障害コード : F0186

Message: DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラック サーバのメモリ装置の温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的 to 実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。

7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: info
Cause: thermal-problem
mibFaultCode: F0186
mibFaultName: fltMemoryUnitThermalThresholdNonCritical
moClass: memory:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryUnitThermalThresholdCritical

障害コード : F0187

Message: DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラックサーバのメモリ装置の温度が重大しきい値を超えている場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。

3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0187
mibFaultName: fltMemoryUnitThermalThresholdCritical
moClass: memory:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryUnitThermalThresholdNonRecoverable

障害コード : F0188

Message: DIMM [location] on server [chassisId]/[slotId] temperature: [thermal]DIMM [location] on server [id] temperature: [thermal]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラック サーバのメモリ装置の温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の要因が関係している可能性があることに注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0188
mibFaultName: fltMemoryUnitThermalThresholdNonRecoverable
moClass: memory:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltMemoryArrayVoltageThresholdNonCritical

障害コード：F0189

Message: Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id] voltage: [voltage]Memory array [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明：

この障害は、メモリアレイの電圧が正常な動作範囲外にあるが、危険な段階にはまだ到達していない場合に発生します。通常、メモリアレイはそれ自体でこの状況から回復します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. SEL がイネーブルの場合は、DIMM の SEL 統計情報を確認して、しきい値を超えたかを判断します。
2. メモリ アレイをモニタして、さらに低下するかを確認します。
3. 障害がブレード サーバのメモリ アレイに発生する場合は、いったんブレードを取り外して、シャーシに取り付け直します。
4. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
5. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: voltage-problem
mibFaultCode: F0189
mibFaultName: fltMemoryArrayVoltageThresholdNonCritical
moClass: memory:Array
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]
```

fltMemoryArrayVoltageThresholdCritical

障害コード : F0190

Message: Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id] voltage: [voltage]Memory array [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明 :

この障害は、メモリアレイの電圧が指定したハードウェアの電圧定格を超えた場合に発生します

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SEL がイネーブルの場合は、DIMM の SEL 統計情報を確認して、しきい値を超えたかを判断します。
2. メモリ アレイをモニタして、さらに低下するかを確認します。
3. 障害がブレード サーバのメモリ アレイに発生する場合は、いったんブレードを取り外して、シャーシに取り付け直します。
4. Cisco UCS Manager で、いったんサーバを停止し、再始動します。
5. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: voltage-problem
mibFaultCode: F0190
mibFaultName: fltMemoryArrayVoltageThresholdCritical
moClass: memory:Array
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]
```

fltMemoryArrayVoltageThresholdNonRecoverable

障害コード : F0191

Message: Memory array [id] on server [chassisId]/[slotId] voltage: [voltage]Memory array [id] on server [id] voltage: [voltage]Memory array [id] on server [chassisId]/[slotId]/[serverInstanceId] voltage: [voltage]

説明 :

この障害は、メモリアレイの電圧が指定したハードウェアの電圧定格を超過し、メモリのハードウェアが損傷するか危険な状態になる可能性がある場合に発生します

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SEL がイネーブルの場合は、DIMM の SEL 統計情報を確認して、しきい値を超えたかを判断します。
2. メモリアレイをモニタして、さらに低下するかを確認します。
3. ブレードサーバのメモリアレイで障害が発生している場合は、サーバをシャーシから取り外し、取り付け直します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: voltage-problem
mibFaultCode: F0191
mibFaultName: fltMemoryArrayVoltageThresholdNonRecoverable
moClass: memory:Array
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]
```

fltAdaptorUnitUnidentifiable-fru

障害コード : F0200

Message: Adapter [id] in server [id] has unidentified FRU.Adapter [id] in server [chassisId]/[slotId] has unidentified FRU.Adapter [id] in server [chassisId]/[slotId]/[serverInstanceId] has unidentified FRU

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないアダプタを検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サポートされているアダプタが取り付けられていることを確認します。
2. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: major
Cause: unidentifiable-fru
mibFaultCode: F0200
mibFaultName: fltAdaptorUnitUnidentifiableFru
moClass: adaptor:Unit
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]

fltAdaptorUnitMissing

障害コード : F0203

Message: Adapter [id] in server [id] presence: [presence]Adapter [id] in server [chassisId]/[slotId] presence: [presence]Adapter [id] in server [chassisId]/[slotId]/[serverInstanceId] presence: [presence]

説明 :

アダプタが欠落しています。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害を発生します。

- エンドポイントによって、アダプタ スロットにアダプタがないことが報告されている。
- エンドポイントで、アダプタ スロット内のアダプタを検出できないか、これと通信できない。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタがサーバのアダプタ スロットに取り付けられていることを確認します。
2. アダプタが正しく接続および設定され、推奨ファームウェアバージョンが実行されていることを確認します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F0203
mibFaultName: fltAdaptorUnitMissing
moClass: adaptor:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltAdaptorUnitAdaptorReachability

障害コード : F0206

Message: Adapter [id]/[id] is unreachableAdapter [chassisId]/[slotId]/[id] is unreachable

説明 :

Cisco UCS Manager は、接続が検出されない adapterwhose にはアクセスできません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバに十分な電力が供給されていない。
- I/O モジュールが機能していない。
- アダプタのファームウェアが失敗した。
- アダプタが機能していない

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で **show post** コマンドを使用すると POST の結果にアクセスできます。
2. Cisco UCS Manager で、サーバの電源の状態をチェックします。
3. 物理サーバの電源の状態が同じであることを確認します。
4. サーバがオフの場合は、サーバをオンにします。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: info
Cause: connectivity-problem
mibFaultCode: F0206
mibFaultName: fltAdaptorUnitAdaptorReachability
moClass: adaptor:Unit
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltAdaptorHostIfLink-down

障害コード : F0207

Message: Adapter [transport] host interface [id]/[id]/[id] link state: [linkState]Adapter [transport] host interface [chassisId]/[slotId]/[id]/[id] link state: [linkState]Adapter [transport] host interface [chassisId]/[slotId]/[serverInstanceId] link state: [linkState]

説明 :

通常、この障害は、次のいずれかの問題の結果として発生します。

- ファブリックインターコネクトがエンドホストモードであり、すべてのアップリンクポートに障害が発生している。
- アダプタが固定されているサーバポートに障害が発生している。
- 一時的なエラーによりリンクに障害が発生している。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 関連するポートがディセーブルの場合は、そのポートをイネーブルにします。
2. 障害が発生したリンクを持つアダプタをサーバに再認識させます。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: link-down
mibFaultCode: F0207
mibFaultName: fltAdaptorHostIfLinkDown
moClass: adaptor:HostIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]
Affected MO:
```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]

```

fltAdaptorExtIfLink-down

障害コード : F0209

Message: Adapter uplink interface [id]/[id]/[id] link state: [linkState]. Please verify connectivity to Fabric Interconnect. Acknowledging FEX might be required. Adapter uplink interface [chassisId]/[slotId]/[id]/[id] link state: [linkState]. Please verify connectivity to Fabric Interconnect. Acknowledging chassis might be required.

説明 :

ネットワーク側アダプタ インターフェイスへのリンクがダウンしています。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害を発生します。

- Cisco UCS Manager で、ファブリック インターコネクトのいずれかへのアダプタの接続を確立または検証できない。
- エンドポイントによって、アダプタ リnkのリンク ダウンまたは vNIC ダウン イベントが報告されている。
- エンドポイントで、アダプタ リnkのエラー リnk状態またはエラー vNIC 状態イベントが報告されている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタが正しく接続および設定され、推奨ファームウェアバージョンが実行されていることを確認します。
2. サーバが検出でスタックしている場合は、サーバを停止し、サーバのスロットを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: link-down
mibFaultCode: F0209
mibFaultName: fltAdaptorExtIfLinkDown

```

```

moClass: adaptor:ExtIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]

```

fltPortPIoLink-down

障害コード : F0276

Message: [transport] port [portId] on chassis [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

説明 :

この障害は、ファブリック インターコネクト ポートがリンクダウン状態になっている場合に発生します。この状態は、ポート宛のトラフィックに影響を与えます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 物理リンクがファブリック インターコネクトとピア コンポーネント間で適切に接続されていることを確認します。
2. ピア エンティティが正しく設定され、ファブリック インターコネクト ポートの設定と一致していることを確認します。
3. ポートの設定を解除し、再設定します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: major
Cause: link-down
mibFaultCode: F0276
mibFaultName: fltPortPIoLinkDown
moClass: port:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]

```

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

fltPortPioFailed

障害コード : F0277

Message: [transport] port [portId] on chassis [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

説明 :

この障害は、ユーザがポートを有効にしている、既知のハードウェア障害または SFP の欠落という問題はなく、ポートライセンスは有効になっているのでポートが作動するはずが、作動せず、ポートに障害が発生している状態であると UCSM が検出した場合、IOM または FEX モジュールのファブリック インターコネクト ポートとサーバ側ポートに発生します。追加の原因が、障害の説明の文字列で表示されます。

推奨処置 :

この障害が発生した場合は、このような原因が表示されるたびに障害の説明の原因情報に基づいて是正措置が実行されます。障害の説明に「ENM source pinning failed」のような原因が表示された場合、ファブリック インターコネクトがエンドホスト ノードモードで動作していて、サーバ側ポートがピン接続しているアップリンク ポートがダウンしている、またはこのアップリンク ポートに適切な VLAN が設定されていないことを意味します。アプライアンス ポートにこのような障害が発生した場合、アップリンク ポートの VLAN 設定をチェックします。アプライアンス ポートのものと同じ ID を使用する VLAN は、アップリンク ポートにも設定する必要があります。正しく設定した後にこの障害が発生した場合は、Cisco UCS Manager とシャーシまたは FEX モジュールに **show tech-support** ファイルを作成して、Cisco TAC に連絡してください。

障害の詳細

Severity: major
Cause: port-failed
mibFaultCode: F0277
mibFaultName: fltPortPioFailed
moClass: port:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

fltPortPIoHardware-failure

障害コード : F0278

Message: [transport] port [portId] on chassis [id] oper state: [operState], reason: hardware-failure[transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState], reason: hardware-failure[transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState], reason: hardware-failure

説明 :

この障害は、IOM または FEX モジュールのファブリック インターコネクト ポートとサーバ側ポートで、システムがハードウェア障害を検出した場合に発生します。

推奨処置 :

この障害が発生した場合は、Cisco UCS Manager およびシャーシまたは FEX モジュールに対する **show tech-support** ファイルを作成して、Cisco TAC に連絡してください。

障害の詳細

```
Severity: major
Cause: port-failed
mibFaultCode: F0278
mibFaultName: fltPortPIoHardwareFailure
moClass: port:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltPortPIoSfp-not-present

障害コード : F0279

Message: [transport] port [portId] on chassis [id] oper state: [operState][transport] port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] oper state: [operState][transport] port [slotId]/[portId] on fabric interconnect [id] oper state: [operState]

説明 :

ファブリック インターコネクト ポートが未設定状態にある場合、その操作には SFP が必要です。この障害は、設定されているポートに SFP が欠落していることを示すために発生します。

推奨処置 :

この障害が発生した場合は、ファブリック インターコネクトのポートにサポート対象の SFP を挿入します。サポート対象の SFP のリストは、www.Cisco.com で参照できます。

障害の詳細

```
Severity: info
Cause: port-failed
mibFaultCode: F0279
mibFaultName: fltPortPIoSfpNotPresent
moClass: port:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltFabricExternalPcDown

障害コード : F0282

Message: [type] port-channel [portId] on fabric interconnect [switchId] oper state: [operState], reason: [stateQual][type] port-channel [portId] on fabric interconnect [switchId] oper state: [operState], reason: [stateQual][type] port-channel [portId] on fabric interconnect [switchId] oper state: [operState], reason: [stateQual]

説明 :

通常、この障害は、ファブリック ポート チャンネルが動作上ダウンしていることをファブリック インターコネクトが報告している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファブリック ポート チャンネルのメンバー ポートの管理がアップ状態になっており、動作していることを確認します。各ポートでリンク接続を確認します。
2. 接続は正しいと思われる場合は、ポート チャンネル メンバーのピア スイッチ ポートの動作状態を確認します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: operational-state-down
mibFaultCode: F0282
mibFaultName: fltFabricExternalPcDown
moClass: fabric:ExternalPc
Type: network
```

```

autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]
Affected MO: fabric/eth-estc/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/fc-estc/[id]/net-[name]/fcoe-pc-switch-[switchId]-fcoe-pc-[portId]
Affected MO: fabric/fc-estc/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/fc-estc/net-[name]/fcoe-pc-switch-[switchId]-fcoe-pc-[portId]
Affected MO: fabric/fc-estc/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/net-group-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]
Affected MO: fabric/lan/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/lan/net-group-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/san/[id]/fcoe-san-pc-[portId]
Affected MO: fabric/san/[id]/net-[name]/fcoe-pc-switch-[switchId]-fcoe-pc-[portId]
Affected MO: fabric/san/[id]/net-[name]/pc-switch-[switchId]-pc-[portId]
Affected MO: fabric/san/[id]/pc-[portId]
Affected MO: fabric/san/net-[name]/fcoe-pc-switch-[switchId]-fcoe-pc-[portId]
Affected MO: fabric/san/net-[name]/pc-switch-[switchId]-pc-[portId]

```

fltDcxVcDown

障害コード : F0283

Message: [transport] VIF [id] on server [chassisId] / [slotId] of switch [switchId] down, reason: [stateQual][transport] VIF [id] on server [id] of switch [switchId] down, reason: [stateQual][transport] VIF [id] on server [chassisId]/[slotId]/[serverInstanceId] of switch [switchId] down, reason: [stateQual]

説明 :

通常、この障害は、仮想インターフェイスの次のいずれかの接続状態がファブリックインターコネクトによって報告された場合に発生します。

- ダウン
- エラー
- 使用不可

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップリンクの物理インターフェイスがアップ状態になっていることを確認します。
2. vNIC/vHBA がピン グループ用に設定されている場合は、ピン グループ ターゲットが正しく設定されていることを確認します。
3. vNIC のネットワーク制御ポリシーで、[Action on Uplink Fail] フィールドが [warning] に設定されていることを確認します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: link-down

```

mibFaultCode: F0283
mibFaultName: fltDcxVcDown
moClass: dcx:Vc
Type: network
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]

```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/switch-[id]/ethlanflowmon/vc-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vc-[id]

fltNetworkElementInoperable

障害コード : F0291

Message: Fabric Interconnect [id] operability: [operability]

説明 :

通常、この障害は、ファブリック インターコネクトのメンバーシップ状態がダウンになっているためにファブリック インターコネクトが動作不能であることを、ファブリック インターコネクトのクラスタ コントローラが報告している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. クラスタの両方のファブリック インターコネクトが同じカーネルおよびシステム ソフトウェア バージョンを実行していることを確認します。
2. ファブリック インターコネクトのソフトウェア バージョンと Cisco UCS Manager のソフトウェア バージョンが同じであることを確認します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: critical
Cause: equipment-inoperable
mibFaultCode: F0291
mibFaultName: fltNetworkElementInoperable
moClass: network:Element
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]

fltMgmtEntityDegraded

障害コード : F0293

Message: Fabric Interconnect [id], HA Cluster interconnect link failure

説明 :

この障害は、ファブリック インターコネクトのクラスタリンク（L1 または L2）の 1 つが動作しない場合に発生します。この問題は、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. L1 および L2 リンクの両方がファブリック インターコネクトの間で適切に接続されていることを確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: link-down
mibFaultCode: F0293
mibFaultName: fltMgmtEntityDegraded
moClass: mgmt:Entity
Type: network
autoCleared: true
Affected MO: sys/mgmt-entity-[id]

fltMgmtEntityDown

障害コード : F0294

Message: Fabric Interconnect [id], HA Cluster interconnect total link failure

説明 :

この障害は、ファブリック インターコネクトの両方のクラスタリンク（L1 および L2）がリンクダウン状態になっている場合に発生します。この問題は、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. L1 および L2 リンクの両方がファブリック インターコネクトの間に適切に接続されていることを確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: link-down
mibFaultCode: F0294
mibFaultName: fltMgmtEntityDown
moClass: mgmt:Entity
Type: network
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltDcxNsFailed

障害コード : F0304

Message: Server [chassisId]/[slotId] (service profile: [assignedToDn]) virtual network interface allocation failed. Server [id] (service profile: [assignedToDn]) virtual network interface allocation failed. Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) virtual network interface allocation failed.

説明 :

アダプタの vif 名前空間のアクティベーションがリソース不足で失敗しました。Cisco UCS Manager は、配置された VIF リソースの数が、ファブリック インターコネクトに接続されたアダプタで使用可能な最大 VIF リソース数を超過した場合に、この障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. NS の「サイズ」および「使用済み」リソースをチェックし、アダプタが vNIC の最大数をいくつ超過したかを確認します。
2. 最大数を超過した、アダプタのすべての vNIC を設定解除または削除します。
3. IOM からの追加のファブリック アップリンクを、対応するファブリック インターコネクトに追加し、シャーシを再認識します。これでアダプタの「NS サイズ」が増加します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: insufficient-resources
mibFaultCode: F0304
mibFaultName: fltDcxNsFailed
moClass: dcx:Ns
```



```

Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/dcxns-[switchId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/dcxns-[switchId]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/dcxns-[switchId]

```

fltComputePhysicalInsufficientlyEquipped

障害コード : F0305

Message: Server [id] (service profile: [assignedToDn]) has insufficient number of DIMMs, CPUs and/or adaptersServer [chassisId]/[slotId] (service profile: [assignedToDn]) has insufficient number of DIMMs, CPUs and/or adaptersServer [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) has insufficient number of DIMMs and/or CPUs

説明 :

通常、この障害は、サーバに十分な数の DIMM、CPU、およびアダプタがないことを Cisco UCS Manager が検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. DIMM がサポート対象の構成に取り付けられていることを確認します。
2. アダプタおよび CPU が取り付けられていることを確認します。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: minor
Cause: insufficiently-equipped
mibFaultCode: F0305
mibFaultName: fltComputePhysicalInsufficientlyEquipped
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalIdentityUnestablishable

障害コード : F0306

Message: Server [id] (service profile: [assignedToDn]) has an invalid FRUServer [chassisId]/[slotId] (service profile: [assignedToDn]) has an invalid FRUServer [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) has an invalid FRU

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないサーバまたは CPU を検出したために発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サポートされているサーバおよび CPU がインストールされていることを確認します。
2. Cisco UCS Manager の機能カタログが最新であることを確認します。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: identity-unestablishable
mibFaultCode: F0306
mibFaultName: fltComputePhysicalIdentityUnestablishable
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputeBoardPowerError

障害コード：F0310

Message: Motherboard of server [chassisId]/[slotId] (service profile: [assignedToDn]) power: [operPower]Motherboard of server [id] (service profile: [assignedToDn]) power: [operPower]Motherboard of server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) power: [operPower]

説明：

通常、この障害は、サーバの電源センサーが問題を検出した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバがシャーシ内に正しく設置されていること、およびすべてのケーブルが固定されていることを確認します。
2. サーバを再インストールした場合は、それを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: power-problem
```

```

mibFaultCode: F0310
mibFaultName: fltComputeBoardPowerError
moClass: compute:Board
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/rack-unit-[id]/board

```

fltComputePhysicalPowerProblem

障害コード : F0311

Message: Server [id] (service profile: [assignedToDn]) oper state: [operState]Server [chassisId]/[slotId]
 (service profile: [assignedToDn]) oper state: [operState]Server [chassisId]/[slotId]/[serverInstanceId]
 (service profile: [assignedToDn]) oper state: [operState]

説明 :

通常、この障害は、サーバの電源センサーが問題を検出した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバがシャーシ内に正しく設置されていること、およびすべてのケーブルが固定されていることを確認します。
2. サーバを再インストールした場合は、それを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: major
Cause: power-problem
mibFaultCode: F0311
mibFaultName: fltComputePhysicalPowerProblem
moClass: compute:Physical
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalThermalProblem

障害コード : F0312

Message: Server [id] (service profile: [assignedToDn]) oper state: [operState]Server [chassisId]/[slotId]
 (service profile: [assignedToDn]) oper state: [operState]Server [chassisId]/[slotId]/[serverInstanceId]
 (service profile: [assignedToDn]) oper state: [operState]

説明 :

通常、この障害は、サーバの温度センサーが問題を検出した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバのファンが正しく動作していることを確認します。
2. 24 時間待機して、問題が解決しているかどうかを確認します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0312
mibFaultName: fltComputePhysicalThermalProblem
moClass: compute:Physical
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalBiosPostTimeout

障害コード : F0313

Message: Server [id] (service profile: [assignedToDn]) BIOS failed power-on self testServer [chassisId]/[slotId] (service profile: [assignedToDn]) BIOS failed power-on self testServer [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) BIOS failed power-on self test

説明 :

通常、この障害は、サーバに診断エラーが発生したときに発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で **show post** コマンドを使用すると POST の結果にアクセスできます。
2. サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: F0313
mibFaultName: fltComputePhysicalBiosPostTimeout
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
```

Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

fltComputePhysicalDiscoveryFailed

障害コード : F0314

Message: Server [id] (service profile: [assignedToDn]) discovery: [discovery]Server [chassisId]/[slotId]
 (service profile: [assignedToDn]) discovery: [discovery]Server [chassisId]/[slotId]/[serverInstanceId]
 (service profile: [assignedToDn]) discovery: [discovery]

説明 :

通常、この障害は、次のいずれかの理由により発生します。

- サーバがサービス プロファイルに関連付けられたときに発生するシャロー ディスカバリに失敗した。
- サーバがダウンしている。
- データ パスが動作していない。
- Cisco UCS Manager がサーバの CIMC と通信できない。
- サーバがファブリック インターコネクトと通信できない。

推奨処置 :

サーバまたはサーバ コンポーネントに障害が発生している場合は、次の処理を実行します。

1. [FSM] タブで、サーバの現在の状態と FSM の動作を確認します。
2. エラーの説明をチェックして、サーバコンポーネントがエラーを示していないかを確認します。
3. サーバの動作状態をチェックします。
4. サーバが操作不能である場合は、サーバを再認識します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: major
Cause: discovery-failed
mibFaultCode: F0314
mibFaultName: fltComputePhysicalDiscoveryFailed
moClass: compute:Physical
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

fltComputePhysicalAssociationFailed

障害コード : F0315

Message: Service profile [assignedToDn] failed to associate with server [id]Service profile [assignedToDn] failed to associate with server [chassisId]/[slotId]Service profile [assignedToDn] failed to associate with server [chassisId]/[slotId]/[serverInstanceId]

説明 :

通常、この障害は、次のいずれかの理由により発生します。

- サービス プロファイルにサーバを関連付けることができませんでした。
- サーバがダウンしている。
- データ パスが動作していない。
- Cisco UCS Manager で 1 つ以上のファブリック インターコネクト、サーバ、またはサーバ上のコンポーネントと通信できない。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. [FSM] タブで、サーバの現在の状態と FSM の動作を確認します。
2. サーバがブーティングなどの不適切な状態のままである場合は、サーバの電源を再投入します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: association-failed
mibFaultCode: F0315
mibFaultName: fltComputePhysicalAssociationFailed
moClass: compute:Physical
Type: configuration
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalInoperable

障害コード : F0317

Message: Server [id] (service profile: [assignedToDn]) health: [operability]Server [chassisId]/[slotId] (service profile: [assignedToDn]) health: [operability]Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) health: [operability]

説明 :

通常、この障害は、サーバに診断エラーが発生したときに発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で `show post` コマンドを使用すると POST の結果にアクセスできます。
2. サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0317
mibFaultName: fltComputePhysicalInoperable
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalUnassignedMissing

障害コード：F0318

Message: Server [id] missing (no profile)Server [chassisId]/[slotId] missing (no profile)Server [chassisId]/[slotId]/[serverInstanceId] (no profile) missing

説明：

通常、この障害は、サービスプロファイルに関連付けられていないサーバを以前に物理的にスロットに挿入したが、Cisco UCS Manager で検出できない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバがスロットに物理的に存在する場合は、いったん取り外して取り付け直します。
2. サーバがスロットに物理的に存在していない場合は、取り付けます。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: equipment-missing
mibFaultCode: F0318
mibFaultName: fltComputePhysicalUnassignedMissing
```

```

moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAssignedMissing

障害コード : F0319

Message: Server [id] missing (service profile: [assignedToDn])Server [chassisId]/[slotId] missing (service profile: [assignedToDn])Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) missing

説明 :

通常、この障害は、サービスプロファイルに関連付けられたサーバを以前に物理的にスロットに挿入したが、Cisco UCS Manager で検出できない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバがスロットに物理的に存在する場合は、いったん取り外して取り付け直します。
2. サーバがスロットに物理的に存在していない場合は、もう一度取り付けます。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-missing
mibFaultCode: F0319
mibFaultName: fltComputePhysicalAssignedMissing
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalUnidentified

障害コード : F0320

Message: Server [id] (service profile: [assignedToDn]) has an invalid FRU: [presence]Server [chassisId]/[slotId] (service profile: [assignedToDn]) has an invalid FRU: [presence]Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) has an invalid FRU: [presence]

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないサーバまたは CPU を検出したために発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サポートされているサーバおよび CPU がインストールされていることを確認します。
2. Cisco UCS Manager の機能カタログが最新であることを確認します。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: identity-unestablishable
mibFaultCode: F0320
mibFaultName: fltComputePhysicalUnidentified
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalUnassignedInaccessible

障害コード：F0321

Message: Server [id] (no profile) inaccessibleServer [chassisId]/[slotId] (no profile) inaccessibleServer [chassisId]/[slotId]/[serverInstanceId] (no profile) inaccessible

説明：

通常、この障害は、サービス プロファイルに関連付けられていないサーバがファブリック インターコネクトとの接続を失った場合に発生します。この障害は、サーバ CIMC とファブリック インターコネクト間に通信の問題がある場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. 短時間のうちに障害がクリアされない場合は、サーバをいったん取り外して取り付け直します。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: warning
Cause: equipment-inaccessible
mibFaultCode: F0321
mibFaultName: fltComputePhysicalUnassignedInaccessible
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAssignedInaccessible

障害コード : F0322

Message: Server [id] (service profile: [assignedToDn]) inaccessibleServer [chassisId]/[slotId] (service profile: [assignedToDn]) inaccessibleServer [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) inaccessible

説明 :

通常、この障害は、サービス プロファイルに関連付けられたサーバがファブリック インターコネクトとの接続を失った場合に発生します。この障害は、サーバ CIMC とファブリック インターコネクト間に通信の問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. 短時間のうちに障害がクリアされない場合は、サーバをいったん取り外して取り付け直します。
3. サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: minor
Cause: equipment-inaccessible
mibFaultCode: F0322
mibFaultName: fltComputePhysicalAssignedInaccessible
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltLsServerFailed

障害コード : F0324

Message: Service profile [name] failed**説明 :**

サーバに障害が発生しました。一般的にこの障害は、アダプタの電源投入時自己診断テストで重大かつ深刻なエラーが発生した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で show post コマンドを使用すると POST の結果にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: server-failed
mibFaultCode: F0324
mibFaultName: fltLsServerFailed
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerDiscoveryFailed

障害コード : F0326

Message: Service profile [name] discovery failed**説明 :**

サーバがサービス プロファイルに関連付けられたときに発生するシャロー ディスカバリが失敗しました。サーバがアップしておりデータパスが機能している場合、この障害は、一般的に次のいずれかの問題の結果として発生します。

- Cisco UCS Manager がサーバの CIMC と通信できない。
- サーバがファブリック インターコネクトと通信できない。

推奨処置 :

サーバまたはサーバ コンポーネントに障害が発生している場合は、次の処理を実行します。

1. [FSM] タブをチェックして、サーバの現在の状態と FSM の動作を表示します。
2. エラーの説明をチェックして、サーバコンポーネントがエラーを示していないかを確認します。
3. サーバの動作状態をチェックします。

4. サーバが動作不能である場合は、サーバを再認識します。
5. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: discovery-failed
mibFaultCode: F0326
mibFaultName: fltLsServerDiscoveryFailed
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerConfigFailure

障害コード : F0327

Message: Service profile [name] configuration failed due to [serverConfigIssues],[networkConfigIssues],[storageConfigIssues],[vnicConfigIssues],[iscsiConfigIssues]

説明 :

指定された設定の修飾子を使用できません。通常、この障害は、指定された修飾子と一致するリソースが不足しているために、Cisco UCS Manager が正常にサービス プロファイルを展開できないために発生します。たとえば、次のような場合にこの障害が発生する可能性があります。

- サービス プロファイルが vHBA を持つサーバのアダプタ用に設定されているが、サーバのアダプタは vHBA をサポートしていない。
- サービス プロファイルがサーバ プールを含むテンプレートから作成されており、サーバ プールが空になっている。
- サービス プロファイルのローカルディスクの設定ポリシーには No Local Storage モードが指定されているが、サーバにはローカルディスクが含まれている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サービス プロファイルに関連付けられたサーバプールのステータスを確認します。プールが空の場合は、ブレードサーバを追加します。
2. サーバの状態をチェックし、サーバが検出済みまたは関連付けられていない状態であることを確認します。
3. サーバが関連付けられている、または未検出である場合は、次のいずれかを実行します。
4. サーバを検出する。
5. 現在のサービス プロファイルからサーバの関連付けを解除する。

6. 別のサーバを選択してサービス プロファイルに関連付ける。
7. サービス プロファイルの各ポリシーを確認し、選択したサーバがポリシーの要件を満たしていることを確認します。
8. サーバがサービス プロファイルの要件を満たしていない場合は、次のいずれかを実行します。
9. サーバに合わせてサービス プロファイルを修正する。
10. 要件を満たす別のサーバを選択して、サービス プロファイルに関連付ける。
11. サーバがサービス プロファイルの要件を満たしていることを確認できた場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: configuration-failure
mibFaultCode: F0327
mibFaultName: fltLsServerConfigFailure
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerMaintenanceFailed

障害コード : F0329

Message: Service profile [name] maintenance failed

説明 :

Cisco UCS Manager では現在この障害情報を使用していません。

推奨処置 :

この障害が発生した場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: maintenance-failed
mibFaultCode: F0329
mibFaultName: fltLsServerMaintenanceFailed
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerRemoved

障害コード : F0330

Message: Service profile [name] underlying resource removed**説明 :**

Cisco UCS Manager が、サービス プロファイルに関連付けられたサーバにアクセスできません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバが物理的にスロットから取り外された。
- サーバが使用できない。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバがスロットから取り外された場合は、サーバをスロットに取り付け直します。
2. サーバが取り外されていない場合は、サーバを取り外してから取り付け直します。**注 :** サーバが動作可能である場合は、このアクションによって現在の動作が中断される可能性があります。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-removed
mibFaultCode: F0330
mibFaultName: fltLsServerRemoved
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerInaccessible

障害コード : F0331

Message: Service profile [name] cannot be accessed**説明 :**

Cisco UCS Manager がサーバの CIMC と通信できない。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバの 1 つまたは複数のポートで障害が発生した。
- I/O モジュールがオフラインである。
- BMC で障害が発生した。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager で CIMC がダウンしていると表示されている場合は、物理的にサーバを装着し直します。
2. Cisco UCS Manager でサーバのポートに障害があると表示されている場合は、そのポートをイネーブルにしてみます。
3. I/O モジュールがオフラインである場合は、そのコンポーネントの障害をチェックします。
4. 上記のアクションで問題を解決できなかった場合は、`show tech-support` ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: server-inaccessible
mibFaultCode: F0331
mibFaultName: fltLsServerInaccessible
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsServerAssociationFailed

障害コード : F0332

Message: Service profile [name] association failed for [pnDn]

説明 :

サービスプロファイルにサーバを関連付けることができませんでした。一般的にこの障害は、Cisco UCS Manager が次の 1 つまたは複数と通信できないために発生します。

- ファブリック インターコネクト
- サーバの CIMC
- SAS コントローラのドライバ
- サーバ

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバとサービスプロファイルの [FSM] タブをチェックして、アソシエーションが失敗した理由を判断します。
2. サーバがブーティングなどの不適切な状態のままである場合は、サーバの電源を再投入します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: association-failed
mibFaultCode: F0332
mibFaultName: fltLsServerAssociationFailed
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]

```

fltLsServerUnassociated

障害コード : F0334

Message: Service profile [name] is not associated

説明 :

サービス プロファイルがまだサーバまたはサーバ プールに関連付けられていません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバ プールに受け入れ可能なサーバがない。
- アソシエーションが失敗した。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サービス プロファイルを関連付けない場合は、この障害を無視します。
2. サービス プロファイルを関連付ける場合は、アソシエーションのエラーをチェックします。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: warning
Cause: unassociated
mibFaultCode: F0334
mibFaultName: fltLsServerUnassociated
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]

```

fltLsServerServer-unfulfilled

障害コード : F0337

Message: Server [pnDn] does not fulfill Service profile [name] due to [configQualifier]

説明 :

サーバは、サービスプロファイルの資格の要件を満たしていません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバが物理的に変更された。
- サーバの必要なコンポーネントに障害が発生した。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバインベントリをサービスプロファイルの資格と比較してチェックします。
2. サーバインベントリがサービスプロファイルの資格を満たしていない場合は、次のいずれかを実行します。
3. サーバを別のサービスプロファイルと関連付けます。
4. 現在のサービスプロファイルの資格に適した十分なリソースがサーバにあることを確認します。
5. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: server-failed
mibFaultCode: F0337
mibFaultName: fltLsServerServerUnfulfilled
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltEtherSwitchIntFloSatellite-connection-absent

障害コード：F0367

Message: No link between NIF port [chassisId]/[slotId]/[portId] and fabric interconnect [switchId]:[peerSlotId]/[peerPortId]

説明：

この障害は、I/O モジュールのポートとファブリック インターコネクトとをリンクする I/O モジュール ファブリック ポートが機能しない場合に発生します

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトとシャーシ間のトポロジを確認します。各 I/O モジュールが 1 つのファブリック インターコネクトだけに接続されていることを確認します。
2. ファブリック インターコネクト サーバ ポートが設定され、イネーブルになっていることを確認します。

3. リンクが正しく接続されていることを確認し、シャーシを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: satellite-connection-absent
mibFaultCode: F0367
mibFaultName: fltEtherSwitchIntFioSatelliteConnectionAbsent
moClass: ether:SwitchIntFio
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltEtherSwitchIntFioSatellite-wiring-problem

障害コード : F0368

Message: Invalid connection between IOM port [chassisId]/[slotId]/[portId] and fabric interconnect [switchId]:[peerSlotId]/[peerPortId]

説明 :

通常、この障害は、I/O モジュールのネットワーク側インターフェイスのサテライト配線の問題の結果として発生し、1 つ以上の IOM アップリンクがファブリック インターコネクト ポートの 1 つに誤って接続されていることが、Cisco UCS Manager によって検出されます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトとシャーシ間のトポロジを確認します。各 I/O モジュールが 1 つのファブリック インターコネクトだけに接続されていることを確認します。
2. リンクが正しく接続されていることを確認し、シャーシを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: satellite-mis-connected
mibFaultCode: F0368
mibFaultName: fltEtherSwitchIntFioSatelliteWiringProblem
moClass: ether:SwitchIntFio
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

fltEquipmentPsuPowerSupplyProblem

障害コード : F0369

Message: Power supply [id] in chassis [id] power: [power]Power supply [id] in fabric interconnect [id] power: [power]Power supply [id] in fex [id] power: [power]Power supply [id] in server [id] power: [power]Power supply [id] in rack-enclosure [id] power: [power]

説明 :

通常、この障害は、Cisco UCS Manager がシャーシ、ファブリック インターコネクトまたは FEX の電源装置ユニットで問題を検出した場合に発生します。たとえば、PSU が機能していない場合などです。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 電源コードが PSU および電源に正しく接続されていることを確認します。
2. 電源が 220 V であることを確認します。
3. PSU がシャーシまたはファブリック インターコネクトに適切に設置されていることを確認します。
4. PSU を取り外して再度設置します。
5. PSU を交換します。
6. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: power-problem
mibFaultCode: F0369
mibFaultName: fltEquipmentPsuPowerSupplyProblem
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

fltEquipmentFanDegraded

障害コード : F0371

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] operability: [operability]Fan [id] in fabric interconnect [id] operability: [operability]Fan [id] in fex [id] operability: [operability]Fan [id] in Fan

Module [tray]-[id] under server [id] operability: [operability] Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] operability: [operability]

説明：

この障害は、ファンモジュールの1つまたは複数のファンが動作していないが、少なくとも1つのファンは動作している場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファンモジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファンモジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 故障したファンモジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: F0371
mibFaultName: fltEquipmentFanDegraded
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentFanInoperable

障害コード：F0373

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] operability: [operability] Fan [id] in fabric interconnect [id] operability: [operability] Fan [id] in fex [id] operability: [operability] Fan [id] in Fan Module [tray]-[id] under server [id] operability: [operability] Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] operability: [operability]

説明 :

この障害は、ファンが動作しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファン モジュールを取り外して、もう一度取り付け直します。一度に取り外せるファン モジュールは 1 つだけです。
2. ファン モジュールを別のファン モジュールと交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0373
mibFaultName: fltEquipmentFanInoperable
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentPsulnoperable

障害コード : F0374

Message: Power supply [id] in chassis [id] operability: [operability] Power supply [id] in fabric interconnect [id] operability: [operability] Power supply [id] in fex [id] operability: [operability] Power supply [id] in server [id] operability: [operability] Power supply [id] in rack-enclosure [id] operability: [operability]

説明 :

通常、この障害は、Cisco UCS Manager がシャーシ、ファブリック インターコネクトまたは FEX の電源装置ユニットで問題を検出した場合に発生します。たとえば、PSU が機能していない場合などです。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 電源コードが PSU および電源に正しく接続されていることを確認します。
2. 電源が 220 V であることを確認します。

3. PSU がシャーシまたはファブリック インターコネクต์に適切に設置されていることを確認します。
4. PSU を取り外して再度設置します。
5. PSU を交換します。
6. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0374
mibFaultName: fltEquipmentPsuInoperable
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentIOCardRemoved

障害コード : F0376

Message: [side] IOM [chassisId]/[id] ([switchId]) is removed

説明 :

通常、この障害は、I/O モジュールがシャーシから取り外されているために発生します。クラスタ構成では、シャーシは他の I/O モジュールにフェールオーバーします。スタンドアロン構成の場合、その I/O モジュールに関連付けられているシャーシのネットワーク接続は失われます。これによりネットワーク接続が失われ、I/O モジュールからのデータ トラフィックが中断されるため、重大な障害となります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. I/O モジュールを再挿入し、接続されているファブリック インターコネクต์ ポートをサーバ ポートとして設定し、数分待ってエラーが解消されるかどうかを確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-removed
mibFaultCode: F0376
mibFaultName: fltEquipmentIOCardRemoved
moClass: equipment:IOCard
```

```
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentFanModuleMissing

障害コード : F0377

Message: Fan module [tray]-[id] in chassis [id] presence: [presence]Fan module [tray]-[id] in server [id] presence: [presence]Fan module [tray]-[id] in fabric interconnect [id] presence: [presence]Fan module [tray]-[id] in rack-enclosure [id] presence: [presence]

説明 :

この障害は、ファンモジュールがスロットに取り付けられていないか、スロットから取り外されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. スロットが空であることが報告されている場合は、スロットにファンモジュールを挿入します。
2. スロットにファンモジュールが装着されていることが報告されている場合は、ファンモジュールをいったん取り外し、もう一度挿入します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F0377
mibFaultName: fltEquipmentFanModuleMissing
moClass: equipment:FanModule
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuMissing

障害コード : F0378

Message: Power supply [id] in chassis [id] presence: [presence]Power supply [id] in fabric interconnect [id] presence: [presence]Power supply [id] in fex [id] presence: [presence]Power supply [id] in server [id] presence: [presence]Power supply [id] in rack-enclosure [id] presence: [presence]

説明 :

通常、この障害は、Cisco UCS Manager がシャーシ、ファブリック インターコネクト、または FEX の電源装置ユニットで問題を検出した場合に発生します。たとえば、PSU が欠落しているなどです。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. PSU がスロットに物理的に存在する場合は、いったん取り外し、取り付け直します。
2. PSU がスロットに物理的に存在していない場合は、新しい PSU を取り付けます。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F0378
mibFaultName: fltEquipmentPsuMissing
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentIOCardThermalProblem

障害コード：F0379

Message: [side] IOM [chassisId]/[id] ([switchId]) operState: [operState]

説明：

この障害は、I/O モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、I/O モジュールに適切なエアフローを確保します。

3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0379
mibFaultName: fltEquipmentIOCardThermalProblem
moClass: equipment:IOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentFanModuleThermalThresholdNonCritical

障害コード : F0380

Message: Fan module [tray]-[id] in chassis [id] temperature: [thermal]Fan module [tray]-[id] in server [id] temperature: [thermal]Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal]Fan module [tray]-[id] in rack-enclosure [id] temperature: [thermal]

説明 :

この障害は、ファンモジュールの温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファン モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファン モジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 故障したファン モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0380
mibFaultName: fltEquipmentFanModuleThermalThresholdNonCritical
moClass: equipment:FanModule
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuThermalThresholdNonCritical

障害コード : F0381

Message: Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]Power supply [id] in rack-enclosure [id] temperature: [thermal]

説明 :

この障害は、PSU モジュールの温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。

- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、PSU モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、PSU モジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある PSU モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0381
mibFaultName: fltEquipmentPsuThermalThresholdNonCritical
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentFanModuleThermalThresholdCritical

障害コード：F0382

Message: Fan module [tray]-[id] in chassis [id] temperature: [thermal]Fan module [tray]-[id] in server [id] temperature: [thermal]Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal]Fan module [tray]-[id] in rack-enclosure [id] temperature: [thermal]

説明：

この障害は、ファンモジュールの温度が重大しきい値を超えた場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファン モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファンモジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 故障したファン モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0382
mibFaultName: fltEquipmentFanModuleThermalThresholdCritical
moClass: equipment:FanModule
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuThermalThresholdCritical

障害コード：F0383

Message: Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]Power supply [id] in rack-enclosure [id] temperature: [thermal]

説明：

この障害は、PSU モジュールの温度が重大しき値を超えた場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、PSU モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、PSU モジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある PSU モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0383
mibFaultName: fltEquipmentPsuThermalThresholdCritical
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
```

Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

fltEquipmentFanModuleThermalThresholdNonRecoverable

障害コード : F0384

Message: Fan module [tray]-[id] in chassis [id] temperature: [thermal] Fan module [tray]-[id] in server [id] temperature: [thermal] Fan module [tray]-[id] in fabric interconnect [id] temperature: [thermal] Fan module [tray]-[id] in rack-enclosure [id] temperature: [thermal]

説明 :

この障害は、ファンモジュールの温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファンモジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファンモジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 故障したファンモジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: critical

```

Cause: thermal-problem
mibFaultCode: F0384
mibFaultName: fltEquipmentFanModuleThermalThresholdNonRecoverable
moClass: equipment:FanModule
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]

```

fltEquipmentPsuThermalThresholdNonRecoverable

障害コード : F0385

Message: Power supply [id] in chassis [id] temperature: [thermal]Power supply [id] in fabric interconnect [id] temperature: [thermal]Power supply [id] in server [id] temperature: [thermal]Power supply [id] in rack-enclosure [id] temperature: [thermal]

説明 :

この障害は、PSU モジュールの温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、PSU モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、PSU モジュールに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある PSU モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。

9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0385
mibFaultName: fltEquipmentPsuThermalThresholdNonRecoverable
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentPsuVoltageThresholdNonCritical

障害コード : F0387

Message: Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]Power supply [id] in rack-enclosure [id] voltage: [voltage]

説明 :

この障害は、PSU の電圧が正常な動作範囲外にあるが、危険な段階にはまだ到達していない場合に発生します。通常、PSU はそれ自体でこの状況から回復します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. さらに悪化していないかどうか PSU をモニタします。
2. PSU を取り外し、再度取り付けてください。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: voltage-problem
mibFaultCode: F0387
mibFaultName: fltEquipmentPsuVoltageThresholdNonCritical
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```


fltEquipmentPsuVoltageThresholdCritical

障害コード : F0389

Message: Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]Power supply [id] in rack-enclosure [id] voltage: [voltage]

説明 :

この障害は、PSU の電圧が指定したハードウェアの電圧定格を超えた場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. PSU を取り外し、再度取り付けてください。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: voltage-problem
mibFaultCode: F0389
mibFaultName: fltEquipmentPsuVoltageThresholdCritical
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

fltEquipmentPsuVoltageThresholdNonRecoverable

障害コード : F0391

Message: Power supply [id] in chassis [id] voltage: [voltage]Power supply [id] in fabric interconnect [id] voltage: [voltage]Power supply [id] in fex [id] voltage: [voltage]Power supply [id] in server [id] voltage: [voltage]Power supply [id] in rack-enclosure [id] voltage: [voltage]

説明 :

この障害は、PSU の電圧が指定したハードウェアの電圧定格を超え、結果として PSU ハードウェアが損傷しているか、または損傷するおそれがある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. PSU を取り外し、再度取り付けてください。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: voltage-problem
mibFaultCode: F0391
mibFaultName: fltEquipmentPsuVoltageThresholdNonRecoverable
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuPerfThresholdNonCritical

障害コード : F0392

Message: Power supply [id] in chassis [id] output current: [perf]Power supply [id] in fabric interconnect [id] output current: [perf]Power supply [id] in server [id] output current: [perf]Power supply [id] in rack-enclosure [id] output current: [perf]

説明 :

この障害は、シャーシ、ファブリック インターコネクト、またはラック サーバの PSU の現在の出力が目的の出力値と一致していない場合に、警告として発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. PSU のステータスをモニタします。
2. 可能であれば、PSU を取り外して、再度取り付けます。
3. 上記のアクションで問題を解決できなかった場合は、シャーシと Cisco UCS Manager の **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: minor
Cause: performance-problem
mibFaultCode: F0392
mibFaultName: fltEquipmentPsuPerfThresholdNonCritical
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuPerfThresholdCritical

障害コード : F0393

Message: Power supply [id] in chassis [id] output current: [perf]Power supply [id] in fabric interconnect [id] output current: [perf]Power supply [id] in server [id] output current: [perf]Power supply [id] in rack-enclosure [id] output current: [perf]

説明 :

この障害は、シャーシ、ファブリック インターコネクト、またはラック サーバの PSU の現在の出力が、目的の出力値よりもかなり上または下である場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. PSU のステータスをモニタします。
2. PSU をできるだけ早く交換することを計画します。
3. 上記のアクションで問題を解決できなかった場合は、シャーシと Cisco UCS Manager の **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: performance-problem
mibFaultCode: F0393
mibFaultName: fltEquipmentPsuPerfThresholdCritical
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentPsuPerfThresholdNonRecoverable

障害コード : F0394

Message: Power supply [id] in chassis [id] output current: [perf]Power supply [id] in fabric interconnect [id] output current: [perf]Power supply [id] in server [id] output current: [perf]Power supply [id] in rack-enclosure [id] output current: [perf]

説明 :

この障害は、シャーシ、ファブリック インターコネクト、またはラック サーバの PSU の現在の出力が、回復不能なしきい値よりもかなり上または下である場合に発生します。

推奨処置 :

この障害が発生した場合は、PSU をできるだけ早く交換することを計画します。

障害の詳細

```
Severity: critical
Cause: performance-problem
mibFaultCode: F0394
mibFaultName: fltEquipmentPsuPerfThresholdNonRecoverable
```

```

moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentFanPerfThresholdNonCritical

障害コード : F0395

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] speed: [perf]

説明 :

この障害は、ファンコントローラから読み取ったファン速度が必要なファン速度と一致せず、正常な動作の範囲外である場合に発生します。これはファンまたはファンコントローラからの読み取りに問題がある可能性を示しています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファン ステータスをモニタします。
2. 問題が長期間にわたって継続するか、他のファンで同じ問題が起きない場合は、ファンを装着し直します。
3. ファン モジュールを交換します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: info
Cause: performance-problem
mibFaultCode: F0395
mibFaultName: fltEquipmentFanPerfThresholdNonCritical
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

```

fltEquipmentFanPerfThresholdCritical

障害コード : F0396

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] speed: [perf]

説明 :

この障害は、ファンコントローラから読み取ったファン速度が必要なファン速度と一致せず、重大しき値を超え、障害の危険がある場合に発生します。これはファンまたはファンコントローラからの読み取りに問題がある可能性を示しています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファン ステータスをモニタします。
2. 問題が長期間にわたって継続するか、他のファンで同じ問題が起きない場合は、ファンを装着し直します。
3. 上記のアクションで問題を解決できなかった場合は、シャーシの **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: info
Cause: performance-problem
mibFaultCode: F0396
mibFaultName: fltEquipmentFanPerfThresholdCritical
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

fltEquipmentFanPerfThresholdNonRecoverable

障害コード : F0397

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] speed: [perf]

説明 :

この障害は、ファンコントローラから読み取られたファン速度が、必要なファン速度をかなり超えている場合に発生します。これは、多くの場合、ファンに障害が発生していることを示しています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファンを交換します。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: performance-problem
mibFaultCode: F0397
mibFaultName: fltEquipmentFanPerfThresholdNonRecoverable
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltEquipmentIOCardFirmwareUpgrade

障害コード : F0398

Message: Chassis controller in IOM [chassisId]/[id] ([switchId]) firmware upgrade problem: [upgradeStatus]

説明 :

通常、この障害は、IOM のアップグレードに失敗した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. IOM の [FSM] タブで、アップグレードの FSM が正常に完了したか失敗したかを確認します。
2. FSM に障害が発生した場合は、FSM のエラー メッセージを確認します。
3. エラーメッセージが読んですぐわかる内容の場合は、物理的な接続を確認します。たとえば、エンドポイントに接続されていない、リンク ダウン、などのエラー メッセージが表示される可能性があります。
4. 上記のアクションで問題を解決できず、障害が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: firmware-upgrade-problem
mibFaultCode: F0398
mibFaultName: fltEquipmentIOCardFirmwareUpgrade
moClass: equipment:IOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentChassisUnsupportedConnectivity

障害コード : F0399

Message: Current connectivity for chassis [id] does not match supported topology

説明 :

通常、この障害は、シャーシの現在の接続がシャーシのディスカバリ ポリシーの設定と一致していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシのディスカバリ ポリシーで正しい数のリンクが設定されていることを確認します。
2. I/O モジュールのリンクのステータスを確認します。
3. シャーシを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: unsupported-connectivity-configuration
mibFaultCode: F0399
mibFaultName: fltEquipmentChassisUnsupportedConnectivity
moClass: equipment:Chassis
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]

fltEquipmentChassisUnacknowledged

障害コード : F0400

Message: Chassis [id] connectivity configuration: [configState]

説明 :

通常、この障害は、シャーシからの I/O モジュール リンクの 1 つまたは複数が認識されていない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. I/O モジュールのリンクのステータスを確認します。
2. シャーシを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: equipment-unacknowledged
mibFaultCode: F0400
mibFaultName: fltEquipmentChassisUnacknowledged
moClass: equipment:Chassis
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]

fltEquipmentIOCardUnsupportedConnectivity

障害コード : F0401

Message: IOM [chassisId]/[id] ([switchId]) current connectivity does not match discovery policy or connectivity is unsupported: [configState]

説明 :

通常、この障害は、I/O モジュールの現在の接続がシャーシのディスカバリ ポリシーの設定と一致していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシのディスカバリ ポリシーで正しい数のリンクが設定されていることを確認します。
2. I/O モジュールのリンクのステータスを確認します。
3. 少なくとも 2 つのリンクが FEX と 61xx ファブリック インターコネクト間で接続されている必要があることに注意してください。
4. シャーシを再認識します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: unsupported-connectivity-configuration
mibFaultCode: F0401
mibFaultName: fltEquipmentIOCardUnsupportedConnectivity
moClass: equipment:IOCard
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fltEquipmentIOCardUnacknowledged

障害コード : F0402

Message: IOM [chassisId]/[id] ([switchId]) connectivity configuration: [configState]

説明：

通常、この障害は、I/O モジュールが認識されていない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. I/O モジュールのリンクのステータスを確認します。
2. シャーシを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-unacknowledged
mibFaultCode: F0402
mibFaultName: fltEquipmentIOCardUnacknowledged
moClass: equipment:IOCard
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardPeerDisconnected

障害コード：F0403

Message: IOM [chassisId]/[id] ([switchId]) peer connectivity: [peerCommStatus]

説明：

通常、この障害は、I/O モジュールがピアの I/O モジュールと通信できない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. 数分経っても障害がクリアされない場合は、I/O モジュールをいったん取り外し、取り付け直します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-disconnected
mibFaultCode: F0403
mibFaultName: fltEquipmentIOCardPeerDisconnected
moClass: equipment:IOCard
Type: connectivity
```

```
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentChassisIdentity

障害コード : F0404

Message: Chassis [id] has a mismatch between FRU identity reported by Fabric/IOM vs. FRU identity reported by CMC

説明 :

通常、この障害は、I/O モジュールの FRU の情報が破損した場合、または不正な形式の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F0404
mibFaultName: fltEquipmentChassisIdentity
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentIOCardIdentity

障害コード : F0405

Message: [side] IOM [chassisId]/[id] ([switchId]) has a malformed FRU

説明 :

通常、この障害は、I/O モジュールの FRU の情報が破損した場合、または不正な形式の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F0405
mibFaultName: fltEquipmentIOCardIdentity
moClass: equipment:IOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentFanModuleIdentity

障害コード : F0406

Message: Fan Module [tray]-[id] in chassis [id] has a malformed FRUFan Module [tray]-[id] in server [id] has a malformed FRUFan Module [tray]-[id] in fabric interconnect [id] has a malformed FRUFan Module [tray]-[id] in rack-enclosure [id] has a malformed FRU

説明 :

通常、この障害は、ファン モジュールの FRU 情報が破損した場合、または不正な形式の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F0406
mibFaultName: fltEquipmentFanModuleIdentity
moClass: equipment:FanModule
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltEquipmentPsuIdentity

障害コード : F0407

Message: Power supply [id] on chassis [id] has a malformed FRUPower supply [id] on server [id] has a malformed FRUPower supply [id] on rack-enclosure [id] has a malformed FRU

説明 :

通常、この障害は、電源装置ユニットの FRU 情報が破損した場合、または不正な形式の場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F0407
mibFaultName: fltEquipmentPsuIdentity
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentChassisPowerProblem

障害コード：F0408

Message: Power state on chassis [id] is [power]

説明：

通常、この障害は、電源ポリシーに定義された最小電力要件をシャーシが満たしていない場合や、1 つまたは複数の電源装置に問題がある場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager で、シャーシのすべての PSU が機能していることを確認します。
2. すべての PSU がシャーシ内に適切に装着され、電源が投入されていることを確認します。
3. 物理的にシャーシの電源コードを取り外し、再接続します。
4. すべての PSU が最大容量で動作している場合は、シャーシに PSU を追加するか、Cisco UCS Manager で電源ポリシーを再定義します。
5. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: power-problem
mibFaultCode: F0408
mibFaultName: fltEquipmentChassisPowerProblem
moClass: equipment:Chassis
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdCritical

障害コード : F0409

Message: Thermal condition on chassis [id] is [thermal]

説明 :

この障害は、次の条件で発生します。

1. シャーシ内のコンポーネントが安全な熱動作範囲外で動作している場合。
2. IOM のシャーシ コントローラがブレード サーバの熱状態を判別できない場合、シャーシの **show tech-support** ファイルで、そのシャーシに現在該当する最も厳しい熱状態の詳細なレポートが提供されます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ブレードサーバと IOM の温度表示をチェックし、推奨される安全な熱動作範囲内であることを確認します。
2. 1 つまたは複数のブレードサーバに対して「Thermal Sensor threshold crossing in blade」エラーの障害がレポートされた場合、そのブレードに対して DIMM またはプロセッサに温度関連障害が発生していないか確認します。
3. 1 つまたは両方の IOM に対して「Thermal Sensor threshold crossing in IOM」エラーの障害がレポートされた場合、その IOM に熱の障害が発生していないか確認します。これらの障害には、熱状態の詳細が含まれます。
4. 「ファンが欠落しているか、障害が発生しています (Missing or Faulty Fan)」エラーの障害がレポートされた場合、そのファンのステータスをチェックします。交換が必要な場合は、シャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。
5. 「No connectivity between IOM and blade」または「Thermal Sensor readings unavailable from blade」エラーの障害がレポートされた場合、そのブレードサーバが動作しているか、およびそのブレードサーバに対して障害が発生していないかを確認します。この場合、シャーシコントローラはフェールセーフ動作モードに入り、予防措置としてファンの速度が上昇する場合があります。
6. 上記のアクションで問題を解決できず、状態が続く場合は、Cisco UCS Manager およびシャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0409
mibFaultName: fltEquipmentChassisThermalThresholdCritical
moClass: equipment:Chassis
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdNonCritical

障害コード : F0410

Message: Thermal condition on chassis [id] is [thermal]

説明 :

UCSM は次の条件でこの障害を発生します。

1. シャーシ内のコンポーネントが安全な熱動作範囲外で動作している場合。
2. IOM のシャーシ コントローラがブレード サーバの熱状態を判別できない場合、シャーシの **show tech-support** ファイルで、そのシャーシに現在該当する最も厳しい熱状態の詳細なレポートが提供されます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ブレード サーバと IOM の温度表示をチェックし、推奨される安全な熱動作範囲内であることを確認します。
2. 1 つまたは複数のブレード サーバに対して「Thermal Sensor threshold crossing in blade」エラーの障害がレポートされた場合、そのブレードに対して DIMM またはプロセッサに温度関連障害が発生していないか確認します。
3. 1 つまたは両方の IOM に対して「Thermal Sensor threshold crossing in IOM」エラーの障害がレポートされた場合、その IOM に熱の障害が発生していないか確認します。これらの障害には、熱状態の詳細が含まれます。
4. 「ファンが欠落しているか、障害が発生しています (Missing or Faulty Fan)」エラーの障害がレポートされた場合、そのファンのステータスをチェックします。交換が必要な場合は、シャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。
5. 「No connectivity between IOM and blade」または「Thermal Sensor readings unavailable from blade」エラーの障害がレポートされた場合、そのブレードサーバが動作しているか、およびそのブレードサーバに対して障害が発生していないかを確認します。この場合、シャーシコントローラはフェールセーフ動作モードに入り、予防措置としてファンの速度が上昇する場合があります。

6. 上記のアクションで問題を解決できず、状態が続く場合は、Cisco UCS Manager およびシャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0410
mibFaultName: fltEquipmentChassisThermalThresholdNonCritical
moClass: equipment:Chassis
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisThermalThresholdNonRecoverable

障害コード : F0411

Message: Thermal condition on chassis [id] is [thermal]

説明 :

UCSM は次の条件でこの障害が発生します。

1. シャーシ内のコンポーネントが安全な熱動作範囲外で動作している場合。
2. IOM のシャーシ コントローラがブレード サーバの熱状態を判別できない場合、シャーシの **show tech-support** ファイルで、そのシャーシに現在該当する最も厳しい熱状態の詳細なレポートが提供されます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ブレード サーバと IOM の温度表示をチェックし、推奨される安全な熱動作範囲内であることを確認します。
2. 1 つまたは複数のブレード サーバに対して「Thermal Sensor threshold crossing in blade」エラーの障害がレポートされた場合、そのブレードに対して DIMM またはプロセッサに温度関連障害が発生していないか確認します。
3. 1 つまたは両方の IOM に対して「Thermal Sensor threshold crossing in IOM」エラーの障害がレポートされた場合、その IOM に熱の障害が発生していないか確認します。これらの障害には、熱状態の詳細が含まれます。
4. 「ファンが欠落しているか、障害が発生しています (Missing or Faulty Fan)」エラーの障害がレポートされた場合、そのファンのステータスをチェックします。交換が必要な場合は、シャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。
5. 「No connectivity between IOM and blade」または「Thermal Sensor readings unavailable from blade」エラーの障害がレポートされた場合、そのブレードサーバが動作しているか、およびそのブレードサーバに対して障害が発生していないかを確認します。この場合、シャー

シコントローラはフェールセーフ動作モードに入り、予防措置としてファンの速度が上昇する場合があります。

6. 上記のアクションで問題を解決できず、状態が続く場合は、Cisco UCS Manager およびシャーシに対する **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0411
mibFaultName: fltEquipmentChassisThermalThresholdNonRecoverable
moClass: equipment:Chassis
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltComputeBoardCmosVoltageThresholdCritical

障害コード : F0424

Message: Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [id] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId]/[serverInstanceId] is [cmosVoltage]

説明 :

この障害は、CMOS のバッテリー電圧が正常な動作範囲よりも低くなっている場合に発生します。これはクロックやその他の CMOS 設定に影響を与えることがあります。

推奨処置 :

この障害が発生した場合は、バッテリーを交換してください。

障害の詳細

```
Severity: major
Cause: voltage-problem
mibFaultCode: F0424
mibFaultName: fltComputeBoardCmosVoltageThresholdCritical
moClass: compute:Board
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/rack-unit-[id]/board
```

fltComputeBoardCmosVoltageThresholdNonRecoverable

障害コード : F0425

Message: Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [id] is [cmosVoltage]Possible loss of CMOS settings: CMOS battery voltage on server [chassisId]/[slotId]/[serverInstanceId] is [cmosVoltage]

説明：

この障害は、CMOS のバッテリー電圧が非常に低くなり、回復不能の可能性がある場合に発生します。これはクロックやその他の CMOS 設定に影響を与えます。

推奨処置：

この障害が発生した場合は、バッテリーを交換してください。

障害の詳細

```
Severity: major
Cause: voltage-problem
mibFaultCode: F0425
mibFaultName: fltComputeBoardCmosVoltageThresholdNonRecoverable
moClass: compute:Board
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/rack-unit-[id]/board
```

fltMgmtEntityElection-failure

障害コード：F0428

Message: Fabric Interconnect [id], election of primary managemt instance has failed

説明：

この障害は、クラスタ構成内のファブリック インターコネク트가、プライマリ ファブリック インターコネク트의選択における合意に到達できなかったという、まれなイベントで発生します。これは、ファブリック インターコネク트 クラスタのフル HA 機能に影響します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 両方のファブリック インターコネク트가初期設定が正しいことを確認します。
2. L1 および L2 リンクがファブリック インターコネク트의間で適切に接続されていることを確認します。
3. Cisco UCS Manager CLI で、1 台のファブリック インターコネク트가 **cluster force primary local-mgmt** コマンドを実行します。
4. ファブリック インターコネク트가をリブートします。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: election-failure
mibFaultCode: F0428
mibFaultName: fltMgmtEntityElectionFailure
moClass: mgmt:Entity
```

Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]

fltMgmtEntityHa-not-ready

障害コード : F0429

Message: Fabric Interconnect [id], HA functionality not ready

説明 :

この障害は、Cisco UCS Manager で、HA クラスタの状態を書き込むための 1 つ以上のシャーシまたはラック サーバを検出できないか、これらと通信できない場合に発生します。これは、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 両方のファブリック インターコネクトで初期設定が正しいことを確認します。
2. L1 および L2 リンクがファブリック インターコネクトの間で適切に接続されていることを確認します。
3. IOM または FEX が到達可能であり、サーバ ポートがイネーブルで動作していることを確認します。
4. シャーシまたはラック サーバが電源投入され到達可能であることを確認します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: ha-not-ready
mibFaultCode: F0429
mibFaultName: fltMgmtEntityHaNotReady
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]

fltMgmtEntityVersion-incompatible

障害コード : F0430

Message: Fabric Interconnect [id], management services, incompatible versions

説明 :

この障害は、下位ファブリック インターコネクトの Cisco UCS Manager ソフトウェアが、プライマリ ファブリック インターコネクトのソフトウェアと同じリリースでない場合に発生します。これは、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 下位ファブリック インターコネクトの Cisco UCS Manager ソフトウェアをプライマリ ファブリック インターコネクトと同じリリースにアップグレードし、両方のファブリック インターコネクトが同じリリースの Cisco UCS Manager を実行していることを確認します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: version-incompatible
mibFaultCode: F0430
mibFaultName: fltMgmtEntityVersionIncompatible
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltEquipmentFanMissing

障害コード : F0434

Message: Fan [id] in fabric interconnect [id] presence: [presence] Fan [id] in fex [id] presence: [presence] Fan [id] in Fan Module [tray]-[id] under server [id] presence: [presence] Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] presence: [presence]

説明 :

この障害は、ファン モジュールのファンを検出できないという、まれなイベントで発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 問題を報告しているスロットにファン モジュールを挿入/再挿入します。
2. 可能な場合は、ファン モジュールを別のファン モジュールと交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F0434
mibFaultName: fltEquipmentFanMissing
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
```

Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]

fltEquipmentIOCardAutoUpgradingFirmware

障害コード : F0435

Message: IOM [chassisId]/[id] ([switchId]) is auto upgrading firmware

説明 :

通常、この障害は、I/O モジュールが自動アップグレードである場合に発生します。自動アップグレードは、IOM のファームウェア バージョンがファブリック インターコネクトのファームウェア バージョンと互換性がない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. IOM とファブリック インターコネクトが同じファームウェア バージョンを実行していない場合は、自動アップグレードの完了を待ちます。
2. IOM のアップグレードが完了したら、Cisco UCS Manager によってこの障害がクリアされていることを確認します。
3. IOM の全体的なステータスが動作可能に変わった後でもこの障害が発生している場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: auto-firmware-upgrade
mibFaultCode: F0435
mibFaultName: fltEquipmentIOCardAutoUpgradingFirmware
moClass: equipment:IOCard
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

fltFirmwarePackItemImageMissing

障害コード : F0436

Message: [type] image with vendor [hwVendor], model [hwModel] and version [version] is deleted

説明 :

通常、この障害は、ファームウェアパッケージ項目で参照しているイメージが欠落している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager GUI で、[Firmware Management Images] タブに移動し、欠落しているイメージが入手可能かどうかを確認します。

2. イメージが存在する場合は、クリックして、モデルおよびベンダーを確認します。
3. 必要なモデルおよびベンダーのイメージが存在していない場合は、イメージまたはバンドルを Cisco.com Web サイトからダウンロードします。
4. イメージが存在し、障害が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: image-deleted
mibFaultCode: F0436
mibFaultName: fltFirmwarePackItemImageMissing
moClass: firmware:PackItem
Type: management
autoCleared: true
Affected MO: org-[name]/fw-catalog-pack-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/fw-catalog-pack-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO: org-[name]/fw-chassis-pack-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/fw-chassis-pack-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO: org-[name]/fw-host-pack-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/fw-host-pack-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO: org-[name]/fw-infra-pack-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/fw-infra-pack-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO: org-[name]/fw-mgmt-pack-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/fw-mgmt-pack-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO: org-[name]/pack-image-[hwVendor] | [hwModel] | [type]
Affected MO:
org-[name]/update-backup-version-holder-[bundleType]/pack-image-[hwVendor] | [hwModel] | [type]
```

fltEtherSwitchIntFloSatellite-wiring-numbers-unexpected

障害コード : F0440

Message: Chassis discovery policy conflict: Link IOM [chassisId]/[slotId]/[portId] to peer port [switchId]:[peerChassisId]/[peerSlotId]/[peerPortId] not configured

説明 :

シャーシのディスカバリ ポリシーの設定が、物理的な IOM アップリンクと矛盾しています。Cisco UCS Manager は、シャーシの IOM アップリンクとファブリック インターコネクト間の物理的なケーブル接続よりも多い数のリンクがシャーシのディスカバリ ポリシーに設定されている場合に、この障害を発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシのディスカバリ ポリシーに設定されている数と同じ数以上の IOM アップリンクをケーブル接続し、それに対応する数のサーバ ポートをファブリック インターコネクトに設定していることを確認します。

2. シャーシを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: info
Cause: unexpected-number-of-links
mibFaultCode: F0440
mibFaultName: fltEtherSwitchIntFioSatelliteWiringNumbersUnexpected
moClass: ether:SwitchIntFio
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltMgmtEntityManagement-services-failure

障害コード : F0451

Message: Fabric Interconnect [id], management services have failed

説明 :

この障害は、ファブリックインターコネクトで管理サービスが失敗するという、まれなイベントで発生します。これは、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 両方のファブリック インターコネクトで初期設定が正しいことを確認します。
2. L1 および L2 リンクがファブリック インターコネクトの間で適切に接続されていることを確認します。
3. ファブリック インターコネクトをリブートします。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: management-services-failure
mibFaultCode: F0451
mibFaultName: fltMgmtEntityManagementServicesFailure
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityManagement-services-unresponsive

障害コード : F0452

Message: Fabric Interconnect [id], management services are unresponsive

説明 :

この障害は、ファブリック インターコネクトの管理サービスが応答しない場合に発生します。これは、ファブリック インターコネクト クラスタのフル HA 機能に影響します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 両方のファブリック インターコネクトで初期設定が正しいことを確認します。
2. L1 および L2 リンクがファブリック インターコネクトの間で適切に接続されていることを確認します。
3. ファブリック インターコネクトをリブートします。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: critical
Cause: management-services-unresponsive
mibFaultCode: F0452
mibFaultName: fltMgmtEntityManagementServicesUnresponsive
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]

fltEquipmentChassisInoperable

障害コード : F0456

Message: Chassis [id] operability: [operability]

説明 :

通常、この障害は、次のいずれかの理由により発生します。

- ファブリック インターコネクトがシャーシと通信できない。クラスタ構成の場合、この障害はファブリック インターコネクトもシャーシと通信できないことを意味します。
- シャーシに無効な FRU があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager で、障害が発生したシャーシを再認識します。
2. 物理的にシャーシの電源コードを取り外し、再接続します。

3. I/O モジュールが機能していることを確認します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: F0456
mibFaultName: fltEquipmentChassisInoperable
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEtherServerIntFioHardware-failure

障害コード : F0458

Message: IOM [transport] interface [portId] on chassis [id] oper state: [operState], reason: [stateQual]Fabric Interconnect [transport] interface [portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]IOM [transport] interface [portId] on fex [id] oper state: [operState], reason: [stateQual]

説明 :

この障害は、IOM/FEX バックプレーン ポートで、Cisco UCS Manager がハードウェアの障害を検出した場合に発生します。

推奨処置 :

この障害が発生した場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: interface-failed
mibFaultCode: F0458
mibFaultName: fltEtherServerIntFioHardwareFailure
moClass: ether:ServerIntFio
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/rack-unit-[id]/diag/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltDcxVcMgmt-vif-down

障害コード : F0459

Message: IOM [chassisId] / [slotId] ([switchId]) management VIF [id] down, reason [stateQual]

説明 :

この障害は、I/O モジュールの転送 VIF がダウンしている場合に発生します。Cisco UCS Manager は、ファブリックインターコネクトが仮想インターフェイスの接続状態を次のいずれかとしてレポートした場合に、この障害が発生します。

- Down
- エラー
- 使用不可

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシの検出が正常に完了していることを確認します。エンドツーエンドですべての通信ポートの状態をチェックします。
2. 接続は正しいと思われる場合は、いったんシャーシを停止し、再始動します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: cmc-vif-down
mibFaultCode: F0459
mibFaultName: fltDcxVcMgmtVifDown
moClass: dcx:Vc
Type: network
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
```

SEM 障害 Cisco UCS Manager

Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]

Affected MO: sys/switch-[id]/ethlanflowmon/vc-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vc-[id]

fltSysdebugMEpLogMEpLogLog

障害コード : F0460

Message: Log capacity on [side] IOM [chassisId]/[id] is [capacity] Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity] Log capacity on Management Controller on server [id] is [capacity] Log capacity on Management Controller on server [chassisId]/[slotId]/[serverInstanceId] is [capacity]

説明 :

通常、この障害は、サーバのシステム イベント ログ (SEL) が最大容量に近づいていることを Cisco UCS Manager が検出したために発生します。ログの空き容量は少なくなっています。これは、情報レベルの障害であり、現時点で SEL をクリアしない場合は、無視できます。

推奨処置 :

この障害が発生した場合は、必要に応じて Cisco UCS Manager の SEL をクリアできます。

障害の詳細

Severity: info
Cause: log-capacity
mibFaultCode: F0460
mibFaultName: fltSysdebugMEpLogMEpLogLog
moClass: sysdebug:MEpLog
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/log-[type]-[id]

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

fltSysdebugMEpLogMEpLogVeryLow

障害コード : F0461

Message: Log capacity on [side] IOM [chassisId]/[id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity]Log capacity on Management Controller on server [id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId]/[serverInstanceId] is [capacity]

説明 :

通常、この障害は、サーバのシステム イベント ログ (SEL) がほとんどいっぱいであることを Cisco UCS Manager が検出したために発生します。ログの空き容量は非常に少なくなっています。これは、情報レベルの障害であり、現時点で SEL をクリアしない場合は、無視できます。

推奨処置 :

この障害が発生した場合は、必要に応じて Cisco UCS Manager の SEL をクリアできます。

障害の詳細

Severity: info
Cause: log-capacity
mibFaultCode: F0461

```

mibFaultName: fltSysdebugMEpLogMEpLogVeryLow
moClass: sysdebug:MEpLog
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]

```

Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

fltSysdebugMEpLogMEpLogFull

障害コード : F0462

Message: Log capacity on [side] IOM [chassisId]/[id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId] is [capacity]Log capacity on Management Controller on server [id] is [capacity]Log capacity on Management Controller on server [chassisId]/[slotId]/[serverInstanceId] is [capacity]

説明 :

通常、この障害は、Cisco UCS Manager が SEL ポリシーで指定された場所に SEL ファイルを転送できなかったために発生します。これは、情報レベルの障害であり、現時点で SEL をクリアしない場合は、無視できます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SEL ポリシーの設定を確認し、指定された場所、ユーザ、およびパスワードが正しいことを確認します。
2. SEL を転送してクリアする必要がある、上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: info
Cause: log-capacity
mibFaultCode: F0462
mibFaultName: fltSysdebugMEpLogMEpLogFull
moClass: sysdebug:MEpLog
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/log-[type]-[id]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/log-[type]-[id]

Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/sas-expander-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/shared-io-module/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/slot-[id]/boardController/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/storage-[type]-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/fex-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]**Affected MO:**

sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]

Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/rack-unit-[id]/mgmt/log-[type]-[id]**Affected MO:** sys/switch-[id]/mgmt/log-[type]-[id]**fltComputePoolEmpty**

障害コード : F0463

Message: server pool [name] is empty

説明 :

通常、この障害は、選択したサーバ プールにサーバが含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバプール ポリシー資格情報の修飾子設定を確認します。サーバの検出後にポリシーが変更されている場合は、サーバを再認識します。
2. 手動でサービス プロファイルをサーバと関連付けます。
3. サーバプールを使用していない場合は、障害を無視します。

4. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0463
mibFaultName: fltComputePoolEmpty
moClass: compute:Pool
Type: server
autoCleared: true
Affected MO: org-[name]/compute-pool-[name]
```

fltUuidpoolPoolEmpty

障害コード : F0464

Message: UUID suffix pool [name] is empty

説明 :

通常、この障害は、UUID 接尾辞プールに UUID 接尾辞が含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プールが使用中である場合は、プールに UUID 接尾辞のブロックを追加します。
2. プールを使用していない場合は、この障害を無視します。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0464
mibFaultName: fltUuidpoolPoolEmpty
moClass: uuidpool:Pool
Type: server
autoCleared: true
Affected MO: org-[name]/uuid-pool-[name]
```

fltIppoolPoolEmpty

障害コード : F0465

Message: IP pool [name] is empty

説明 :

通常、この障害は、IP アドレス プールに IP アドレスが含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プールが使用中である場合は、プールに IP アドレスのブロックを追加します。

2. プールを使用していない場合は、この障害を無視します。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0465
mibFaultName: fltIppoolPoolEmpty
moClass: ippool:Pool
Type: server
autoCleared: true
Affected MO: fabric/lan/network-sets/ip-pool-[name]
Affected MO: org-[name]/ip-pool-[name]
```

fltMacpoolPoolEmpty

障害コード : F0466

Message: MAC pool [name] is empty

説明 :

通常、この障害は、MAC アドレス プールに MAC アドレスが含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プールが使用中である場合は、プールに MAC アドレスのブロックを追加します。
2. プールを使用していない場合は、この障害を無視します。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0466
mibFaultName: fltMacpoolPoolEmpty
moClass: macpool:Pool
Type: server
autoCleared: true
Affected MO: org-[name]/mac-pool-[name]
```

fltFirmwareUpdatableImageUnusable

障害コード : F0470

Message: backup image is unusable. reason: [operStateQual]

説明 :

通常、この障害は、エンドポイントのバックアップ ファームウェア イメージが使用不能である場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. エンドポイントの [FSM] タブで障害およびエラー メッセージを確認し、ファームウェア イメージが使用できない理由を特定します。
2. ファームウェア イメージが不良または破損している場合は、別のコピーをシスコ Web サイトからダウンロードし、新しいイメージでエンドポイントのバックアップバージョンを更新します。
3. イメージが存在し、障害が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: image-unusable
mibFaultCode: F0470
mibFaultName: fltFirmwareUpdatableImageUnusable
moClass: firmware:Updatable
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-updatable
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/boardController/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fw-updatable
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fw-updatable
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios/fw-updatable
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fw-updatable
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fw-updatable
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/psu-[id]/fw-updatable
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fw-updatable
Affected MO:
 sys/chassis-[id]/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fw-updatable
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-updatable
Affected MO: sys/fex-[id]/mgmt/fw-updatable
Affected MO: sys/fex-[id]/psu-[id]/fw-updatable
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-updatable
Affected MO: sys/mgmt/fw-updatable
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-updatable
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/bios/fw-updatable
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fw-updatable
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-updatable
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fw-updatable
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-updatable
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/mgmt/fw-updatable
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-updatable
Affected MO: sys/switch-[id]/mgmt/fw-updatable
Affected MO: sys/switch-[id]/psu-[id]/fw-updatable

fltFirmwareBootUnitCantBoot

障害コード : F0471

Message: unable to boot the startup image. End point booted with backup image

説明 :

通常、この障害は、エンドポイントのスタートアップファームウェアイメージが破損しているかまたは無効であり、エンドポイントがそのイメージから起動できない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. エンドポイントの [FSM] タブで障害およびエラー メッセージを確認し、ファームウェア イメージが使用できない理由を特定します。エラーメッセージには、通常、イメージが間違っている、またはチェックサムが失敗したなど、エンドポイントがスタートアップ イメージから起動できない理由の説明が含まれています。
2. ファームウェア イメージが不良または破損している場合は、別のコピーをシスコ Web サイトからダウンロードし、新しいイメージでエンドポイントのスタートアップバージョンを更新します。
3. 障害が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: image-cannot-boot
mibFaultCode: F0471
mibFaultName: fltFirmwareBootUnitCantBoot
moClass: firmware:BootUnit
Type: management
autoCleared: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit-[type]
Affected MO: capabilities/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
```

```

sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]

```

Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/psu-[id]/fw-boot-def/bootunit-[type]

fltFcpoolInitiatorsEmpty

障害コード : F0476

Message: FC pool [purpose] [name] is empty

説明 :

通常、この障害は、WWN プールに WWN が含まれていない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. プールが使用中である場合は、プールに WWN のブロックを追加します。
2. プールを使用していない場合は、この障害を無視します。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0476
mibFaultName: fltFcpoolInitiatorsEmpty
moClass: fcpool:Initiators
Type: server
autoCleared: true
Affected MO: org-[name]/wwn-pool-[name]
```

fltEquipmentIOCardInaccessible

障害コード : F0478

Message: [side] IOM [chassisId]/[id] ([switchId]) is inaccessible

説明：

通常、この障害は、I/O モジュールがファブリック インターコネクトとの接続を失ったために発生します。クラスタ構成では、シャーシは他の I/O モジュールにフェールオーバーします。スタンドアロン構成の場合、その I/O モジュールに関連付けられているシャーシのネットワーク接続は失われます。これによりネットワーク接続が失われ、I/O モジュールからのデータトラフィックが中断されるため、重大な障害となります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-inaccessible
mibFaultCode: F0478
mibFaultName: fltEquipmentIOCardInaccessible
moClass: equipment:IOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```


fltDcxVifLinkState

障害コード : F0479

Message: Virtual interface [id] link state is down**説明 :**

この障害は、Cisco UCS がアップリンク ポートからのデータを送受信できない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害の発生したアップリンク ポートを再度イネーブルにします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: vif-down
mibFaultCode: F0479
mibFaultName: fltDcxVifLinkState
moClass: dcx:Vif
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fcoe/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fcoe/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/fcoe/vif-[id]

```

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fcoe/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fcoe/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fcoe/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/pc-[portId]/vif-[id]
Affected MO:

```

sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/pc-[portId]/vif-[id]

```

fltEquipmentFanModuleDegraded

障害コード : F0480

Message: Fan module [tray]-[id] in chassis [id] operability: [operability] Fan module [tray]-[id] in server [id] operability: [operability] Fan module [tray]-[id] in fabric interconnect [id] operability: [operability] Fan module [tray]-[id] in rack-enclosure [id] operability: [operability]

説明 :

この障害は、ファン モジュールが動作しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファン モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファン モジュールに適切なエアフローを確保します。
3. ファン モジュールのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: minor

```

Cause: equipment-degraded
mibFaultCode: F0480
mibFaultName: fltEquipmentFanModuleDegraded
moClass: equipment:FanModule
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]

```

fltEquipmentIOCardPost-failure

障害コード : F0481

Message: [side] IOM [chassisId]/[id] ([switchId]) POST failure

説明 :

通常、この障害は、電源投入時自己診断テスト (POST) の実行中に I/O モジュールでエラーが発生した場合に発生します。この障害の影響は、POST 中に発生したエラーによって異なります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. I/O モジュールの POST の結果をチェックします。Cisco UCS Manager GUI では、I/O モジュールの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、I/O モジュールのスコープの下で **show post** コマンドを使用すると POST の結果にアクセスできます。
2. POST の結果が FRU エラーを示している場合、UCS Manager に FRU の障害が発生したかどうかをチェックし、その障害に対する推奨処置を実行します。
3. それ以外の場合は、I/O モジュールをリブートします。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-problem
mibFaultCode: F0481
mibFaultName: fltEquipmentIOCardPostFailure
moClass: equipment:IOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fltEquipmentFanPerfThresholdLowerNonRecoverable

障害コード : F0484

Message: Fan [id] in Fan Module [tray]-[id] under chassis [id] speed: [perf]Fan [id] in fabric interconnect [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under server [id] speed: [perf]Fan [id] in Fan Module [tray]-[id] under rack-enclosure [id] speed: [perf]

説明 :

この障害は、ファンコントローラから読み取ったファン速度が必要なファン速度よりかなり遅く、ファンに障害が発生した可能性がある場合に発生します。

推奨処置 :

この障害が発生した場合は、シャーシの詳細な **show tech-support** ファイルを作成し、ファンモジュールを交換します。必要に応じて、Cisco TAC に連絡してください。

障害の詳細

```
Severity: critical
Cause: performance-problem
mibFaultCode: F0484
mibFaultName: fltEquipmentFanPerfThresholdLowerNonRecoverable
moClass: equipment:Fan
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/fex-[id]/fan-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]
```

fltMemoryUnitIdentity-unestablishable

障害コード : F0502

Message: DIMM [location] on server [chassisId]/[slotId] has an invalid FRUDIMM [location] on server [id] has an invalid FRUDIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] has an invalid FRU

説明 :

通常、この障害は、サーバ内で Cisco UCS Manager がサポートされていない DIMM を検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. 上記のアクションで問題を解決できなかった場合は、サーバにサポートされていない DIMM または DIMM 設定がある可能性があります。 **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

Severity: warning

```

Cause: identity-unestablishable
mibFaultCode: F0502
mibFaultName: fltMemoryUnitIdentityUnestablishable
moClass: memory:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]

```

fltComputePhysicalPost-failure

障害コード : F0517

Message: Server [id] POST or diagnostic failureServer [chassisId]/[slotId] POST or diagnostic failureServer [chassisId]/[slotId]/[serverInstanceId] POST or diagnostic failure

説明 :

通常、この障害は、POST 中にサーバで診断障害またはエラーが発生した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で show post コマンドを使用すると POST の結果にアクセスできます。
2. サーバをリブートします。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** コマンドを実行し、シスコのテクニカルサポートにお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-problem
mibFaultCode: F0517
mibFaultName: fltComputePhysicalPostFailure
moClass: compute:Physical
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltEquipmentPsuOffline

障害コード : F0528

Message: Power supply [id] in chassis [id] power: [power]Power supply [id] in fabric interconnect [id] power: [power]Power supply [id] in fex [id] power: [power]Power supply [id] in server [id] power: [power]Power supply [id] in rack-enclosure [id] power: [power]

説明 :

通常、この障害は、Cisco UCS Manager が、シャーシ、ファブリック インターコネクト、または FEX の電源装置ユニットがオフラインになっていることを検出した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 電源コードが PSU および電源に正しく接続されていることを確認します。
2. 電源が 220 V であることを確認します。
3. PSU がシャーシまたはファブリック インターコネクトに適切に設置されていることを確認します。
4. PSU を取り外して再度設置します。
5. PSU を交換します。
6. 上記のアクションで問題を解決できなかった場合は、PSU の種類を書き留め、**show tech-support** コマンドを実行して、シスコのテクニカルサポートにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-offline
mibFaultCode: F0528
mibFaultName: fltEquipmentPsuOffline
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltStorageRaidBatteryInoperable

障害コード：F0531

Message: RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason] RAID Battery on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明：

この障害は、RAID バックアップ ユニットの動作しないときに発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. バックアップ ユニットのバッテリーの場合、バッテリーを交換します。
2. バックアップ ユニットのスーパーキャパシタ タイプでそのスーパーキャパシタが見つからない場合、その場所を確認し、ない場合は供給します。

3. バックアップユニットがスーパーキャパシタ タイプで TFM が見つからない場合、その場所を確認し、ない場合は供給します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0531
mibFaultName: fltStorageRaidBatteryInoperable
moClass: storage:RaidBattery
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/chassis-[id]/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery
```

fltSysdebugMEpLogTransferError

障害コード : F0532

Message: Server [chassisId]/[slotId] [type] transfer failed: [operState]Server [id] [type] transfer failed: [operState]

説明 :

この障害は、SEL など、管理対象のエンドポイント ログ ファイルを転送できなかった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害が SEL に関連している場合は、サーバの CIMC への接続を確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: file-transfer-failed
mibFaultCode: F0532
mibFaultName: fltSysdebugMEpLogTransferError
moClass: sysdebug:MEpLog
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
```


Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/mgmt/log-[type]-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/log-[type]-[id]
Affected MO: sys/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/log-[type]-[id]
Affected MO: sys/rack-unit-[id]/mgmt/log-[type]-[id]
Affected MO: sys/switch-[id]/mgmt/log-[type]-[id]

fltComputeRtcBatteryInoperable

障害コード : F0533

Message: RTC Battery on server [chassisId]/[slotId] operability: [operability]

説明 :

この障害は、CMOS のバッテリー電圧が正常な動作範囲を下回っている場合に発生します。これは、システム クロックに影響します。

推奨処置：

この障害が発生した場合は、CMOS バッテリーを交換します。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0533
mibFaultName: fltComputeRtcBatteryInoperable
moClass: compute:RtcBattery
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/rtc-battery
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/rtc-battery
Affected MO: sys/rack-unit-[id]/board/rtc-battery
```

fltMemoryBufferUnitThermalThresholdNonCritical

障害コード：F0535

Message: Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal]Buffer Unit [id] on server [id] temperature: [thermal]Buffer Unit [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明：

この障害は、ブレードまたはラック サーバのメモリ バッファ装置の温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。

4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: info
Cause: thermal-problem
mibFaultCode: F0535
mibFaultName: fltMemoryBufferUnitThermalThresholdNonCritical
moClass: memory:BufferUnit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltMemoryBufferUnitThermalThresholdCritical

障害コード : F0536

Message: Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal]Buffer Unit [id] on server [id] temperature: [thermal]Buffer Unit [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラック サーバのメモリ バッファ装置の温度が重大しきい値を超えている場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0536
mibFaultName: fltMemoryBufferUnitThermalThresholdCritical
moClass: memory:BufferUnit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltMemoryBufferUnitThermalThresholdNonRecoverable

障害コード : F0537

Message: Buffer Unit [id] on server [chassisId]/[slotId] temperature: [thermal] Buffer Unit [id] on server [id] temperature: [thermal] Buffer Unit [id] on server [chassisId]/[slotId]/[serverInstanceId] temperature: [thermal]

説明 :

この障害は、ブレードまたはラック サーバのメモリ バッファ装置の温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。

- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0537
mibFaultName: fltMemoryBufferUnitThermalThresholdNonRecoverable
moClass: memory:BufferUnit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]
```

fltComputeIOHubThermalNonCritical

障害コード：F0538

Message: IO Hub on server [chassisId]/[slotId] temperature: [thermal]

説明：

この障害は、IO コントローラの温度が非重大しきい値より上または下に外れている場合に発生します。

推奨処置：

この障害が発生した場合は、このサーバに関連するその他の環境イベントをモニタし、温度範囲が推奨される範囲内にあることを確認します。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0538
mibFaultName: fltComputeIOHubThermalNonCritical
moClass: compute:IOHub
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub
Affected MO: sys/rack-unit-[id]/board/iohub
```

fltComputeIOHubThermalThresholdCritical

障害コード：F0539

Message: IO Hub on server [chassisId]/[slotId] temperature: [thermal]

説明：

この障害は、IO コントローラの温度が重大しきい値より上または下に外れている場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバに関連するその他の環境イベントをモニタし、温度範囲が推奨される範囲内にあることを確認します。
2. 可能であれば、しばらくの間、サーバの電源をオフにしておくことを検討してください。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0539
mibFaultName: fltComputeIOHubThermalThresholdCritical
moClass: compute:IOHub
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub
Affected MO: sys/rack-unit-[id]/board/iohub
```

fltComputeIOHubThermalThresholdNonRecoverable

障害コード : F0540

Message: IO Hub on server [chassisId]/[slotId] temperature: [thermal]

説明 :

この障害は、IO コントローラの温度が動作回復の可能な範囲から外れている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. すぐにサーバをシャットダウンします。
2. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0540
mibFaultName: fltComputeIOHubThermalThresholdNonRecoverable
moClass: compute:IOHub
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub
Affected MO: sys/rack-unit-[id]/board/iohub
```

fltEquipmentChassisIdentity-unestablishable

障害コード : F0543

Message: Chassis [id] has an invalid FRU

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないシャーシが検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** コマンドを実行し、シスコのテクニカル サポートにお問い合わせください。

障害の詳細

```
Severity: major
Cause: identity-unestablishable
mibFaultCode: F0543
```

```

mibFaultName: fltEquipmentChassisIdentityUnestablishable
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]

```

fltSwVlanPortNsResourceStatus

障害コード : F0549

Message: Vlan-Port Resource exceeded

説明 :

この障害は、Cisco UCS インスタンスの設定済み VLAN の合計数が、ファブリック インターコネクトの設定済み VLAN の最大許容数を越えた場合に発生します。

推奨処置 :

Cisco UCS Manager CLI または Cisco UCS Manager GUI でこの障害が発生した場合、ポート VLAN の数をチェックし、システムが VLAN の最大数をいくつ超過したかを確認します。次のいずれかの方法で VLAN ポート の数を減らします。

- LAN クラウドに設定されている VLAN を削除します。
- vNIC に設定されている VLAN を削除します。
- 1 つ以上の vNIC の設定を解除します。
- ファブリック インターコネクトの 1 つまたは複数のアップリンク イーサネット ポートの設定を解除します。
- この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: limit-reached
mibFaultCode: F0549
mibFaultName: fltSwVlanPortNsResourceStatus
moClass: sw:VlanPortNs
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/vlan-port-ns

```

fltFabricLanPinGroupEmpty

障害コード : F0621

Message: LAN Pin Group [name] is empty

説明 :

通常、この障害は、LAN ピン グループにターゲットが含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、LAN ピン グループにターゲットを追加します。

障害の詳細

```
Severity: minor
Cause: empty-pin-group
mibFaultCode: F0621
mibFaultName: fltFabricLanPinGroupEmpty
moClass: fabric:LanPinGroup
Type: server
autoCleared: true
Affected MO: fabric/lan/lan-pin-group-[name]
```

fltFabricSanPinGroupEmpty

障害コード : F0622

Message: SAN Pin Group [name] is empty

説明 :

通常、この障害は、SAN ピン グループにターゲットが含まれていない場合に発生します。

推奨処置 :

この障害が発生した場合は、SAN ピン グループにターゲットを追加します。

障害の詳細

```
Severity: minor
Cause: empty-pin-group
mibFaultCode: F0622
mibFaultName: fltFabricSanPinGroupEmpty
moClass: fabric:SanPinGroup
Type: server
autoCleared: true
Affected MO: fabric/san/san-pin-group-[name]
```

fltAdaptorExtEthIfMisConnect

障害コード : F0625

Message: Adapter [id] eth interface [id] in server [id] mis-connected

説明 :

ネットワーク側アダプタ インターフェイスへのリンクが誤って接続されています。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害を発生します。

- Cisco UCS Manager によって、以前に設定したスイッチ ポートまたは FEX ポートと、アダプタの外部インターフェイスとの間に新規接続が検出されている。
- Cisco UCS Manager によって、ファブリック インターコネクトまたは FEX と、その非ピアアダプタのインターフェイスとの間に、誤って接続されたリンクが検出されている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタのリンクが、ピア ファブリック インターコネクトまたは FEX に属するポートに接続されているかどうかを確認します。
2. この接続が正しいと思える場合は、サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: link-misconnected
mibFaultCode: F0625
mibFaultName: fltAdaptorExtEthIfMisConnect
moClass: adaptor:ExtEthIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]
```

fltAdaptorHostEthIfMisConnect

障害コード : F0626

Message: Adapter [id] eth interface [id] in server [id] mis-connected

説明 :

ネットワーク側ホスト インターフェイスへのリンクが誤って接続されています。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害を発生します。

- Cisco UCS Manager によって、以前に設定したスイッチ ポートと、ホストイーサネット インターフェイスとの間に新規接続が検出されている。
- Cisco UCS Manager によって、ホスト インターフェイスと非ピア ファブリック インターコネクトとの間に誤って接続されたリンクが検出されている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ホストイーサネット インターフェイスが、ピア ファブリック インターコネクトに属するポートに接続されているかどうかを確認します。
2. 接続が正しいと思える場合は、サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: link-misconnected
mibFaultCode: F0626
```

```

mibFaultName: fltAdaptorHostEthIfMisConnect
moClass: adaptor:HostEthIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]

```

fltPowerBudgetPowerBudgetCmcProblem

障害コード : F0635

Message: Power cap application failed for chassis [id]

説明 :

通常、この障害は、サーバ CIMC が設定済み電力制限の強制に失敗した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシの電力消費をチェックします。シャーシが電力制限で設定されている電力よりもかなり多くの電力を消費している場合は、他のシャーシの電力消費を削減して増分を相殺できるように、グループの上限を減らすことを検討します。
2. 上記のアクションで問題を解決できなかった場合は、Cisco UCS Manager とシャーシの **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: power-cap-fail
mibFaultCode: F0635
mibFaultName: fltPowerBudgetPowerBudgetCmcProblem
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget

```

fltPowerBudgetPowerBudgetBmcProblem

障害コード : F0637

Message: Power cap application failed for server [chassisId]/[slotId]Power cap application failed for server [id]

説明 :

通常、この障害は、サーバ CIMC または BIOS が設定済み電力制限の強制に失敗した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ブレードサーバの電力消費をチェックします。サーバが電力制限に設定されている電力よりもかなり多くの電力を消費している場合は、ブレードの制限設定ごとに手動に切り替えます。電力消費がまだ多すぎる場合は、他のシャーシの電力消費を削減して増分を相殺できるように、グループの上限を減らすことを検討します。
2. 電力消費がまだ多すぎる場合、CIMC または BIOS のソフトウェアで障害が発生している可能性があります。
3. Cisco UCS Manager とシャーシの **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: power-cap-fail
mibFaultCode: F0637
mibFaultName: fltPowerBudgetPowerBudgetBmcProblem
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget
```

fltPowerBudgetPowerBudgetDiscFail

障害コード：F0640

Message: Insufficient power available to discover server [chassisId]/[slotId]Insufficient power available to discover server [id]

説明：

通常、この障害は、グループに使用できる電力がないために検出が失敗した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. グループの上限を増やすことを検討します。
2. Cisco UCS インスタンスのブレードサーバまたはシャーシの数を減らします。

- 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: power-cap-fail
mibFaultCode: F0640
mibFaultName: fltPowerBudgetPowerBudgetDiscFail
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget
```

fltPowerGroupPowerGroupInsufficientBudget

障害コード : F0642

Message: insufficient budget for power group [name]

説明 :

通常、この障害は、グループの上限が最小ハードウェア要件に満たない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

- グループの上限を増やすことを検討します。
- Cisco UCS インスタンスのブレード サーバまたはシャーシの数を減らします。
- 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: power-cap-fail
mibFaultCode: F0642
mibFaultName: fltPowerGroupPowerGroupInsufficientBudget
moClass: power:Group
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]
```

fltPowerGroupPowerGroupBudgetIncorrect

障害コード : F0643

Message: admin committed insufficient for power group [name], using previous value [operCommitted]

説明 :

通常、この障害は、グループの上限が最小ハードウェア要件に満たない場合に発生します。このような状況では、Cisco UCS Manager は、プロビジョニングのために以前に入力したグループの上限を使用します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. グループの上限を増やすことを検討します。
2. Cisco UCS インスタンスのブレードサーバまたはシャーシの数を減らします。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: power-cap-fail
mibFaultCode: F0643
mibFaultName: fltPowerGroupPowerGroupBudgetIncorrect
moClass: power:Group
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]

fltLicenseInstanceGracePeriodWarning1

障害コード : F0670

Message: One or more ports with license type [feature] on fabric-interconnect [scope] have started using license grace period.

説明 :

ファブリック インターコネクトの少なくとも 1 台のポートが猶予期間で動作しています。通常、この障害は、すべてのデフォルトライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになっている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクトにインストールされ、使用中になっているライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクトの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: license-graceperiod-entered
mibFaultCode: F0670
mibFaultName: fltLicenseInstanceGracePeriodWarning1
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

fltLicenseInstanceGracePeriodWarning2

障害コード : F0671

Message: One or more ports with license type [feature] on fabric-interconnect [scope] are running in the grace period for more than 10 days

説明 :

ファブリック インターコネクトの少なくとも 1 台のポートが、10 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 10 日より長く実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクトにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクトの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: license-graceperiod-10days
mibFaultCode: F0671
mibFaultName: fltLicenseInstanceGracePeriodWarning2
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

fltLicenseInstanceGracePeriodWarning3

障害コード : F0672

Message: One or more ports with license type [feature] on fabric-interconnect [scope] are running in the grace period for more than 30 days

説明 :

ファブリック インターコネクトの少なくとも 1 台のポートが、30 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 30 日より長く実行している場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクトにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクトの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: license-graceperiod-30days
mibFaultCode: F0672
mibFaultName: fltLicenseInstanceGracePeriodWarning3
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fltLicenseInstanceGracePeriodWarning4

障害コード：F0673

Message: One or more ports with license type [feature] on fabric-interconnect [scope] are running in the grace period for more than 60 days

説明：

ファブリック インターコネクトの少なくとも 1 台のポートが、60 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 60 日より長く実行している場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクトにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクトの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: license-graceperiod-60days
mibFaultCode: F0673
mibFaultName: fltLicenseInstanceGracePeriodWarning4
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

fltLicenseInstanceGracePeriodWarning5

障害コード : F0674

Message: One or more ports with license type [feature] on fabric-interconnect [scope] are running in the grace period for more than 90 days

説明 :

ファブリック インターコネクトの少なくとも 1 台のポートが、90 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 90 日より長く実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクトにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクトの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: license-graceperiod-90days
mibFaultCode: F0674
mibFaultName: fltLicenseInstanceGracePeriodWarning5
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]

fltLicenseInstanceGracePeriodWarning6

障害コード : F0675

Message: One or more ports with license type [feature] on fabric-interconnect [scope] are running in the grace period for more than 119 days

説明 :

ファブリック インターコネクットの少なくとも 1 台のポートが、119 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 119 日より長く実行している場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクットにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクットの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: license-graceperiod-119days
mibFaultCode: F0675
mibFaultName: fltLicenseInstanceGracePeriodWarning6
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fltLicenseInstanceGracePeriodWarning7

障害コード：F0676

Message: Grace period of one or more ports with license type [feature] on fabric-interconnect [scope] is expired. Please acquire a license for the same.

説明：

ファブリック インターコネクットの少なくとも 1 台のポートが、120 日より長く猶予期間で動作しています。通常、この障害は、すべてのデフォルト ライセンスがポートに割り当てられた後、固定モジュールの 1 つ以上のポートがイネーブルになり、ライセンスされていないポートが 120 日より長く実行している場合に発生します。この段階で、システムのライセンス状態は期限切れに設定されます。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 各ファブリック インターコネクットにインストールされ、消費されるライセンスの数を確認します。Cisco UCS Manager GUI では、ファブリック インターコネクットの [Admin] タブからライセンス情報にアクセスできます。Cisco UCS Manager CLI では、ライセンスのスコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. ライセンスが設定されていないポートをディセーブルにして、イネーブルになっているポートの数を合計ライセンス数まで下げます。

- 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、ただちに Cisco TAC に問い合わせして、ライセンスを取得してください。

障害の詳細

```
Severity: critical
Cause: license-graceperiod-expired
mibFaultCode: F0676
mibFaultName: fltLicenseInstanceGracePeriodWarning7
moClass: license:Instance
Type: management
autoCleared: true
Affected MO: sys/license/feature-[name]-[vendor]-[version]/inst-[scope]
```

fltLicenseFileBadLicenseFile

障害コード : F0677

Message: license file [name] on fabric-interconnect [scope] can not be installed

説明 :

ファブリック インターコネクトのライセンスファイルのインストールに失敗しました。通常、この障害は、ライセンス ファイルが誤ってフォーマットされているか、ホスト ID がファブリック インターコネクトのホスト ID と一致していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

- Cisco UCS Manager CLI で、両方のファブリック インターコネクトのホスト ID を確認します。ライセンスのスコープの下で show server-host-id detail コマンドを入力すると、ホスト ID 情報にアクセスできます。
- ホスト ID とライセンス ファイルの内容を照合します。ホスト ID がいずれかのファブリック インターコネクトのホスト ID と一致している場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。一致していない場合は、Cisco TAC に連絡し、正しいライセンス ファイルを入手してください。

障害の詳細

```
Severity: critical
Cause: license-file-uninstallable
mibFaultCode: F0677
mibFaultName: fltLicenseFileBadLicenseFile
moClass: license:File
Type: management
autoCleared: false
Affected MO: sys/license/file-[scope]:[id]
```

fltLicenseFileFileNotDeleted

障害コード : F0678

Message: license file [name] from fabric-interconnect [scope] could not be deleted

説明：

ファブリック インターコネクトのライセンス ファイルの削除に失敗しました。通常、この障害は、ライセンス フレームワークでファイルを削除できない場合に発生します。

推奨処置：

この障害が発生した場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: license-file-not-deleted
mibFaultCode: F0678
mibFaultName: fltLicenseFileFileNotDeleted
moClass: license:File
Type: management
autoCleared: false
Affected MO: sys/license/file-[scope]:[id]
```

fltMgmtIfMisConnect

障害コード：F0688

Message: Management Port [id] in server [id] is mis connected

説明：

この障害は、サーバと FEX の接続が変更された場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバと FEX の間の接続を確認します。
2. 接続が誤って変更されている場合は、以前の設定に復元します。
3. 接続の変更が意図的であった場合は、サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: link-misconnected
mibFaultCode: F0688
mibFaultName: fltMgmtIfMisConnect
moClass: mgmt:If
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
```

```

sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fltLsComputeBindingAssignmentRequirementsNotMet

障害コード : F0689

Message: Assignment of service profile [name] to server [pnDn] failed

説明：

選択したサービスプロファイルにサーバを割り当てられませんでした。通常、この障害は、次のいずれかの問題の結果として発生します。

- 選択したサーバがサービスプロファイルの要件を満たしていない。
- サービスプロファイルが制限付き移行用に設定されている場合、選択したサーバが現在または以前に割り当てられているサーバと一致していない。

推奨処置：

この障害が発生した場合は、サービスプロファイルの要件を満たしているか、現在または以前に割り当てられているサーバと一致する別のサーバを選択します。

障害の詳細

```
Severity: minor
Cause: assignment-failed
mibFaultCode: F0689
mibFaultName: fltLsComputeBindingAssignmentRequirementsNotMet
moClass: ls:ComputeBinding
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]/pn
Affected MO: org-[name]/ls-[name]/pn-req
Affected MO: org-[name]/tier-[name]/ls-[name]/pn
Affected MO: org-[name]/tier-[name]/ls-[name]/pn-req
```

fltEquipmentFexPost-failure

障害コード：F0702

Message: fex [id] POST failure

説明：

通常、この障害は、電源投入時自己診断テスト（POST）の実行中に FEX でエラーが発生した場合に発生します。この障害の影響は、POST の実行中にどのエラーが発生したかによって異なります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. FEX の POST の結果をチェックします。Cisco UCS Manager GUI では、FEX の [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、FEX のスコープの下で **show post** コマンドを入力すると、POST の結果にアクセスできます。
2. FEX をリブートします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-problem
mibFaultCode: F0702
mibFaultName: fltEquipmentFexPostFailure
moClass: equipment:Fex
Type: equipment
autoCleared: true
Affected MO: sys/fex-[id]
```

fltEquipmentFexIdentity

障害コード : F0703

Message: Fex [id] has a malformed FRU

説明 :

通常、この障害は、FEX の FRU 情報が破損した場合、または不正な形式の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F0703
mibFaultName: fltEquipmentFexIdentity
moClass: equipment:Fex
Type: equipment
autoCleared: true
Affected MO: sys/fex-[id]
```

fltAdaptorHostEthIfMissing

障害コード : F0708

Message: Connection to Adapter [id] eth interface [id] in server [id] missing

説明 :

ネットワーク側ホスト インターフェイスへのリンクが欠落しています。Cisco UCS Manager は、以前に設定されたスイッチ ポートと、以前のピア ホスト インターフェイスとの間に欠落した接続を検出すると、この障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタのリンクが、非ピア ファブリック インターコネクに属するポートに接続されているかどうかを確認します。

2. この接続が正しいと思える場合は、サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: link-missing
mibFaultCode: F0708
mibFaultName: fltAdaptorHostEthIfMissing
moClass: adaptor:HostEthIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]
```

fltPortPioInvalid-sfp

障害コード : F0713

Message: [transport] port [portId] on chassis [id] role : [ifRole] transceiver type:[xcvrType][transport]
 port [slotId]/[aggrPortId]/[portId] on fabric interconnect [id] role : [ifRole] transceiver
 type:[xcvrType][transport] port [slotId]/[portId] on fabric interconnect [id] role : [ifRole] transceiver
 type:[xcvrType]

説明 :

この障害は、サポートされていないトランシーバの種類を挿入した場合に、ファブリックインターコネクトポート、ネットワーク側の IOM ポート、または FEX モジュールポートに対して発生します。ポートにサポートされていないトランシーバがある場合、そのポートは使用できません。

推奨処置 :

この障害が発生した場合は、トランシーバをサポート対象の SFP タイプと交換します。サポート対象の SFP のリストについては、シスコ Web サイトにあるドキュメンテーションを参照してください。

障害の詳細

```
Severity: major
Cause: unsupported-transceiver
mibFaultCode: F0713
mibFaultName: fltPortPioInvalidSfp
moClass: port:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
```


Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

fltMgmtIfMissing

障害コード : F0717

Message: Connection to Management Port [id] in server [id] is missing

説明 :

この障害は、サーバと FEX 間の接続が削除または設定解除された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバと FEX の間の接続を確認します。
2. 接続が誤って変更されている場合は、以前の設定に復元します。
3. 接続の変更が意図的であった場合は、サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: warning
Cause: link-missing
mibFaultCode: F0717
mibFaultName: fltMgmtIfMissing
moClass: mgmt:If
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO:

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

```

fltFabricEthLanPcEpDown

障害コード : F0727

Message: [type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

説明 :

通常、この障害は、イーサネット ポート チャンネルのメンバ ポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム イーサネット スイッチのリンクの接続をチェックします。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F0727
mibFaultName: fltFabricEthLanPcEpDown
moClass: fabric:EthLanPcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
```

fltFabricFcSanPcEpDown

障害コード : F0728

Message: [type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

説明 :

通常、この障害は、ファイバチャネルポートチャネルのメンバーポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリームのファイバチャネルスイッチのリンク接続を確認します。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F0728
mibFaultName: fltFabricFcSanPcEpDown
moClass: fabric:FcSanPcEp
Type: network
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
```

fltEquipmentIOCardThermalThresholdNonCritical

障害コード : F0729

Message: [side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、I/O モジュールの温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 設置場所のクリーニングを定期的 to 実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。

8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F0729
mibFaultName: fltEquipmentIOCardThermalThresholdNonCritical
moClass: equipment:IOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardThermalThresholdCritical

障害コード : F0730

Message: [side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、I/O モジュールの温度が重大しき値を超えた場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的 to 実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。

8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0730
mibFaultName: fltEquipmentIOCardThermalThresholdCritical
moClass: equipment:IOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentIOCardThermalThresholdNonRecoverable

障害コード : F0731

Message: [side] IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、I/O モジュールの温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。

5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F0731
mibFaultName: fltEquipmentIOCardThermalThresholdNonRecoverable
moClass: equipment:IOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentChassisSeeprom-inoperable

障害コード : F0733

Message: Device [id] SEEPROM operability: [seepromOperState]

説明 :

この障害は、シャーシの共有ストレージ (SEEPROM) が動作しないという、まれなイベントで発生します。

推奨処置 :

この障害が発生した場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: F0733
mibFaultName: fltEquipmentChassisSeepromInoperable
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltFabricFcSanPcEpIncompatibleSpeed

障害コード : F0734

Message: Member [slotId]/[portId] cannot be added to SAN Port-Channel [portId] on fabric interconnect [id], reason: [membership]

説明 :

通常、この障害は、ファイバチャネルポートチャネルの、サポートされるポートの最大ファイバチャネル速度が、ポートチャネルに対して設定された **admin** 速度に対応していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理のいずれかを実行します。

- ポートチャネルのメンバポートでサポートされる最大速度と一致するように、ポートチャネルの **admin** 速度を変更します。
- ファブリックインターコネクットの拡張モジュールを、ポートチャネルに設定された **admin** 速度と一致する拡張モジュールと交換します。

障害の詳細

```
Severity: major
Cause: incompatible-speed
mibFaultCode: F0734
mibFaultName: fltFabricFcSanPcEpIncompatibleSpeed
moClass: fabric:FcSanPcEp
Type: network
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
```

fltFabricFcSanPcIncompatibleSpeed

障害コード : F0735

Message: Cannot set admin speed to the requested value, Speed incompatible with member ports in the port-channel

説明 :

通常、この障害は、ファイバチャネルポートチャネルの、サポートされるポートの最大ファイバチャネル速度が、ポートチャネルに対して設定された **admin** 速度に対応していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理のいずれかを実行します。

- ポートチャネルのメンバポートでサポートされる最大速度と一致するように、ポートチャネルの **admin** 速度を変更します。
- ファブリックインターコネクットの拡張モジュールを、ポートチャネルに設定された **admin** 速度と一致する拡張モジュールと交換します。

障害の詳細

Severity: major
Cause: incompatible-speed
mibFaultCode: F0735
mibFaultName: fltFabricFcSanPcIncompatibleSpeed
moClass: fabric:FcSanPc
Type: network
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]

fltExtmgmtIfMgmtifdown

障害コード : F0736

Message: Management interface on Fabric Interconnect [id] is [operState]

説明 :

この障害は、ファブリックインターコネクトによって、外部管理インターフェイスの動作状態がダウンになっていることが報告された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトの外部管理インターフェイスの状態遷移をチェックします。
2. 外部管理インターフェイスのリンク接続をチェックします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: major
Cause: mgmtif-down
mibFaultCode: F0736
mibFaultName: fltExtmgmtIfMgmtifdown
moClass: extmgmt:If
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/extmgmt-intf

fltPowerChassisMemberPowerGroupCapInsufficient

障害コード : F0740

Message: Chassis [id] cannot be capped as group cap is low. Please consider raising the cap.

説明 :

通常、この障害は、更新されたグループの上限が最小ハードウェア要件を満たすのに不十分なため、結果として、電力グループに追加されたシャーンを制限できない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. グループの上限を増やすことを検討します。
2. Cisco UCS インスタンスのブレードサーバまたはシャーシの数を減らします。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: group-cap-insufficient
mibFaultCode: F0740
mibFaultName: fltPowerChassisMemberPowerGroupCapInsufficient
moClass: power:ChassisMember
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]/ch-member-[id]
```

fltPowerChassisMemberChassisFirmwareProblem

障害コード : F0741

Message: Chassis [id] cannot be capped as at least one of the CMC or CIMC or BIOS firmware version is less than 1.4. Please upgrade the firmware for cap to be applied.

説明 :

通常、この障害は、サーバの CIMC ファームウェアが Cisco UCS Release 1.4 よりも前のリリースである場合に発生します。

推奨処置 :

この障害が発生した場合は、CIMC ファームウェア（および必要に応じて Cisco UCS インスタンスすべて）を、Cisco UCS Release 1.4 以降にアップグレードすることを検討してください。

障害の詳細

```
Severity: major
Cause: old-chassis-component-firmware
mibFaultCode: F0741
mibFaultName: fltPowerChassisMemberChassisFirmwareProblem
moClass: power:ChassisMember
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]/ch-member-[id]
```

fltPowerChassisMemberChassisPsuInsufficient

障害コード : F0742

Message: Chassis [id] cannot be capped as at least two PSU need to be powered

説明 :

通常、この障害は、少なくとも 2 台の PSU に電源が投入されていない場合に発生します。

推奨処置：

この障害が発生した場合は、少なくとも 2 台の PSU を取り付け、電源をオンにします。

障害の詳細

Severity: major
Cause: psu-insufficient
mibFaultCode: F0742
mibFaultName: fltPowerChassisMemberChassisPsuInsufficient
moClass: power:ChassisMember
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]/ch-member-[id]

fltPowerChassisMemberChassisPsuRedundanceFailure

障害コード：F0743

Message: Chassis [id] was configured for redundancy, but running in a non-redundant configuration.

説明：

通常、この障害は、シャーシの電源冗長に失敗した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. シャーシに PSU を追加することを検討します。
2. 動作しない PSU をすべて交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: major
Cause: psu-redundancy-fail
mibFaultCode: F0743
mibFaultName: fltPowerChassisMemberChassisPsuRedundanceFailure
moClass: power:ChassisMember
Type: environmental
autoCleared: true
Affected MO: sys/power-ep/group-[name]/ch-member-[id]

fltPowerBudgetPowerCapReachedCommit

障害コード：F0744

Message: P-State lowered as consumption hit power cap for server [chassisId]/[slotId]P-State lowered as consumption hit power cap for server [id]

説明：

通常、この障害は、Cisco UCS Manager がアクティブにブレード サーバの電力を制限している場合に発生します。

推奨処置：

この障害が発生した場合に必要なアクションはありません。

障害の詳細

```
Severity: info
Cause: power-consumption-hit-limit
mibFaultCode: F0744
mibFaultName: fltPowerBudgetPowerCapReachedCommit
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget
```

fltSysdebugAutoCoreFileExportTargetAutoCoreTransferFailure

障害コード：F0747

Message: Auto core transfer failure at remote server [hostname]:[path] [exportFailureReason]

説明：

この障害は、Cisco UCS Manager がリモート TFTP サーバにコア ファイルを転送できない場合に発生します。これは、通常、次のいずれかの問題の結果として発生します。

- リモート TFTP サーバにアクセスできない。
- パス、ポート、サーバ名など、コアエクスポートターゲットに指定されている TFTP サーバの 1 つまたは複数のパラメータが間違っている。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. リモート サーバへの接続を確認します。
2. リモート サーバのパス情報を確認します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: tftp-server-error
mibFaultCode: F0747
mibFaultName: fltSysdebugAutoCoreFileExportTargetAutoCoreTransferFailure
moClass: sysdebug:AutoCoreFileExportTarget
```

Type: sysdebug
autoCleared: true
Affected MO: sys/sysdebug/file-export

fltFabricMonSpanConfigFail

障害コード : F0757

Message: Configuration for traffic monitor [name] failed, reason: [configFailReason]

説明 :

通常、この障害は、トラフィック モニタリング セッションの設定が正しくない場合に発生します。

推奨処置 :

この障害が発生した場合は、障害の説明に示されている設定の問題を修正します。

障害の詳細

Severity: major
Cause: config-error
mibFaultCode: F0757
mibFaultName: fltFabricMonSpanConfigFail
moClass: fabric:Mon
Type: network
autoCleared: true
Affected MO: fabric/lanmon/[id]/eth-mon-[name]
Affected MO: fabric/sanmon/[id]/fc-mon-[name]

fltPowerBudgetChassisPsuInsufficient

障害コード : F0764

Message: Chassis [id] cannot be capped as the available PSU power is not enough for the chassis and the blades. Please correct the problem by checking input power or replace the PSU

説明 :

通常、この障害は、使用可能な PSU 電源がシャーシとブレードの電力バジェットを導入するのに十分ではない場合に発生します。

推奨処置 :

この障害が発生した場合は、PSU 入力電源をチェックするか、PSU を交換します。

障害の詳細

Severity: major
Cause: psu-insufficient
mibFaultCode: F0764
mibFaultName: fltPowerBudgetChassisPsuInsufficient
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget

fltPowerBudgetTStateTransition

障害コード : F0765

Message: Blade [chassisId]/[slotId] has been severely throttled. CIMC はブレードにバジェットが再導入された場合、またはブレードをリブートすることによって、回復できます。If problem persists, please ensure that OS is ACPI compliant
 Rack server [id] has been severely throttled. CIMC はブレードにバジェットが再導入された場合、またはブレードをリブートすることによって、回復できます。If problem persists, please ensure that OS is ACPI compliant

説明 :

通常、この障害は、プロセッサの T 状態を使用して CPU を強く抑制している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 影響を受ける電力グループ、ブレードサーバ、またはシャーシの電力バジェットを再導入します。
2. 問題が解決しない場合は、ブレードサーバをリブートします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: critical
Cause: no-ack-from-bios
mibFaultCode: F0765
mibFaultName: fltPowerBudgetTStateTransition
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget

fltPowerPolicyPowerPolicyApplicationFail

障害コード : F0766

Message: Insufficient budget to apply no-cap priority through policy [name]. Blades will continue to be capped

説明 :

この障害は、電源ポリシーを1つ以上のブレードサーバに適用できない場合に発生します。影響を受けるブレードサーバは、それらのサーバの電力バジェットが制限されているため、電力制限なしで正常に動作することはできません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 電源ポリシー内のブレードサーバの電力バジェットを増やします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: no-cap-fail
mibFaultCode: F0766
mibFaultName: fltPowerPolicyPowerPolicyApplicationFail
moClass: power:Policy
Type: environmental
autoCleared: true
Affected MO: org-[name]/power-policy-[name]
Affected MO: policy-ep/system-policies/power-policy-[name]
```

fltMgmtIfNew

障害コード : F0772

Message: New connection discovered on Management Port [id] in server [id]

説明 :

この障害は、サーバと FEX 間の接続が追加または変更された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバと FEX の間の接続を確認します。
2. 接続が誤って変更されている場合は、以前の設定に復元します。
3. 接続の変更が意図的であった場合は、サーバを再認識します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: new-link
mibFaultCode: F0772
```

```

mibFaultName: fltMgmtIfNew
moClass: mgmt:If
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/mgmt/if-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/if-[id]
Affected MO: sys/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/if-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/if-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/if-[id]

```


Affected MO: sys/rack-unit-[id]/mgmt/if-[id]
Affected MO: sys/switch-[id]/mgmt/if-[id]

fltAdaptorExtEthIfMissing

障害コード : F0775

Message: Connection to Adapter [id] eth interface [id] in server [id] missing

説明 :

ネットワーク側アダプタ インターフェイスへのリンクが誤って接続されています。Cisco UCS Manager は、以前にファブリック インターコネクトまたは FEX に設定されたポートと、以前のピア ネットワーク側アダプタ インターフェイスとの間の接続が誤っているかまたは欠落していることを検出した場合に、この障害を発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタのインターフェイスが、ピア ファブリック インターコネクトまたは FEX に属するポートに接続されているかどうかを確認します。
2. この接続が正しいと思える場合は、サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: warning
Cause: link-missing
mibFaultCode: F0775
mibFaultName: fltAdaptorExtEthIfMissing
moClass: adaptor:ExtEthIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]

fltStorageLocalDiskSlotEpUnusable

障害コード : F0776

Message: Local disk [id] on server [serverId] is not usable by the operating system

説明 :

この障害は、サーバのディスク ドライブが、ストレージ コントローラでサポートされていないスロットに存在する場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サポートされているスロットにサーバのディスク ドライブを挿入します。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: equipment-inoperable
mibFaultCode: F0776
mibFaultName: fltStorageLocalDiskSlotEpUnusable
moClass: storage:LocalDiskSlotEp
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/disk-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/disk-[id]
Affected MO: sys/rack-unit-[id]/board/disk-[id]
```

fltFabricEthEstcPcEpDown

障害コード : F0777

Message: [type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

説明 :

通常、この障害は、イーサネット ポート チャンネルのメンバポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム イーサネット スイッチのリンクの接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F0777
mibFaultName: fltFabricEthEstcPcEpDown
moClass: fabric:EthEstcPcEp
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
```

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

fltEquipmentFexIdentity-unestablishable

障害コード : F0778

Message: Chassis [id] has an invalid FRU

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないシャーシを検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: identity-unestablishable
mibFaultCode: F0778
mibFaultName: fltEquipmentFexIdentityUnestablishable
moClass: equipment:Fex
Type: equipment
autoCleared: true
Affected MO: sys/fex-[id]

fltEquipmentFanModuleInoperable

障害コード : F0794

Message: Fan module [tray]-[id] in chassis [id] operability: [operability] Fan module [tray]-[id] in server [id] operability: [operability] Fan module [tray]-[id] in fabric interconnect [id] operability: [operability] Fan module [tray]-[id] in rack-enclosure [id] operability: [operability]

説明 :

この障害は、ファン モジュールが動作しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファンモジュールを取り外して、もう一度取り付けてください。複数のファンがこの障害の影響を受けている場合は、一度に1つずつファンモジュールを取り外し、もう一度取り付けます。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F0794
mibFaultName: fltEquipmentFanModuleInoperable
moClass: equipment:FanModule
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]
```

fltLsmaintMaintPolicyUnresolvableScheduler

障害コード : F0795

Message: Schedule [schedName] referenced by maintenance policy [name] does not exist

説明 :

メンテナンスポリシーによって参照されているスケジュールが存在していません。通常、この障害は、次のいずれかの問題の結果として発生します。

- スケジュールが存在しない。
- スケジュールが削除された。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 指定されたスケジュールが存在するかどうかを確認します。削除または欠落している場合は、作成してみます。
2. 指定されたスケジュールが削除または欠落している場合は、再作成します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: non-existent-scheduler
mibFaultCode: F0795
mibFaultName: fltLsmaintMaintPolicyUnresolvableScheduler
```

```
moClass: lsmaint:MaintPolicy
Type: server
autoCleared: true
Affected MO: org-[name]/maint-[name]
```

fltFabricVsanErrorDisabled

障害コード : F0796

Message: VSAN [name] is [operState]

説明 :

通常、この障害は、VSAN の ID が 3840 ～ 4078 の制限付き範囲内にあり、ファブリック インターコネクトでファイバチャネルのエンドホストモードがイネーブルになっている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトのポートチャネルを削除します。
2. ファブリック インターコネクトのアップリンク トランキングをディセーブルにします。
3. ファイバチャネル スイッチ モードのファブリック インターコネクトを設定します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vsan-misconfigured
mibFaultCode: F0796
mibFaultName: fltFabricVsanErrorDisabled
moClass: fabric:Vsan
Type: network
autoCleared: true
Affected MO: fabric/fc-estc/[id]/net-[name]
Affected MO: fabric/fc-estc/net-[name]
Affected MO: fabric/san/[id]/net-[name]
Affected MO: fabric/san/net-[name]
```

fltFabricVsanEpErrorDisabled

障害コード : F0797

Message: [type] Port [slotId]/[portId] on fabric interconnect [switchId] has VSAN [id] in error disabled state
Port channel [portId] on fabric interconnect [switchId] has VSAN [id] in error disabled state

説明 :

通常、この障害は、ポートが制限付き範囲（3840 ～ 4078）内の ID を持つ VSAN に割り当てられているか、または予約済みの VSAN 4079 である場合に発生します。

推奨処置 :

VSAN ID が 3840 ～ 4078 の制限付き範囲内にある場合は、次の手順を実行します。

1. ファブリック インターコネクトのポート チャネルを削除します。
2. ファブリック インターコネクトのアップリンク トランキングをディセーブルにします。
3. ファイバ チャネル スイッチ モードのファブリック インターコネクトを設定します。
4. VSAN が予約済みの VSAN 4079 である場合は、予約されていない VSAN にポートを割り当てます。
5. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vsan-misconfigured
mibFaultCode: F0797
mibFaultName: fltFabricVsanEpErrorDisabled
moClass: fabric:VsanEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO: fabric/fc-estc/[id]/phys-fc-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/vsan-[id]
Affected MO: fabric/san/[id]/pc-[portId]/vsan-[id]
Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO: fabric/san/[id]/phys-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
```

```

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fooesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fooesanep-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsan-[id]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fooesanep-slot-[slotId]-port-[portId]/vsan-[id]

```

fltPowerBudgetFirmwareMismatch

障害コード : F0798

Message: Firmware on blade [chassisId]/[slotId] does not allow chassis level power capping. Please consider upgrading to at least 1.4 version

説明 :

通常、この障害は、サーバの CIMC または BIOS ファームウェアが Cisco UCS Release 1.4 よりも前のリリースである場合に発生します。

推奨処置 :

この障害が発生した場合は、CIMC ファームウェア（および必要に応じて Cisco UCS インスタンスすべて）を、Cisco UCS Release 1.4 以降にアップグレードすることを検討してください。

障害の詳細

```

Severity: major
Cause: old-firmware
mibFaultCode: F0798
mibFaultName: fltPowerBudgetFirmwareMismatch
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget

```

fltProcessorUnitIdentity-unestablishable

障害コード : F0801

Message: Processor [id] on server [chassisId]/[slotId] has an invalid FRUProcessor [id] on server [id] has an invalid FRUProcessor [id] on server [chassisId]/[slotId]/[serverInstanceId] has an invalid FRU

説明 :

通常、この障害は、サポートされていないCPUをCisco UCS Managerがサーバ内で検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. 上記のアクションで問題を解決できなかった場合は、サーバ内にサポートされていないCPU設定がある可能性があります。**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: warning
Cause: identity-unestablishable
mibFaultCode: F0801
mibFaultName: fltProcessorUnitIdentityUnestablishable
moClass: processor:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]
```

fltIqnpoolPoolEmpty

障害コード：F0821

Message: iqn pool [name] is empty

説明：

通常、この障害は、IQN プールに IQN が含まれていない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. プールが使用中である場合は、プールに IQN のブロックを追加します。
2. プールを使用していない場合は、この障害を無視します。

障害の詳細

```
Severity: minor
Cause: empty-pool
mibFaultCode: F0821
mibFaultName: fltIqnpoolPoolEmpty
moClass: iqnpool:Pool
Type: server
autoCleared: true
Affected MO: org-[name]/iqn-pool-[name]
```


fltFabricDceSwSrvPcEpDown

障害コード : F0831

Message: [type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

説明 :

通常、この障害は、ファブリック ポート チャンネルのメンバー ポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FEX または IOM とファブリック インターコネクタ間のリンク接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F0831
mibFaultName: fltFabricDceSwSrvPcEpDown
moClass: fabric:DceSwSrvPcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/server/sw-[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
```

fltFabricEpMgrEpTransModeFail

障害コード : F0832

Message: Port constraint violation on switch [id]: [confQual]**説明 :**

この障害は、少なくとも1台の論理インターフェイスが誤って設定されている場合に発生します。これは、ファブリックインターコネクットの別のタイプまたはシリーズにアップグレードした場合、または設定をインポートした場合に発生する可能性があります。設定は、次の制約に準拠している必要があります。

- 最初のファイバチャネル ポートは奇数のポート番号である必要があります。Cisco UCS 6100 シリーズ ファブリック インターコネクタから Cisco UCS 6200 シリーズ ファブリック インターコネクタへアップグレードすると、この制限に違反することはなくなります。
- 中間に存在する未設定 FC ポートを使用して、すべての FC ポートを連続的に設定する必要があります。これは、Cisco UCS 6100 シリーズのファブリック インターコネクタ設定から Cisco UCS 6200 シリーズのファブリック インターコネクタに設定をインポートした場合の、Cisco UCS 6100 シリーズのファブリック インターコネクタからのアップグレード時に発生する可能性があります。たとえば、Cisco UCS 6100 シリーズのファブリック インターコネクタには、ポート FC2/1 から FC2/6 ままで設定されたポートを持つ FC 拡張モジュールがあります。Cisco UCS 6200 シリーズのファブリック インターコネクタにその設定をインポートした場合、FC ポート 2/7 から 2/16 は未設定のままになります。欠落している FC ポートを設定することで、この問題を修正できます。
- イーサネット範囲と FC ポート範囲は重複できません。これは、Cisco UCS 6100 シリーズのファブリック インターコネクタから Cisco UCS 6200 シリーズのファブリック インターコネクタにアップグレードするときに発生する可能性があります。たとえば、一部の Cisco UCS 6100 拡張モジュールには、FC ポート 2/1 とイーサネット ポート 2/1 のように、同じ ID の FC ポートとイーサネット ポートがあります。
- ファブリック インターコネクタ ID/モジュール ID/ポート ID ごとに最大で 1 台の論理ポートが必要です。たとえば、1 台のポートをイーサネットおよび FC の両方として設定することはできません。これは、Cisco UCS 6100 シリーズのファブリック インターコネクタからのアップグレード時に発生することがあります。たとえば、一部の Cisco UCS 6100 拡張モジュールには、FC ポート 2/1 とイーサネット ポート 2/1 のように、同じ ID の FC ポートとイーサネット ポートがあります。
- モジュール内で、イーサネット ポートのポート ID は最小の FC ポート ID よりも小さい必要があります。これはすべてのイーサネット ポートが左側に、すべての FC ポートが右側になければならないことを意味します。これは固定モジュールに 40 ポートを搭載した Cisco UCS 6140 ファブリック インターコネクタから、固定モジュールに 32 ポートを搭載した Cisco UCS 6248 ファブリック インターコネクタへのアップグレード時に発生することがあります。たとえば、Cisco UCS 6248 が最初にイーサネット ポート 1/1 ~ 1/16 および FC ポート 1/17 ~ 1/32 で設定されていた場合、イーサネット ポート 1/1 ~ 1/32 が未設定でイーサネット ポート 1/33 ~ 1/40 が設定された Cisco UCS 6140 から設定をインポートすると、結果の設定はイーサネット 1/1 ~ 1/16、FC 1/17 ~ 1/32、およびイーサネット 1/33 ~ 1/40 になります。これは有効な設定ではありません。ポート 1/33 ~ 1/40 を削除して設定を修正する必要があります。

- 非 Unified イーサネット ポートは FC ポートとして設定できません。次の点に注意してください。
- Cisco UCS 6100 シリーズ ファブリック インターコネクトから Cisco UCS 6200 シリーズ ファブリック インターコネクトへアップグレードすると、この制限に違反することはありません。
- Cisco UCS 6200 シリーズ ファブリック インターコネクトから Cisco UCS 6100 シリーズ ファブリック インターコネクトへダウングレードすると、この制限に違反する場合があります。
- この制限は、Cisco UCS 6100 シリーズ ファブリック インターコネクトのポートを事前プロビジョニングし、要件と一致しない拡張モジュールを取り付けた場合に違反することがあります。
- 非 Unified FC ポートはイーサネットポートとして設定できません。次の点に注意してください。
- Cisco UCS 6100 シリーズ ファブリック インターコネクトから Cisco UCS 6200 シリーズ ファブリック インターコネクトへアップグレードすると、この制限に違反することはありません。
- Cisco UCS 6200 シリーズ ファブリック インターコネクトから Cisco UCS 6100 シリーズ ファブリック インターコネクトへダウングレードすると、この制限に違反する場合があります。
- この制限は、Cisco UCS 6100 シリーズ ファブリック インターコネクトのポートを事前プロビジョニングし、要件と一致しない拡張モジュールを取り付けた場合に違反することがあります。
- Cisco UCS 6100 シリーズのファブリック インターコネクトでは、サーバポートを拡張モジュールに設定できません。Cisco UCS 6200 シリーズ ファブリック インターコネクトから Cisco UCS 6100 シリーズ ファブリック インターコネクトへダウングレードすると、この制限に違反する場合があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 設定が不適切で「error-misconfigured」障害を発生させているすべての論理インターフェイスのリストを作成します。
2. 各論理インターフェイスについて、設定ミスの障害にリストされている理由をメモします。
3. Cisco UCS Manager にログインして、設定ミスしたそれぞれの論理インターフェイスを修正します。Cisco UCS Manager CLI を使用した場合は、すべての変更をコミットします。
4. その他の設定ミスを示す障害またはエラーメッセージがあれば確認し、そのエラーを修正します。

5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: config-error
mibFaultCode: F0832
mibFaultName: fltFabricEpMgrEpTransModeFail
moClass: fabric:EpMgr
Type: network
autoCleared: true
Affected MO: fabric/[id]
```

fltFabricVlanMisconfigured

障害コード : F0833

Message: VLAN [name] is [operState] because of conflicting vlan-id with a fcqe-vlan

説明 :

通常、この障害は、VLAN に FCoE VLAN と同じ ID がある場合に発生します。この問題は、トラフィックを中断させる可能性があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VLAN ID を確認します。
2. VLAN の ID が同じファブリック インターコネクトの VLAN に割り当てられている FCoE VLAN の ID と一致している場合は、VLAN または FCoE VLAN の ID を変更します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: vlan-misconfigured
mibFaultCode: F0833
mibFaultName: fltFabricVlanMisconfigured
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricPloEpErrorMisconfigured

障害コード : F0834

Message: Interface [name] is [operState]. Reason: [operStateReason]

説明：

この障害は、論理インターフェイスが誤って設定されている場合に発生します。これは、ファブリック インターコネクトの別のタイプまたはシリーズにアップグレードした場合、または設定をインポートした場合に発生する可能性があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 設定が不適切で「**error-misconfigured**」障害を発生させているすべての論理インターフェイスのリストを作成します。
2. 各論理インターフェイスについて、設定ミスの障害にリストされている理由をメモします。
3. Cisco UCS Manager にログインして、設定ミスしたそれぞれの論理インターフェイスを修正します。Cisco UCS Manager CLI を使用した場合は、すべての変更をコミットします。
4. その他の設定ミスを示す障害またはエラーメッセージがあれば確認し、そのエラーを修正します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: interface-misconfigured
mibFaultCode: F0834
mibFaultName: fltFabricPioEpErrorMisconfigured
moClass: fabric:PioEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
```

SEM 障害 Cisco UCS Manager

[illegible]

SEM 障害 Cisco UCS Manager

Affected MO:
 fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/sanmon/[id]/fc-mon-[name]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO: fabric/server/cart-ep-ven-[vendor]-mod-[model]-ser-[serial]

Affected MO: fabric/server/chassis-[chassisId]

Affected MO: fabric/server/chassis-[chassisId]/cart-slot-[slotId]

Affected MO: fabric/server/chassis-[chassisId]/cart-slot-[slotId]/ins-[serverInstanceId]

Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]

Affected MO: fabric/server/chassis-ep-ven-[vendor]-mod-[model]-ser-[serial]

Affected MO: fabric/server/compute-ep-ven-[vendor]-mod-[model]-ser-[serial]

Affected MO: fabric/server/sw-[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO: fabric/server/sw-[id]/slot-[slotId]-port-[portId]
Affected MO:
 sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-eth/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO: sys/switch-[id]/border-eth/pc-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/pc-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/sanmon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]

fltFabricEthLanEpMissingPrimaryVlan

障害コード : F0835

Message: Primary vlan missing from fabric: [switchId], port: [slotId]/[aggrPortId]/[portId]. Primary vlan missing from fabric: [switchId], port: [slotId]/[portId].

説明 :

この障害は、アップリンク ポートまたはポート チャネルが Cisco UCS インスタンスに存在しないプライマリ VLAN で設定されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プライマリ VLAN を含めるようにポートまたはポート チャネルの設定を更新します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: missing-primary-vlan
mibFaultCode: F0835
mibFaultName: fltFabricEthLanEpMissingPrimaryVlan
moClass: fabric:EthLanEp
Type: management
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:

```

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

```

fltFabricEthLanPcMissingPrimaryVlan

障害コード : F0836

Message: Primary vlan missing from fabric: [switchId], port-channel: [portId].

説明 :

この障害は、アップリンク ポートまたはポート チャネルが Cisco UCS インスタンスに存在しないプライマリ VLAN で設定されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プライマリ VLAN を含めるようにポートまたはポート チャネルの設定を更新します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: missing-primary-vlan
mibFaultCode: F0836
mibFaultName: fltFabricEthLanPcMissingPrimaryVlan
moClass: fabric:EthLanPc
Type: management
autoCleared: true
Affected MO: fabric/lan/[id]/pc-[portId]

```

fltVnicEtherPinningMismatch

障害コード : F0840

Message: Hard pinning target for eth vNIC [name], service profile [name] does not have all the required vlans configured

説明 :

この障害は、サービス プロファイルの vNIC に必要な 1 つ以上の VLAN が、ハード ピン接続された LAN ピン グループのターゲット アップリンク ポートまたはポート チャネルに設定されていない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager GUI の LAN アップリンク マネージャで、LAN ピン グループのターゲット アップリンク ポートまたはポート チャネルの vNIC のすべての VLAN を設定します。Cisco UCS Manager CLI を使用する場合は、スコープ **/eth-uplink/vlan** に移動し、LAN ピン グループに必要なメンバー ポートを作成します。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: pinning-mismatch
mibFaultCode: F0840
mibFaultName: fltVnicEtherPinningMismatch
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]
```

fltVnicEtherPinningMisconfig

障害コード：F0841

Message: Hard pinning target for eth vNIC [name], service profile [name] is missing or misconfigured

説明：

この障害は、ハード ピン接続された LAN ピン グループ用の vNIC ターゲット アップリンク ポートまたはポート チャネルの 1 つまたは複数が、欠落しているかまたは不適切なポート タイプとして誤って設定されている場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. LAN ピン グループの設定を確認します。
2. ピン グループのポートおよびポート チャネルの設定を修正します。
3. 必要なすべての VLAN がターゲット ポートまたはポート チャネルで許可されていることを確認します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: pinning-misconfig
mibFaultCode: F0841
mibFaultName: fltVnicEtherPinningMisconfig
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]

```

fltProcessorUnitDisabled

障害コード : F0842

Message: Processor [id] on server [chassisId]/[slotId] operState: [operState]Processor [id] on server [id] operState: [operState]Processor [id] on server [chassisId]/[slotId]/[serverInstanceId] operState: [operState]

説明 :

この障害は、プロセッサがディセーブルになっているという、まれなイベントで発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. この障害がブレードサーバで発生した場合は、サーバをシャーシから取り外して、もう一度差し込みます。
2. Cisco UCS Manager で、いったんブレードサーバを停止し、再始動します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-disabled
mibFaultCode: F0842
mibFaultName: fltProcessorUnitDisabled
moClass: processor:Unit
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]
Affected MO: sys/rack-unit-[id]/board/cpu-[id]

```

fltMemoryUnitDisabled

障害コード : F0844

Message: DIMM [location] on server [chassisId]/[slotId] operState: [operState]DIMM [location] on server [id] operState: [operState]DIMM [location] on server [chassisId]/[slotId]/[serverInstanceId] operState: [operState]

説明 :

この障害は、サーバ BIOS が DIMM をディセーブルにした場合に発生します。BIOS は、DIMM の場所が正しくない、または速度に互換性がないなどのいくつかの理由で、DIMM をディセーブルにする可能性があります。

推奨処置：

この障害が発生した場合は、『Cisco UCS B-Series Troubleshooting Guide』を参照し、DIMM の問題の解決方法を確認してください。

障害の詳細

```
Severity: major
Cause: equipment-disabled
mibFaultCode: F0844
mibFaultName: fltMemoryUnitDisabled
moClass: memory:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]
```

fltFirmwareBootUnitActivateStatusFailed

障害コード：F0856

Message: Activation failed and Activate Status set to failed.

説明：

この障害は通常、ファームウェアのアクティベーションが失敗した場合、またはアクティベーション後の実行イメージが対応するスタートアップ イメージでない場合に発生します。

- ファームウェアのアクティベーションが失敗した。
- アクティベーション後にサーバで実行しているファームウェアのバージョンが、スタートアップ イメージとして Cisco UCS Manager に一覧されているバージョンではない。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 障害が発生したエンドポイントの [FSM] タブに移動し、アクティベーションが失敗したという理由のエラー説明を確認します。
2. FSM に障害が発生した場合は、FSM のエラー メッセージを確認します。
3. 可能な場合は、エラー メッセージで説明されている問題を修正します。
4. 問題が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: activation-failed
```

```

mibFaultCode: F0856
mibFaultName: fltFirmwareBootUnitActivateStatusFailed
moClass: firmware:BootUnit
Type: management
autoCleared: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit-[type]
Affected MO: capabilities/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]

```


Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/psu-[id]/fw-boot-def/bootunit-[type]

fltFabricInternalPcDown

障害コード : F0858

Message: [type] port-channel [portId] on fabric interconnect [id] oper state: [operState], reason: [stateQual]

説明 :

この障害は、サーバの転送 VIF がダウンしている場合に発生します。Cisco UCS Manager は、ファブリック インターコネクトが仮想インターフェイスの接続状態を次のいずれかとしてレポートした場合に、この障害が発生します。

- Down
- エラー
- 使用不可

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ブレードサーバの検出が成功していることを確認します。
2. エンドツーエンドですべての通信中ポートの状態をチェックします。
3. 接続は正しいと思われる場合は、いったんサーバを停止し、再始動します。

4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: operational-state-down
mibFaultCode: F0858
mibFaultName: fltFabricInternalPcDown
moClass: fabric:InternalPc
Type: network
autoCleared: true
Affected MO: fabric/server/sw-[id]/pc-[portId]
```

fltMgmtEntityDevice-1-shared-storage-error

障害コード : F0863

Message: device [chassis1], error accessing shared-storage

説明 :

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障害は、(a) ファブリック インターコネクトのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクト クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置 :

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F0863
mibFaultName: fltMgmtEntityDevice1SharedStorageError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDevice-2-shared-storage error

障害コード : F0864

Message: device [chassis2], error accessing shared-storage

説明 :

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障

害は、(a) ファブリック インターコネクトのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクト クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置：

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F0864
mibFaultName: fltMgmtEntityDevice2SharedStorageError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDevice-3-shared-storage error

障害コード：F0865

Message: device [chassis3], error accessing shared-storage

説明：

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障害は、(a) ファブリック インターコネクトのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクト クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置：

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F0865
mibFaultName: fltMgmtEntityDevice3SharedStorageError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityHa-ssh-keys-mismatched

障害コード : F0866

Message: Fabric Interconnect [id], management services, mismatched SSH keys

説明 :

この障害は、次のいずれかのシナリオが発生したことを示します。

- クラスタ構成で HA に使用されている内部 SSH キーが一致していない。これにより、特定の操作が失敗します。
- 別のファブリック インターコネクトが、最初にプライマリの既存の設定を消去せずに、クラスタ内のプライマリ ファブリック インターコネクトに接続されている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 下位ファブリック インターコネクトの Cisco UCS Manager CLI にログインします。
2. **connect local-mgmt** と入力します。
3. **erase configuration** と入力し、下位ファブリック インターコネクトの設定を消去してリブートします。
4. セカンダリ ファブリック インターコネクトがリブートされたら、クラスタ用に再設定します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: ha-ssh-keys-mismatched
mibFaultCode: F0866
mibFaultName: fltMgmtEntityHaSshKeysMismatched
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtPmonEntryUCSM process failure

障害コード : F0867

Message: UCSM process [name] failed on FI [switchId]

説明 :

この障害は、Cisco UCS Manager のプロセス クラッシュという、まれなイベントで発生します。通常、障害が発生したプロセスは再起動し、問題から回復します。プロセスが正常に再起動した後、保留中の操作が再始動されます。

推奨処置 :

この障害の発生時にプロセスが正常に再起動しなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: ucsm-process-failure
mibFaultCode: F0867
mibFaultName: fltMgmtPmonEntryUCSMProcessFailure
moClass: mgmt:PmonEntry
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]/[name]
```

fltComputeBoardPowerFail

障害コード : F0868

Message: Motherboard of server [chassisId]/[slotId] (service profile: [assignedToDn]) power: [power]Motherboard of server [id] (service profile: [assignedToDn]) power: [power]Motherboard of server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) power: [power]

説明 :

通常、この障害は、CIMC がサーバの電源をオンにできない場合に発生します。これは、ハードウェアのコンポーネント障害を示している可能性があります。

推奨処置 :

この障害が表示される場合、次の処理を実行します

1. ブレードサーバの場合は、ブレードサーバをシャーシから取り外し、取り付け直します。
2. ラックサーバの場合は、手動でサーバの A/C 電源を再投入します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: power-problem
mibFaultCode: F0868
mibFaultName: fltComputeBoardPowerFail
moClass: compute:Board
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/rack-unit-[id]/board
```

fltComputeABoardThermalProblem

障害コード : F0869

Message: Motherboard [faultQualifier] of server [chassisId]/[slotId] (service profile: [assignedToDn]) thermal: [thermal]Motherboard of server [id] (service profile: [assignedToDn]) thermal:

[thermal]Motherboard [faultQualifier] of server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) thermal: [thermal]

説明：

通常、この障害は、サーバのマザーボード温度センサーが問題を検出した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバのファンが正しく動作していることを確認します。
2. 24 時間待機して、問題が解決しているかどうかを確認します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F0869
mibFaultName: fltComputeABoardThermalProblem
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]
```

fltVmVifLinkState

障害コード：F0876

Message: Virtual interface [vifId] link is down; reason [stateQual]

説明：

この障害は、Cisco UCS がアップリンク ポートからのデータを送受信できない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 障害の発生したアップリンク ポートをイネーブルにします。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: vif-down
```

```

mibFaultCode: F0876
mibFaultName: fltVmVifLinkState
moClass: vm:Vif
Type: management
autoCleared: true
Affected MO: vmm/computeEp-[uuid]/nic-[name]/sw-[phSwitchId]vif-[vifId]
Affected MO: vmm/hv-[uuid]/nic-[name]/sw-[phSwitchId]vif-[vifId]
Affected MO: vmm/vm-[uuid]/nic-[name]/sw-[phSwitchId]vif-[vifId]

```

fltEquipmentPsuPowerSupplyShutdown

障害コード : F0881

Message: Power supply [id] in chassis [id] shutdown reason:[powerStateQualifier]Power supply [id] in rack-enclosure [id] shutdown reason:[powerStateQualifier]

説明 :

通常、この障害は、予想よりも電流が多い、予想よりも温度が高い、またはファンで障害が発生しているために、シャーシ、ファブリック インターコネクト、または FEX の電源装置ユニットがシャットダウンした場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、サーバの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、サーバに適切なエアフローを確保します。
3. Cisco UCS シャーシまたはラック内のサーバのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレードサーバおよびラックサーバの電源を切ります。
6. 電源コードが PSU および電源に正しく接続されていることを確認します。
7. 電源が 220 V であることを確認します。
8. PSU がシャーシまたはファブリック インターコネクトに適切に設置されていることを確認します。
9. PSU を取り外して再度設置します。
10. PSU を交換します。
11. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-offline
mibFaultCode: F0881

```

```

mibFaultName: fltEquipmentPsuPowerSupplyShutdown
moClass: equipment:Psu
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuPowerThreshold

障害コード : F0882

Message: Power supply [id] on chassis [id] has exceeded its power thresholdPower supply [id] on server [id] has exceeded its power thresholdPower supply [id] on rack-enclosure [id] has exceeded its power threshold

説明 :

この障害は、電源装置ユニットが電流を過剰に引き込んでいる場合に発生します。

推奨処置 :

この障害が発生した場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: power-problem
mibFaultCode: F0882
mibFaultName: fltEquipmentPsuPowerThreshold
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]

```

fltEquipmentPsuInputError

障害コード : F0883

Message: Power supply [id] on chassis [id] has disconnected cable or bad input voltagePower supply [id] on server [id] has disconnected cable or bad input voltagePower supply [id] on rack-enclosure [id] has disconnected cable or bad input voltage

説明 :

この障害は、電源コードが切断されているか、または入力電圧が誤っている場合に発生します。

推奨処置 :

この障害が発生した場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: power-problem
mibFaultCode: F0883
mibFaultName: fltEquipmentPsuInputError
moClass: equipment:Psu
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]
Affected MO: sys/fex-[id]/psu-[id]
Affected MO: sys/rack-enclosure-[id]/psu-[id]
Affected MO: sys/rack-unit-[id]/psu-[id]
Affected MO: sys/switch-[id]/psu-[id]
```

fltEquipmentSwitchCardPowerOff

障害コード : F0884

Message: Switch card is powered down.

説明 :

この障害は、スイッチ カードの電源がオフになっている場合に発生します。

推奨処置 :

この障害が発生した場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: power-down
mibFaultCode: F0884
mibFaultName: fltEquipmentSwitchCardPowerOff
moClass: equipment:SwitchCard
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]/slot-[id]
```

fltNetworkElementInventoryFailed

障害コード : F0885

Message: Fabric Interconnect [id] inventory is not complete [inventoryStatus]

説明 :

Cisco UCS Manager は、管理サブシステムが I/O カードまたは物理ポートなどの物理コンポーネントのインベントリを実行できない場合に、この障害を発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. HA クラスターの両方のファブリック インターコネクトが同じソフトウェアバージョンを実行していることを確認します。

2. ファブリック インターコネクト ソフトウェアが、Cisco UCS Manager ソフトウェアと互換性のあるバージョンであることを確認します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: inventory-failed
mibFaultCode: F0885
mibFaultName: fltNetworkElementInventoryFailed
moClass: network:Element
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]
```

fltAdaptorUnitExtnUnidentifiable-fru

障害コード : F0900

Message: Adapter extension [id] in server [chassisId]/[slotId] has unidentified FRU

説明 :

通常、この障害は、Cisco UCS Manager がパススルー アダプタなどのサポートされていないアダプタユニット拡張を検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サポートされているアダプタ ユニット拡張が取り付けられていることを確認します。
2. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: unidentifiable-fru
mibFaultCode: F0900
mibFaultName: fltAdaptorUnitExtnUnidentifiableFru
moClass: adaptor:UnitExtn
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/adaptor-extn-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/adaptor-extn-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/adaptor-extn-[id]
```

fltAdaptorUnitExtnMissing

障害コード : F0901

Message: Adapter extension [id] in server [chassisId]/[slotId] presence: [presence]

説明 :

通常、この障害は、パススルー アダプタなどの I/O アダプタ ユニット拡張が欠落しているときに発生します。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害を発生します。

- エンドポイントによって、パススルー アダプタなど、アダプタ スロットに接続されているアダプタ ユニット拡張がないことが報告されている。
- エンドポイントで、アダプタ スロットに接続されているアダプタ ユニット拡張を検出できないか、これと通信できない。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタ ユニット拡張がサーバのアダプタ スロットに正しく接続されていることを確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F0901
mibFaultName: fltAdaptorUnitExtnMissing
moClass: adaptor:UnitExtn
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/adaptor-extn-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/adaptor-extn-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/adaptor-extn-[id]
```

fltEquipmentFexFex-unsupported

障害コード : F0902

Message: Fex [id] with model [model] is unsupported

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていない FEX を検出したために発生します。たとえば、モデル、ベンダー、またはリビジョンは認識されません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サポートされている FEX が取り付けられていることを確認します。

2. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: fex-unsupported
mibFaultCode: F0902
mibFaultName: fltEquipmentFexFexUnsupported
moClass: equipment:Fex
Type: equipment
autoCleared: true
Affected MO: sys/fex-[id]
```

fltVnicIScsiConfig-failed

障害コード : F0903

Message: iSCSI vNIC [name], service profile [name] has duplicate iqn name [initiatorName]

説明 :

通常、この障害は、iScsi Vnic が同じ iqn の名前を参照した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. iqn の名前が iSCSI vnic ごとに固有であることを確認します。
2. **show identity iqn** を使用して、iSCSI vnic がその領域に登録されているかどうかをチェックします。
3. その領域での iqn の登録には、サービス プロファイルの説明を変更するなど、妨げにならないアクションを実行します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: configuration-failed
mibFaultCode: F0903
mibFaultName: fltVnicIScsiConfigFailed
moClass: vnic:IScsi
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/iscsi-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/iscsi-[name]
```

fltPkiKeyRingStatus

障害コード : F0909

Message: [name] Keyring's certificate is invalid, reason: [certStatus].

説明 :

この障害は、キーリングの証明書ステータスが無効になった場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: invalid-keyring-certificate
mibFaultCode: F0909
mibFaultName: fltPkiKeyRingStatus
moClass: pki:KeyRing
Type: security
autoCleared: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltPkiTPStatus

障害コード : F0910

Message: [name] Trustpoint's cert-chain is invalid, reason: [certStatus].

説明 :

この障害は、トラストポイントの証明書ステータスが無効になった場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: invalid-trustpoint-cert-chain
mibFaultCode: F0910
mibFaultName: fltPkiTPStatus
moClass: pki:TP
Type: security
autoCleared: true
Affected MO: sys/pki-ext/tp-[name]
```

fltComputePhysicalDisassociationFailed

障害コード : F0915

Message: Failed to disassociate server [id]Failed to disassociate server [chassisId]/[slotId]Failed to disassociate server [chassisId]/[slotId]/[serverInstanceId]

説明 :

通常、この障害は、次のいずれかの理由により発生します。

- サーバがダウンしている。
- データパスが動作していない。
- Cisco UCS Manager で 1 つ以上のファブリック インターコネクト、サーバ、またはサーバ上のコンポーネントと通信できない。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトのサーバポートを含むサーバへの通信パス、IOM リンクおよびサーバの現在の状態をチェックします。
2. サーバがブーティングなどの不適切な状態のままである場合は、サーバの電源を再投入します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: disassociation-failed
mibFaultCode: F0915
mibFaultName: fltComputePhysicalDisassociationFailed
moClass: compute:Physical
Type: configuration
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalNetworkMisconfigured

障害コード：F0916

Message: Server [id] (service profile: [assignedToDn]) has mis-configured network vif resourcesServer [chassisId]/[slotId] (service profile: [assignedToDn]) has mis-configured network vif resourcesServer [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) has mis-configured network vif resources

説明：

通常、この障害は、UCSM VIF ID マップがフルバックアップ/復元などでアダプタに導入された VIF ID マップと異なる場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバを再認識します。これは、Deep Discovery-Deep Association をトリガーして、問題を解決します。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** コマンドを実行し、シスコのテクニカルサポートにお問い合わせください。

障害の詳細

Severity: minor
Cause: vif-ids-mismatch
mibFaultCode: F0916
mibFaultName: fltComputePhysicalNetworkMisconfigured
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

fltVnicProfileProfileConfigIncorrect

障害コード : F0917

Message: The Port Profile [name] has an invalid configuration.

説明 :

この障害は、ポート プロファイル設定に無効なエントリがある場合に発生します。

推奨処置 :

ドキュメントをチェックし、ポート プロファイル設定の違法なエントリを修正します。

障害の詳細

Severity: warning
Cause: profile-config-incorrect
mibFaultCode: F0917
mibFaultName: fltVnicProfileProfileConfigIncorrect
moClass: vnic:Profile
Type: configuration
autoCleared: true
Affected MO: fabric/lan/profiles/vnic-[name]

fltComputeABoardMotherBoardVoltageThresholdUpperNonRecoverable

障害コード : F0918

Message: Motherboard input voltage in server [id] is [voltage]Motherboard [faultQualifier] input voltage in server [chassisId]/[slotId] is [voltage]Motherboard input voltage(12V/5V/3V) in server [chassisId]/[slotId]/[serverInstanceId] is [voltage]

説明 :

この障害は、1 つ以上のマザーボード入力電圧が非常に高くなり、復旧の可能性がほとんどない場合に発生します。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: voltage-problem

```

mibFaultCode: F0918
mibFaultName: fltComputeABoardMotherBoardVoltageThresholdUpperNonRecoverable
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]

```

fltComputeABoardMotherBoardVoltageThresholdLowerNonRecoverable

障害コード : F0919

Message: Motherboard input voltage in server [id] is [voltage]Motherboard [faultQualifier] input voltage in server [chassisId]/[slotId] is [voltage]Motherboard input voltage(12V/5V/3V) in server [chassisId]/[slotId]/[serverInstanceId] is [voltage]

説明 :

この障害は、1 つ以上のマザーボード入力電圧が非常に低くなり、復旧の可能性がほとんどない場合に発生します。

推奨処置 :

未設定。

障害の詳細

```

Severity: major
Cause: voltage-problem
mibFaultCode: F0919
mibFaultName: fltComputeABoardMotherBoardVoltageThresholdLowerNonRecoverable
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]

```

fltComputeABoardMotherBoardVoltageUpperThresholdCritical

障害コード : F0920

Message: Motherboard input voltage in server [id] is [voltage]Motherboard [faultQualifier] input voltage in server [chassisId]/[slotId] is [voltage]Motherboard input voltage(12V/5V/3V) in server [chassisId]/[slotId]/[serverInstanceId] is [voltage]

説明 :

この障害は、1 つ以上のマザーボード上の入力電圧が重大しきい値の上限を超過した場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: minor
Cause: voltage-problem
mibFaultCode: F0920
mibFaultName: fltComputeABoardMotherBoardVoltageUpperThresholdCritical
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]
```

fltComputeABoardMotherBoardVoltageLowerThresholdCritical

障害コード : F0921

Message: Motherboard input voltage in server [id] is [voltage]Motherboard [faultQualifier] input voltage in server [chassisId]/[slotId] is [voltage]Motherboard [faultQualifier] input voltage(12V/5V/3V) in server [chassisId]/[slotId]/[serverInstanceId] is [voltage]

説明 :

この障害は、1 つ以上のマザーボード上の入力電圧が重大しきい値の下限を超過した場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: minor
Cause: voltage-problem
mibFaultCode: F0921
mibFaultName: fltComputeABoardMotherBoardVoltageLowerThresholdCritical
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]
```

fltVnicEtherIfVlanAccessFault

障害コード : F0932

Message: The named vlan [name] for vNIC [name] cannot be accessed from org [name]

説明 :

この障害は通常、サービス プロファイルの **vnic** インターフェイス (LAN) が解決可能であるが、サービス プロファイルが **vlan** にアクセスできない場合に発生します。この場合は、デフォルトの **VLAN** が使用されます。

推奨処置：

この障害は、次のアクションのいずれかを実行すると削除されます。

1. **vnic** のインターフェイス名をアクセスできる **VLAN** に変更します。
2. デフォルトの **VLAN** を使用する場合、**vnic** のインターフェイス名をデフォルトに変更します。
3. サービス プロファイルの組織 (または親組織) で **vlan** 許可または **vlan** グループ許可を作成して、名前付き **vlan** へのアクセスを構成します。

障害の詳細

```
Severity: major
Cause: inaccessible-vlan-referenced
mibFaultCode: F0932
mibFaultName: fltVnicEtherIfVlanAccessFault
moClass: vnic:EtherIf
Type: configuration
autoCleared: true
Affected MO:
fabric/lan/network-sets/fabric-network-[name]/fabric-network-def-[name]/vm-network-def-[name]/if-[name]
Affected MO: fabric/lan/profiles/vnic-[name]/if-[name]
Affected MO: fabric/lanmon/eth-flow-monitoring/flow-exporter-profile-[name]/if-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ipc-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ipc-[name]/if-[name]
```

fltVnicEtherIfVlanUnresolvable

障害コード : F0933

Message: The named vlan [name] for vNIC [name] cannot be resolved

説明：

この障害 (警告) は、サービス プロファイルの **vnic** インターフェイス (LAN) が解決できない場合に発生します。この場合、デフォルトの **VLAN** が接続先 **VLAN** として使用されます。

推奨処置：

この障害は、次のアクションのいずれかを実行すると削除されます。

1. 既存の **VLAN** に **vnic** インターフェイス名を変更します。
2. 名前付き **vlan** を作成します。

障害の詳細

```

Severity: warning
Cause: referenced-vlan-unresolvable
mibFaultCode: F0933
mibFaultName: fltVnicEtherIfVlanUnresolvable
moClass: vnic:EtherIf
Type: configuration
autoCleared: true
Affected MO:
fabric/lan/network-sets/fabric-network-[name]/fabric-network-def-[name]/vm-network-def-[name]/if-[name]
Affected MO: fabric/lan/profiles/vnic-[name]/if-[name]
Affected MO: fabric/lanmon/eth-flow-monitoring/flow-exporter-profile-[name]/if-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ipc-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ipc-[name]/if-[name]

```

fltVnicEtherIfInvalidVlan

障害コード : F0934

Message: Invalid Vlan in the allowed vlan list

説明 :

通常、この障害は、サービス プロファイルまたはポート プロファイルの vnic に無効な VLAN が含まれている場合に発生します。無効な VLAN は次のいずれかの可能性があります。

1. 有効なプライマリ VLAN に関連付けられていない隔離 VLAN またはコミュニティ VLAN
2. vnic で許可された関連付けられているセカンダリ VLAN がないプライマリ VLAN
3. LAN 側/アプライアンス側の VLAN に一致しない共有タイプまたはプライマリ VLAN 名がある VLAN
4. FCoE VLAN と重複する VLAN

推奨処置 :

次の処置のいずれかを実行すると、この障害は解決されます。

1. 無効な VLAN が隔離 VLAN またはコミュニティ VLAN である場合、有効なプライマリ VLAN にマッピングされていることを確認します。
2. 無効な VLAN がプライマリ VLAN である場合、そのセカンダリ VLAN を許可するか vnic またはポート プロファイルから無効な VLAN を削除します。
3. 無効な VLAN が、LAN 側/アプライアンス側の VLAN ID が同じ VLAN と共有プロパティが一致しない場合、この VLAN のプロパティを変更して他と同じにします。
4. 無効な VLAN が FCoE VLAN と重複する場合、別の VLAN を設定します。

障害の詳細

```

Severity: major
Cause: invalid-vlan-in-the-allowed-vlan-list
mibFaultCode: F0934
mibFaultName: fltVnicEtherIfInvalidVlan
moClass: vnic:EtherIf
Type: configuration
autoCleared: true
Affected MO:
fabric/lan/network-sets/fabric-network-[name]/fabric-network-def-[name]/vm-network-def-[name]/if-[name]
Affected MO: fabric/lan/profiles/vnic-[name]/if-[name]
Affected MO: fabric/lanmon/eth-flow-monitoring/flow-exporter-profile-[name]/if-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ipc-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ipc-[name]/if-[name]

```

fltFabricVlanVlanConflictPermit

障害コード : F0935

Message: There are multiple vlans with id [id] have different accessibility configured.

説明 :

この障害は、同じ ID を使用する複数のグローバル VLAN に異なるアクセスが設定されている場合に発生します。

推奨処置 :

VLAN/VLAN グループ許可を設定してアクセス設定を変更します。

障害の詳細

```

Severity: warning
Cause: vlan-conflict-permit
mibFaultCode: F0935
mibFaultName: fltFabricVlanVlanConflictPermit
moClass: fabric:Vlan
Type: configuration
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltFabricVlanReqVlanPermitUnresolved

障害コード : F0936

Message: The VLAN permit does not reference any existing vlans.

説明 :

この障害は、VLAN 許可は存在するが、その名前の vnic がない場合に発生します。

推奨処置 :

その VLAN 許可を削除し、参照先の VLAN を作成します（または無視します）。

障害の詳細

```
Severity: warning
Cause: vlan-permit-unresolved
mibFaultCode: F0936
mibFaultName: fltFabricVlanReqVlanPermitUnresolved
moClass: fabric:VlanReq
Type: configuration
autoCleared: true
Affected MO: org-[name]/vlan-req-[name]
```

fltFabricVlanGroupReqVlanGroupPermitUnresolved

障害コード : F0937

Message: The VLAN permit does not reference any existing net groups.

説明 :

この障害は、VLAN グループ許可は存在するが、参照先のネットワーク グループがない場合に発生します。

推奨処置 :

その VLAN 許可を削除し、参照先の VLAN を作成します（または無視します）。

障害の詳細

```
Severity: warning
Cause: group-permit-unresolved
mibFaultCode: F0937
mibFaultName: fltFabricVlanGroupReqVlanGroupPermitUnresolved
moClass: fabric:VlanGroupReq
Type: configuration
autoCleared: true
Affected MO: org-[name]/vlan-group-req-[name]
```

fltExtpolClientClientLostConnectivity

障害コード : F0988

Message: UCS has lost connectivity with UCS Central

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: client-lost-connectivity
mibFaultCode: F0988
mibFaultName: fltExtpolClientClientLostConnectivity
moClass: extpol:Client
```

```
Type: network
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltStorageLocalDiskDegraded

障害コード : F0996

Message: Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on storage enclosure [id] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

この障害は、ローカルディスクが低下した場合に発生します。障害の説明には、劣化の原因を示す物理ドライブの状態が記載されています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ドライブの状態が「rebuild」または「copyback」の場合、再ビルドまたはコピーバック操作が完了するまで待機します。
2. ドライブの状態が「predictive-failure」の場合、ディスクを交換します。

障害の詳細

```
Severity: warning
Cause: equipment-degraded
mibFaultCode: F0996
mibFaultName: fltStorageLocalDiskDegraded
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltStorageRaidBatteryDegraded

障害コード : F0997

Message: RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]RAID Battery on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

この障害は、RAID バックアップ ユニットの劣化している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害の原因がバックアップユニットが再学習サイクル中であることを示している場合、再学習が完了するまで待機します。
2. 障害の原因がバックアップユニットが失敗しようであることを示している場合、バックアップユニットを交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: F0997
mibFaultName: fltStorageRaidBatteryDegraded
moClass: storage:RaidBattery
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/chassis-[id]/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery
```

fltStorageRaidBatteryRelearnAborted

障害コード : F0998

Message: RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason]RAID Battery on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。この障害は、バックアップユニットの再学習サイクルが中止されたときに発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 学習サイクルをやり直してください。
2. バックアップユニットを交換してください。

障害の詳細

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: F0998
mibFaultName: fltStorageRaidBatteryRelearnAborted
moClass: storage:RaidBattery
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/chassis-[id]/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery
```

fltStorageRaidBatteryRelearnFailed

障害コード : F0999

Message: RAID Battery on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] RAID Battery on server [id] operability: [operability]. Reason: [operQualifierReason] RAID Battery on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのブレースホルダとしてのみ発生する可能性があります。この障害は、バックアップユニットの **relearning** サイクルが失敗したときに発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 学習サイクルをやり直してください。
2. バックアップユニットを交換してください。

障害の詳細

```
Severity: major
Cause: equipment-degraded
mibFaultCode: F0999
mibFaultName: fltStorageRaidBatteryRelearnFailed
moClass: storage:RaidBattery
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/raid-battery
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/raid-battery
Affected MO: sys/chassis-[id]/storage-[type]-[id]/raid-battery
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/raid-battery
```

fltStorageADefConfiguration-error

障害コード : F1000

Message: Vsan trunking is not supported on Vhbas. Targets with overlapping path should have same vsan.

説明 :

ストレージ接続ポリシーで、重複するパス設定を持つストレージターゲットは同様の VSAN 設定が必要です。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ストレージ接続ポリシーで、重複するパス設定を持つターゲットを探します。同じ VSAN がこれらのターゲットに適用されていることを確認します。

障害の詳細

```
Severity: info
Cause: configuration-error
mibFaultCode: F1000
mibFaultName: fltStorageADefConfigurationError
moClass: storage:ADef
Type: equipment
autoCleared: true
Affected MO: org-[name]/ls-[name]/grp-[name]/fc-group/storage-conndef
Affected MO: org-[name]/san-conn-pol-[name]/grp-[name]/fc-group/storage-conndef
Affected MO: org-[name]/storage-connpolicy-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/grp-[name]/fc-group/storage-conndef
```

fltStorageInitiatorConfiguration-error

障害コード：F1001

Message: Initiator [name] either cannot be resolved or does not match with one of the storage targets. No zones are deployed for this initiator and the target.

説明：

イニシエータが解決できないか、いずれかのターゲットと一致しません。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. このイニシエータによって参照されている vHBA インターフェイスが存在するかどうかを確認します。
2. このイニシエータによって参照されている vHBA インターフェイスのスイッチ ID または VSAN 名がいずれかのターゲットと一致するかどうかを確認します。

障害の詳細

```
Severity: warning
Cause: configuration-error
mibFaultCode: F1001
mibFaultName: fltStorageInitiatorConfigurationError
moClass: storage:Initiator
Type: equipment
autoCleared: true
Affected MO: org-[name]/ls-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/san-conn-pol-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/grp-[name]/ini-[name]
```

fltStorageVsanRefVsanUnresolvable

障害コード : F1002

Message: The named vsan [name] for storage target cannot be resolved

説明 :

この障害（警告）は、ストレージターゲットのVSANインターフェイス（VSAN）が解決できない場合に発生します。この場合、デフォルトのVSANが運用VSANとして使用されます。

推奨処置 :

この障害は、次のアクションのいずれかを実行すると削除されます。

1. VSAN 参照名を既存の VSAN に変更します。
2. 名前付き vsan を作成します。

障害の詳細

```
Severity: warning
Cause: referenced-vsan-unresolvable
mibFaultCode: F1002
mibFaultName: fltStorageVsanRefVsanUnresolvable
moClass: storage:VsanRef
Type: configuration
autoCleared: true
Affected MO: fabric/fc-estc/zone-profile-[name]/zone-[name]/vsan-ref
Affected MO:
org-[name]/ls-[name]/grp-[name]/fc-group/storage-conndef/fc-target-ep-[targetwwpn]/vsan-ref
Affected MO:
org-[name]/san-conn-pol-[name]/grp-[name]/fc-group/storage-conndef/fc-target-ep-[targetwwpn]/vsan-ref
Affected MO: org-[name]/storage-connpolicy-[name]/fc-target-ep-[targetwwpn]/vsan-ref
Affected MO:
org-[name]/tier-[name]/ls-[name]/grp-[name]/fc-group/storage-conndef/fc-target-ep-[targetwwpn]/vsan-ref
```

fltStorageControllerPatrolReadFailed

障害コード : F1003

Message: Controller [id] on server [chassisId]/[slotId] had a patrol read failure. Reason: [operQualifierReason]
Controller [id] on server [id] had a patrol read failure. Reason: [operQualifierReason]
Controller [id] on chassis [id] had a patrol read failure. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのブレースホルダとしてのみ発生する可能性があります。この障害は、パトロール読み取り操作が失敗したときに発生します。

推奨処置 :

パトロールの読み取り操作を再実行します。

障害の詳細

```
Severity: warning
```

```

Cause: operation-failed
mibFaultCode: F1003
mibFaultName: fltStorageControllerPatrolReadFailed
moClass: storage:Controller
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]

```

fltStorageControllerInoperable

障害コード : F1004

Message: Controller [id] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason]Controller [id] on server [id] is inoperable. Reason: [operQualifierReason]Controller [id] on chassis [id] is inoperable. Reason: [operQualifierReason]

説明 :

この障害は、ストレージコントローラがアクセスできない場合に発生します。

推奨処置 :

PCI およびメザニンベースのストレージコントローラの場合、ストレージコントローラの装着をチェックします。問題が解決しない場合は、コントローラを交換します。

障害の詳細

```

Severity: critical
Cause: equipment-inoperable
mibFaultCode: F1004
mibFaultName: fltStorageControllerInoperable
moClass: storage:Controller
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]

```

fltStorageLocalDiskRebuildFailed

障害コード : F1005

Message: Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on storage enclosure [id] operability: [operability]. Reason: [operQualifierReason]Local disk [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロンラックサーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。この障害は、再

構築操作が失敗したときに発生します。これは、パフォーマンスの低下を引き起こす可能性があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 再ビルド操作をやり直します。
2. ディスクを交換します。

障害の詳細

```
Severity: major
Cause: equipment-offline
mibFaultCode: F1005
mibFaultName: fltStorageLocalDiskRebuildFailed
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltStorageLocalDiskCopybackFailed

障害コード：F1006

Message: Local disk [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on storage enclosure [id] operability: [operability]. Reason: [operQualifierReason] Local disk [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明：

注：この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのブレースホルダとしてのみ発生する可能性があります。この障害は、コピーバック操作が失敗したときに発生します。これは、パフォーマンスの低下を引き起こす可能性があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. コピーバック操作をやり直します。

2. ディスクを交換します。

障害の詳細

```
Severity: major
Cause: equipment-offline
mibFaultCode: F1006
mibFaultName: fltStorageLocalDiskCopybackFailed
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltStorageVirtualDriveInoperable

障害コード : F1007

Message: Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

この障害は、仮想ドライブが動作不能になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 仮想ドライブによって使用されるディスクの存在と状況を確認します。
2. 必要に応じて、使用されたディスクを再装着または交換します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-inoperable
mibFaultCode: F1007
mibFaultName: fltStorageVirtualDriveInoperable
moClass: storage:VirtualDrive
```

```

Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]

```

fltStorageVirtualDriveDegraded

障害コード : F1008

Message: Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

この障害は、仮想ドライブが劣化した場合に発生します。障害の説明には、劣化の原因を示す物理ドライブの状態が記載されています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ドライブが整合性検査操作を実行している場合、操作が完了するまで待機します。
2. 仮想ドライブによって使用されるディスクの存在と状況を確認します。
3. 必要に応じて、使用されたディスクを再装着または交換します。
4. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: major
Cause: equipment-degraded
mibFaultCode: F1008
mibFaultName: fltStorageVirtualDriveDegraded
moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]

```

fltStorageVirtualDriveReconstructionFailed

障害コード : F1009

Message: Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。この障害は、ドライブの再構築操作が失敗したときに発生します。これは、パフォーマンスの低下を引き起こす可能性があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 再構成操作をやり直します。
2. 仮想ドライブを削除して再作成します。

障害の詳細

Severity: major
Cause: equipment-degraded
mibFaultCode: F1009
mibFaultName: fltStorageVirtualDriveReconstructionFailed
moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]

fltStorageVirtualDriveConsistencyCheckFailed

障害コード : F1010

Message: Virtual drive [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on server [id] operability: [operability]. Reason: [operQualifierReason] Virtual drive [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。この障害は、ド

ライブ整合性チェック操作が失敗したときに発生します。これは、パフォーマンスの低下を引き起こす可能性があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 整合性検査操作をやり直してください。
2. 仮想ドライブを削除して再作成します。

障害の詳細

```
Severity: major
Cause: equipment-degraded
mibFaultCode: F1010
mibFaultName: fltStorageVirtualDriveConsistencyCheckFailed
moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]
```

fltAaaProviderGroupProvidergroup

障害コード：F1026

Message: For [dn]: Server Group with name [name] already exist, You need to specify a unique name for this object.

説明：

通常、この障害は、名前が同じ複数のプロバイダーグループを Cisco UCS Manager が検出したために発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. この問題の原因となる、重複している設定されたプロバイダーグループを削除する必要があります。

障害の詳細

```
Severity: major
Cause: provider-group-already-exists
mibFaultCode: F1026
mibFaultName: fltAaaProviderGroupProvidergroup
moClass: aaa:ProviderGroup
Type: security
```



```

autoCleared: true
Affected MO: sys/ldap-ext/providergroup-[name]
Affected MO: sys/radius-ext/providergroup-[name]
Affected MO: sys/tacacs-ext/providergroup-[name]

```

fltAaaConfigServergroup

障害コード : F1027

Message: For [dn]: [realm] Server Group with name [providerGroup] doesn't exist or is not deployed.

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていない 認証方法を検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 認証用に設定されたサーバ グループが存在することを確認します。
2. サーバグループが設定されていない場合、認証に使用するサーバグループを作成します。

障害の詳細

```

Severity: critical
Cause: invalid-server-group
mibFaultCode: F1027
mibFaultName: fltAaaConfigServergroup
moClass: aaa:Config
Type: security
autoCleared: true
Affected MO: sys/auth-realm/console-auth
Affected MO: sys/auth-realm/default-auth
Affected MO: sys/auth-realm/domain-[name]/domain-auth

```

fltAaaRoleNotDeployed

障害コード : F1028

Message: Role [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないロールを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ロールの合計がサポートされているロールの最大数未満であることを確認します。
2. すべてのロールにわたる権限の合計が権限の最大数未満であることを確認します。

障害の詳細

```

Severity: critical

```

```
Cause: role-config-error
mibFaultCode: F1028
mibFaultName: fltAaaRoleRoleNotDeployed
moClass: aaa:Role
Type: security
autoCleared: true
Affected MO: sys/user-ext/role-[name]
```

fltAaaLocaleLocaleNotDeployed

障害コード : F1029

Message: Locale [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないロケールを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ロケールの合計がサポートされているロールの最大数未満であることを確認します。

障害の詳細

```
Severity: critical
Cause: locale-config-error
mibFaultCode: F1029
mibFaultName: fltAaaLocaleLocaleNotDeployed
moClass: aaa:Locale
Type: security
autoCleared: true
Affected MO: sys/user-ext/locale-[name]
```

fltAaaUserRoleUserRoleNotDeployed

障害コード : F1030

Message: For user: [name] role [name] can't be assigned. Error: [configStatusMessage].For Ldap Group: [name] role [name] can't be assigned. Error: [configStatusMessage].

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていない LDAP グループまたはローカル ユーザのユーザ ロールを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ロールが存在することを確認します。
2. ロールが適用されていることを確認します。
3. ロールがLDAPグループまたはローカルユーザに割り当てられたロケールと互換性があることを確認します。

障害の詳細

Severity: critical
Cause: user-role-config-error
mibFaultCode: F1030
mibFaultName: fltAaaUserRoleUserRoleNotDeployed
moClass: aaa:UserRole
Type: security
autoCleared: true
Affected MO: sys/ldap-ext/ldapgroup-[name]/role-[name]
Affected MO: sys/user-ext/remoteuser-[name]/role-[name]
Affected MO: sys/user-ext/user-[name]/role-[name]

fltAaaUserLocaleUserLocaleNotDeployed

障害コード : F1031

Message: For user: [name] locale [name] can't be assigned. Error: [configStatusMessage].For Ldap Group: [name] locale [name] can't be assigned. Error: [configStatusMessage].

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていない LDAP グループまたはローカル ユーザのユーザ ロケールを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ロケールが存在することを確認します。
2. ロケールが適用されていることを確認します。
3. ロケールがLDAP グループまたはローカルユーザに割り当てられたロールと互換性があることを確認します。

障害の詳細

Severity: critical
Cause: user-locale-config-error
mibFaultCode: F1031
mibFaultName: fltAaaUserLocaleUserLocaleNotDeployed
moClass: aaa:UserLocale
Type: security
autoCleared: true
Affected MO: sys/ldap-ext/ldapgroup-[name]/locale-[name]
Affected MO: sys/user-ext/remoteuser-[name]/locale-[name]
Affected MO: sys/user-ext/user-[name]/locale-[name]

fltPkiKeyRingKeyRingNotDeployed

障害コード : F1032

Message: Keyring [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager が無効なキーリングを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. このキーリング用に設定された信頼ポイントが存在することを確認します。
2. 上記の信頼ポイントが適用されていることを確認します。

障害の詳細

```
Severity: critical
Cause: keyring-config-error
mibFaultCode: F1032
mibFaultName: fltPkiKeyRingKeyRingNotDeployed
moClass: pki:KeyRing
Type: security
autoCleared: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltCommSnmptSyscontactEmpty

障害コード : F1033

Message: UCS Manager cannot deploy an empty value of SNMP Syscontact when Callhome is enabled. The previous value [sysContact] for SNMP Syscontact has been retained.

説明 :

通常、この障害は、Callhome が有効なときに SNMP Syscontact が空に設定されている UCS Central から無効な設定を UCS Manager が受信した場合に発生します。

推奨処置 :

この障害が発生した場合は、UCS Central の SNMP Syscontact フィールドが、この UCSM に対応するドメイン グループに対して正しく設定されていることを確認します。

障害の詳細

```
Severity: warning
Cause: snmp-config-error
mibFaultCode: F1033
mibFaultName: fltCommSnmptSyscontactEmpty
moClass: comm:Snmp
Type: configuration
autoCleared: true
Affected MO: sys/svc-ext/snmp-svc
```

fltCommDateTimeCommTimeZoneInvalid

障害コード : F1034

Message: Timezone:[timezone] is invalid

説明 :

通常、この障害は、Cisco UCS Manager がサポートされていないロールを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ロールの合計がサポートされているロールの最大数未満であることを確認します。
2. すべてのロールにわたる権限の合計が権限の最大数未満であることを確認します。

障害の詳細

```
Severity: minor
Cause: timezone-file-not-exists
mibFaultCode: F1034
mibFaultName: fltCommDateTimeCommTimeZoneInvalid
moClass: comm:DateTime
Type: configuration
autoCleared: true
Affected MO: org-[name]/comm-pol-[name]/datetime-svc
Affected MO: sys/svc-ext/datetime-svc
```

fltAaaUserLocalUserNotDeployed

障害コード : F1035

Message: Local User [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager が無効なシステム ユーザを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. snmp ユーザがローカル ユーザ名を使用していないことを確認します。

障害の詳細

```
Severity: major
Cause: user-config-error
mibFaultCode: F1035
mibFaultName: fltAaaUserLocalUserNotDeployed
moClass: aaa:User
Type: security
autoCleared: true
Affected MO: sys/user-ext/user-[name]
```

fltCommSnmpUserSnmpUserNotDeployed

障害コード : F1036

Message: SNMP User [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager が無効な snmp ユーザを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. システム ユーザが snmp ユーザ名を使用していないことを確認します。
2. 認証タイプが MD5 ではないことを確認します。
3. AES が有効になっていることを確認します。

障害の詳細

```
Severity: major
Cause: snmp-user-config-error
mibFaultCode: F1036
mibFaultName: fltCommSnmpUserSnmpUserNotDeployed
moClass: comm:SnmpUser
Type: configuration
autoCleared: true
Affected MO: sys/svc-ext/snmp-svc/snmpv3-user-[name]
```

fltCommSvcEpCommSvcNotDeployed

障害コード : F1037

Message: Communication Service configuration can't be deployed. Error: [configStatusMessage]

説明 :

この障害は通常、Cisco UCS Manager が無効な通信ポリシー構成を検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. すべての通信サービスで設定されているポートが一意であることを確認します。

障害の詳細

```
Severity: major
Cause: comm-svc-config-error
mibFaultCode: F1037
mibFaultName: fltCommSvcEpCommSvcNotDeployed
moClass: comm:SvcEp
Type: configuration
autoCleared: true
Affected MO: sys/svc-ext
```

fltComputeABoardPowerUsageProblem

障害コード : F1040

Message: Motherboard [faultQualifier] of server [chassisId]/[slotId] (service profile: [assignedToDn]) powerUsage: [powerUsage] Motherboard of server [id] (service profile: [assignedToDn]) powerUsage: [powerUsage] Motherboard [faultQualifier] of server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) powerUsage: [powerUsage]

説明 :

この障害は通常、マザーボードの電力消費が特定のしきい値を超えたときに発生します。このとき、サーバの電力使用状況センサーが問題を検出します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: power-problem
mibFaultCode: F1040
mibFaultName: fltComputeABoardPowerUsageProblem
moClass: compute:ABoard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]
Affected MO: sys/rack-unit-[id]/board
Affected MO: sys/rack-unit-[id]/ext-board-[id]
```

fltSwVlanPortNsVLANCompNotSupport

障害コード：F1056

Message: VLAN Port Count Optimization is not supported

説明：

未設定。

推奨処置：

未設定。

障害の詳細

```
Severity: critical
Cause: no-vlan-optimization
mibFaultCode: F1056
mibFaultName: fltSwVlanPortNsVLANCompNotSupport
moClass: sw:VlanPortNs
Type: network
autoCleared: true
Affected MO: sys/switch-[id]/vlan-port-ns
```

fltPolicyControlEpSuspendModeActive

障害コード：F1057

Message: UCSM is suspended from receiving updates from UCS Central.

説明：

この障害は、登録されている UCS Central から更新を受信している間に UCSM が中断状態に入った場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. UCS Central が以前のバージョンに復元されているかポリシー ロールバックが発生したかどうかをチェックしてください。システム制御 EP ポリシー スコープの下での **set suspendstate on** コマンドを使用したために UCS が手動の中断モードになっている可能性があります。
2. システム スコープの下での **show control-ep policy detail** を使用して、中断の状態を確認してください。UCS Central から更新を受信する場合、UCSM と互換性のあるバージョンに復元するか、ポリシー制御スコープの下での **set ackstate acked** を使用して確認し、中断状態をオフに設定する必要があります。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: suspend-mode-entered
mibFaultCode: F1057
mibFaultName: fltPolicyControlEpSuspendModeActive
moClass: policy:ControlEp
Type: management
autoCleared: true
Affected MO: sys/control-ep-[type]
```

fltNetworkElementThermalThresholdCritical

障害コード : F1080

Message: Fabric Interconnect [id] temperature: [thermal]

説明 :

この障害は、ファブリック インターコネクトの温度が重大しきい値を超えた場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、ファブリック インターコネクトの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、ファブリック インターコネクトに適切なエアフローを確保します。
3. エアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。

5. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
6. 障害のあるファブリック インターコネクトを交換します。
7. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F1080
mibFaultName: fltNetworkElementThermalThresholdCritical
moClass: network:Element
Type: environmental
autoCleared: true
Affected MO: sys/switch-[id]
```

fltFabricFcoeSanPcEpDown

障害コード : F1081

Message: [type] Member [slotId]/[aggrPortId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership][type] Member [slotId]/[portId] of Port-Channel [portId] on fabric interconnect [id] is down, membership: [membership]

説明 :

通常、この障害は、FCoE アップリンク ポートのメンバー ポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム スイッチのリンクの接続をチェックします。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F1081
mibFaultName: fltFabricFcoeSanPcEpDown
moClass: fabric:FcoeSanPcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
```

```

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/larmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sarmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

```

fltFabricFcoeSanEpDown

障害コード : F1082

Message: FCoE uplink port [slotId]/[aggrPortId]/[portId] is downFCoE uplink port [slotId]/[portId] is down

説明 :

通常、この障害は、FCoE アップリンク ポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム スイッチのリンクの接続をチェックします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: membership-down
mibFaultCode: F1082
mibFaultName: fltFabricFcoeSanEpDown
moClass: fabric:FcoeSanEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/larmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

```

Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

fltFabricVsanMembershipDown

障害コード : F1083

Message: FCoE or FC uplink is down on Vsan [vsanId]

説明 :

この障害は、FCoE アップリンクの特定の VSAN メンバーがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VSAN がピアスイッチで作成されているかどうかをチェックし、アップストリームスイッチのリンクの接続をチェックします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: minor
Cause: membership-down
mibFaultCode: F1083
mibFaultName: fltFabricVsanMembershipDown
moClass: fabric:VsanMembership
Type: network
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/vsanmember-[vsanId]
Affected MO: fabric/san/[id]/pc-[portId]/vsanmember-[vsanId]
Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO: fabric/san/[id]/phys-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/vsanmember-[vsanId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/vsanmember-[vsanId]

fltFabricFcoeSanEpUnsupported

障害コード : F1084

Message: FCoE uplink port [slotId]/[aggrPortId]/[portId] cannot be supported on springfields when FI is in eth endhost mode and FC switching mode
 FCoE uplink port [slotId]/[portId] cannot be supported on springfields when FI is in eth endhost mode and FC switching mode

説明 :

通常、この障害は、FCoE のアップリンク ポートが特定の FI プラットフォームでサポートされない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: fcoe-uplink-unsupported-fi-settings
mibFaultCode: F1084
mibFaultName: fltFabricFcoeSanEpUnsupported
moClass: fabric:FcoeSanEp
Type: network

```

autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

```

fltFabricFcoeSanPcDown

障害コード : F1085

Message: FCoE uplink port channel [portId] is down

説明 :

通常、この障害は、FCoE のアップリンク ポート チャンネルがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム スイッチのリンクの接続をチェックします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: membership-down
mibFaultCode: F1085
mibFaultName: fltFabricFcoeSanPcDown
moClass: fabric:FcoeSanPc
Type: network
autoCleared: true
Affected MO: fabric/san/[id]/fcoesanpc-[portId]

```

fltFabricFcoeSanPcUnsupported

障害コード : F1086

Message: FCoE uplink port channel [portId] cannot be supported on springfields when FI is in eth endhost mode and FC switching mode

説明 :

通常、この障害は、FCoE のアップリンク ポートが特定の FI プラットフォームでサポートされない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: fcoe-uplink-port-channel-unsupported-fi-settings
mibFaultCode: F1086
mibFaultName: fltFabricFcoeSanPcUnsupported
moClass: fabric:FcoeSanPc
Type: network
autoCleared: true
Affected MO: fabric/san/[id]/fcoesanpc-[portId]
```

fltFabricFcoeEstcEpDown

障害コード : F1087

Message: FCoE storage port [slotId]/[aggrPortId]/[portId] is downFCoE storage port [slotId]/[portId] is down

説明 :

通常、この障害は、FCoE ストレージ ポートがダウンしている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップストリーム スイッチのリンクの接続をチェックします。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: membership-down
mibFaultCode: F1087
mibFaultName: fltFabricFcoeEstcEpDown
moClass: fabric:FcoeEstcEp
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
```

```

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/larmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/sarmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

```

fltFabricPinTargetDown

障害コード : F1088

Message: Pin target is a non-existent interface

説明 :

通常、この障害は、PinGroup に解決できない対象がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. PinGroup の対象が正しくプロビジョニングされているかどうかをチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: warning
Cause: invalid-target
mibFaultCode: F1088
mibFaultName: fltFabricPinTargetDown
moClass: fabric:PinTarget
Type: network
autoCleared: true
Affected MO: fabric/lan/lan-pin-group-[name]/target-[fabricId]
Affected MO: fabric/san/san-pin-group-[name]/target-[fabricId]

```

fltFabricExternalEpFcZoningEnable

障害コード : F1089

Message: FC zoning is not supported from FI when connected to an uplink FC switch. Fabric: [switchId], Port: [slotId]/[portId].

説明：

この障害は、FC ゾーン分割が FI から有効になり、同時に FI がアップリンク FC スイッチに接続されている場合に発生します。

推奨処置：

FC ゾーン分割は、UCSM またはアップリンク FC スイッチのいずれかから設定できます。UCSM からの FC ゾーン分割を無効にするか、アップリンク スイッチの接続を解除してこの障害をクリアします。

障害の詳細

```
Severity: warning
Cause: fc-zoning-enabled
mibFaultCode: F1089
mibFaultName: fltFabricExternalEpFcZoningEnable
moClass: fabric:ExternalEp
Type: management
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/pc-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/phys-eth-slot-[slotId]-port-[portId]
Affected MO: fabric/eth-estc/[id]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
```


[illegible]

Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO: fabric/lan/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/lan/net-group-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lan/net-group-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/lanmon/[id]/eth-mon-[name]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/net-[name]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO: fabric/san/[id]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcp-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO: fabric/san/net-[name]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/san/net-[name]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO:
 fabric/san/net-[name]/sw-[switchId]-slot-[slotId]-aggr-port-[aggrPortId]/phys-switch-[switchId]-slot-[slotId]-port-[portId]

Affected MO: fabric/sanmon/[id]/fc-mon-[name]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcp-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcp-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/dest-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesanpcep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-eth-slot-[slotId]-port-[portId]/eth-target-ep-[name]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-eth/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO: sys/switch-[id]/border-eth/pc-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/pc-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]
Affected MO:
 sys/switch-[id]/sammon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/eth-target-[name]

fltFabricEthLanEpOverlapping-vlan

障害コード : F1090

Message: On Fabric: [switchId], Port: [slotId]/[aggrPortId]/[portId] following overlapping VLANs detected: [overlappingVlans] On Fabric: [switchId], Port: [slotId]/[portId] following overlapping VLANs detected: [overlappingVlans]

説明 :

この障害は、設定の誤りが原因で VLAN の重複が発生した場合に発生します。

推奨処置 :

グループに属する VLAN に設定されているポートは、重複する VLAN に属する別のネットワーク グループの他のポートと交差することはできません。

障害の詳細

Severity: info
Cause: configuration-error
mibFaultCode: F1090
mibFaultName: fltFabricEthLanEpOverlappingVlan

```

moClass: fabric:EthLanEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

```

fltFabricEthLanPcOverlapping-vlan

障害コード : F1091

Message: Overlapping VLANs detected on Fabric: [switchId], Port: [portId] in configured VLANs: [overlappingVlans]

説明 :

この障害は、設定の誤りが原因で VLAN の重複が発生した場合に発生します。

推奨処置 :

グループに属する VLAN に設定されているポートは、重複する VLAN に属する別のネットワーク グループの他のポートと交差することはできません。

障害の詳細

```

Severity: info
Cause: configuration-error
mibFaultCode: F1091
mibFaultName: fltFabricEthLanPcOverlappingVlan
moClass: fabric:EthLanPc
Type: network
autoCleared: true
Affected MO: fabric/lan/[id]/pc-[portId]

```

fltFabricFcEstcEpFc-storage-port-invalid

障害コード : F1092

Message: FC storage port should not be created in NPV mode

説明：

通常、この障害は、FC ストレージ ポートが NPV モードで作成された場合に発生します。

推奨処置：

FC ストレージ ポートは、NPV モードで作成することはできません。

障害の詳細

```
Severity: minor
Cause: fc-storageport-npv-mode
mibFaultCode: F1092
mibFaultName: fltFabricFcEstcEpFcStoragePortInvalid
moClass: fabric:FcEstcEp
Type: network
autoCleared: true
Affected MO: fabric/fc-estc/[id]/phys-fc-slot-[slotId]-port-[portId]
```

fltFabricFcoeEstcEpFcoe-storage-port-invalid

障害コード：F1093

Message: FCOE storage port should not be created in NPV mode

説明：

通常、この障害は、FCOE ストレージ ポートが NPV モードで作成された場合に発生します。

推奨処置：

FCOE ストレージ ポートは、NPV モードで作成することはできません。

障害の詳細

```
Severity: minor
Cause: fcoe-storageport-npv-mode
mibFaultCode: F1093
mibFaultName: fltFabricFcoeEstcEpFcoeStoragePortInvalid
moClass: fabric:FcoeEstcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]
```

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]

fltFabricFcSanPcFc-portchannel-members-invalid

障害コード : F1094

Message: FC port channel member ports should have same max speed**説明 :**

通常、この障害は、FC ポート チャネルの管理速度が自動になっていて、その複数のメンバーポートの最高速度が異なっている場合に発生します。

推奨処置 :

FC ポート チャネルの管理速度が自動に設定されている場合、メンバー ポートの最高速度を同じにする必要があります。

障害の詳細**Severity:** major**Cause:** fc-portchannel-members-inconsistent-speed**mibFaultCode:** F1094**mibFaultName:** fltFabricFcSanPcFcPortchannelMembersInvalid**moClass:** fabric:FcSanPc**Type:** network**autoCleared:** true**Affected MO:** fabric/san/[id]/pc-[portId]**fltFabricVlanMisconfigured-mcast-policy**

障害コード : F1095

Message: VLAN [name] multicast policy [mcastPolicyName] is non-default.**説明 :**

この障害は、スプリングフィールドファブリックに属する VLAN に、割り当てられたデフォルト以外のマルチキャスト ポリシーがある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. この VLAN のマルチキャスト ポリシーの割り当てを解除するか、マルチキャスト ポリシーをデフォルトに変更します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細**Severity:** major**Cause:** vlan-mcast-policy-misconfigured

```

mibFaultCode: F1095
mibFaultName: fltFabricVlanMisconfiguredMcastPolicy
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltMgmtConnectionDisabled

障害コード : F1097

Message: Management Connection [type] in server [id] is not operational

説明 :

この障害は、複数の管理接続が認識された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 未使用の管理接続を無効にします。
2. 新しい管理接続を使用する必要がある場合、サーバを停止し、再始動します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: warning
Cause: another-connection-already-enabled
mibFaultCode: F1097
mibFaultName: fltMgmtConnectionDisabled
moClass: mgmt:Connection
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:

```



```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/switch-[id]/mgmt/mgmt-connection-[type]

```

fltMgmtConnectionUnused

障害コード : F1098

Message: Management Connection [type] in server [id] is unused

説明 :

この障害は、管理接続が無効の場合に発生します。

推奨処置 :

この障害が発生した場合は、有効になっている管理接続がなければ接続を有効にすることができます。それ以外の場合は無視できます。

障害の詳細

Severity: info

```

Cause: connection-unused
mibFaultCode: F1098
mibFaultName: fltMgmtConnectionUnused
moClass: mgmt:Connection
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]

```

```

Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/switch-[id]/mgmt/mgmt-connection-[type]

```

fltMgmtConnectionUnsupportedConnectivity

障害コード : F1099

Message: Unsupported connectivity for management connection [type] in server [id]

説明 :

通常、この障害は、サーバの管理ポートの物理接続がサポートされていないことを Cisco UCS Manager が検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ファブリック エクステンダにラック マウント サーバの管理ポートを接続します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: minor
Cause: unsupported-connectivity
mibFaultCode: F1099
mibFaultName: fltMgmtConnectionUnsupportedConnectivity
moClass: mgmt:Connection
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/rack-unit-[id]/mgmt/mgmt-connection-[type]
Affected MO: sys/switch-[id]/mgmt/mgmt-connection-[type]

```

fltCallhomeEpNoSnmpPolicyForCallhome

障害コード : F1102

Message: UCS Manager cannot apply Callhome policy if SNMP Policy is not configured or if SNMP Syscontact has an empty value. The Callhome policy from UCS Central has not been applied.

説明 :

通常、この障害は、Callhome は UCS Central に設定されているが、ローカルに定義されている SNMP Syscontact が不在 UCS Central から無効な設定を UCS Manager が受信した場合に発生します。

推奨処置 :

この障害が発生した場合は、SNMP ポリシーがローカルでまたは UCS Central を介して UCSM マネージャに設定されていることを確認します。

障害の詳細

Severity: minor
Cause: callhome-config-error
mibFaultCode: F1102
mibFaultName:fltCallhomeEpNoSnmpPolicyForCallhome
moClass: callhome:Ep
Type: configuration
autoCleared: true
Affected MO: call-home

fltCapabilityCatalogueLoadErrors

障害コード : F1103

Message: Load errors: File parse errors: [fileParseFailures], provider load failures: [providerLoadFailures], XML element load errors: [loadErrors].

説明 :

機能カタログの完全なロードに失敗しました。これは、障害のある UCSM イメージか障害のあるカタログ イメージのいずれかが原因である可能性があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 機能カタログのバージョンをチェックします。
2. カタログに関する既知の問題があるかどうか、または既知の問題を修正するカタログ イメージがあるかどうかを確認する場合は、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: load-catalog-failed
mibFaultCode: F1103
mibFaultName:fltCapabilityCatalogueLoadErrors
moClass: capability:Catalogue
Type: management
autoCleared: true
Affected MO: capabilities

fltExtmgmtArpTargetsArpTargetsNotValid

障害コード : F1114

Message: Invalid ARP Targets configured for Management Interface Polling. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager が無効な ARP ターゲット設定を検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ARP ターゲット IP アドレスと外部管理 IP アドレスが同じサブネット内にあることを確認します。

2. ARP ターゲット IP アドレスがこのシステムのファブリック インターコネクトの IP アドレスと同じではないことを確認します。
3. ARP ターゲット IP アドレスが仮想 IP アドレスと同じではないことを確認します。

障害の詳細

```
Severity: major
Cause: arp-targets-config-error
mibFaultCode: F1114
mibFaultName: fltExtmgmtArpTargetsArpTargetsNotValid
moClass: extmgmt:ArpTargets
Type: management
autoCleared: true
Affected MO: sys/extmgmt-intf-monitor-policy/arp-target-policy
```

fltVnicFcPinningMisconfig

障害コード : F1209

Message: Hard pinning target for vHBA [name], service profile [name] is missing or misconfigured

説明 :

この障害は、ハードピン接続された SAN ピン グループ用の vNIC ターゲット アップリンク ポートまたはポート チャネルの 1 つまたは複数が、欠落しているかまたは不適切なポート タイプとして誤って設定されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SAN ピン グループの設定を確認します。
2. ピン グループのポートおよびポート チャネルの設定を修正します。
3. 必要なすべての vSAN がターゲット ポートまたはポート チャネルで許可されていることを確認します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: pinning-misconfig
mibFaultCode: F1209
mibFaultName: fltVnicFcPinningMisconfig
moClass: vnic:Fc
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/fc-[name]
Affected MO: org-[name]/san-conn-pol-[name]/fc-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/fc-[name]
```

fltExtpolClientGracePeriodWarning

障害コード : F1211

Message: UCS domain [name] registered with UCS Central has entered into the grace period.

説明 :

1 つの UCS ドメインがライセンスなしで UCS Central に登録されています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、**service-reg** セッションからライセンス スコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: license-graceperiod-entered
mibFaultCode: F1211
mibFaultName: fltExtpolClientGracePeriodWarning
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]

fltExtpolClientGracePeriodWarning2

障害コード : F1212

Message: UCS Domain [name] registered with UCS Central is running in the grace period for more than 10 days

説明 :

この UCS ドメインがライセンスなしで UCS Central に登録されています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスの スコープの下で **show usage detail** コマンドを入力して、ライセンス情報にアクセスできます。

2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: license-graceperiod-10days
mibFaultCode: F1212
mibFaultName: fltExtpolClientGracePeriodWarning2
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning3

障害コード : F1213

Message: UCS Domain [name] registered with UCS Central is running in the grace period for more than 30 days

説明 :

UCS Central に登録されたこの UCS ドメインが 30 日を超える猶予期間で実行しています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録され、非ライセンスの UCS ドメインが 120 日を超えて実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Manager GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコープの下で show usage detail コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: license-graceperiod-30days
mibFaultCode: F1213
mibFaultName: fltExtpolClientGracePeriodWarning3
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning4

障害コード : F1214

Message: UCS Domain [name] registered with UCS Central is running in the grace period for more than 60 days

説明 :

UCS Central に登録されたこの UCS ドメインが 60 日を超える猶予期間で実行しています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録され、非ライセンスの UCS ドメインが 60 日を超えて実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコープの下で `show usage detail` コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、`show tech-support` ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: license-graceperiod-60days
mibFaultCode: F1214
mibFaultName: fltExtPolClientGracePeriodWarning4
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtPolClientGracePeriodWarning5

障害コード : F1215

Message: UCS Domain [name] registered with UCS Central is running in the grace period for more than 90 days

説明 :

UCS Central に登録されたこの UCS ドメインが 90 日を超える猶予期間で実行しています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録され、非ライセンスの UCS ドメインが 90 日を超えて実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central によりインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコープの下で `show usage detail` コマンドを入力して、ライセンス情報にアクセスできます。

2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: license-graceperiod-90days
mibFaultCode: F1215
mibFaultName: fltExtpolClientGracePeriodWarning5
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning6

障害コード : F1216

Message: UCS Domain [name] registered with UCS Central is running in the grace period for more than 119 days

説明 :

UCS Central に登録されたこの UCS ドメインが 119 日を超える猶予期間で実行しています。この障害は通常、すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが UCS Central に登録され、非ライセンスの UCS ドメインが 119 日を超えて実行している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコープの下で show usage detail コマンドを入力して、ライセンス情報にアクセスできます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: license-graceperiod-119days
mibFaultCode: F1216
mibFaultName: fltExtpolClientGracePeriodWarning6
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning7

障害コード : F1217

Message: Grace period for UCS Domain [name] registered with UCS Central has expired. Please acquire a license for the same.

説明 :

UCS Central に登録されたこの UCS ドメインが 120 日を超える猶予期間で実行しています。すべてのデフォルトの（および調達された）ライセンスが他の UCS ドメインに割り当てられた後に、UCS ドメインが UCS Central に登録され、非ライセンスの UCS ドメインが 120 日を超えて実行している場合に発生します。この段階で、システムのライセンス状態は期限切れに設定されます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCS Central にインストールされ消費されたライセンスの数を確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブからライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコップの下で `show usage detail` コマンドを入力して、ライセンス情報にアクセスできます。
2. ライセンスが設定されていない UCS ドメインをディセーブルにして、イネーブルになっているドメインの数を合計ライセンス数まで下げます。
3. 上記のアクションで問題を解決できなかった場合は、`show tech-support` ファイルを作成し、ただちに Cisco TAC に問い合わせして、ライセンスを取得してください。

障害の詳細

```
Severity: critical
Cause: license-graceperiod-expired
mibFaultCode: F1217
mibFaultName: fltExtpolClientGracePeriodWarning7
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltExtpolClientGracePeriodWarning1

障害コード : F1218

Message: UCS Domain [name] is registered with UCS Central without a valid license.

説明 :

この UCS ドメインがライセンスなしで UCS Central に登録されています。この障害は通常、すべてのデフォルトのライセンスが他の UCS ドメインに割り当てられた後に、この UCS ドメインが最初のアクティベーション ライセンスなしで UCS Central に登録された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 最初のアクティベーション ライセンスが UCS Central にインストールされているかどうかを確認します。Cisco UCS Central GUI では、UCS Central の [Operations Management] タブか

らライセンス情報にアクセスできます。Cisco UCS Central CLI では、ライセンスのスコープの下で `show usage detail` コマンドを入力して、ライセンス情報にアクセスできます。

2. ライセンスが設定されていない UCS ドメインをディセーブルにして、イネーブルになっているドメインの数を合計ライセンス数まで下げます。
3. 上記のアクションで問題を解決できなかった場合は、`show tech-support` ファイルを作成し、ただちに Cisco TAC に問い合わせして、ライセンスを取得してください。

障害の詳細

```
Severity: critical
Cause: license-insufficient
mibFaultCode: F1218
mibFaultName: fltExtpolClientGracePeriodWarning1
moClass: extpol:Client
Type: management
autoCleared: true
Affected MO: extpol/reg/clients/client-[id]
```

fltStorageItemFilesystemIssues

障害コード : F1219

Message: Partition [name] on fabric interconnect [id] has file system errors

説明 :

この障害は、パーティションに障害が生じた場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. `show tech-support` ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: equipment-degraded
mibFaultCode: F1219
mibFaultName: fltStorageItemFilesystemIssues
moClass: storage:Item
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]/stor-part-[name]
```

fltStorageInitiatorDuplicate-fc-zone

障害コード : F1220

Message: Duplicate FC zones are created for initiator [name], because the same target wwpn [duplicateTarget] is duplicately configured in both boot and storage connection policy.

説明 :

ブート ポリシーとストレージ接続ポリシーの両方で同じターゲット WWPN が重複して設定されているため、重複した FC ゾーンが作成されています。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ブート ポリシーまたはストレージ接続ポリシーから重複しているターゲット WWPN を削除します。

障害の詳細

```
Severity: info
Cause: configuration-error
mibFaultCode: F1220
mibFaultName: fltStorageInitiatorDuplicateFcZone
moClass: storage:Initiator
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/san-conn-pol-[name]/grp-[name]/ini-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/grp-[name]/ini-[name]
```

fltStorageIniGroupSwitch-mode-disabled

障害コード：F1221

Message: FC zones cannot be deployed because FI is not running in FC switch mode.

説明：

FI が FC スイッチ モードで動作していないため、FC ゾーンを展開できません。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. FC ゾーンを展開する場合には、FC スイッチ モードを有効にします。
2. FI が FC エンドホスト モードを実行している場合にこの障害をクリアするには、イニシエータ グループからイニシエータを削除します。

障害の詳細

```
Severity: warning
Cause: configuration-error
mibFaultCode: F1221
mibFaultName: fltStorageIniGroupSwitchModeDisabled
moClass: storage:IniGroup
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/grp-[name]
Affected MO: org-[name]/san-conn-pol-[name]/grp-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/grp-[name]
```

fltPkiKeyRingModulus

障害コード：F1222

Message: [name] Keyring's key modulus is invalid.

説明 :

この障害は、キーリングがモジュラス セットなしで作成された場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: invalid-keyring-modulus
mibFaultCode: F1222
mibFaultName: fltPkiKeyRingModulus
moClass: pki:KeyRing
Type: security
autoCleared: true
Affected MO: sys/pki-ext/keyring-[name]
```

fltAaaOrgLocaleOrgNotPresent

障害コード : F1223

Message: Locale Org [name] can't be deployed. Error: [configStatusMessage]

説明 :

通常、この障害は、Cisco UCS Manager が識別できない組織参照を検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 同じものを作成しない場合は、この組織で参照されている組織 DN が存在することを確認します。

障害の詳細

```
Severity: warning
Cause: locale-org-config-error
mibFaultCode: F1223
mibFaultName: fltAaaOrgLocaleOrgNotPresent
moClass: aaa:Org
Type: security
autoCleared: true
Affected MO: sys/user-ext/locale-[name]/org-[name]
```

fltNetworkOperLevelExtraprimaryvlans

障害コード : F1229

Message: Fabric Interconnect [id]: Number of primary vlans exceeds the max limit on the FI: Number of Primary Vlans: [primaryVlanCount] and Max primary vlans allowed: [maxPrimaryVlanCount]

説明 :

この障害は、ファブリック インターコネクトのプライマリ VLAN の数がサポートされる数より多い場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. オペレータが、FIにある余剰なプライマリ VLAN を削除することをお勧めします。これらの余剰プライマリ VLAN がある場合でも、システムは正常に機能しているように見えることがあります。ただし、システムが推奨されているスケール制限を超えて動作しているとパフォーマンスの問題が発生することがあります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: extra-primary-vlans
mibFaultCode: F1229
mibFaultName: fltNetworkOperLevelExtraprimaryvlans
moClass: network:OperLevel
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]/oper-level
```

fltEquipmentHealthLedCriticalError

障害コード：F1236

Message: [dn] shows error. Reason [healthLedStateQualifier]

説明：

この障害は、ブレードの LED がオレンジ色の点滅に変わった場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 障害の概要を読み、アクションのコースを決定します。

障害の詳細

```
Severity: critical
Cause: health-led-amber-blinking
mibFaultCode: F1236
mibFaultName: fltEquipmentHealthLedCriticalError
moClass: equipment:HealthLed
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/blade-[slotId]/health-led
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/health-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/chassis-[id]/health-led
```

```

Affected MO: sys/chassis-[id]/psu-[id]/health-led
Affected MO: sys/chassis-[id]/slot-[id]/health-led
Affected MO: sys/fex-[id]/health-led
Affected MO: sys/fex-[id]/psu-[id]/health-led
Affected MO: sys/fex-[id]/slot-[id]/health-led
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-enclosure-[id]/psu-[id]/health-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/health-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-unit-[id]/health-led
Affected MO: sys/rack-unit-[id]/psu-[id]/health-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/switch-[id]/psu-[id]/health-led

```

fltEquipmentHealthLedMinorError

障害コード : F1237

Message: [dn] shows error. Reason: [healthLedStateQualifier]

説明 :

この障害は、ブレードの LED がオレンジ色に変わった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害の概要を読み、アクションのコースを決定します。

障害の詳細

```

Severity: minor
Cause: health-led-amber
mibFaultCode: F1237
mibFaultName: fltEquipmentHealthLedMinorError
moClass: equipment:HealthLed
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/blade-[slotId]/health-led
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/health-led
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/health-led
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/chassis-[id]/health-led
Affected MO: sys/chassis-[id]/psu-[id]/health-led
Affected MO: sys/chassis-[id]/slot-[id]/health-led
Affected MO: sys/fex-[id]/health-led
Affected MO: sys/fex-[id]/psu-[id]/health-led
Affected MO: sys/fex-[id]/slot-[id]/health-led
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-enclosure-[id]/psu-[id]/health-led
Affected MO: sys/rack-unit-[id]/ext-board-[id]/health-led
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/rack-unit-[id]/health-led
Affected MO: sys/rack-unit-[id]/psu-[id]/health-led
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/health-led
Affected MO: sys/switch-[id]/psu-[id]/health-led

```


fltVnicEtherIfRemoteVlanUnresolvable

障害コード : F1249

Message: The named vlan [name] for vNIC [name] cannot be resolved remotely

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: warning
Cause: referenced-remote-vlan-unresolvable
mibFaultCode: F1249
mibFaultName: fltVnicEtherIfRemoteVlanUnresolvable
moClass: vnic:EtherIf
Type: configuration
autoCleared: true
Affected MO:
fabric/lan/network-sets/fabric-network-[name]/fabric-network-def-[name]/vm-network-def-[name]/if-[name]
Affected MO: fabric/lan/profiles/vnic-[name]/if-[name]
Affected MO: fabric/lanmon/eth-flow-monitoring/flow-exporter-profile-[name]/if-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/ls-[name]/ipc-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/if-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ipc-[name]/if-[name]

```

fltVnicFcIfRemoteVsanUnresolvable

障害コード : F1250

Message: The named vsan [name] for vHBA [name] cannot be resolved remotely

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: warning
Cause: referenced-remote-vsan-unresolvable
mibFaultCode: F1250
mibFaultName: fltVnicFcIfRemoteVsanUnresolvable
moClass: vnic:FcIf
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/fc-[name]/if-default
Affected MO: org-[name]/san-conn-pol-[name]/fc-[name]/if-default

```

Affected MO: org-[name]/san-conn-templ-[name]/if-default
Affected MO: org-[name]/tier-[name]/ls-[name]/fc-[name]/if-default

fltVnicEtherVirtualization-conflict

障害コード : F1251

Message: Multiple connection policies cannot be assigned to the same Eth vNIC

説明 :

この障害は、複数の接続ポリシーが同じ vNIC に割り当てられた場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 接続ポリシーの異なるタイプ（ダイナミック/VMQ）が割り当てられている場合は、vNIC をチェックします。1 つのタイプのみを保持します。
2. 同じタイプの複数の接続ポリシーが割り当てられている場合は、CLI を介した vNIC をチェックします。1 つの接続ポリシーのみを保持します。

障害の詳細

Severity: major
Cause: multiple-connection-policies
mibFaultCode: F1251
mibFaultName: fltVnicEtherVirtualizationConflict
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]

fltLslssueslscsi-config-failed

障害コード : F1252

Message: Service Profile [name] configuration failed due to iSCSI issue [iscsiConfigIssues]

説明 :

通常、この障害は、Cisco UCS Manager サービス プロファイルの設定が iSCSI 設定の問題が原因で失敗した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 問題報告に従ってサービス プロファイルの iSCSI 設定を修正します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: configuration-failed
mibFaultCode: F1252
mibFaultName: fltLsIssuesIscsiConfigFailed
moClass: ls:Issues
Type: configuration
autoCleared: true
Affected MO: org-[name]/ls-[name]/config-issue
Affected MO: org-[name]/tier-[name]/ls-[name]/config-issue

```

fltStorageLocalDiskMissing

障害コード : F1256

Message: Local disk [id] missing on server [chassisId]/[slotId]Local disk [id] missing on server [id]Local disk [id] missing on storage enclosure [id]Local disk [id] missing on chassis [id]

説明 :

この障害は、ディスクが存在しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ディスクを挿入します。

障害の詳細

```

Severity: info
Cause: equipment-missing
mibFaultCode: F1256
mibFaultName: fltStorageLocalDiskMissing
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltStorageFlexFlashControllerInoperable

障害コード : F1257

Message: FlexFlash Controller [id] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason] Status: [controllerHealth]FlexFlash Controller [id] on server [id] is inoperable. Reason: [operQualifierReason] Status: [controllerHealth]

説明：

この障害は、FlexFlash コントローラがアクセスできない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ファームウェアの不一致としてレポートされた場合、CIMC とボードコントローラファームウェアを更新します。
2. 致命的なエラーとしてレポートされた場合、CIMC をリセットして、ボードコントローラファームウェアを更新します。
3. PCI およびメザニンベースのコントローラの場合、ストレージコントローラの装着をチェックします。問題が解決しない場合は、コントローラを交換します。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F1257
mibFaultName: fltStorageFlexFlashControllerInoperable
moClass: storage:FlexFlashController
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]
```

fltStorageFlexFlashCardInoperable

障害コード：F1258

Message: FlexFlash Card [slotNumber] on server [chassisId]/[slotId] is inoperable. Reason: [operQualifierReason] FlexFlash Card [slotNumber] on server [id] is inoperable. Reason: [operQualifierReason]

説明：

この障害は、FlexFlash カードがアクセスできない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 書き込みの保護としてレポートされた場合、カードから書き込み保護を削除します。
2. 無効な容量としてレポートされた場合、OS ディスク ユーティリティを使用してパーティションを削除または再作成します。
3. 上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

```
Severity: major
```

```
Cause: equipment-inoperable
mibFaultCode: F1258
mibFaultName: fltStorageFlexFlashCardInoperable
moClass: storage:FlexFlashCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/card-[slotNumber]
```

fltStorageFlexFlashCardMissing

障害コード : F1259

Message: FlexFlash Card [slotNumber] missing on server [chassisId]/[slotId]FlexFlash Card [slotNumber] missing on server [id]

説明 :

この障害は、FlexFlash カードが存在しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. カードを挿入します。

障害の詳細

```
Severity: info
Cause: equipment-missing
mibFaultCode: F1259
mibFaultName: fltStorageFlexFlashCardMissing
moClass: storage:FlexFlashCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/card-[slotNumber]
```

fltStorageFlexFlashVirtualDriveDegraded

障害コード : F1260

Message: FlexFlash Virtual Drive RAID degraded on server [chassisId]/[slotId]. Reason: [raidState]FlexFlash Virtual Drive RAID degraded on server [id]. Reason: [raidState]

説明 :

この障害は、FlexFlash RAID が劣化すると発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FlexFlash スクラブ ポリシーを [yes] に設定して、サーバを再確認します。このアクションでカード内のすべてのデータが消去されることに注意してください。

2. コントローラ/カードの状態を確認します。上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

```
Severity: minor
Cause: equipment-degraded
mibFaultCode: F1260
mibFaultName: fltStorageFlexFlashVirtualDriveDegraded
moClass: storage:FlexFlashVirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/vd-[id]
```

fltStorageFlexFlashVirtualDriveInoperable

障害コード : F1261

Message: FlexFlash Virtual Drive on server [chassisId]/[slotId] is inoperable. Reason: [raidState]FlexFlash Virtual Drive on server [id] is inoperable. Reason: [raidState]

説明 :

この障害は、FlexFlash の仮想ドライブが動作不能になっている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FlexFlash スクラブ ポリシーを [yes] に設定して、サーバを再確認します。このアクションでカード内のすべてのデータが消去されることに注意してください。
2. コントローラ/カードの状態を確認します。上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F1261
mibFaultName: fltStorageFlexFlashVirtualDriveInoperable
moClass: storage:FlexFlashVirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/vd-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/vd-[id]
```

fltStorageFlexFlashControllerUnhealthy

障害コード : F1262

Message: FlexFlash Controller [id] on server [chassisId]/[slotId] is unhealthy. Reason: [operQualifierReason] Status: [controllerHealth] FlexFlash Controller [id] on server [id] is unhealthy. Reason: [operQualifierReason] Status: [controllerHealth]

説明 :

この障害は、FlexFlash コントローラの状態が異常になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 古いファームウェア/ファームウェアの不一致としてレポートされた場合、CIMC とボードコントローラ ファームウェアを更新し、サーバをリブートします。
2. FlexFlash スクラブ ポリシーを [yes] に設定して、サーバを再確認します。このアクションでカード内のすべてのデータが消去されることに注意してください。
3. コントローラの状態を確認します。上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

Severity: minor
Cause: equipment-unhealthy
mibFaultCode: F1262
mibFaultName: fltStorageFlexFlashControllerUnhealthy
moClass: storage:FlexFlashController
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]

fltAaaProviderGroupProvidergroupsize

障害コード : F1279

Message: For [dn]: Server Group [name] has [size] provider references. Authentication might fail, if this provider group is used with auth-domain.

説明 :

通常、この障害は、Cisco UCS Manager がプロバイダー参照がないプロバイダー グループを検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. プロバイダー参照がないプロバイダー グループを削除する必要があります。
2. またはプロバイダー グループにプロバイダー参照を追加します。

障害の詳細

```

Severity: warning
Cause: provider-group-size-empty
mibFaultCode: F1279
mibFaultName: fltAaaProviderGroupProvidergroupsize
moClass: aaa:ProviderGroup
Type: security
autoCleared: true
Affected MO: sys/ldap-ext/providergroup-[name]
Affected MO: sys/radius-ext/providergroup-[name]
Affected MO: sys/tacacs-ext/providergroup-[name]

```

fltFirmwareAutoSyncPolicyDefaultHostPackageMissing

障害コード : F1284

Message: Default host firmware package is missing or deleted.

説明 :

通常、この障害は、ファームウェアの自動同期ポリシーが自動確認またはユーザ確認に設定されていて、デフォルトのホスト ファームウェア パックが使用できない場合に発生します。

- ファームウェアの自動同期は発生していません。
- Default host firmware package is missing or deleted.

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. [Servers] タブに移動して、ポリシー ノードを展開します。ポリシー ノードの下で [Host Firmware Packages] を選択します。
2. FSM に障害が発生した場合は、FSM のエラー メッセージを確認します。
3. 「default」という名前のホストのファームウェア パッケージを作成します。問題が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: major
Cause: default-hostpack-missing
mibFaultCode: F1284
mibFaultName: fltFirmwareAutoSyncPolicyDefaultHostPackageMissing
moClass: firmware:AutoSyncPolicy
Type: management
autoCleared: true
Affected MO: org-[name]/fw-auto-sync

```

fltFirmwareAutoSyncPolicyDefaultHostPackageMissingVersions

障害コード : F1285

Message: B-series,C-series and M-series package versions are empty in default host firmware package

説明 :

通常、この障害は、ファームウェアの自動同期ポリシーが自動確認またはユーザ確認に設定されていて、デフォルトのホスト ファームウェア パッケージにサーババージョンセットがある場合に発生します。

- ファームウェアの自動同期は発生していません。
- デフォルトのホスト ファームウェア パッケージではブレードまたはラックのバージョンは空です。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. [Servers] タブに移動して、ポリシー ノードを展開します。ポリシー ノードの下で [Host Firmware Packages] を選択します。
2. FSM に障害が発生した場合は、FSM のエラー メッセージを確認します。
3. 「Default」のホストファームウェアパッケージを開き、ラックまたはブレードのバージョンを更新します。問題が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: default-hostpack-missing-versions
mibFaultCode: F1285
mibFaultName: fltFirmwareAutoSyncPolicyDefaultHostPackageMissingVersions
moClass: firmware:AutoSyncPolicy
Type: management
autoCleared: true
Affected MO: org-[name]/fw-auto-sync
```

fltFabricNetflowMonSessionFlowMonConfigFail

障害コード：F1304

Message: Configuration for traffic flow monitor [name] failed, reason: [configFailReason]

説明：

通常、この障害は、トラフィック フロー モニタリング セッションの設定が正しくない場合に発生します。

推奨処置：

この障害が発生した場合は、障害の説明に示されている設定の問題を修正します。

障害の詳細

```
Severity: major
Cause: config-error
mibFaultCode: F1304
mibFaultName: fltFabricNetflowMonSessionFlowMonConfigFail
moClass: fabric:NetflowMonSession
Type: network
```

```
autoCleared: true
Affected MO: fabric/lanmon/eth-flow-monitoring/netflow-mon-[name]
```

fltFabricNetflowMonSessionNetflowSessionConfigFail

障害コード : F1305

Message: Netflow session configuration failed because [configQualifier]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: config-error
mibFaultCode: F1305
mibFaultName: fltFabricNetflowMonSessionNetflowSessionConfigFail
moClass: fabric:NetflowMonSession
Type: network
autoCleared: true
Affected MO: fabric/lanmon/eth-flow-monitoring/netflow-mon-[name]
```

fltFabricPooledVlanNamedVlanUnresolved

障害コード : F1306

Message: VLAN [name] for VLAN group [name] cannot be resolved to any existing vlans.

説明 :

通常、この障害は、VLAN グループの名前付き VLAN が既存の VLAN に対応していない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VLAN を作成します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: warning
Cause: named-vlan-unresolved
mibFaultCode: F1306
mibFaultName: fltFabricPooledVlanNamedVlanUnresolved
moClass: fabric:PooledVlan
Type: network
autoCleared: true
Affected MO: fabric/lan/[id]/net-group-[name]/net-[name]
Affected MO: fabric/lan/net-group-[name]/net-[name]
```

fltExtvmmVMNDRefVmNetworkReferenceIncorrect

障害コード : F1320

Message: VM Network [name] references [vmNetworkDefName] that is already being referenced by another VM Network

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: warning
Cause: vm-network-reference-incorrect
mibFaultCode: F1320
mibFaultName: fltExtvmmVMNDRefVmNetworkReferenceIncorrect
moClass: extvmm:VMNDRef
Type: configuration
autoCleared: true
Affected MO: fabric/lan/vm-network-sets/vm-network-[name]/vm-network-def-ref[name]

fltExtmgmtNdiscTargetsNdiscTargetsNotValid

障害コード : F1321

Message: Invalid NDISC Targets configured for Management Interface Polling. Error: [configStatusMessage]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: ndisc-targets-config-error
mibFaultCode: F1321
mibFaultName: fltExtmgmtNdiscTargetsNdiscTargetsNotValid
moClass: extmgmt:NdiscTargets
Type: management
autoCleared: true
Affected MO: sys/extmgmt-intf-monitor-policy/ndisc-target-policy

fltFirmwareBootUnitPowerCycleRequired

障害コード : F1325

Message: Board controller upgraded, manual a/c power cycle required on server [serverId]

説明 :

未設定。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ボードコントローラの電源を再投入します。

障害の詳細

```

Severity: critical
Cause: board-ctrl-upgraded
mibFaultCode: F1325
mibFaultName: fltFirmwareBootUnitPowerCycleRequired
moClass: firmware:BootUnit
Type: generic
autoCleared: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit-[type]
Affected MO: capabilities/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]

```

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/psu-[id]/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/sas-expander-[id]/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]

Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]

Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]

```

Affected MO: sys/chassis-[id]/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/psu-[id]/fw-boot-def/bootunit-[type]

```

fltMgmtControllerUnsupportedDimmBlacklisting

障害コード : F1328

Message: Dimm blacklisting is not supported on server [chassisId]/[slotId]Dimm blacklisting is not supported on server [id]

説明 :

通常、この障害は、サーバの CIMC ファームウェアが Cisco UCS Release 2.2 よりも前のリリースである場合に発生します。

推奨処置 :

この障害が発生した場合は、CIMC ファームウェア（および必要に応じて Cisco UCS インスタンスすべて）を、Cisco UCS Release 2.2 以降にアップグレードすることを検討してください。

障害の詳細

```

Severity: info
Cause: incompatible-server-firmware
mibFaultCode: F1328
mibFaultName: fltMgmtControllerUnsupportedDimmBlacklisting
moClass: mgmt:Controller
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt
Affected MO: sys/chassis-[id]/boardController/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/chassis-[id]/mgmt
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt
Affected MO: sys/chassis-[id]/shared-io-module/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/mgmt
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt
Affected MO: sys/fex-[id]/mgmt
Affected MO: sys/fex-[id]/slot-[id]/mgmt
Affected MO: sys/mgmt
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt
Affected MO: sys/rack-unit-[id]/boardController/mgmt
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt

```

Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt
Affected MO: sys/rack-unit-[id]/mgmt
Affected MO: sys/switch-[id]/mgmt

fltFabricEthLanEpUdldLinkDown

障害コード : F1358

Message: UDLD state for ether port [slotId]/[aggrPortId]/[portId] on fabric interconnect [switchId] is: [udldOperState]. UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

説明 :

この障害は、イーサネット アップリンクが単方向に接続されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップリンク ポートの tx と rx の接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: udld-link-down
mibFaultCode: F1358
mibFaultName: fltFabricEthLanEpUdldLinkDown
moClass: fabric:EthLanEp
Type: network
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-slot-[slotId]-port-[portId]

fltFabricEthLanPcEpUdldLinkDown

障害コード : F1359

Message: UDLD state for ether port [slotId]/[aggrPortId]/[portId] on fabric interconnect [switchId] is: [udldOperState]. UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

説明 :

この障害は、イーサネット アップリンクのポートチャネル メンバーが単方向に接続されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップリンク ポートの tx と rx の接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: udld-link-down
mibFaultCode: F1359
mibFaultName: fltFabricEthLanPcEpUdldLinkDown
moClass: fabric:EthLanPcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO: fabric/lan/[id]/pc-[portId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]-port-[portId]
```

fltFabricFcoeSanEpUdldLinkDown

障害コード : F1360

Message: UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState]. UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

説明 :

この障害は、FCoE アップリンク ポートが単方向に接続されている場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アップリンク ポートの tx と rx の接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: udld-link-down
mibFaultCode: F1360
mibFaultName: fltFabricFcoeSanEpUdldLinkDown
moClass: fabric:FcoeSanEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/larmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesane-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO: fabric/san/[id]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/sarmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesane-slot-[slotId]-port-[portId]
```

fltFabricFcoeSanPcEpUdldLinkDown

障害コード : F1361

Message: UDLD state for ether port [slotId]/[aggrPortId]/[portId] on fabric interconnect [switchId] is: [udldOperState]. UDLD state for ether port [slotId]/[portId] on fabric interconnect [switchId] is: [udldOperState].

説明 :

この障害は、FCoE アップリンクのポートチャネル メンバーが単方向に接続されている場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. アップリンク ポートの tx と rx の接続をチェックします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: udd-link-down
mibFaultCode: F1361
mibFaultName: fltFabricFcoeSanPcEpUddLinkDown
moClass: fabric:FcoeSanPcEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/larmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO: fabric/san/[id]/fcoesancep-[portId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesancep-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/sarmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesancep-slot-[slotId]-port-[portId]
```

fltFirmwareStatusCimcFirmwareMismatch

障害コード：F1365

Message: Aggregate blade CIMC firmware mismatch. Firmware: [cimeVersion]

説明：

通常、この障害は、集約ブレード内のマスターおよびスレーブ ノードの CIMC ファームウェア イメージが一致しない場合に発生します。

推奨処置：

マスターおよびスレーブ CIMC を同じファームウェアバージョンに更新してアクティブにします。

障害の詳細

```
Severity: critical
Cause: cimc-firmware-mismatch
mibFaultCode: F1365
mibFaultName: fltFirmwareStatusCimcFirmwareMismatch
moClass: firmware:Status
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/fw-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fw-status
Affected MO: sys/chassis-[id]/fw-status
Affected MO: sys/chassis-[id]/psu-[id]/fw-status
Affected MO: sys/chassis-[id]/slot-[id]/fw-status
Affected MO: sys/fex-[id]/psu-[id]/fw-status
Affected MO: sys/fex-[id]/slot-[id]/fw-status
Affected MO: sys/fw-status
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-status
Affected MO: sys/rack-unit-[id]/fw-status
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-status
Affected MO: sys/switch-[id]/fw-status
Affected MO: sys/switch-[id]/psu-[id]/fw-status
```

fltFirmwareStatusPldFirmwareMismatch

障害コード : F1366

Message: Aggregate blade board controller firmware mismatch. Firmware: [pldVersion]

説明 :

通常、この障害は、集約ブレード内のマスターおよびスレーブ ノードのボード コントローラ ファームウェア イメージが一致しない場合に発生します。

推奨処置 :

マスターおよびスレーブのボード コントローラを同じファームウェアバージョンに更新します。

障害の詳細

```
Severity: critical
Cause: pld-firmware-mismatch
mibFaultCode: F1366
mibFaultName: fltFirmwareStatusPldFirmwareMismatch
moClass: firmware:Status
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/fw-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fw-status
Affected MO: sys/chassis-[id]/fw-status
Affected MO: sys/chassis-[id]/psu-[id]/fw-status
Affected MO: sys/chassis-[id]/slot-[id]/fw-status
Affected MO: sys/fex-[id]/psu-[id]/fw-status
Affected MO: sys/fex-[id]/slot-[id]/fw-status
Affected MO: sys/fw-status
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-status
```

Affected MO: sys/rack-unit-[id]/fw-status
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-status
Affected MO: sys/switch-[id]/fw-status
Affected MO: sys/switch-[id]/psu-[id]/fw-status

fltSysdebugLogExportStatusLogExportFailure

障害コード : F1369

Message: Log export to remote server failed from [switchId]:[exportFailureReason]

説明 :

この障害は、Cisco UCS Manager がリモート サーバにログ ファイルを転送できない場合に発生します。これは、通常、次のいずれかの問題の結果として発生します。

- リモート サーバにアクセスできない。
- パス、ユーザ名、パスワード、ssh キー、サーバ名など、ログエクスポートターゲットに指定されているリモート サーバの 1 つまたは複数のパラメータが間違っている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. リモート サーバへの接続を確認します。
2. リモート サーバのパス情報を確認します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: server-error
mibFaultCode: F1369
mibFaultName: fltSysdebugLogExportStatusLogExportFailure
moClass: sysdebug:LogExportStatus
Type: sysdebug
autoCleared: true
Affected MO: sys/sysdebug/log-export-policy/log-export-status-[switchId]

fltVnicEtherVirtualization-netflow-conflict

障害コード : F1380

Message: Netflow and VMQ/SRIOV-USNIC policies cannot be assigned to the same Eth vNIC

説明 :

通常、この障害は、netflow src vnic が USNIC または VMQ vnic を作成した場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. netflow セッションから vnic を削除するか、usnic/vmq ポリシーを削除します。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: multiple-connection-policies
mibFaultCode: F1380
mibFaultName: fltVnicEtherVirtualizationNetflowConflict
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]
```

fltFabricVlanPrimaryVlanMissingForIsolated

障害コード : F1382

Message: Primary Vlan can not be resolved for isolated vlan [name]

説明 :

通常、この障害は、特定の独立 VLAN に対応するプライマリ VLAN ID の解決で、Cisco UCS Manager に問題が生じた場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 有効なプライマリ VLAN に独立 VLAN を関連付けます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: primary-vlan-missing-for-isolated
mibFaultCode: F1382
mibFaultName: fltFabricVlanPrimaryVlanMissingForIsolated
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricVlanPrimaryVlanMissingForCommunity

障害コード : F1383

Message: Primary Vlan can not be resolved for community vlan [name]

説明 :

通常、この障害は、特定のコミュニティ VLAN に対応するプライマリ VLAN ID の解決で、Cisco UCS Manager に問題が生じた場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 有効なプライマリ VLAN にコミュニティ VLAN を関連付けます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: primary-vlan-missing-for-community
mibFaultCode: F1383
mibFaultName: fltFabricVlanPrimaryVlanMissingForCommunity
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricVlanMismatch-a

障害コード：F1384

Message: VLAN [name] has [overlapStateForA] with another vlan under lan-cloud/appliance-cloud for the fabric interconnect A

説明：

通常、この障害は、1つのクラウドの下にある VLAN のプライベート VLAN のプロパティが、ファブリック インターコネクト A の別のクラウドの下にある VLAN のプライベート VLAN のプロパティと競合している場合に発生します。クラウドは、LAN クラウドまたはアプライアンス クラウドのいずれかを意味します。この問題によって、この VLAN の使用が停止する場合があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 両方のクラウドの下にある VLAN の共有プロパティとその VLAN ID によって参照されるファブリック A をチェックします。
2. VLAN の共有プロパティが他のクラウドの VLAN と一致しない場合、相互に一致させるために、VLAN の共有のいずれかの共有プロパティを変更します。
3. VLAN が隔離/コミュニティ VLAN である場合、その VLAN ID によって参照される両方のクラウドの下にある VLAN の pubnwnname プロパティをチェックします。

4. 隔離/コミュニティ VLAN の pubnwnname プロパティが他のクラウドの隔離/コミュニティ VLAN と一致しない場合、相互に一致させるために、VLAN のいずれかの pubnwnname プロパティを変更します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vlan-mismatch
mibFaultCode: F1384
mibFaultName: fltFabricVlanMismatchA
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricVlanMismatch-b

障害コード : F1385

Message: VLAN [name] has [overlapStateForB] with another vlan under lan-cloud/appliance-cloud for the fabric interconnect B

説明 :

通常、この障害は、1つのクラウドの下にある VLAN のプライベート VLAN のプロパティが、ファブリック インターコネクト B の別のクラウドの下にある VLAN のプライベート VLAN のプロパティと競合している場合に発生します。クラウドは、LAN クラウドまたはアプライアンスクラウドのいずれかを意味します。この問題によって、この VLAN の使用が停止する場合があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 両方のクラウドの下にある VLAN の共有プロパティとその VLAN ID によって参照されるファブリック B をチェックします。
2. VLAN の共有プロパティが他のクラウドの VLAN と一致しない場合、相互に一致させるために、VLAN の共有のいずれかの共有プロパティを変更します。
3. VLAN が隔離/コミュニティ VLAN である場合、その VLAN ID によって参照される両方のクラウドの下にある VLAN の pubnwnname プロパティをチェックします。
4. 隔離/コミュニティ VLAN の pubnwnname プロパティが他のクラウドの隔離/コミュニティ VLAN と一致しない場合、相互に一致させるために、VLAN のいずれかの pubnwnname プロパティを変更します。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vlan-mismatch
mibFaultCode: F1385
mibFaultName: fltFabricVlanMismatchB
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltFabricVlanErrorAssocPrimary

障害コード : F1386

Message: VLAN [name] is in error state because the associated primary vlan [assocPrimaryVlanState]

説明 :

通常、この障害は、セカンダリ VLAN の関連付けられたプライマリ VLAN にエラーがある場合に発生します。この問題によって、この VLAN の使用が停止する場合があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VLAN の pubnwnname プロパティをチェックします。
2. pubnwnname が指定されていない、または存在しないプライマリ VLAN のことを指している場合、良好な状態にあるプライマリ VLAN の名前を指定します。
3. pubnwnname がプライマリ VLAN ではない VLAN を指している場合、該当する VLAN をプライマリ VLAN に変更するか、異なるプライマリ VLAN を指定します。
4. pubnwnname が有効なプライマリ VLAN を指している場合、プライマリ VLAN の状態をチェックします。
5. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: vlan-error-assoc-primary
mibFaultCode: F1386
mibFaultName: fltFabricVlanErrorAssocPrimary
moClass: fabric:Vlan
Type: network
autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]
```

fltLsServerSvnicNotPresent

障害コード : F1388

Message: Service profile [name] does not contain service vnics for netflow.

説明 :

サービス プロファイルにサービス vnic がないため、netflow はこのサーバ上では機能しません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サービス プロファイルに最大数の vnic がすでに作成されているため、netflow に必要なサービス vnic に対応できません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. すでに netflow を有効にしている場合、サービス vnic に対応できるように、サービス プロファイルの vnic の数を減らしてください。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: svnic-not-present
mibFaultCode: F1388
mibFaultName: fltLsServerSvnicNotPresent
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltLsIssuesKvmPolicyUnsupported

障害コード : F1389

Message: Kvm mgmt policy not supported by current CIMC version

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: minor
Cause: unsupported-cimc-firmware
mibFaultCode: F1389
mibFaultName: fltLsIssuesKvmPolicyUnsupported
moClass: ls:Issues
Type: server
autoCleared: true
```

Affected MO: org-[name]/ls-[name]/config-issue
Affected MO: org-[name]/tier-[name]/ls-[name]/config-issue

fltMgmtBackupPolicyConfigConfiguration backup outdated

障害コード : F1392

Message: Config backup may be outdated

説明 :

この障害は、最後のバックアップ設定に時間がかかる場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 設定のバックアップを実行してください。

障害の詳細

Severity: minor
Cause: config-backup-outdated
mibFaultCode: F1392
mibFaultName: fltMgmtBackupPolicyConfigConfigurationBackupOutdated
moClass: mgmt:BackupPolicyConfig
Type: management
autoCleared: true
Affected MO: sys/bkup-policy-cfg

fltNetworkOperLevelExtrasecondaryvlans

障害コード : F1396

Message: Fabric Interconnect [id]: Number of secondary vlans exceeds the max limit on the FI: Number of secondary vlans: [secondaryVlanCount] and Max secondary vlans allowed: [maxSecondaryVlanCount]

説明 :

この障害は、ファブリック インターコネクトのセカンダリ VLAN の数がサポートされる数より多い場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. オペレータが、FIにある余剰セカンダリ VLANを削除することをお勧めします。これらの余剰セカンダリ VLANがある場合でも、システムは正常に機能しているように見えることがあります。ただし、システムが推奨されているスケール制限を超えて動作しているとパフォーマンスの問題が発生することがあります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

Severity: major
Cause: extra-secondary-vlans

```

mibFaultCode: F1396
mibFaultName: fltNetworkOperLevelExtrasecondaryvlans
moClass: network:OperLevel
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]/oper-level

```

fltSwVlanExtrasecondaryvlansperprimary

障害コード : F1397

Message: Number of secondary vlans associated with the primary vlan [id] in Fabric Interconnect [switchId] exceeds the max limit: Number of secondary vlans: [secVlanPerPrimaryVlanCount].

説明 :

この障害は、ファブリック インターコネクトのプライマリ VLAN ごとのセカンダリ VLAN の数がサポートされる数より多い場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. オペレータが、FI にあるこのプライマリ VLAN 上の余剰セカンダリ VLAN を削除することをお勧めします。このプライマリ VLAN 上にこれらの余剰セカンダリ VLAN がある場合でも、システムは正常に機能しているように見えることがあります。ただし、システムが推奨されているスケール制限を超えて動作しているとパフォーマンスの問題が発生することがあります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: minor
Cause: extra-secondary-vlans-per-primary
mibFaultCode: F1397
mibFaultName: fltSwVlanExtrasecondaryvlansperprimary
moClass: sw:Vlan
Type: equipment
autoCleared: true
Affected MO: fabric/lan/profiles/vnic-[name]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:

```

[illegible]

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/chassis-[id]/vnic-[name]/vlan-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]

Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoeestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/access-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-eth/pc-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoeestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-eth/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/fcoeestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/fcoesan-pc-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/fcoeestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/border-fc/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/border-fc/vlan-[id]
Affected MO: sys/switch-[id]/ethlanflowmon/flowexporter-netflow-[name]/vlan-[id]
Affected MO: sys/switch-[id]/ethlanflowmon/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/pc-[portId]/vlan-[id]
Affected MO:

```

sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/lanmon-eth/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vlan-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-[id]
Affected MO:
sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/fcoestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/phys/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/fcoesan-pc-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/sanmon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/sanmon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/ethestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/sanmon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoestc-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO:
sys/switch-[id]/sanmon-fc/mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/fcoesan-ep-slot-[slotId]port-[portId]/vlan-[id]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vc-[id]/vlan-[id]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vlan-[id]

```

fltCimcvmediaActualMountEntryVmediaMountFailed

障害コード : F1404

Message: Server [chassisId]/[slotId] (service profile: [assignedToDn]) vmedia mapping [mappingName] has failed. Server [id] (service profile: [assignedToDn]) vmedia mapping [mappingName] has failed. Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) vmedia mapping [mappingName] has failed.

説明 :

未設定。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. マウント関連の詳細（リモート サーバ IP、ポート、パスおよびファイルは到達可能）をチェックしてサーバを再認識します。

障害の詳細

```

Severity: major
Cause: vmedia-mount-inaccessible
mibFaultCode: F1404
mibFaultName: fltCimcvmediaActualMountEntryVmediaMountFailed
moClass: cimcvmedia:ActualMountEntry
Type: server
autoCleared: true

```


[illegible]

Affected MO: sys/fex-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/fex-[id]/slot-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO: sys/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/boardController/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO:
 sys/rack-unit-[id]/ext-board-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO: sys/rack-unit-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]
Affected MO: sys/switch-[id]/mgmt/actual-mount-list/actual-mount-entry-[virtualDiskId]

fltEquipmentTpmSlaveTpm

障害コード : F1439

Message: Server [chassisId]/[slotId], has a TPM present on the Slave Board which will be unoperational.

説明 :

この障害は、TPM がスレーブ ボードに存在するが、サーバが使用できないことを示します。集約ブレードサーバの場合、マスター ボードの TPM のみを使用できます。

推奨処置 :

スレーブ ボードからの TPM を削除して、別のサーバで使用できますが、サーバ機能に影響はありません。

障害の詳細

Severity: info
Cause: tpm-on-slave-board
mibFaultCode: F1439
mibFaultName: fltEquipmentTpmSlaveTpm
moClass: equipment:Tpm
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/Tpm-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/Tpm-[id]
Affected MO: sys/rack-unit-[id]/board/Tpm-[id]

fltStorageMezzFlashLifeConfiguration-error

障害コード : F1448

Message: Flash Life on server [chassisId]/[slotId] flashStatus: [flashStatus]

説明 :

この障害は、エラーが原因で Fusion-io の残量を UCSM が回復できない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Fusion-io ファームウェアをアップグレードします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: configuration-error
mibFaultCode: F1448
mibFaultName: fltStorageMezzFlashLifeConfigurationError
moClass: storage:MezzFlashLife
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/flash-life-
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/flash-life-
Affected MO: sys/chassis-[id]/storage-[type]-[id]/flash-life-
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/flash-life-
```

fltStorageMezzFlashLifeDegraded

障害コード : F1449

Message: Flash Life on server [chassisId]/[slotId] flashStatus: [flashStatus]

説明：

この障害は、Fusion-io の残量が 10 パーセント以下である場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. Fusion-io の残量のモニタを継続します。0 パーセントになった場合、アダプタは読み取り専用に復帰することがあります。

障害の詳細

```
Severity: warning
Cause: equipment-degraded
mibFaultCode: F1449
mibFaultName: fltStorageMezzFlashLifeDegraded
moClass: storage:MezzFlashLife
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/flash-life-
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/flash-life-
Affected MO: sys/chassis-[id]/storage-[type]-[id]/flash-life-
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/flash-life-
```

fltStorageFlexFlashControllerMismatch

障害コード : F1450

Message: FlexFlash Controller [id] on server [chassisId]/[slotId] has SD cards with different sizes.FlexFlash Controller [id] on server [id] has SD cards with different sizes.

説明 :

この障害は、FlexFlash SD カードのサイズが一致しない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 既存のカードの 1 つを削除し、削除していないものと同じサイズの別のカードと交換します。

障害の詳細

Severity: major
Cause: equipment-unhealthy
mibFaultCode: F1450
mibFaultName: fltStorageFlexFlashControllerMismatch
moClass: storage:FlexFlashController
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]

fltStorageFlexFlashDriveUnhealthy

障害コード : F1451

Message: FlexFlash Drive [id] on server [chassisId]/[slotId] is unhealthy. Reason: [operQualifierReason]
Status: [operationState]FlexFlash Drive [id] on server [id] is unhealthy. Reason: [operQualifierReason]
Status: [operationState]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: equipment-unhealthy
mibFaultCode: F1451
mibFaultName: fltStorageFlexFlashDriveUnhealthy
moClass: storage:FlexFlashDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/card-[slotNumber]/drive-[name]
Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/card-[slotNumber]/drive-[name]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/card-[slotNumber]/drive-[name]

fltStorageFlexFlashCardUnhealthy

障害コード : F1452

Message: FlexFlash Card [slotNumber] on server [chassisId]/[slotId] is unhealthy. Reason: [cardHealth]FlexFlash Card [slotNumber] on server [id] is unhealthy. Reason: [cardHealth]

説明 :

この障害は、FlexFlash カードの状態が異常である場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FlexFlash コントローラが自動同期をサポートしている、自動同期が現在設定されている、FlexFlash コントローラが RAID グループを構築しているかどうかを確認します。RAID グループが構築されている場合、RAID グループが同期されるまで待機します。ホスト OS が生成する I/O の量に応じて、RAID-1 ミラーの構築には数時間かかる可能性があることに注意してください。
2. 上記のアクションで問題を解決できなかった場合は、Flex Flash 自動同期を設定し、RAID グループが再構築されるまで待機します。これには数時間かかる可能性があります。
3. 上記のアクションで問題を解決できなかった場合は、Flex Flash コントローラをリセットします。
4. 上記のアクションで問題を解決できなかった場合は、SD カードを再フォーマットします。
5. Flex Flash スクラブポリシーを [Yes] に設定して、サーバを再認識します。このアクションでカード内のすべてのデータが消去されることに注意してください。
6. カードの状態を確認します。上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

Severity: minor
Cause: equipment-unhealthy
mibFaultCode: F1452
mibFaultName: fltStorageFlexFlashCardUnhealthy
moClass: storage:FlexFlashCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/card-[slotNumber]

fltPoolElementDuplicatedAssigned

障害コード : F1453

Message: ID is duplicated assigned for multiple servers(Check UCSC for details)

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: duplicated-assigned
mibFaultCode: F1453
mibFaultName: fltPoolElementDuplicatedAssigned
moClass: pool:Element
Type: server
autoCleared: true
Affected MO: ip/[id]
Affected MO: iqn/[name]
Affected MO: mac/[id]
Affected MO: uuid/[id]
Affected MO: wwn/[id]
```

fltMgmtInterfaceNamedInbandVlanUnresolved

障害コード : F1454

Message: [configMessage]

説明 :

この障害は、インバンドインターフェイス コンフィギュレーションに問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、インバンド IP に設定されている VLAN が作成され、VLAN がインバンドプロファイルにあるか、IP アドレスが設定されているかを確認します

障害の詳細

```
Severity: minor
Cause: named-inband-vlan-unresolved
mibFaultCode: F1454
mibFaultName: fltMgmtInterfaceNamedInbandVlanUnresolved
moClass: mgmt:Interface
Type: management
autoCleared: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
```

Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

fltMgmtInterfaceInbandUnsupportedServer

障害コード : F1455

Message: [configMessage]

説明 :

この障害は、インバンド インターフェイス コンフィギュレーションに問題がある場合に発生します。

推奨処置：

この障害が発生した場合は、インバンド IP に設定されている VLAN が作成され、VLAN がインバンド プロファイルにあるか、IP アドレスが設定されているかを確認します

障害の詳細

```
Severity: minor
Cause: inband-unsupported-server
mibFaultCode: F1455
mibFaultName: fltMgmtInterfaceInbandUnsupportedServer
moClass: mgmt:Interface
Type: management
autoCleared: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
```



```

Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

```

fltMgmtInterfaceInbandUnsupportedFirmware

障害コード : F1456

Message: [configMessage]

説明 :

この障害は、インバンド インターフェイス コンフィギュレーションに問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、インバンド IP に設定されている VLAN が作成され、VLAN がインバンド プロファイルにあるか、IP アドレスが設定されているかを確認します

障害の詳細

```

Severity: minor
Cause: unsupported-cimc-firmware
mibFaultCode: F1456
mibFaultName: fltMgmtInterfaceInbandUnsupportedFirmware
moClass: mgmt:Interface
Type: management
autoCleared: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/boardController/mgmt/iface-[mode]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

```

fltSwVlanPortNsResourceStatusWarning

障害コード : F1464

Message: Total Available Vlan-Port Count on switch [switchId] is below 10%

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: warning
Cause: near-max-limit
mibFaultCode: F1464
mibFaultName: fltSwVlanPortNsResourceStatusWarning
moClass: sw:VlanPortNs
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/vlan-port-ns
```

fltNetworkElementMemoryerror

障害コード : F1465

Message: Fabric Interconnect [id] memory less than expected! Total Memory: [totalMemory] and Expected Memory: [expectedMemory]

説明 :

この障害は、FI の合計メモリが予想より少ない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FI の DIMM の手動物理インスペクションを行う必要があります。DIMM を取り外して再挿入し、合計メモリを確認します。これで問題が解決しない場合は、DIMM の 1 つが動作不良になっているため、交換する必要があります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: memory-error
mibFaultCode: F1465
mibFaultName: fltNetworkElementMemoryerror
moClass: network:Element
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]
```

fltComputePhysicalAdapterMismatch

障害コード : F1467

Message: Server [id] (service profile: [assignedToDn]) has invalid adapter combinatonServer [chassisId]/[slotId] (service profile: [assignedToDn]) has invalid adapter combination

説明 :

通常、この障害は、サーバの Cisco VIC の組み合わせが無効であることを Cisco UCS Manager が検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 有効なアダプタの組み合わせが取り付けられている構成であることを確認します。
2. サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: adaptor-mismatch
mibFaultCode: F1467
mibFaultName: fltComputePhysicalAdapterMismatch
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltNetworkElementRemoved

障害コード : F1493

Message: Fabric Interconnect [id] operability: [operability]

説明 :

この障害は、クラスタリングの設定でファブリック インターコネクトを取り外すと発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 取り外したファブリック インターコネクトをシャーシに再挿入します（UCS Mini にのみ適用）。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-removed
mibFaultCode: F1493
mibFaultName: fltNetworkElementRemoved
moClass: network:Element
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]
```

fltPowerBudgetChassisPsuMixedMode

障害コード : F1498

Message: Chassis [id] has a mix of high-line and low-line PSU input power sources.

説明：

この障害は、高ラインと低ラインの PSU 入力電源が混在している場合に発生します。

推奨処置：

この障害が発生した場合は、すべての PSU 入力電源を同じモードになるように変更します

障害の詳細

```
Severity: critical
Cause: psu-mixed-mode
mibFaultCode: F1498
mibFaultName: fltPowerBudgetChassisPsuMixedMode
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget
```

fltPowerBudgetPowerBudgetUnavailable

障害コード：F1499

Message: Insufficient power available to power-on server [chassisId]/[slotId]Insufficient power available to power-on server [id]

説明：

この障害は、使用できる十分な電力がサーバに割り当てられていない場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. グループの上限を増やすことを検討します。
2. 接続されている PSU を増やすことや、PSU ポリシーを変更することにより、シャーシが使用可能な電力を増やすことを検討します。
3. 電源が投入されているブレード サーバ数を削減するか、Cisco UCS インスタンスのシャーシ数を削減します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: power-budget-unavailable
mibFaultCode: F1499
```

```

mibFaultName: fltPowerBudgetPowerBudgetUnavailable
moClass: power:Budget
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/budget
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/budget
Affected MO: sys/chassis-[id]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/budget
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/budget
Affected MO: sys/fex-[id]/budget
Affected MO: sys/rack-unit-[id]/budget
Affected MO: sys/rack-unit-[id]/ext-board-[id]/budget
Affected MO: sys/switch-[id]/budget

```

fltStorageLocalDiskInaccessible

障害コード : F1519

Message: Storage LocalDisk [id] is inaccessible. Reason: [operQualifierReason]

説明 :

この障害は、ローカルディスクが異常または不良の場合に発生します。障害の説明には、劣化の原因を示す物理ドライブの状態が記載されています。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ローカルディスクの障害を解決します

障害の詳細

```

Severity: major
Cause: equipment-inaccessible
mibFaultCode: F1519
mibFaultName: fltStorageLocalDiskInaccessible
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltEquipmentChassisInvalid-fru

障害コード : F1558

Message: Chassis [id] has a empty value for FRU identity reported by CMC.

説明 :

通常、この障害は、シャーシの FRU 情報が空の値の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: fru-problem
mibFaultCode: F1558
mibFaultName: fltEquipmentChassisInvalidFru
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentSwitchIOCardRemoved

障害コード : F1559

Message: [side] FI IOM [chassisId]/[id] ([switchId]) is removed

説明 :

通常、この障害は、FI I/O モジュールがシャーシから取り外されているために発生します。クラスタ構成では、シャーシは他の FI I/O モジュールにフェールオーバーします。スタンドアロン構成の場合、その FI I/O モジュールに関連付けられているシャーシのネットワーク接続は失われます。これによりネットワーク接続が失われ、FI I/O モジュールからのデータトラフィックが中断されるため、重大な障害となります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FI I/O モジュールを再挿入し、接続されているファブリック インターコネクト ポートをサーバポートとして設定し、数分待つてエラーが解消されるかどうかを確認します。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: equipment-removed
mibFaultCode: F1559
mibFaultName: fltEquipmentSwitchIOCardRemoved
```

```
moClass: equipment:SwitchIOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalProblem

障害コード : F1560

Message: [side] FI IOM [chassisId]/[id] ([switchId]) operState: [operState]

説明 :

この障害は、FI I/O モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、FI I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、FI I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある FI I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
```



```
mibFaultCode: F1560
mibFaultName: fltEquipmentSwitchIOCardThermalProblem
moClass: equipment:SwitchIOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdNonCritical

障害コード : F1561

Message: [side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、FI I/O モジュールの温度が非重大しきい値を超えたが、まだ重大しきい値未満である場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、FI I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび FI I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび FI I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的 to 実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラック サーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
8. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F1561
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdNonCritical
moClass: equipment:SwitchIOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdCritical

障害コード : F1562

Message: [side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、FI I/O モジュールの温度が重大しきい値を超えた場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、FI I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび FI I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび FI I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある FI I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしき

い値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。

9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F1562
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdCritical
moClass: equipment:SwitchIOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardThermalThresholdNonRecoverable

障害コード : F1563

Message: [side] FI IOM [chassisId]/[id] ([switchId]) temperature: [thermal]

説明 :

この障害は、FI I/O モジュールの温度が動作範囲外になっている場合に発生します。この問題は回復不能です。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。
- CPU のセンサーが 82 °C (179.6 °F) に到達すると、システムはその CPU をオフラインにします。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、FI I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび FI I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび FI I/O モジュールのエアフローが妨げられないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。

6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある FI I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F1563
mibFaultName: fltEquipmentSwitchIOCardThermalThresholdNonRecoverable
moClass: equipment:SwitchIOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentSwitchIOCardPeerDisconnected

障害コード : F1564

Message: FI IOM [chassisId]/[id] ([switchId]) peer connectivity: [peerCommStatus]

説明 :

通常、この障害は、FI I/O モジュールがピアの FI I/O モジュールと通信できない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. 数分経っても障害がクリアされない場合は、FI I/O モジュールをいったん取り外し、取り付け直します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-disconnected
mibFaultCode: F1564
mibFaultName: fltEquipmentSwitchIOCardPeerDisconnected
moClass: equipment:SwitchIOCard
```

Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]

fltEquipmentSwitchIOCardIdentity

障害コード : F1565

Message: [side] FI IOM [chassisId]/[id] ([switchId]) has a malformed FRU

説明 :

通常、この障害は、FI I/O モジュールの FRU の情報が破損した場合、または不正な形式の場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが最新であることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: critical
Cause: fru-problem
mibFaultCode: F1565
mibFaultName: fltEquipmentSwitchIOCardIdentity
moClass: equipment:SwitchIOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]

fltEquipmentSwitchIOCardCpuThermalThresholdCritical

障害コード : F1566

Message: [side] FI IOM [chassisId]/[id] ([switchId]) processor temperature exceeded the limit

説明 :

通常、この障害は、FI-IOM のプロセッサの温度が制限を超えると発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、FI I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、シャーシおよび FI I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシおよび FI I/O モジュールのエアフローが妨げられないことを確認します。

4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のブレード サーバおよびラック サーバの電源を切ります。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある FI I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: critical
Cause: thermal-problem
mibFaultCode: F1566
mibFaultName: fltEquipmentSwitchIOCardCpuThermalThresholdCritical
moClass: equipment:SwitchIOCard
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltStorageLocalDiskThermalIssueCritical

障害コード : F1604

Message: Local disk [id] on server [chassisId]/[slotId] has thermal issue: [thermal]Local disk [id] on server [id] has thermal issue: [thermal]Local disk [id] on chassis [id] has thermal issue: [thermal]Local disk [id] on storage enclosure [id] has thermal issue: [thermal]

説明 :

この障害は、ローカル ドライブに重要な温度の問題が発生している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 過熱のドライブが 1 つだけの場合、ドライブを交換します。
2. 過熱のドライブが多数ある場合、サーバを取り外します。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F1604
```

```

mibFaultName: fltStorageLocalDiskThermalIssueCritical
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltStorageLocalDiskThermalIssueNonRecoverable

障害コード : F1605

Message: Local disk [id] on server [chassisId]/[slotId] has thermal issue: [thermal]Local disk [id] on server [id] has thermal issue: [thermal]Local disk [id] on chassis [id] has thermal issue: [thermal]Local disk [id] on storage enclosure [id] has thermal issue: [thermal]

説明 :

この障害は、ローカル ドライブに回復不能な温度の問題が発生している場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 過熱のドライブが 1 つだけの場合、ドライブを交換します。
2. 過熱のドライブが多数ある場合、サーバを取り外します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: thermal-problem
mibFaultCode: F1605
mibFaultName: fltStorageLocalDiskThermalIssueNonRecoverable
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltStorageLocalDiskNot-supported

障害コード : F1606

Message: Local disk [id] is not supported on server [chassisId]/[slotId]Local disk [id] is not supported on server [id]Local disk [id] is not supported on chassis [id]Local disk [id] is not supported on storage enclosure [id]

説明 :

この障害は、ローカルディスクがこのサーバまたはシャーシでサポートされていない場合に発生します。

推奨処置 :

未設定。

障害の詳細

```

Severity: major
Cause: not-supported
mibFaultCode: F1606
mibFaultName: fltStorageLocalDiskNotSupported
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltFabricComputeMSlotEpMisplacedInChassisSlot

障害コード : F1616

Message: Server, vendor([vendor]), model([model]), serial([serial]) in slot [chassisId]/[slotId]/[serverInstanceId] presence: [presence]

説明 :

通常、この障害は、スロット内のサーバが以前にスロットに搭載されていたものと一致していないことが Cisco UCS Manager によって検出された場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバが使用停止されていた場合は、サーバを再認識します。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: server-moved
mibFaultCode: F1616
mibFaultName: fltFabricComputeMSlotEpMisplacedInChassisSlot
moClass: fabric:ComputeMSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/cart-slot-[slotId]/ins-[serverInstanceId]
```

fltFabricComputeMSlotEpServerIdentificationProblem

障害コード：F1617

Message: Problem identifying server [serverInstanceId] in slot [chassisId]/[slotId]

説明：

通常、この障害は、カートリッジスロット内のサーバの識別で Cisco UCS Manager に問題が発生した場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. カートリッジをいったん取り外し、取り付け直します。
2. サーバを再認識します。
3. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: server-identification-problem
mibFaultCode: F1617
mibFaultName: fltFabricComputeMSlotEpServerIdentificationProblem
moClass: fabric:ComputeMSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/cart-slot-[slotId]/ins-[serverInstanceId]
```

fltFabricCartridgeSlotEpMisplacedInChassisSlot

障害コード : F1618

Message: Cartridge, vendor([vendor]), model([model]), serial([serial]) in slot [chassisId]/[slotId] presence: [presence]

説明 :

通常、この障害は、シャーシスロット内のカートリッジが以前にスロットに搭載されていたものと一致していないことが Cisco UCS Manager によって検出された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 以前のカートリッジが意図的に取り外され、新しいカートリッジが取り付けられている場合は、カートリッジを再認識します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: warning
Cause: cartridge-moved
mibFaultCode: F1618
mibFaultName: fltFabricCartridgeSlotEpMisplacedInChassisSlot
moClass: fabric:CartridgeSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/cart-slot-[slotId]

fltStorageControllerNot-supported

障害コード : F1620

Message: Controller [id] is not supported on chassis [id]

説明 :

この障害は、ストレージコントローラがこのシャーシでサポートされていない場合に発生します。

推奨処置 :

ストレージコントローラがサポートされるコントローラの一覧にあるかどうかを確認します。サポートされるコントローラと交換します。

障害の詳細

Severity: critical
Cause: not-supported
mibFaultCode: F1620
mibFaultName: fltStorageControllerNotSupported
moClass: storage:Controller
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]

fltStorageVirtualDriveDeployment-failure

障害コード : F1621

Message: Virtual drive [name] deployment failure. Reason: [configQualifierReason]

説明 :

この障害は、UCSMが仮想ドライブのリソースを見つけたが、これを展開できなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 仮想ドライブの展開で使用するディスクの存在と状態を確認します。
2. また、DasScsiLun mo を削除すると障害をクリアできます
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: equipment-inoperable
mibFaultCode: F1621
mibFaultName: fltStorageVirtualDriveDeploymentFailure
moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]

fltStorageVirtualDriveMissing

障害コード : F1622

Message: Virtual drive [name] missing

説明 :

この障害は、仮想ドライブが正常に展開されたが、後で削除されたことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. この障害があるということは、次のアソシエーション FSM が発生したときに UCSM が仮想ドライブの再作成を試行することを意味します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-missing
mibFaultCode: F1622
mibFaultName: fltStorageVirtualDriveMissing
moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]
```

fltStorageVirtualDriveMismatch

障害コード : F1623

Message: Virtual drive [name] mismatch. Reason: [configQualifierReason]

説明 :

この障害は、仮想ドライブが正常に展開されたが、後で仮想マシンが UCSM に必要とされる設定と一致しないことを UCSM が検出したことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. DasScsiLun mo を実際の仮想ドライブに対応するように変更します。
2. LSI ホスト ユーティリティを使用し、仮想ドライブを元の設定に復元します。
3. 障害の発生したドライブまたは見つからないドライブを交換し、LSI ホスト ユーティリティを使用して仮想ドライブを元の設定に復元します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: configuration-mismatch
mibFaultCode: F1623
mibFaultName: fltStorageVirtualDriveMismatch
```

```

moClass: storage:VirtualDrive
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]

```

fltStorageVDMemberEpMismatch

障害コード : F1624

Message: Virtual drive member [id] in a mismatched state. Reason: [operQualifierReason]

説明 :

この障害は、仮想ドライブのメンバーである物理ドライブが一致していない状態であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VdMemberEpで参照されているローカルディスクをチェックし、予期される動作なのかどうかを確認します。
2. 予期されない場合、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: info
Cause: configuration-mismatch
mibFaultCode: F1624
mibFaultName: fltStorageVDMemberEpMismatch
moClass: storage:VDMemberEp
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/vd-[id]/member-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/vd-container-[id]/vd-[id]/member-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/vd-[id]/member-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/vd-container-[id]/vd-[id]/member-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/vd-[id]/member-[id]
Affected MO: sys/chassis-[id]/vd-container-[id]/vd-[id]/member-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/vd-[id]/member-[id]
Affected MO: sys/rack-unit-[id]/vd-container-[id]/vd-[id]/member-[id]

```

fltFirmwareBootUnitFirmwareBootFailed

障害コード : F1627

Message: Endpoint firmware went faulty.

説明 :

通常、この障害は、ファームウェアのアクティベーションが失敗した場合、またはエンドポイントが起動し、障害が発生した場合に、次の理由で発生します。

- ファームウェアのアクティベーションが失敗した。
- エンドポイントで実行しているファームウェア バージョンに障害が発生した。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害が発生したエンドポイントの [FSM] タブに移動するか、または CLI で、アクティベーションが失敗したという理由のエラー説明を確認します。
2. FSM に障害が発生した場合は、FSM のエラー メッセージを確認します。
3. 可能な場合は、エラー メッセージで説明されている問題を修正します。
4. 問題が解消されない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: activation-failed
mibFaultCode: F1627
mibFaultName: fltFirmwareBootUnitFirmwareBootFailed
moClass: firmware:BootUnit
Type: management
autoCleared: true
Affected MO: capabilities/ep/mgmt-ext/fw-boot-def/bootunit-[type]
Affected MO: capabilities/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
```

```

sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/chassis-[id]/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/nvme-switch-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/sas-expander-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/onboard-device-[deviceType]-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios/fw-boot-def/bootunit-[type]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/rack-unit-[id]/psu-[id]/fw-boot-def/bootunit-[type]

```


Affected MO: sys/switch-[id]/mgmt/fw-boot-def/bootunit-[type]
Affected MO: sys/switch-[id]/psu-[id]/fw-boot-def/bootunit-[type]

fltAaaDefaultAuthDefaultAuthNotDeployed

障害コード : F1668

Message: DefaultAuth can't be deployed. Error: [configStatusMessage]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: critical
Cause: defaultauth-config-error
mibFaultCode: F1668
mibFaultName: fltAaaDefaultAuthDefaultAuthNotDeployed
moClass: aaa:DefaultAuth
Type: security
autoCleared: true
Affected MO: sys/auth-realm/default-auth

fltAaaDomainDomainNotDeployed

障害コード : F1669

Message: Domain [name] can't be deployed. Error: [configStatusMessage]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: critical
Cause: domain-config-error
mibFaultCode: F1669
mibFaultName: fltAaaDomainDomainNotDeployed
moClass: aaa:Domain
Type: security
autoCleared: true
Affected MO: sys/auth-realm/domain-[name]

fltLsServerFAULT

障害コード : F1671

Message: The UUID stored in Service Profile [name] does not match the UUID stored in server [pnDn]

説明 :

Smbios endianness の変更に関するバグを修正した最近の UCSM のアップグレードにより、UCSM インベントリには BIOS に保存されている UUID に一致する更新済み UUID がありますが、サービス プロファイルに保存された UUID は更新されていないため、一致しません。

推奨処置：

この障害が発生した場合は、次の処理のいずれかを実行します。

1. サービス プロファイルの関連付けを解除して、再度関連付けます
2. サーバをデコミッションして、リコミッションします。
3. サーバの新しい UUID を設定します

障害の詳細

```
Severity: info
Cause: fault
mibFaultCode: F1671
mibFaultName: fltLsServerFAULT
moClass: ls:Server
Type: server
autoCleared: true
Affected MO: org-[name]/ls-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]
```

fltMgmtBackupLocal Internal backup failed

障害コード：F1672

Message: Local Internal backup failed while upgrade. Please re-trigger a manual backup.

説明：

この障害は、アップグレード中にローカル内部バックアップが失敗した場合に発生します

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 設定のバックアップを実行してください。

障害の詳細

```
Severity: minor
Cause: local-internal-backup-failed
mibFaultCode: F1672
mibFaultName: fltMgmtBackupLocalInternalBackupFailed
moClass: mgmt:Backup
Type: management
autoCleared: true
Affected MO: sys/backup-[hostname]
```

fltVnicEtherCdn-config-not-applied

障害コード：F1680

Message: CDN can not be applied for vnic [name] in Service Profile [name]

説明：

通常、この障害は、vnic の CDN がアダプタ ハードウェアまたはファームウェアの非互換性を理由に適用されない場合に発生します

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. CDN がサポートされるアダプタの場合、サポートされるバージョンにファームウェアをアップグレードします
2. サポートされていないアダプタの場合、サポートされるアダプタのみに vnic を手動で配置します
3. CDN を使用することを目的としない場合、BIOS ポリシーで CDN を無効にします
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: config-missing
mibFaultCode: F1680
mibFaultName: fltVnicEtherCdnConfigNotApplied
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]
```

fltComputePhysicalConnectivityDown

障害コード : F1681

Message: Connectivity between the CIMC and one of the FIs is down. Connectivity may be down for expected reasons (e.g. FI/CIMC firmware upgrade).Connectivity between the CIMC and one of the FIs is down. Connectivity may be down for expected reasons (e.g. FI/CIMC firmware upgrade).Connectivity between the CIMC and one of the FIs is down. Connectivity may be down for expected reasons (e.g. FI/CIMC firmware upgrade).

説明：

この障害は、サーバの CIMC と FI の 1 つまたは両方の間に接続の問題がある場合に発生します。この管理パス損失は基盤となる OS の通信には影響しないことに注意してください。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード中またはその後に発生する場合があります。
2. 短時間のうちに障害がクリアされない場合は、CIMC をリセットしてください。これは OS の通信には影響しません。

- 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: equipment-inaccessible
mibFaultCode: F1681
mibFaultName: fltComputePhysicalConnectivityDown
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltStorageSasExpanderInoperable

障害コード : F1685

Message: SAS Expander [id]/[id] operability: [operability]. Reason [operQualifierReason].

説明 :

この障害は、SAS エクスパンダが動作不能であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

- show tech-support ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: equipment-inoperable
mibFaultCode: F1685
mibFaultName: fltStorageSasExpanderInoperable
moClass: storage:SasExpander
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]
```

fltStorageSasExpanderAccessibility-problem

障害コード : F1686

Message: SAS Expander [id]/[id] operability: [operability]. Reason [operQualifierReason].

説明 :

この障害は、SAS エクスパンダが到達不能であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: equipment-accessibility-problem
mibFaultCode: F1686
mibFaultName: fltStorageSasExpanderAccessibilityProblem
moClass: storage:SasExpander
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]
```

fltStorageSasExpanderDegraded

障害コード : F1687

Message: SAS Expander [id]/[id] operability: [operability]. Reason [uplinkStateReason].

説明 :

この障害は、SAS エクスパンダのリンクが最適な状態ではないことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: warning
Cause: equipment-degraded
mibFaultCode: F1687
mibFaultName: fltStorageSasExpanderDegraded
moClass: storage:SasExpander
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]
```

fltStorageLocalDiskLink-degraded

障害コード : F1688

Message: Local Disk [id]/[id]/[id] link state: [linkState]. Reason [linkStateReason].

説明 :

この障害は、ストレージ ローカル ディスクのリンクが最適ではないことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: minor
Cause: equipment-link-degraded
mibFaultCode: F1688
mibFaultName: fltStorageLocalDiskLinkDegraded
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltFabricFcSanNumOfVsanExceedLimit

障害コード : F1694

Message: VSAN count for [dn] exceeds the limit.

説明 :

この障害は、VSAN の数が制限を超える場合に発生します。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: vsan-exceed-limit
mibFaultCode: F1694
mibFaultName: fltFabricFcSanNumOfVsanExceedLimit
moClass: fabric:FcSan
Type: configuration
autoCleared: true
Affected MO: fabric/san/[id]
```

fltSwVlanPortNsCompressedSetsExhaustedWarning

障害コード : F1700

Message: Network configuration on switch [switchId] resulted in using up ALL of the optimization sets supported by hardware.

説明 :

Cisco UCS Manager は、ファブリック インターコネクトがハードウェアでプログラムされる最適化セットをすべて使い果たすと、この障害を発生します。この障害は、設定の問題を示すものではありません。ただし、現在または将来の設定によりエラーが発生する可能性があり、該当するアラートが表示されます。その他のアラートが表示される場合は、問題の原因である可能性があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. UCSM で設定エラーが表示されるかどうかを確認し、表示される場合はそれらのエラーで推奨されるアクションを実行します。

障害の詳細

Severity: warning
Cause: compr-sets-exhausted
mibFaultCode: F1700
mibFaultName: fltSwVlanPortNsCompressedSetsExhaustedWarning
moClass: sw:VlanPortNs
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/vlan-port-ns

fltNetworkElementKernelMemCriticalThreshold

障害コード : F1701

Message: Fabric Interconnect [id] kernel low memory free reached critical level: [kernelMemFree] (MB).

説明 :

この障害は、FI のカーネル メモリが 100 MB 未満になったときに発生します

推奨処置 :

この障害が発生した場合 :

1. カーネルの LowFree メモリは最小ウォーターマークの 100 MB 未満にドロップしました。tech-support 情報を収集し、シスコカスタマーサポート (TAC) にお問い合わせください。
2. また、「show system internal kernel meminfo」により FI のメモリ フットプリントをログ記録できます

障害の詳細

Severity: major
Cause: kernel-mem-critical-threshold
mibFaultCode: F1701
mibFaultName: fltNetworkElementKernelMemCriticalThreshold
moClass: network:Element
Type: equipment

```
autoCleared: true
Affected MO: sys/switch-[id]
```

fltFlowctrlItemFlowctrlconfig

障害コード : F1702

Message: Flow Control Policy: [name], has unsupported configuration. 優先順位の一時停止と送受信フローの制御は同時にオンにすることはできず、修正されるまでポリシー設定は適用されません。

説明 :

この障害は、フロー制御ポリシーにサポートされていない設定がある場合に発生します。この障害は、アップグレード/インポート操作中に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 障害メッセージで指定されたフロー制御ポリシーを確認し、その設定をサポートされる設定に修正します。

障害の詳細

```
Severity: major
Cause: unsupported-policy-config
mibFaultCode: F1702
mibFaultName: fltFlowctrlItemFlowctrlconfig
moClass: flowctrl:Item
Type: configuration
autoCleared: true
Affected MO: fabric/lan/flowctrl/policy-[name]
```

fltNetworkElementSystemshutdown

障害コード : F1703

Message: Fabric Interconnect [id] will reboot in 120 sec

説明 :

通常、この障害は、ファンが取り外されたり壊れたりしてファブリックインターコネクトが再起動する場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 正常なファンに交換するか、ファンを取り付けます。

障害の詳細

```
Severity: critical
Cause: fan-removal
mibFaultCode: F1703
mibFaultName: fltNetworkElementSystemshutdown
moClass: network:Element
```



```
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]
```

fltMgmtHealthStatusHealthWarningIssue

障害コード : F1704

Message: [healthQualifier] : Please check the Health tab for more details

説明 :

この障害は、コンポーネント（BMC/CIMC）の状態に警告の問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. show tech-support ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: warning
Cause: health-warning
mibFaultCode: F1704
mibFaultName: fltMgmtHealthStatusHealthWarningIssue
moClass: mgmt:HealthStatus
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/health
Affected MO: sys/chassis-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/health
```

```

Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/health
Affected MO: sys/fex-[id]/mgmt/health
Affected MO: sys/fex-[id]/slot-[id]/mgmt/health
Affected MO: sys/mgmt/health
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/mgmt/health
Affected MO: sys/switch-[id]/health
Affected MO: sys/switch-[id]/mgmt/health

```

fltMgmtHealthStatusHealthMinorIssue

障害コード : F1705

Message: [healthQualifier] : Please check the Health tab for more details

説明 :

この障害は、コンポーネント（BMC/CIMC）の状態にマイナーな問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```

Severity: minor
Cause: health-minor
mibFaultCode: F1705
mibFaultName: fltMgmtHealthStatusHealthMinorIssue
moClass: mgmt:HealthStatus
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/health

```

Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/health
Affected MO: sys/chassis-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/health
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/health
Affected MO: sys/fex-[id]/mgmt/health
Affected MO: sys/fex-[id]/slot-[id]/mgmt/health
Affected MO: sys/mgmt/health
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/mgmt/health
Affected MO: sys/switch-[id]/health
Affected MO: sys/switch-[id]/mgmt/health

fltMgmtHealthStatusHealthMajorIssue

障害コード : F1706

Message: [healthQualifier] : Please check the Health tab for more details[healthQualifier] : [description]

説明 :

この障害は、コンポーネント（CMC/CIMC/FI）の状態にメジャーな問題がある場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. CMC/CIMC コンポーネントに関する場合、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。
2. FI に関する場合で障害の説明が「SER Uncorrectable Error」から始まる場合、スイッチのリブートが推奨されます。これで問題が解決しない場合は、TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: health-major
mibFaultCode: F1706
mibFaultName: fltMgmtHealthStatusHealthMajorIssue
moClass: mgmt:HealthStatus
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/health
Affected MO: sys/chassis-[id]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/health
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
```

```

Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/health
Affected MO: sys/fex-[id]/mgmt/health
Affected MO: sys/fex-[id]/slot-[id]/mgmt/health
Affected MO: sys/mgmt/health
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/mgmt/health
Affected MO: sys/switch-[id]/health
Affected MO: sys/switch-[id]/mgmt/health

```

fltMgmtHealthStatusHealthCriticalIssue

障害コード : F1707

Message: [healthQualifier] : Please check the Health tab for more details

説明 :

この障害は、コンポーネント（BMC/CIMC）の状態に重要な問題がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```

Severity: critical
Cause: health-critical
mibFaultCode: F1707
mibFaultName: fltMgmtHealthStatusHealthCriticalIssue
moClass: mgmt:HealthStatus
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/health
Affected MO: sys/chassis-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/health
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/health
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/health
Affected MO: sys/fex-[id]/mgmt/health
Affected MO: sys/fex-[id]/slot-[id]/mgmt/health
Affected MO: sys/mgmt/health
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/mgmt/health
Affected MO: sys/switch-[id]/health
Affected MO: sys/switch-[id]/mgmt/health

```

fltComputePhysicalDeprecated

障害コード : F1708

Message: Server [id] (service profile: [assignedToDn]) discovery: [discovery] Hardware Deprecated or FRU not supported
 Server [chassisId]/[slotId] (service profile: [assignedToDn]) discovery: [discovery]
 Hardware Deprecated or FRU not supported
 Server [chassisId]/[slotId]/[serverInstanceId] (service profile: [assignedToDn]) discovery: [discovery] Hardware Deprecated or FRU not supported

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major

```

Cause: discovery-failed
mibFaultCode: F1708
mibFaultName: fltComputePhysicalDeprecated
moClass: compute:Physical
Type: operational
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalAdapterFirmwareNeedsUpdate

障害コード : F1709

Message: Some of the adapters in Server [chassisId]/[slotId] needs firmware update to operate in 40G mode. These adapters are currently configured in 4x10G mode

説明 :

未設定。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ブレードのアダプタ ファームウェアを更新し、シャーシを認識します

障害の詳細

```

Severity: minor
Cause: connectivity-problem
mibFaultCode: F1709
mibFaultName: fltComputePhysicalAdapterFirmwareNeedsUpdate
moClass: compute:Physical
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalIdentityUnestablishableOrDeprecated

障害コード : F1710

Message: Server [id] (service profile: [assignedToDn]) has an invalid FRU. The server is either deprecated or not supported. Server [chassisId]/[slotId] (service profile: [assignedToDn]) has an invalid FRU. The server is either deprecated or not supported

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: major
Cause: identity-unestablishable

```

```

mibFaultCode: F1710
mibFaultName: fltComputePhysicalIdentityUnestablishableOrDeprecated
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltEquipmentIOCardDeprecated

障害コード : F1713

Message: [side] IOM [chassisId]/[id] ([switchId]) is either deprecated or not supported

説明 :

通常、この障害は、I/O モジュールが非推奨になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. Cisco UCS Manager の機能カタログが正しいバージョンであることを確認します。必要に応じて、カタログをアップデートします。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: fru-problem
mibFaultCode: F1713
mibFaultName: fltEquipmentIOCardDeprecated
moClass: equipment:IOCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]

```

fltFabricSwChPhEpUncleanConfiguration

障害コード : F1719

Message: Chassis [chassisId] has unclean configuration

説明 :

通常、この障害は、シャーシの停止後にクリーンでない設定がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サービス プロファイルの関連付けが完全に削除されているかどうかを確認します。
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: equipment-removed
mibFaultCode: F1719
mibFaultName: fltFabricSwChPhEpUncleanConfiguration
moClass: fabric:SwChPhEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-ep-ven-[vendor]-mod[model]-ser-[serial]

fltFabricComputeSlotEpNotSupportedInChassisSlot

障害コード : F1720

Message: Server in slot [chassisId]/[slotId] is not supported on this platform

説明 :

通常、この障害は、シャーシスロット内のサーバが現在のプラットフォームでサポートされていないことが Cisco UCS Manager によって検出された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. サーバを取り外します。

障害の詳細

Severity: critical
Cause: equipment-inoperable
mibFaultCode: F1720
mibFaultName: fltFabricComputeSlotEpNotSupportedInChassisSlot
moClass: fabric:ComputeSlotEp
Type: equipment
autoCleared: true
Affected MO: fabric/server/chassis-[chassisId]/slot-[slotId]

fltFabricDceSwSrvEpDown

障害コード : F1721

Message: Chassis discovery detected on port [slotId]/[portId]. UCS-FI-M-6324 platform does not support chassis discovery on non-scalability port

説明 :

通常、この障害は、UCS-FI-6324 プラットフォームで非プライマリ シャーシを検出するためにサーバポートとして非拡張性ポートが設定されている場合に発生します。

推奨処置 :

この障害が発生した場合は、以下に説明する代わりにアクションを試行します。

1. サーバポートの設定を解除し、FI の通常のポートから拡張性ポートにケーブルを移動します。

障害の詳細

```

Severity: major
Cause: unsupported-config
mibFaultCode: F1721
mibFaultName: fltFabricDceSwSrvEpDown
moClass: fabric:DceSwSrvEp
Type: network
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/slot-[slotId]-port-[portId]
Affected MO: fabric/server/sw-[id]/slot-[slotId]-port-[portId]

```

fltStorageLocalDiskThermalIssueNonCritical

障害コード : F1731

Message: Local disk [id] on server [chassisId]/[slotId] has thermal issue: [thermal]Local disk [id] on server [id] has thermal issue: [thermal]Local disk [id] on storage enclosure [id] has thermal issue: [thermal]

説明 :

この障害は、ローカルドライブに重大ではない温度の問題が発生している場合に発生します。

推奨処置 :

この障害が発生した場合は、このサーバに関連するその他の環境イベントをモニタし、温度範囲が推奨される範囲内にあることを確認します。問題が解決しない場合は、次のアクションを実行します。

1. 過熱のドライブが 1 つだけの場合、ドライブを交換します。
2. 過熱のドライブが多数ある場合、サーバを取り外します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: minor
Cause: thermal-problem
mibFaultCode: F1731
mibFaultName: fltStorageLocalDiskThermalIssueNonCritical
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

```

fltStorageLocalDiskFailed

障害コード : F1732

Message: Local disk [id] failed on server [chassisId]/[slotId]Local disk [id] failed on server [id]Local disk [id] failed on storage enclosure [id]

説明 :

この障害は、ディスクが不良になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ディスクを交換するか、追加の調査のためにハードウェア チームに送ります。

障害の詳細

```

Severity: info
Cause: equipment-failed
mibFaultCode: F1732
mibFaultName: fltStorageLocalDiskFailed
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]

```

Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]

fltEquipmentSystemIOControllerRemoved

障害コード : F1744

Message: System IO Controller [chassisId]/[id] is removed

説明 :

通常、この障害は、システム IO コントローラを Colusa シャーシから取り外したために発生します。これはネットワーク接続が失われる可能性があるため、重大な障害です。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. システム IO コントローラを再挿入し、接続されているファブリック インターコネクトポートをサーバポートとして設定し、数分待つてエラーが解消されるかどうかを確認します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: critical
Cause: equipment-removed
mibFaultCode: F1744
mibFaultName: fltEquipmentSystemIOControllerRemoved
moClass: equipment:SystemIOController
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]

fltComputeRackUnitFanSpeedConfigurationFailed

障害コード : F1745

Message: Server [id] (service profile: [assignedToDn]) Fan Speed Policy failed: [fanSpeedConfigStatus]

説明 :

通常、この障害は、設定されたファン速度ポリシーが十分でないために発生します

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 電力制御ポリシーのファン速度ポリシーの値をより高い値に増やします。

障害の詳細

Severity: info
Cause: equipment-degraded

mibFaultCode: F1745
mibFaultName: fltComputeRackUnitFanSpeedConfigurationFailed
moClass: compute:RackUnit
Type: equipment
autoCleared: true
Affected MO: sys/rack-unit-[id]

fltFabricEthLanNumOfVLANCompGrpExceedLimit

障害コード : F1748

Message: VLAN compression group count for [dn] exceeds the limit.

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: vlan-comp-grp-count-exceeds-limit
mibFaultCode: F1748
mibFaultName: fltFabricEthLanNumOfVLANCompGrpExceedLimit
moClass: fabric:EthLan
Type: configuration
autoCleared: true
Affected MO: fabric/lan/[id]

fltFabricMulticastPolicySameOrEmptyPeerQuerierIp

障害コード : F1749

Message: FI-B querier IP [querierIpAddrPeer] is empty or same as FI-A.

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: warning
Cause: fi-b-querier-ip-empty-or-same-as-primary
mibFaultCode: F1749
mibFaultName: fltFabricMulticastPolicySameOrEmptyPeerQuerierIp
moClass: fabric:MulticastPolicy
Type: configuration
autoCleared: true
Affected MO: org-[name]/mc-policy-[name]

fltAdaptorUnitDeprecated

障害コード : F1753

Message: Adapter [id] in server [id] may be deprecated or not supported.Adapter [id] in server [chassisId]/[slotId] may be deprecated or not supported.Adapter [id] in server [chassisId]/[slotId]/[serverInstanceId] may be deprecated or not supported.

説明 :

通常、この障害は、現在のリリースで非推奨になったアダプタを Cisco UCS Manager が検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. アダプタがリリースでサポートされ、非推奨にされていないかどうかを確認します
2. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: deprecated
mibFaultCode: F1753
mibFaultName: fltAdaptorUnitDeprecated
moClass: adaptor:Unit
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltMgmtInterfaceInbandPinningInvalid

障害コード : F1754

Message: [configMessage]

説明 :

この障害は、サーバインターフェイスがアップリンクにピン接続されていない場合に発生します。

推奨処置 :

この障害が発生した場合は、インバンドプロファイルで指定されたすべての VLAN で設定されている動作中のアップリンクがあるかどうかを確認します

障害の詳細

```
Severity: warning
Cause: invalid-pinning
mibFaultCode: F1754
mibFaultName: fltMgmtInterfaceInbandPinningInvalid
moClass: mgmt:Interface
Type: management
autoCleared: true
Affected MO: org-[name]/ls-[name]/iface-[mode]
Affected MO: org-[name]/tier-[name]/ls-[name]/iface-[mode]
```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/boardController/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/iface-[mode]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/mgmt/iface-[mode]
Affected MO: sys/fex-[id]/slot-[id]/mgmt/iface-[mode]
Affected MO: sys/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/iface-[mode]
Affected MO: sys/rack-unit-[id]/mgmt/iface-[mode]
Affected MO: sys/switch-[id]/mgmt/iface-[mode]

fltEtherPioInvalid-sfp

障害コード : F1755

Message: Port [slotId]/[portId] on FI-[switchId] does not support CR4 (passive copper) cable

説明 :

3GFI Donner ポート（最後の 6 個の 40G ポート）は「negotiate auto」をサポートしていません。CR4（Passive Copper モード）ケーブルが挿入されると、この障害が発生します

推奨処置 :

この障害が発生した場合は、ファブリック ケーブルを 40G ポートに交換します。

障害の詳細

```
Severity: major
Cause: unsupported-transceiver
mibFaultCode: F1755
mibFaultName: fltEtherPioInvalidSfp
moClass: ether:PIo
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]
```

fltNetworkOperLevelExtravif

障害コード : F1756

Message: Fabric Interconnect [id]: Number of VIFs configured exceeds the max limit on the FI: Number of VIFs configured: [vifCount] and Max VIFs allowed: [maxVifCount]

説明 :

この障害は、ファブリック インターコネクต์にサポートされる数以上の仮想インターフェイス（VIF）がある場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. オペレータが、FI にある余剰な仮想インターフェイス（VIF）を削除することをお勧めします。これらの余剰 VIF がある場合でも、システムは正常に機能しているように見えます。ただし、システムが推奨されているスケール制限を超えて動作しているとパフォーマンスの問題が発生することがあります。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: extra-vif
mibFaultCode: F1756
mibFaultName: fltNetworkOperLevelExtravif
moClass: network:OperLevel
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]/oper-level
```

fltNetworkElementDeprecated

障害コード : F1757

Message: Fabric Interconnect [id] operability: [operability]

説明 :

通常、この障害は、ファブリック インターコネクト モデルが非推奨になった場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 以前の稼働リリースにダウングレードし、非推奨でないファブリック インターコネクト モデルでアップグレードを計画します。

障害の詳細

```
Severity: critical
Cause: equipment-deprecated
mibFaultCode: F1757
mibFaultName: fltNetworkElementDeprecated
moClass: network:Element
Type: equipment
autoCleared: true
Affected MO: sys/switch-[id]
```

fltFabricNetGroupNativeVlanNotFound

障害コード : F1758

Message: Native VLAN [nativeNet] for VLAN group [name] cannot be found among the member vlans in the VLAN group.

説明 :

通常、この障害は、VLAN グループのネイティブ VLAN が VLAN グループのメンバー VLAN に見つからない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. VLAN グループのメンバー VLAN を作成します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: native-vlan-not-found
mibFaultCode: F1758
mibFaultName: fltFabricNetGroupNativeVlanNotFound
moClass: fabric:NetGroup
Type: network
autoCleared: true
Affected MO: fabric/lan/[id]/net-group-[name]
Affected MO: fabric/lan/net-group-[name]
```

fltEquipmentChassisChassislimit-exceeded

障害コード : F1761

Message: Chassis limit exceeded for this platform with the addition of chassis [id]

説明 :

通常、この障害は、システムにあるシャーシ数がプラットフォームでサポートされる最大数を超過していることを Cisco UCS Manager が検出したために発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. リリースノートからプラットフォームでサポートされるシャーシの最大数を確認します。
システムのシャーシ数がサポートされる最大数未満であっても障害が発生する場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: chassis-limit-exceeded
mibFaultCode: F1761
mibFaultName: fltEquipmentChassisChassislimitExceeded
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltMgmtEntityDevice-1-shared-storage-connect エラー

障害コード : F1766

Message: device [chassis1], error connecting to shared-storage management interface

説明 :

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障

害は、(a) ファブリック インターコネクトのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクト クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置：

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F1766
mibFaultName: fltMgmtEntityDevice1SharedStorageConnectError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDevice-2-shared-storage-connect エラー

障害コード：F1767

Message: device [chassis2], error connecting to shared-storage management interface

説明：

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障害は、(a) ファブリック インターコネクトのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクト クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置：

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F1767
mibFaultName: fltMgmtEntityDevice2SharedStorageConnectError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltMgmtEntityDevice-3-shared-storage-connect エラー

障害コード : F1768

Message: device [chassis3], error connecting to shared-storage management interface

説明 :

この障害は、クラスタの状態の書き込み用に選択された共有ストレージがアクセス不可能であるという、まれなイベントとして発生します。通常、この障害は、一時的な障害です。この障害は、(a) ファブリック インターコネクットのブート、(b) IO モジュールのリセット、(c) ラック サーバのリブート、または (d) システムのアップグレード/ダウングレードのいずれかで発生する可能性があります。システムがリブート/リセット/アップグレード/ダウングレードを実行して通常の動作に戻った後にこの障害がクリアされない場合は、ファブリック インターコネクタ クラスタの完全な HA 機能に影響を及ぼすことがあります。

推奨処置 :

システムが通常の動作に戻った後もこの障害がクリアされない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: device-shared-storage-error
mibFaultCode: F1768
mibFaultName: fltMgmtEntityDevice3SharedStorageConnectError
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]
```

fltSwEthLanBorderVlan-limit-exceeded

障害コード : F1778

Message: Maximum allowed VLANs limit has been exceeded, please delete the extra VLANs to ensure proper system functioning.

説明 :

通常、この障害は、アップグレード後、新しいリリースで許可される VLAN の上限が変更された場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 新しいリリースで定義された制限値に適合するために余分な VLAN を削除します。現在の数と許可される最大数の詳細は、「system/upgrade-validation」スコープ下の UCSM CLI で確認できます。
2. 注 : FCoE VSAN に関連付けられている VLAN もまた、VLAN 全体の上限にカウントされます。
3. 上記のアクションで問題を解決できなかった場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

Severity: major
Cause: max-vlan-limit-exceeded
mibFaultCode: F1778
mibFaultName: fltSwEthLanBorderVlanLimitExceeded
moClass: sw:EthLanBorder
Type: network
autoCleared: true
Affected MO: sys/switch-[id]/border-eth

fltMgmtEntityMgmt-db-version-mismatch

障害コード : F1781

Message: Management database version mismatch detected failover may not complete

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: replication-failure
mibFaultCode: F1781
mibFaultName: fltMgmtEntityMgmtDbVersionMismatch
moClass: mgmt:Entity
Type: management
autoCleared: true
Affected MO: sys/mgmt-entity-[id]

fltEquipmentTpmTpmMismatch

障害コード : F1784

Message: Server [id], has a TPM mismatch.

説明 :

この障害は、互換性のない CPU/TPM の組み合わせが原因で発生します

推奨処置 :

この障害が発生した場合は、使用した TPM モデルを確認します

1. 障害の概要を読み、アクションのコースを決定します。

障害の詳細

Severity: warning
Cause: tpm-mismatch
mibFaultCode: F1784
mibFaultName: fltEquipmentTpmTpmMismatch
moClass: equipment:Tpm

```

Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/Tpm-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/Tpm-[id]
Affected MO: sys/rack-unit-[id]/board/Tpm-[id]

```

fltEquipmentSharedIOModuleInaccessible

障害コード : F1792

Message: Shared IO Module [id] of chassis [chassisId] is offline

説明 :

通常、この障害は、共有 I/O モジュールがファブリック インターコネクトとの接続を失ったために発生します。これによりネットワーク接続が失われ、データトラフィックが中断されるため、重大な障害となります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```

Severity: critical
Cause: equipment-inaccessible
mibFaultCode: F1792
mibFaultName: fltEquipmentSharedIOModuleInaccessible
moClass: equipment:SharedIOModule
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module

```

fltEquipmentChassisInaccessible-b

障害コード : F1793

Message: Chassis not reachable from B side

説明 :

通常、この障害は、共有 I/O モジュールが B 側 FI との接続を失ったために発生します。これによりネットワーク接続が失われ、B 側のデータトラフィックが中断されるため、メジャーな障害となります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。

2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inaccessible
mibFaultCode: F1793
mibFaultName: fltEquipmentChassisInaccessibleB
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentChassisInaccessible-a

障害コード : F1794

Message: Chassis not reachable from A side

説明 :

通常、この障害は、共有 I/O モジュールが A 側 FI との接続を失ったために発生します。これによりネットワーク接続が失われ、A 側のデータトラフィックが中断されるため、メジャーな障害となります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 数分待ち、障害がクリアするかどうかを確認します。これは通常、一時的な問題で、ファームウェアのアップグレード後に発生する場合があります。
2. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-inaccessible
mibFaultCode: F1794
mibFaultName: fltEquipmentChassisInaccessibleA
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentSystemIOControllerThermalProblem

障害コード : F1795

Message: System IO Controller [id] on Chassis [chassisId], operState: [operState]

説明 :

この障害は、システム I/O コントローラ モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のサーバの電源をオフにします。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F1795
mibFaultName: fltEquipmentSystemIOControllerThermalProblem
moClass: equipment:SystemIOController
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
```

fltEquipmentSystemIOControllerUnacknowledged

障害コード：F1796

Message: System IO Controller [id] or its component in Chassis [chassisId] is replaced or re-inserted.
Acknowledge the SIOC

説明：

システム IO コントローラが認識されていない状態です。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害が発生します。

- SystemIOController またはそのアダプタが再挿入あるいは交換されたことを Cisco UCS Manager が検出します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. SIOC を認識します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: equipment-unacknowledged
mibFaultCode: F1796
mibFaultName: fltEquipmentSystemIOControllerUnacknowledged
moClass: equipment:SystemIOController
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
```

fltEquipmentIOCardBackPlanePortProblem

障害コード：F1797

Message: One or more of the Backplane Ports are not up in IOM [chassisId]/[id] connected to FI [switchId]

説明：

この障害は、1 つ以上のバックプレーン ポートで障害が発生した場合に発生します。

推奨処置：

この障害が発生した場合は、バックプレーン ポートのステータスを確認します

障害の詳細

```
Severity: major
Cause: backplane-port-problem
mibFaultCode: F1797
mibFaultName: fltEquipmentIOCardBackPlanePortProblem
moClass: equipment:IOCard
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]
Affected MO: sys/fex-[id]/slot-[id]
```

fltEquipmentSwitchIOCardBackPlanePortProblem

障害コード：F1798

Message: One or more of the Backplane Ports are not up in IOM [chassisId]/[id] connected to FI [switchId]

説明 :

この障害は、1 つ以上のバックプレーン ポートで障害が発生した場合に発生します。

推奨処置 :

この障害が発生した場合は、バックプレーン ポートのステータスを確認します

障害の詳細

```
Severity: major
Cause: backplane-port-problem
mibFaultCode: F1798
mibFaultName: fltEquipmentSwitchIOCardBackPlanePortProblem
moClass: equipment:SwitchIOCard
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/sw-slot-[id]
```

fltEquipmentFexBackPlanePortProblem

障害コード : F1799

Message: One or more of the Backplane Ports are not up in FEX [id] connected to FI [switchId]

説明 :

この障害は、1 つ以上のバックプレーン ポートで障害が発生した場合に発生します。

推奨処置 :

この障害が発生した場合は、バックプレーン ポートのステータスを確認します

障害の詳細

```
Severity: major
Cause: backplane-port-problem
mibFaultCode: F1799
mibFaultName: fltEquipmentFexBackPlanePortProblem
moClass: equipment:Fex
Type: network
autoCleared: true
Affected MO: sys/fex-[id]
```

fltFabricFcZoneProfileSwitch-mode-disabled

障害コード : F1825

Message: FC User zones cannot be deployed because FI is not running in FC switch mode.

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: warning
Cause: configuration-error
mibFaultCode: F1825
mibFaultName: fltFabricFcZoneProfileSwitchModeDisabled
moClass: fabric:FcZoneProfile
Type: configuration
autoCleared: true
Affected MO: fabric/fc-estc/zone-profile-[name]
```

fltFabricFcUserZoneConfigFailure

障害コード : F1826

Message: FC User Zone [name] configuration failed as it reached max user defined or system zone configuration limit

説明 :

指定された修飾子と一致するリソースが不足しているため、Cisco UCS Manager が正常に FC ユーザ定義ゾーンを展開できません。通常、この障害は、ユーザ定義のゾーンの制限またはシステムゾーンの制限の超過した結果として発生します

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ユーザ定義のゾーン数が制限を超えている場合、未使用のユーザ定義のゾーンを解放します。
2. ユーザ定義のゾーン数を制限未満であるが、システムの FC ゾーン数が 8000 を超えている場合は、サービス プロファイルから未使用のゾーンの解放を試みます。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: configuration-failure
mibFaultCode: F1826
mibFaultName: fltFabricFcUserZoneConfigFailure
moClass: fabric:FcUserZone
Type: configuration
autoCleared: true
Affected MO: fabric/fc-estc/zone-profile-[name]/zone-[name]
```

fltStorageEnclosureThermalIssueNonCritical

障害コード : F1831

Message: HDD MotherBoard on [id] has a thermal problem: [thermal]

説明 :

この障害は、HDD マザーボード モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のサーバの電源をオフにします。
6. 設置場所のクリーニングを定期的実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: minor
Cause: thermal-problem
mibFaultCode: F1831
mibFaultName: fltStorageEnclosureThermalIssueNonCritical
moClass: storage:Enclosure
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]
Affected MO: sys/chassis-[id]/enc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]
```

fltStorageEnclosureThermalIssueCritical

障害コード : F1832

Message: HDD MotherBoard on [id] has a thermal problem: [thermal]**説明 :**

この障害は、HDD マザーボード モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のサーバの電源をオフにします。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```
Severity: major
Cause: thermal-problem
mibFaultCode: F1832
mibFaultName: fltStorageEnclosureThermalIssueCritical
moClass: storage:Enclosure
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]
```

```

Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]
Affected MO: sys/chassis-[id]/enc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]

```

fltStorageEnclosureThermalIssueNonRecoverable

障害コード : F1833

Message: HDD MotherBoard on [id] has a thermal problem: [thermal]

説明 :

この障害は、HDD マザーボード モジュールに熱問題がある場合に発生します。次の原因となる可能性のある要因に注意してください。

- 極端な温度下では、Cisco UCS 機器の動作の効率が低下が生じたり、早期劣化、チップの障害、および機器の障害を含むさまざまな問題が生じたりすることがあります。また、極端な温度変化によって、CPU がソケットから外れることがあります。
- Cisco UCS 機器は、吸気温度が 10 °C (50 °F) を下回らず、35 °C (95 °F) を上回らない環境で動作する必要があります。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 製品仕様書で、I/O モジュールの動作温度範囲を確認します。
2. 『Cisco UCS Site Preparation Guide』を確認して、前面および背面のスペースを含め、I/O モジュールに適切なエアフローを確保します。
3. Cisco UCS シャーシのエアフローが妨げられていないことを確認します。
4. サイトの冷却システムが正常に動作していることを確認します。
5. 未使用のサーバの電源をオフにします。
6. 設置場所のクリーニングを定期的の実施して、ほこりやごみがたまらないようにしてください。ほこりやごみがたまるとシステムが過熱するおそれがあります。
7. 障害のある I/O モジュールを交換します。
8. Cisco UCS 電力制限機能を使用して、電力消費量を制限します。電力制限は、ブレードおよびラックサーバを含めたシステムの電力消費量を、システムの最大定格電力以下のしきい値に制限できます。電力制限は熱放散に影響するため、設置場所の温度を下げるために役立ちます。
9. この処置で問題が解決しない場合は、**show tech-support** ファイルを作成し、Cisco TACにお問い合わせください。

障害の詳細

```

Severity: critical
Cause: thermal-problem
mibFaultCode: F1833
mibFaultName: fltStorageEnclosureThermalIssueNonRecoverable
moClass: storage:Enclosure
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]
Affected MO: sys/chassis-[id]/enc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]

```

fltStorageControllerDegraded

障害コード : F1834

Message: Controller [id] on server [chassisId]/[slotId] is degraded. Reason: [operQualifierReason]Controller [id] on server [id] is degraded. Reason: [operQualifierReason]Controller [id] on chassis [id] is degraded. Reason: [operQualifierReason]

説明 :

この障害は、ストレージコントローラのパフォーマンスが低下した場合に発生します。

推奨処置 :

NVMe SSD の場合 : 問題が解決しない場合は、コントローラを交換します。

障害の詳細

```

Severity: warning
Cause: equipment-degraded
mibFaultCode: F1834
mibFaultName: fltStorageControllerDegraded
moClass: storage:Controller
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]

```

fltStorageSasExpanderLink-misconnect

障害コード : F1835

Message: SAS Expander [id]/[id] uplink state: [uplinkState]. Reason [uplinkStateReason].

説明 :

この障害は、SAS エクспанダのアップリンク状態が誤った接続であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: equipment-link-misconnect
mibFaultCode: F1835
mibFaultName: fltStorageSasExpanderLinkMisconnect
moClass: storage:SasExpander
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]
```

fltStorageSasExpanderLink-degraded

障害コード : F1836

Message: SAS Expander [id]/[id] uplink state: [uplinkState]. Reason [uplinkStateReason].

説明 :

この障害は、SAS エクスパンダのアップリンク状態が準最適であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```
Severity: major
Cause: equipment-link-degraded
mibFaultCode: F1836
mibFaultName: fltStorageSasExpanderLinkDegraded
moClass: storage:SasExpander
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]
Affected MO: sys/chassis-[id]/sas-expander-[id]
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]
```

fltStorageEnclosureMissing

障害コード : F1837

Message: Enclosure [id]/[id] is missing.

説明 :

この障害は、取り外し可能なラックが見つからないことを示します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. そのラックで取り外しの操作を実行してクリーンアップします。

障害の詳細

```
Severity: minor
Cause: equipment-missing
mibFaultCode: F1837
mibFaultName: fltStorageEnclosureMissing
moClass: storage:Enclosure
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]
Affected MO: sys/chassis-[id]/enc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]
```

fltStorageEnclosureFru-empty

障害コード：F1838

Message: HDD Expansion Tray [id]/[id] FRU could not be identified.

説明：

この障害は、HDD 拡張トレイが交換され、FRU の詳細を取得する必要があることを示します

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. アクティブな CMC をリセットします

障害の詳細

```
Severity: minor
Cause: equipment-fru-missing
mibFaultCode: F1838
mibFaultName: fltStorageEnclosureFruEmpty
moClass: storage:Enclosure
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]
Affected MO: sys/chassis-[id]/enc-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]
```

fltStorageEnclosureDiskSlotEpMissing

障害コード : F1839

Message: Disk Slot [id]/[id]/[id] is missing.

説明 :

この障害は、ディスク スロットが見つからないことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. スロットが取り外し可能なラックの一部である場合は、そのラックで取り外しの操作を実行してクリーンアップします。
2. スロットが取り外し可能でないラックの一部である場合は、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: equipment-missing
mibFaultCode: F1839
mibFaultName: fltStorageEnclosureDiskSlotEpMissing
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]
```

fltStorageEnclosureDiskSlotEpEquipment-inoperable

障害コード : F1840

Message: Disk Slot [id]/[id]/[id] operability: [operability]. Reason [operQualifierReason].

説明 :

この障害は、ディスク スロットが動作不良であることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. **show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください

障害の詳細

```

Severity: major
Cause: equipment-inoperable
mibFaultCode: F1840
mibFaultName: fltStorageEnclosureDiskSlotEpEquipmentInoperable
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

```

fltStorageEnclosureDiskSlotEpChassis-spare

障害コード : F1841

Message: Chassis spare disk in slot [id]/[id]/[id] is assigned to a controller.

説明 :

この障害は、シャーシのスペアとしてマークされたディスク スロットがコントローラに割り当てられていることを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 不良なディスクを交換します

障害の詳細

```

Severity: info
Cause: equipment-unavailable
mibFaultCode: F1841
mibFaultName: fltStorageEnclosureDiskSlotEpChassisSpare
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

```

fltStorageEnclosureDiskSlotEpHotspare-unsupported

障害コード : F1842

Message: Slot [id]/[id]/[id] ownership is automatically unassigned since the controller(s) does not support chassis global hot spare.

説明 :

この障害は、コントローラがシャーン幅ホットスペアをサポートしないため、ディスクスロットの所有権が自動的に割り当てられなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ホットスペアがサポートされるストレージコントローラのあるサーバを挿入します（または）ディスクゾーン分割ポリシーで所有権を変更します

障害の詳細

```
Severity: minor
Cause: equipment-hotspare-unsupported
mibFaultCode: F1842
mibFaultName: fltStorageEnclosureDiskSlotEpHotspareUnsupported
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]
```

fltStorageEnclosureDiskSlotEpSharing-unsupported

障害コード : F1843

Message: Slot [id]/[id]/[id] ownership is automatically unassigned since the controller(s) does not support sharing.

説明 :

この障害は、コントローラが共有をサポートしないため、ディスクスロット所有権が自動的に割り当てられなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 共有がサポートされるストレージコントローラのあるサーバを挿入します（または）ディスクゾーン分割ポリシーで所有権を変更します

障害の詳細

```

Severity: minor
Cause: equipment-ownership-unsupported
mibFaultCode: F1843
mibFaultName: fltStorageEnclosureDiskSlotEpSharingUnsupported
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

```

fltStorageEnclosureDiskSlotEploe-ownership-unassigned

障害コード : F1844

Message: Slot [id]/[id]/[id] ownership is automatically unassigned since IO Expander with second controller is present in place of server in first slot.

説明 :

この障害は、最初のスロットにサーバの代わりに第 2 のコントローラがある IO エクスパンダがあるためにディスク スロット所有権が自動的に割り当てられなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 最初のスロットにサーバを挿入します（または）ディスク ゾーン分割ポリシーで所有権を変更します

障害の詳細

```

Severity: minor
Cause: equipment-ioe-ownership-unassigned
mibFaultCode: F1844
mibFaultName: fltStorageEnclosureDiskSlotEpIoeOwnershipUnassigned
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]

```

Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

fltStorageEnclosureDiskSlotEpHddslot-server2-ownership-unassigned

障害コード : F1845

Message: Slot [id]/[id]/[id] ownership is automatically unassigned since HDD Expansion Tray is present in place of server in second slot.

説明 :

この障害は、2 番目のスロットでサーバの代わりに HDD 拡張トレイがあるためにディスク スロットの所有権が自動的に割り当てられなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 2 番目のスロットにサーバを挿入します（または）ディスク ゾーン分割ポリシーで所有権を変更します

障害の詳細

Severity: minor
Cause: equipment-hddslot-server2-ownership-unassigned
mibFaultCode: F1845
mibFaultName: fltStorageEnclosureDiskSlotEpHddslotServer2OwnershipUnassigned
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

fltEquipmentChassisProfileFailed

障害コード : F1846

Message: Chassis Profile [name] failed

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: equipment-failed
mibFaultCode: F1846
mibFaultName: fltEquipmentChassisProfileFailed
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileDiscoveryFailed

障害コード : F1847

Message: Chassis Profile [name] discovery failed

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: discovery-failed
mibFaultCode: F1847
mibFaultName: fltEquipmentChassisProfileDiscoveryFailed
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileConfigFailure

障害コード : F1848

Message: Chassis Profile [name] configuration failed due to [chassisConfigIssues],[storageConfigIssues]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: configuration-failure
mibFaultCode: F1848
mibFaultName: fltEquipmentChassisProfileConfigFailure
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true

Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileRemoved

障害コード : F1849

Message: Chassis Profile [name] underlying resource removed

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: equipment-removed
mibFaultCode: F1849
mibFaultName: fltEquipmentChassisProfileRemoved
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileInaccessible

障害コード : F1850

Message: Chassis Profile [name] cannot be accessed

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: equipment-inaccessible
mibFaultCode: F1850
mibFaultName: fltEquipmentChassisProfileInaccessible
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileAssociationFailed

障害コード : F1851

Message: Chassis Profile [name] association failed for [chassisDn]

説明 :

シャーシプロファイルにシャーシを関連付けることができませんでした

推奨処置 :

未設定。

障害の詳細

Severity: major
Cause: association-failed
mibFaultCode: F1851
mibFaultName:fltEquipmentChassisProfileAssociationFailed
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltEquipmentChassisProfileUnassociated

障害コード : F1852

Message: Chassis Profile [name] is not associated

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: warning
Cause: unassociated
mibFaultCode: F1852
mibFaultName:fltEquipmentChassisProfileUnassociated
moClass: equipment:ChassisProfile
Type: chassis-profile
autoCleared: true
Affected MO: org-[name]/cp-[name]
Affected MO: org-[name]/cp-tier-[name]/cp-[name]

fltFabricNetGroupRefNetSanGroupUnresolvable

障害コード : F1873

Message: Network/SAN group does not exist or not permitted

説明 :

この障害は、netGroupRef/SanGroupRef で参照されている NetGroup/SanGroup がないか、netGroupRef/SanGroupRef MO がネットワーク グループ/SAN グループと同じ組織にない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. NetGroup/SanGroup があるかどうかを確認し、ない場合は作成します。
2. NetGroup/SanGroup が netGroupRef/SanGroupRef と同じ組織にあるかどうかを確認します。

障害の詳細

```
Severity: major
Cause: network-san-group-does-not-exist
mibFaultCode: F1873
mibFaultName: fltFabricNetGroupRefNetSanGroupUnresolvable
moClass: fabric:NetGroupRef
Type: configuration
autoCleared: true
Affected MO: fabric/lan/profiles/vnic-[name]/net-group-ref-[name]
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]/net-group-ref-[name]
Affected MO: org-[name]/lan-conn-templ-[name]/net-group-ref-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]/net-group-ref-[name]
Affected MO: org-[name]/san-conn-templ-[name]/net-group-ref-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-enc-[id]/net-group-ref-[name]
```

[illegible]


```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/chassis-[id]/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO: sys/chassis-[id]/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/chassis-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/sas-expander-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/shared-io-module/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/slot-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/chassis-[id]/slot-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:

```

SEM 障害 Cisco UCS Manager

[illegible]

```

sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/ext-board-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO: sys/rack-unit-[id]/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/rack-unit-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/ethlanflowmon/vc-[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/ethlanflowmon/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/switch-[id]/lanmon-eth/mon-[name]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/switch-[id]/mgmt/fabric-[switchId]/path-[id]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]/net-group-ref-[name]
Affected MO:
sys/switch-[id]/mgmt/fabric-[switchId]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vc-[id]/net-group-ref-[name]
Affected MO: sys/switch-[id]/sanmon-fc/mon-[name]/vc-[id]/vlan-cmc[id]/net-group-ref-[name]

```

fltEtherPioUnknownServerDevice

障害コード : F1889

Message: [slotId]/[portId] on FI-[switchId] is connected by a unknown server device

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: info
Cause: port-misconfigure
mibFaultCode: F1889
mibFaultName: fltEtherPioUnknownServerDevice
moClass: ether:Pio
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]

```



```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

```

fltEtherPioInterfaceMismatch

障害コード : F1891

Message: Port [slotId]/[portId] on FI-[switchId] does not match with breakout cable

説明 :

3GFI トランシーバ タイプとインターフェイス タイプが一致しない場合、このエラーが発生します

推奨処置 :

この障害が発生した場合は、インターフェイスをブレイクアウトに変更します。

障害の詳細

```

Severity: minor
Cause: transceiver-mismatch
mibFaultCode: F1891
mibFaultName: fltEtherPioInterfaceMismatch
moClass: ether:Pio
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]

```

fltAdaptorUnitPci-config-issue

障害コード : F1892

Message: Adapter [id] in server [chassisId]/[slotId] is not visible to host

説明 :

アダプタがホスト OS に表示されません。Cisco UCS Manager は、次のシナリオのいずれかが発生すると、この障害が発生します。

- シャーシ アダプタへの PCIe 接続がサーバに設定されていない。
- 対応する SIOC がない。
- シングル サーバ デュアル SIOC 接続が適用され、CIMC/BIOS ファームウェア バージョンでこの機能がサポートされていない。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. 対応する SIOC がシャーシに挿入されるかどうかを確認します。
2. CIMC/BIOS が推奨されるファームウェア バージョンを実行しているかどうかを確認します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: pci-config-issue
mibFaultCode: F1892
mibFaultName: fltAdaptorUnitPciConfigIssue
moClass: adaptor:Unit
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltNetworkElementEvacuationon

障害コード：F1893

Message: Fabric Interconnect [id] operEvacState: [operEvacState]

説明：

通常、この障害は、ファブリック インターコネクトが退避される場合に発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. ファブリック インターコネクトのエバキュエーション オプションがオフになっていることを確認します。

障害の詳細

```
Severity: info
Cause: fabric-evacuated
mibFaultCode: F1893
mibFaultName: fltNetworkElementEvacuationon
moClass: network:Element
Type: equipment
```

```
autoCleared: true
Affected MO: sys/switch-[id]
```

fltNetworkLimitUnicast-mac

障害コード : F1894

Message: No. of unicast mac addresses ([actualCount]) on switch [id] has reached the upper limit([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトのユニキャスト MAC アドレスの数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます

推奨処置 :

未設定。

障害の詳細

```
Severity: warning
Cause: unicast-mac-exhausted
mibFaultCode: F1894
mibFaultName: fltNetworkLimitUnicastMac
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]
```

fltNetworkLimitMulticast-mac

障害コード : F1895

Message: No. of multicast mac addresses ([actualCount]) on switch [id] has reached the upper limit([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトのマルチキャスト MAC アドレスの数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます

推奨処置 :

未設定。

障害の詳細

```
Severity: warning
Cause: multicast-mac-exhausted
mibFaultCode: F1895
mibFaultName: fltNetworkLimitMulticastMac
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]
```

fltNetworkLimitPvlifvlanmbr

障害コード : F1896

Message: No. of PV LifVlanMbr count ([actualCount]) in the asic [asicNumber] corresponding to ports (eth [slotNumber]/[startPortNumber] through eth [slotNumber]/[endPortNumber]) on switch [id] has reached the upper limit ([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトの特定の ASIC の PV LifVlanMbr の数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ユーザは現在の ASIC からシャーシを取り外し、別の ASIC に移す必要があります

障害の詳細

Severity: warning
Cause: pvlif-vlan-mbr-exhausted
mibFaultCode: F1896
mibFaultName: fltNetworkLimitPvlifvlanmbr
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]

fltNetworkLimitPvsystem

障害コード : F1897

Message: No. of PV System count ([actualCount]) on switch [id] has reached the upper limit ([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトの PV システム カウントの数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます

推奨処置 :

未設定。

障害の詳細

Severity: warning
Cause: pvsystem-exhausted
mibFaultCode: F1897
mibFaultName: fltNetworkLimitPvsystem
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]

fltNetworkLimitIgmppgroup

障害コード : F1898

Message: No. of IGMP Group count ([actualCount]) on switch [id] has reached the upper limit ([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトの IGMP グループ カウントの数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1.

障害の詳細

Severity: warning
Cause: igmp-group-exhausted
mibFaultCode: F1898
mibFaultName: fltNetworkLimitIgmppgroup
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]

fltMgmtDbStateDb-corruption-detected

障害コード : F1899

Message: Management database corruption detected and recovered on Fabric Interconnect [id]. Number of corruption events: [corruptedCount]. Last corruption event timestamp: [lastOccurrenceTime]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: info
Cause: mgmt-db-corruption
mibFaultCode: F1899
mibFaultName: fltMgmtDbStateDbCorruptionDetected
moClass: mgmt:DbState
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/mgmt-db-state

fltMgmtDbStateHigh-db-corruption-detected

障害コード : F1900

Message: High number of management database corruption events on Fabric Interconnect [id]. Number of corruption events: [corruptedCount]. Number of corruption events: [corruptedCount]. Last corruption event timestamp: [lastOccurrenceTime]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: mgmt-db-corruption
mibFaultCode: F1900
mibFaultName: fltMgmtDbStateHighDbCorruptionDetected
moClass: mgmt:DbState
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/mgmt-db-state
```

fltEquipmentInventoryStatusHardwareMismatch

障害コード : F1901

Message: Adaptor unit inventory mismatchPass through adaptor unit extension inventory mismatchGraphics card inventory mismatchSecurity unit inventory mismatchStorage controller inventory mismatchCPU inventory mismatchDIMM inventory mismatchMini storage inventory mismatch

説明 :

UCSM は次の条件でこの障害を発生します。

1. ラック サーバのサーバ ハードウェア コンポーネントがサーバを停止せずに変更された場合。
2. 非ラック サーバのサーバ ハードウェア コンポーネントが変更され、サーバが認識されていない場合。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ラック サーバでは、ハードウェア コンポーネントが変更された場合にサーバを停止し、再始動します。
2. 非ラック サーバでは、ハードウェア コンポーネントが変更された場合にサーバを認識します。
3. ハードウェア コンポーネントを変更していない場合、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
```

```

Cause: hardware-mismatch
mibFaultCode: F1901
mibFaultName: fltEquipmentInventoryStatusHardwareMismatch
moClass: equipment:InventoryStatus
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/adaptor-extn-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/graphics-card-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/mini-storage-[type]-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/security-unit-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/inv-status
Affected MO: sys/chassis-[id]/blade-[slotId]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/adaptor-extn-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/graphics-card-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/mini-storage-[type]-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/security-unit-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/inv-status
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/inv-status
Affected MO: sys/chassis-[id]/storage-[type]-[id]/inv-status
Affected MO: sys/rack-unit-[id]/adaptor-[id]/adaptor-extn-[id]/inv-status
Affected MO: sys/rack-unit-[id]/adaptor-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/graphics-card-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/mini-storage-[type]-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/security-unit-[id]/inv-status
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/inv-status
Affected MO: sys/rack-unit-[id]/inv-status

```

fltEquipmentChassisPhysical-security

障害コード : F1902

Message: Chassis [id] operability: [operability]Chassis [id] operability: [operability]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロンラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。UCSMは次の条件でこの障害を発生します。

1. 1 つ以上のシャーシのふたが開いている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. すべてのシャーシのふたを閉じます。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: info
Cause: chassis-intrusion
mibFaultCode: F1902
mibFaultName: fltEquipmentChassisPhysicalSecurity
moClass: equipment:Chassis
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]
```

fltEquipmentComputeConnConfig-problem

障害コード : F1903

Message: Second server is inserted on this Chassis when server sioc connectivity was set to: [serverSiocConnectivity]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。UCSMは次の条件でこの障害が発生します。

1. シングルサーバデュアル SIOC 接続がシャーシで選択されているときに 2 番目のサーバがこのシャーシに挿入されている。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シングルサーバデュアル VIC の設定を修正します。
2. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: config-problem
mibFaultCode: F1903
mibFaultName: fltEquipmentComputeConnConfigProblem
moClass: equipment:ComputeConn
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/compute-conn
```

fltVnicEtherPrimaryVlanMissing

障害コード : F1907

Message: Hard pinning target for eth vNIC [name], service profile [name] does not have the corresponding primary VLAN configured

説明 :

この障害は、vNIC に設定されたセカンダリ VLAN に、ハード ピン接続された LAN ピン グループのターゲット アップリンク ポートまたはポート チャネルに設定された対応するプライマリ VLAN がない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. LAN ピン グループの設定を確認します。
2. ピン グループのポートおよびポート チャネルの設定を修正します。
3. Cisco UCS Manager GUI の LAN Uplinks Manager で、vNIC に設定された対応するセカンダリ VLAN のターゲット アップリンク ポートまたはポート チャネルにプライマリ VLAN を設定します。
4. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: missing-primary-vlan
mibFaultCode: F1907
mibFaultName: fltVnicEtherPrimaryVlanMissing
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]
```

fltVnicEtherNetSanGroupMisconfigured

障害コード : F1908

Message: Network/SAN group has been misconfigured

説明 :

この障害は、vnicEtherIf のネイティブ VLAN と、vNIC に割り当てられた netGroup のネイティブ VLAN が同じでない場合に発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. vnicEtherIf または NetGroup 上のネイティブ VLAN が同じになるように変更します。

障害の詳細

```
Severity: major
```

```

Cause: network-san-group-misconfigured
mibFaultCode: F1908
mibFaultName: fltVnicEtherNetSanGroupMisconfigured
moClass: vnic:Ether
Type: configuration
autoCleared: true
Affected MO: org-[name]/lan-conn-pol-[name]/ether-[name]
Affected MO: org-[name]/ls-[name]/ether-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/ether-[name]

```

fltComputePhysicalKmpFault

障害コード : F1912

Message: Server [id] (service profile: [assignedToDn]) kmip fault [kmipFault]. Reason : [kmipFaultDescription]. Server [chassisId]/[slotId] (service profile: [assignedToDn]) kmip fault [kmipFault]. Reason : [kmipFaultDescription].

説明 :

通常、この障害は、Cisco UCS Manager が KMIP サーバに関する問題を検出した場合に発生します

推奨処置 :

未設定。

障害の詳細

```

Severity: minor
Cause: kmip-fault
mibFaultCode: F1912
mibFaultName: fltComputePhysicalKmpFault
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltComputePhysicalHardwareInventoryMismatch

障害コード : F1913

Message: Server [id] hardware inventory mismatch. Decommission and recommission the server to clear the fault Server [chassisId]/[slotId] hardware inventory mismatch. Acknowledge the server to clear the fault

説明 :

UCSM は次の条件でこの障害を発生します。

1. ラック サーバのサーバ ハードウェア コンポーネントがサーバを停止せずに変更された場合。
2. 非ラック サーバのサーバ ハードウェア コンポーネントが変更され、サーバが認識されていない場合。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ラック サーバでは、ハードウェア コンポーネントが変更された場合にサーバを停止し、再始動します。
2. 非ラック サーバでは、ハードウェア コンポーネントが変更された場合にサーバを認識します。
3. ハードウェア コンポーネントを変更していない場合、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: hardware-inventory-mismatch
mibFaultCode: F1913
mibFaultName: fltComputePhysicalHardwareInventoryMismatch
moClass: compute:Physical
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]
```

fltComputePhysicalPciConfigMismatch

障害コード : F1914

Message: Mismatch in PCIe configuration of the chassis adapters

説明 :

UCSM は次の条件でこの障害が発生します。

1. SIOC が交換され、新しい SIOC が、シャーシのシングル サーバデュアル SIOC 接続をサポートしていない 3.1.3 以前の CMC ファームウェアを実行している場合。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. シャーシプロファイルの関連付けを再トリガーし、SIOCファームウェアを更新して、サーバ SIOC 接続を再設定します
2. SIOC を交換していない場合、**show tech-support** ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: critical
Cause: pci-config-mismatch
mibFaultCode: F1914
mibFaultName: fltComputePhysicalPciConfigMismatch
moClass: compute:Physical
Type: equipment
autoCleared: true
```

```

Affected MO: sys/chassis-[id]/blade-[slotId]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]
Affected MO: sys/rack-unit-[id]

```

fltStorageEnclosureDiskSlotEpSecond-controller-absent

障害コード : F1915

Message: Slot [id]/[id]/[id] ownership is automatically unassigned because of unavailability of second storage controller in the server.

説明 :

この障害は、サーバに接続された 2 番目のコントローラがないためにディスク スロットの所有権が自動的に割り当てられなかったことを示します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. 2 番目のコントローラをサーバに追加します（または）ディスク ゾーン分割ポリシーで所有権を変更します

障害の詳細

```

Severity: minor
Cause: equipment-second-controller-absent
mibFaultCode: F1915
mibFaultName: fltStorageEnclosureDiskSlotEpSecondControllerAbsent
moClass: storage:EnclosureDiskSlotEp
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-slot-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-slot-[id]

```

fltAdaptorUnitUnConnectedAdaptorReachability

障害コード : F1926

Message: Adapter [id]/[id] is unreachableAdapter [chassisId]/[slotId]/[id] is unreachable

説明 :

Cisco UCS Manager では、接続が検出されていないアダプタにアクセスできません。通常、この障害は、次のいずれかの問題の結果として発生します。

- サーバに十分な電力が供給されていない。
- I/O モジュールが機能していない。

- アダプタのファームウェアが失敗した。
- アダプタが機能していない
- アダプタが UCSM に接続されていません

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. サーバの POST の結果をチェックします。Cisco UCS Manager GUI では、サーバの [General] タブから POST の結果にアクセスできます。Cisco UCS Manager CLI では、サーバのスコープの下で show post コマンドを使用すると POST の結果にアクセスできます。
2. Cisco UCS Manager で、サーバの電源の状態をチェックします。
3. 物理サーバの電源の状態が同じであることを確認します。
4. サーバがオフの場合は、サーバをオンにします。
5. サーバが UCSM に接続されていない場合は、UCSM によって管理に必要な際に接続します。
6. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: warning
Cause: connectivity-problem
mibFaultCode: F1926
mibFaultName: fltAdaptorUnitUnConnectedAdaptorReachability
moClass: adaptor:Unit
Type: connectivity
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]
```

fltMgmtHealthStatusHealthInfoIssue

障害コード：F1927

Message: [healthQualifier] : Please check the Health tab for more details

説明：

未設定。

推奨処置：

未設定。

障害の詳細

```
Severity: info
Cause: health-info
```

```

mibFaultCode: F1927
mibFaultName: fltMgmtHealthStatusHealthInfoIssue
moClass: mgmt:HealthStatus
Type: management
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/health
Affected MO: sys/chassis-[id]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/health
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/health
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/health
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/health
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/health
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/health
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/health
Affected MO: sys/fex-[id]/mgmt/health
Affected MO: sys/fex-[id]/slot-[id]/mgmt/health
Affected MO: sys/mgmt/health
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/health
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/health
Affected MO: sys/rack-unit-[id]/mgmt/health
Affected MO: sys/switch-[id]/health
Affected MO: sys/switch-[id]/mgmt/health

```

fltComputeRackUnitPhysical-security

障害コード : F1932

Message: Chassis enclosure for server [id] is open

説明 :

ラック サーバのシャーシのラックが開いている場合にこの障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ラック サーバのシャーシのラックを閉じます。

障害の詳細

```
Severity: info
Cause: chassis-intrusion
mibFaultCode: F1932
mibFaultName: fltComputeRackUnitPhysicalSecurity
moClass: compute:RackUnit
Type: equipment
autoCleared: true
Affected MO: sys/rack-unit-[id]
```

fltBiosUnitFD0FailedSecurityVerification

障害コード : F1933

Message: Bios Flash Descriptor 0 on server [chassisId]/[slotId] failed security verificationBios Flash Descriptor 0 on server [id] failed security verification

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロンラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。BIOS フラッシュ記述子の署名の検証が失敗すると、この障害が発生します。BIOS の署名検証は、サーバの A/C 電源オンで、シャーシまたは BIOS のアクティブ化にプッシュされるときに発生します。

推奨処置 :

既知の適切なイメージを使用して、BIOS の更新とアクティブ化をもう一度試してください。

障害の詳細

```
Severity: critical
Cause: image-corrupted
mibFaultCode: F1933
mibFaultName: fltBiosUnitFD0FailedSecurityVerification
moClass: bios:Unit
Type: security
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/bios
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/bios
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/bios
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/bios
```

Affected MO: sys/rack-unit-[id]/bios
Affected MO: sys/rack-unit-[id]/ext-board-[id]/bios

fltComputeBoardFailedSecureFuseValidation

障害コード : F1934

Message: Intel PCH secure fuse fails validation on server [chassisId]/[slotId]Intel PCH secure fuse fails validation on server [id]

説明 :

注 : この障害は、現在 UCSM では発生しません。この障害は、スタンドアロン ラック サーバなどの別のリリースのプレースホルダとしてのみ発生する可能性があります。CIMC 検出が誤ってプログラムされた場合や、Intel PCH が侵害された場合に、この障害が発生します。

推奨処置 :

この障害は、fltBiosUnitFD0FailedSecurityVerification とともに表示されますと、再試してください BIOS の更新とアクティブ化します。それから、CIMC をリブートします。もしくは、Cisco TAC までお問い合わせください。

障害の詳細

Severity: critical
Cause: equipment-unhealthy
mibFaultCode: F1934
mibFaultName: fltComputeBoardFailedSecureFuseValidation
moClass: compute:Board
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board
Affected MO: sys/rack-unit-[id]/board

fltVnicFcUnsupported

障害コード : F1944

Message: FC/FCoE [name], service profile [name] is not supported when both the links are connected in a 3GFI Direct-Connect mode

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: info
Cause: vhba-not-supported
mibFaultCode: F1944
mibFaultName: fltVnicFcUnsupported
moClass: vnic:Fc
Type: configuration
autoCleared: false

Affected MO: org-[name]/ls-[name]/fc-[name]
Affected MO: org-[name]/san-conn-pol-[name]/fc-[name]
Affected MO: org-[name]/tier-[name]/ls-[name]/fc-[name]

fltStorageControllerNon-optimal

障害コード : F1945

Message: Controller [id] on server [chassisId]/[slotId] is operating in a non-optimal state. Reason: [operQualifierReason]Controller [id] on server [id] is operating in a non-optimal state. Reason: [operQualifierReason]Controller [id] on chassis [id] is operating in a non-optimal state. Reason: [operQualifierReason]

説明 :

NVMe コントローラが最適な状態で動作しているとき、この障害が発生します。

推奨処置 :

問題が解決しない場合は、NVMe コントローラを交換します。

障害の詳細

Severity: major
Cause: equipment-non-optimal
mibFaultCode: F1945
mibFaultName: fltStorageControllerNonOptimal
moClass: storage:Controller
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]

fltStorageFlexFlashCardIoerrors

障害コード : F1946

Message: FlexFlash Card [slotNumber] on server [chassisId]/[slotId] is unhealthy. Reason: IO ErrorsFlexFlash Card [slotNumber] on server [id] is unhealthy. 理由 : IO エラー

説明 :

Flex Flash カードが読み取り/書き込みエラーになる場合、この障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SD カードのフォーマット オプションを使用して、SD カードを再度フォーマット化します。（または）
2. Flex Flash スクラブ ポリシーを [Yes] に設定して、サーバを再認識します。このアクションでカード内のすべてのデータが消去されることに注意してください。
3. カードの状態を確認します。上記のアクションによって問題を解決できなかった場合は、カードを交換します。

障害の詳細

Severity: minor
Cause: equipment-unhealthy
mibFaultCode: F1946
mibFaultName: f1tStorageFlexFlashCardIoerrors
moClass: storage:FlexFlashCard
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-flexflash-[id]/card-[slotNumber]
Affected MO: sys/rack-unit-[id]/board/storage-flexflash-[id]/card-[slotNumber]

fltStorageNvmeSwitchDegraded

障害コード : F1947

Message: MSwitch [id] on server [chassisId]/[slotId] operability: [operability]. Reason: [operQualifierReason]MSwitch [id] on server [id] operability: [operability]. Reason: [operQualifierReason]MSwitch [id] on chassis [id] operability: [operability]. Reason: [operQualifierReason]

説明 :

最適な状態で MSwitch が動作しているとき、この障害が発生します。

推奨処置 :

問題が解決しない場合は、MSwitch を交換します。

障害の詳細

Severity: critical
Cause: equipment-degraded
mibFaultCode: F1947
mibFaultName: f1tStorageNvmeSwitchDegraded
moClass: storage:NvmeSwitch
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/nvme-switch-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/nvme-switch-[id]
Affected MO: sys/rack-unit-[id]/board/nvme-switch-[id]

fltStorageLocalDiskUnhealthy

障害コード : F1948

Message: Local disk [id] exceeding its threshold operating temperature on server [chassisId]/[slotId]Local disk exceeding its threshold operating temperature [id] failed on server [id]Local disk exceeding its threshold operating temperature [id] failed on storage enclosure [id]

説明 :

物理ドライブがしきい値の動作温度を超える場合、この障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. ディスクを交換するか、追加の調査のためにハードウェア チームに送ります。

障害の詳細

```
Severity: major
Cause: equipment-unhealthy
mibFaultCode: F1948
mibFaultName: fltStorageLocalDiskUnhealthy
moClass: storage:LocalDisk
Type: equipment
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]
```

fltNetworkLimitIftmcpv

障害コード : F1949

Message: VP grouping switch resources are exhausted

説明 :

通常 VP グルーピング スイッチ リソースを使い切ると、この障害が発生します。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. システム内の VNICs / Vlans の数を減らす

障害の詳細

```
Severity: critical
Cause: iftmc-pv-exhausted
mibFaultCode: F1949
mibFaultName: fltNetworkLimitIftmcpv
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]
```

fltNetworkLimitDvif

障害コード : F1950

Message: No. of Dvif count ([actualCount]) on switch [id] has reached the upper limit([upperLimit]). Will get cleared when the count reaches the lower limit ([lowerLimit])

説明 :

通常、この障害は、ファブリック インターコネクトの DVIF の数が上限しきい値に達した場合に発生します。数が下限しきい値に達するとクリアされます

推奨処置 :

未設定。

障害の詳細

```
Severity: warning
Cause: dvif-exhausted
mibFaultCode: F1950
mibFaultName: fltNetworkLimitDvif
moClass: network:Limit
Type: management
autoCleared: true
Affected MO: sys/switch-[id]/limit-type-[type]-asic-[asicNumber]
```

fltAdaptorExtEthIfUnsupportedConection

障害コード : F1951

Message: Adapter [id] eth interface [id] connection in server [id] is un-supported

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```
Severity: major
Cause: connectivity-problem
mibFaultCode: F1951
mibFaultName: fltAdaptorExtEthIfUnsupportedConection
moClass: adaptor:ExtEthIf
Type: network
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]
```

fltFabricVsanReserved

障害コード : F1956

Message: VSAN [name] is [configOverlap] because fcoeVlan-id [fcoeVlan] is in the reserved VLAN range

説明 :

通常、VSAN が予約済みの VLAN の範囲内の fcoeVlan ID の場合、この障害が発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. VSAN ID を確認します。
2. VSAN の fcoeVlanID が予約済みの範囲内の場合、予約済みの VLAN 範囲外で作成するか、予約済みの範囲を変更します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vsan-misconfigured
mibFaultCode: F1956
mibFaultName: fltFabricVsanReserved
moClass: fabric:Vsan
Type: network
autoCleared: true
Affected MO: fabric/fc-estc/[id]/net-[name]
Affected MO: fabric/fc-estc/net-[name]
Affected MO: fabric/san/[id]/net-[name]
Affected MO: fabric/san/net-[name]
```

fltFabricVlanReserved

障害コード：F1957

Message: VLAN [name] is [configOverlap] because vlan-id [id] is in the reserved VLAN range

説明：

通常、VLAN が予約済みの VLAN 範囲のときにこの障害が発生します。

推奨処置：

この障害が発生した場合は、次の処理を実行します。

1. VLAN ID を確認します。
2. VLAN の ID は予約済みの範囲内の場合、予約済みの VLAN 範囲外の VLAN を再作成するか、予約された範囲を変更します。
3. 上記のアクションで問題を解決できなかった場合は、show tech-support ファイルを作成し、Cisco TAC にお問い合わせください。

障害の詳細

```
Severity: major
Cause: vlan-misconfigured
mibFaultCode: F1957
mibFaultName: fltFabricVlanReserved
moClass: fabric:Vlan
Type: network
```

```

autoCleared: true
Affected MO: fabric/eth-estc/[id]/net-[name]
Affected MO: fabric/eth-estc/net-[name]
Affected MO: fabric/lan/[id]/net-[name]
Affected MO: fabric/lan/net-[name]

```

fltEquipmentSystemIOControllerInoperable

障害コード : F1959

Message: System IO Controller [id] on Chassis [chassisId], operState: [operState]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: major
Cause: inoperable
mibFaultCode: F1959
mibFaultName: fltEquipmentSystemIOControllerInoperable
moClass: equipment:SystemIOController
Type: environmental
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]

```

fltComputeRackUnitUnsupportedConfig

障害コード : F1962

Message: Unsupported configuration is found in server [id]. 理由 : SAS/SATA コントローラと MSwitch の混在はサポートされていません。

説明 :

UCSM は次の条件でこの障害を発生します。

1. SAS/SATA コントローラに MSwitch を混在させることはサポートされていません。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. SAS/SATA コントローラと MSwitch を混在させている場合、サーバから SAS/SATA Controller/cages を削除します。

障害の詳細

```

Severity: critical
Cause: unsupported-config
mibFaultCode: F1962
mibFaultName: fltComputeRackUnitUnsupportedConfig
moClass: compute:RackUnit
Type: equipment

```

autoCleared: false
Affected MO: sys/rack-unit-[id]

fltComputeRackUnitConfigMismatch

障害コード : F1963

Message: Configuration mismatch found in server [id]. Reason: [operQualifierReason]

説明 :

UCSM は次の条件でこの障害を発生します。

1. MSwitches で実行されている FWs/リビジョン間の不一致がある場合。

推奨処置 :

この障害が発生した場合は、次の処理を実行します。

1. FW/リビジョンの不一致がある場合は、すべての MSwitches に同じ FW/リビジョンをインストールします。

障害の詳細

Severity: critical
Cause: config-mismatch
mibFaultCode: F1963
mibFaultName: fltComputeRackUnitConfigMismatch
moClass: compute:RackUnit
Type: equipment
autoCleared: true
Affected MO: sys/rack-unit-[id]

fltMgmtKvmCertificateCertificate-unsupported

障害コード : F1966

Message: KVM certificate configuration is not supported on Management Controller on server [chassisId]/[slotId]KVM certificate configuration is not supported on Management Controller on server [id]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

Severity: minor
Cause: certificate-unsupported
mibFaultCode: F1966
mibFaultName: fltMgmtKvmCertificateCertificateUnsupported
moClass: mgmt:KvmCertificate
Type: management
autoCleared: true
Affected MO: org-[name]/kvm-mgmt-policy-[name]/cert

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/cert
Affected MO: sys/chassis-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/cert
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/shared-io-module/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/cert
Affected MO: sys/fex-[id]/mgmt/cert
Affected MO: sys/fex-[id]/slot-[id]/mgmt/cert
Affected MO: sys/mgmt/cert
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/boardController/mgmt/cert
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/cert
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/rack-unit-[id]/mgmt/cert
Affected MO: sys/switch-[id]/mgmt/cert

fltMgmtKvmCertificateCertificate-empty-params

障害コード:F1967

Message: KVM certificate parameters are incomplete on server [chassisId]/[slotId]KVM certificate parameters are incomplete on server [id]

説明 :

未設定。

推奨処置 :

未設定。

障害の詳細

```

Severity: minor
Cause: certificate-empty-params
mibFaultCode: F1967
mibFaultName: fltMgmtKvmCertificateCertificateEmptyParams
moClass: mgmt:KvmCertificate
Type: management
autoCleared: true
Affected MO: org-[name]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sas-expander-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/chassis-[id]/blade-[slotId]/mgmt/cert
Affected MO: sys/chassis-[id]/boardController/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sas-expander-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/boardController/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/boardController/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/mgmt/cert
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/mgmt/cert
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/sas-expander-[id]/mgmt/cert

```

Affected MO: sys/chassis-[id]/shared-io-module/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/boardController/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/storage-[type]-[id]/mgmt/cert
Affected MO: sys/chassis-[id]/sw-slot-[id]/mgmt/cert
Affected MO: sys/fex-[id]/mgmt/cert
Affected MO: sys/fex-[id]/slot-[id]/mgmt/cert
Affected MO: sys/mgmt/cert
Affected MO: sys/rack-unit-[id]/adaptor-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/sas-expander-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/boardController/mgmt/cert
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/ext-board-[id]/boardController/mgmt/cert
Affected MO: sys/rack-unit-[id]/ext-board-[id]/mgmt/cert
Affected MO: sys/rack-unit-[id]/kvm-mgmt-policy-[name]/cert
Affected MO: sys/rack-unit-[id]/mgmt/cert
Affected MO: sys/switch-[id]/mgmt/cert

tcaProcessorLoad

障害コード : F33142

Message: Threshold Crossed: processor:Runtime property: load

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33142
mibFaultName: tcaProcessorLoad
moClass: processor:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/cpu-rt

tcaProcessorLoadMin

障害コード : F33144

Message: Threshold Crossed: processor:Runtime property: loadMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33144
mibFaultName: tcaProcessorLoadMin

```
moClass: processor:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/cpu-rt
```

tcaProcessorLoadMax

障害コード : F33145

Message: Threshold Crossed: processor:Runtime property: loadMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33145
mibFaultName: tcaProcessorLoadMax
moClass: processor:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/cpu-rt
```

tcaProcessorLoadAvg

障害コード : F33146

Message: Threshold Crossed: processor:Runtime property: loadAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33146
mibFaultName: tcaProcessorLoadAvg
moClass: processor:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/cpu-rt
```

tcaFcBytesRxDelta

障害コード : F33167

Message: Threshold Crossed: fc:Stats property: bytesRxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F33167
mibFaultName: tcaFcBytesRxDelta
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesRxDeltaMin

障害コード : F33168

Message: Threshold Crossed: fc:Stats property: bytesRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33168
mibFaultName: tcaFcBytesRxDeltaMin
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesRxDeltaMax

障害コード : F33169

Message: Threshold Crossed: fc:Stats property: bytesRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33169
mibFaultName: tcaFcBytesRxDeltaMax
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesRxDeltaAvg

障害コード : F33170

Message: Threshold Crossed: fc:Stats property: bytesRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33170
mibFaultName: tcaFcBytesRxDeltaAvg
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats

```

Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

tcaFcPacketsRxDelta

障害コード : F33177

Message: Threshold Crossed: fc:Stats property: packetsRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33177
mibFaultName: tcaFcPacketsRxDelta
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

tcaFcPacketsRxDeltaMin

障害コード : F33178

Message: Threshold Crossed: fc:Stats property: packetsRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F33178
mibFaultName: tcaFcPacketsRxDeltaMin
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcPacketsRxDeltaMax

障害コード : F33179

Message: Threshold Crossed: fc:Stats property: packetsRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33179
mibFaultName: tcaFcPacketsRxDeltaMax
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcPacketsRxDeltaAvg

障害コード : F33180

Message: Threshold Crossed: fc:Stats property: packetsRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33180
mibFaultName: tcaFcPacketsRxDeltaAvg
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats
```

tcaFcBytesTxDelta

障害コード : F33187

Message: Threshold Crossed: fc:Stats property: bytesTxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33187
mibFaultName: tcaFcBytesTxDelta
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
```



```

sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesTxDeltaMin

障害コード : F33188

Message: Threshold Crossed: fc:Stats property: bytesTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33188
mibFaultName: tcaFcBytesTxDeltaMin
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesTxDeltaMax

障害コード : F33189

Message: Threshold Crossed: fc:Stats property: bytesTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33189
mibFaultName: tcaFcBytesTxDeltaMax
moClass: fc:Stats
Type: equipment

```

```

autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcBytesTxDeltaAvg

障害コード : F33190

Message: Threshold Crossed: fc:Stats property: bytesTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33190
mibFaultName: tcaFcBytesTxDeltaAvg
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

```

tcaFcPacketsTxDelta

障害コード : F33197

Message: Threshold Crossed: fc:Stats property: packetsTxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33197
mibFaultName: tcaFcPacketsTxDelta
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats
```

tcaFcPacketsTxDeltaMin

障害コード : F33198

Message: Threshold Crossed: fc:Stats property: packetsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33198
mibFaultName: tcaFcPacketsTxDeltaMin
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
```

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

tcaFcPacketsTxDeltaMax

障害コード : F33199

Message: Threshold Crossed: fc:Stats property: packetsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33199
mibFaultName: tcaFcPacketsTxDeltaMax
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

tcaFcPacketsTxDeltaAvg

障害コード : F33200

Message: Threshold Crossed: fc:Stats property: packetsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33200
mibFaultName: tcaFcPacketsTxDeltaAvg
moClass: fc:Stats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/stats

tcaFcCrcRxDelta

障害コード : F33211

Message: Threshold Crossed: fc:ErrStats property: crcRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33211
mibFaultName: tcaFcCrcRxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcCrcRxDeltaMin

障害コード : F33212

Message: Threshold Crossed: fc:ErrStats property: crcRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33212
mibFaultName: tcaFcCrcRxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcCrcRxDeltaMax

障害コード : F33213

Message: Threshold Crossed: fc:ErrStats property: crcRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33213
mibFaultName: tcaFcCrcRxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcCrcRxDeltaAvg

障害コード : F33214

Message: Threshold Crossed: fc:ErrStats property: crcRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33214
mibFaultName: tcaFcCrcRxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcDiscardRxDelta

障害コード : F33221

Message: Threshold Crossed: fc:ErrStats property: discardRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33221
mibFaultName: tcaFcDiscardRxDelta
moClass: fc:ErrStats
Type: equipment

```

autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardRxDeltaMin

障害コード : F33222

Message: Threshold Crossed: fc:ErrStats property: discardRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33222
mibFaultName: tcaFcDiscardRxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardRxDeltaMax

障害コード : F33223

Message: Threshold Crossed: fc:ErrStats property: discardRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33223
mibFaultName: tcaFcDiscardRxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcDiscardRxDeltaAvg

障害コード : F33224

Message: Threshold Crossed: fc:ErrStats property: discardRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33224
mibFaultName: tcaFcDiscardRxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
```

```

sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcTooLongRxDelta

障害コード : F33231

Message: Threshold Crossed: fc:ErrStats property: tooLongRxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33231
mibFaultName: tcaFcTooLongRxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcTooLongRxDeltaMin

障害コード : F33232

Message: Threshold Crossed: fc:ErrStats property: tooLongRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33232
mibFaultName: tcaFcTooLongRxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcTooLongRxDeltaMax

障害コード : F33233

Message: Threshold Crossed: fc:ErrStats property: tooLongRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33233
mibFaultName: tcaFcTooLongRxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:

```

```
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcTooLongRxDeltaAvg

障害コード : F33234

Message: Threshold Crossed: fc:ErrStats property: tooLongRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33234
mibFaultName: tcaFcTooLongRxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcTooShortRxDelta

障害コード : F33241

Message: Threshold Crossed: fc:ErrStats property: tooShortRxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33241
mibFaultName: tcaFcTooShortRxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
```

Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcTooShortRxDeltaMin

障害コード : F33242

Message: Threshold Crossed: fc:ErrStats property: tooShortRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33242
mibFaultName: tcaFcTooShortRxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcTooShortRxDeltaMax

障害コード : F33243

Message: Threshold Crossed: fc:ErrStats property: tooShortRxDeltaMax

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33243
mibFaultName: tcaFcTooShortRxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcTooShortRxDeltaAvg

障害コード：F33244

Message: Threshold Crossed: fc:ErrStats property: tooShortRxDeltaAvg

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33244
mibFaultName: tcaFcTooShortRxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
```

Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcRxDelta

障害コード : F33251

Message: Threshold Crossed: fc:ErrStats property: rxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33251
mibFaultName: tcaFcRxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcRxDeltaMin

障害コード : F33252

Message: Threshold Crossed: fc:ErrStats property: rxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F33252
mibFaultName: tcaFcRxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcRxDeltaMax

障害コード : F33253

Message: Threshold Crossed: fc:ErrStats property: rxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33253
mibFaultName: tcaFcRxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```


tcaFcRxDeltaAvg

障害コード : F33254

Message: Threshold Crossed: fc:ErrStats property: rxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33254
mibFaultName: tcaFcRxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardTxDelta

障害コード : F33261

Message: Threshold Crossed: fc:ErrStats property: discardTxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33261
mibFaultName: tcaFcDiscardTxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:

```

```

sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardTxDeltaMin

障害コード : F33262

Message: Threshold Crossed: fc:ErrStats property: discardTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33262
mibFaultName: tcaFcDiscardTxDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardTxDeltaMax

障害コード : F33263

Message: Threshold Crossed: fc:ErrStats property: discardTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33263
mibFaultName: tcaFcDiscardTxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcDiscardTxDeltaAvg

障害コード : F33264

Message: Threshold Crossed: fc:ErrStats property: discardTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33264
mibFaultName: tcaFcDiscardTxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcTxDelta

障害コード : F33271

Message: Threshold Crossed: fc:ErrStats property: txDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33271
mibFaultName: tcaFcTxDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcTxDeltaMin

障害コード : F33272

Message: Threshold Crossed: fc:ErrStats property: crcRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33272
mibFaultName: tcaFcTxDeltaMin
moClass: fc:ErrStats
Type: equipment

```

autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcTxDeltaMax

障害コード : F33273

Message: Threshold Crossed: fc:ErrStats property: txDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33273
mibFaultName: tcaFcTxDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcTxDeltaAvg

障害コード : F33274

メッセージ: しきい値 Crossed: fc:ErrStats プロパティ: txDeltaAvg

説明:

推奨処置:

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33274
mibFaultName: tcaFcTxDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcLinkFailuresDelta

障害コード: F33281

Message: Threshold Crossed: fc:ErrStats property: linkFailuresDelta

説明:

推奨処置:

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33281
mibFaultName: tcaFcLinkFailuresDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
```

```

sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcLinkFailuresDeltaMin

障害コード : F33282

Message: Threshold Crossed: fc:ErrStats property: linkFailuresDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33282
mibFaultName: tcaFcLinkFailuresDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcLinkFailuresDeltaMax

障害コード : F33283

Message: Threshold Crossed: fc:ErrStats property: linkFailuresDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33283
mibFaultName: tcaFcLinkFailuresDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcLinkFailuresDeltaAvg

障害コード : F33284

Message: Threshold Crossed: fc:ErrStats property: linkFailuresDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33284
mibFaultName: tcaFcLinkFailuresDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:

```



```
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcSyncLossesDelta

障害コード : F33291

Message: Threshold Crossed: fc:ErrStats property: syncLossesDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33291
mibFaultName: tcaFcSyncLossesDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcSyncLossesDeltaMin

障害コード : F33292

Message: Threshold Crossed: fc:ErrStats property: syncLossesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33292
mibFaultName: tcaFcSyncLossesDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
```

Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcSyncLossesDeltaMax

障害コード : F33293

Message: Threshold Crossed: fc:ErrStats property: syncLossesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33293
mibFaultName: tcaFcSyncLossesDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcSyncLossesDeltaAvg

障害コード : F33294

Message: Threshold Crossed: fc:ErrStats property: syncLossesDeltaAvg

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33294
mibFaultName: tcaFcSyncLossesDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaFcSignalLossesDelta

障害コード：F33301

Message: Threshold Crossed: fc:ErrStats property: signalLossesDelta

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33301
mibFaultName: tcaFcSignalLossesDelta
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
```

Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcSignalLossesDeltaMin

障害コード : F33302

Message: Threshold Crossed: fc:ErrStats property: signalLossesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33302
mibFaultName: tcaFcSignalLossesDeltaMin
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaFcSignalLossesDeltaMax

障害コード : F33303

Message: Threshold Crossed: fc:ErrStats property: signalLossesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F33303
mibFaultName: tcaFcSignalLossesDeltaMax
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaFcSignalLossesDeltaAvg

障害コード : F33304

Message: Threshold Crossed: fc:ErrStats property: signalLossesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33304
mibFaultName: tcaFcSignalLossesDeltaAvg
moClass: fc:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/san/[id]/pc-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaMemoryTotal

障害コード : F33483

Message: Threshold Crossed: memory:Runtime property: total

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33483
mibFaultName: tcaMemoryTotal
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaMemoryTotalMin

障害コード : F33485

Message: Threshold Crossed: memory:Runtime property: totalMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33485
mibFaultName: tcaMemoryTotalMin
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaMemoryTotalMax

障害コード : F33486

Message: Threshold Crossed: memory:Runtime property: totalMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33486
mibFaultName: tcaMemoryTotalMax
moClass: memory:Runtime
Type: server
```

```
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaMemoryTotalAvg

障害コード : F33487

Message: Threshold Crossed: memory:Runtime property: totalAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33487
mibFaultName: tcaMemoryTotalAvg
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaMemoryAvailable

障害コード : F33491

Message: Threshold Crossed: memory:Runtime property: available

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33491
mibFaultName: tcaMemoryAvailable
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaMemoryAvailableMin

障害コード : F33493

Message: Threshold Crossed: memory:Runtime property: availableMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33493
```

```

mibFaultName: tcaMemoryAvailableMin
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

```

tcaMemoryAvailableMax

障害コード : F33494

Message: Threshold Crossed: memory:Runtime property: availableMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33494
mibFaultName: tcaMemoryAvailableMax
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

```

tcaMemoryAvailableAvg

障害コード : F33495

Message: Threshold Crossed: memory:Runtime property: availableAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33495
mibFaultName: tcaMemoryAvailableAvg
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

```

tcaMemoryCached

障害コード : F33499

Message: Threshold Crossed: memory:Runtime property: cached

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33499
mibFaultName: tcaMemoryCached
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

tcaMemoryCachedMin

障害コード : F33501

Message: Threshold Crossed: memory:Runtime property: cachedMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33501
mibFaultName: tcaMemoryCachedMin
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

tcaMemoryCachedMax

障害コード : F33502

Message: Threshold Crossed: memory:Runtime property: cachedMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33502
mibFaultName: tcaMemoryCachedMax
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt

tcaMemoryCachedAvg

障害コード : F33503

Message: Threshold Crossed: memory:Runtime property: cachedAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33503
mibFaultName: tcaMemoryCachedAvg
moClass: memory:Runtime
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/[type]-mem-rt
```

tcaAdaptorTotalPacketsDelta

障害コード : F33720

Message: Threshold Crossed: adaptor:EthPortStats property: totalPacketsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33720
mibFaultName: tcaAdaptorTotalPacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
```

tcaAdaptorTotalPacketsDeltaMin

障害コード : F33721

Message: Threshold Crossed: adaptor:EthPortStats property: totalPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33721
```

```

mibFaultName: tcaAdaptorTotalPacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorTotalPacketsDeltaMax

障害コード : F33722

Message: Threshold Crossed: adaptor:EthPortStats property: totalPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33722
mibFaultName: tcaAdaptorTotalPacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorTotalPacketsDeltaAvg

障害コード : F33723

Message: Threshold Crossed: adaptor:EthPortStats property: totalPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33723
mibFaultName: tcaAdaptorTotalPacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorGoodPacketsDelta

障害コード : F33730

Message: Threshold Crossed: adaptor:EthPortStats property: goodPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33730
mibFaultName: tcaAdaptorGoodPacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorGoodPacketsDeltaMin

障害コード : F33731

Message: Threshold Crossed: adaptor:EthPortStats property: goodPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33731
mibFaultName: tcaAdaptorGoodPacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorGoodPacketsDeltaMax

障害コード : F33732

Message: Threshold Crossed: adaptor:EthPortStats property: goodPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33732
mibFaultName: tcaAdaptorGoodPacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorGoodPacketsDeltaAvg

障害コード : F33733

Message: Threshold Crossed: adaptor:EthPortStats property: goodPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33733
mibFaultName: tcaAdaptorGoodPacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorVlanPacketsDelta

障害コード : F33740

Message: Threshold Crossed: adaptor:EthPortStats property: vlanPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33740
mibFaultName: tcaAdaptorVlanPacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorVlanPacketsDeltaMin

障害コード : F33741

Message: Threshold Crossed: adaptor:EthPortStats property: vlanPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33741
mibFaultName: tcaAdaptorVlanPacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorVlanPacketsDeltaMax

障害コード : F33742

Message: Threshold Crossed: adaptor:EthPortStats property: vlanPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F33742
mibFaultName: tcaAdaptorVlanPacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorVlanPacketsDeltaAvg

障害コード : F33743

Message: Threshold Crossed: adaptor:EthPortStats property: vlanPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33743
mibFaultName: tcaAdaptorVlanPacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorPausePacketsDelta

障害コード : F33750

Message: Threshold Crossed: adaptor:EthPortStats property: pausePacketsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33750
mibFaultName: tcaAdaptorPausePacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
```

tcaAdaptorPausePacketsDeltaMin

障害コード : F33751

Message: Threshold Crossed: adaptor:EthPortStats property: pausePacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33751
mibFaultName: tcaAdaptorPausePacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
```

tcaAdaptorPausePacketsDeltaMax

障害コード : F33752

Message: Threshold Crossed: adaptor:EthPortStats property: pausePacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33752
mibFaultName: tcaAdaptorPausePacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorPausePacketsDeltaAvg

障害コード : F33753

Message: Threshold Crossed: adaptor:EthPortStats property: pausePacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33753
mibFaultName: tcaAdaptorPausePacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorPerPriorityPausePacketsDelta

障害コード : F33760

Message: Threshold Crossed: adaptor:EthPortStats property: perPriorityPausePacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33760
mibFaultName: tcaAdaptorPerPriorityPausePacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorPerPriorityPausePacketsDeltaMin

障害コード : F33761

Message: Threshold Crossed: adaptor:EthPortStats property: perPriorityPausePacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33761
mibFaultName: tcaAdaptorPerPriorityPausePacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]

Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorPerPriorityPausePacketsDeltaMax

障害コード : F33762

Message: Threshold Crossed: adaptor:EthPortStats property: perPriorityPausePacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33762
mibFaultName: tcaAdaptorPerPriorityPausePacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

tcaAdaptorPerPriorityPausePacketsDeltaAvg

障害コード : F33763

Message: Threshold Crossed: adaptor:EthPortStats property: perPriorityPausePacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F33763
mibFaultName: tcaAdaptorPerPriorityPausePacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorPppPacketsDelta

障害コード : F33770

Message: Threshold Crossed: adaptor:EthPortStats property: pppPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33770
mibFaultName: tcaAdaptorPppPacketsDelta
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorPppPacketsDeltaMin

障害コード : F33771

Message: Threshold Crossed: adaptor:EthPortStats property: pppPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33771
mibFaultName: tcaAdaptorPppPacketsDeltaMin
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
```

tcaAdaptorPppPacketsDeltaMax

障害コード : F33772

Message: Threshold Crossed: adaptor:EthPortStats property: pppPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33772
mibFaultName: tcaAdaptorPppPacketsDeltaMax
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
```

tcaAdaptorPppPacketsDeltaAvg

障害コード : F33773

Message: Threshold Crossed: adaptor:EthPortStats property: pppPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33773
mibFaultName: tcaAdaptorPppPacketsDeltaAvg
moClass: adaptor:EthPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-stats-[trafficDirection]

```

tcaAdaptorLessThan64Delta

障害コード : F33810

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan64Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33810
mibFaultName: tcaAdaptorLessThan64Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:

```

```

sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan64DeltaMin

障害コード : F33811

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan64DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33811
mibFaultName: tcaAdaptorLessThan64DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan64DeltaMax

障害コード : F33812

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan64DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33812
mibFaultName: tcaAdaptorLessThan64DeltaMax
moClass: adaptor:EthPortBySizeSmallStats

```



```

Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan64DeltaAvg

障害コード : F33813

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan64DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33813
mibFaultName: tcaAdaptorLessThan64DeltaAvg
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorEquals64Delta

障害コード : F33820

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: equals64Delta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33820
mibFaultName: tcaAdaptorEquals64Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
```

tcaAdaptorEquals64DeltaMin

障害コード : F33821

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: equals64DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33821
mibFaultName: tcaAdaptorEquals64DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
```

Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

tcaAdaptorEquals64DeltaMax

障害コード : F33822

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: equals64DeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33822
mibFaultName: tcaAdaptorEquals64DeltaMax
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

tcaAdaptorEquals64DeltaAvg

障害コード : F33823

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: equals64DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33823
mibFaultName: tcaAdaptorEquals64DeltaAvg
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:

```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan128Delta

障害コード : F33830

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan128Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33830
mibFaultName: tcaAdaptorLessThan128Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan128DeltaMin

障害コード : F33831

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan128DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33831
mibFaultName: tcaAdaptorLessThan128DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan128DeltaMax

障害コード : F33832

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan128DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33832
mibFaultName: tcaAdaptorLessThan128DeltaMax
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan128DeltaAvg

障害コード : F33833

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan128DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33833
mibFaultName: tcaAdaptorLessThan128DeltaAvg
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan256Delta

障害コード : F33840

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan256Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33840
mibFaultName: tcaAdaptorLessThan256Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan256DeltaMin

障害コード : F33841

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan256DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33841
mibFaultName: tcaAdaptorLessThan256DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan256DeltaMax

障害コード : F33842

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan256DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33842

```

```

mibFaultName: tcaAdaptorLessThan256DeltaMax
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan256DeltaAvg

障害コード : F33843

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan256DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33843
mibFaultName: tcaAdaptorLessThan256DeltaAvg
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan512Delta

障害コード : F33850

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan512Delta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33850
mibFaultName: tcaAdaptorLessThan512Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
```

tcaAdaptorLessThan512DeltaMin

障害コード : F33851

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan512DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33851
mibFaultName: tcaAdaptorLessThan512DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
```

Affected MO:

vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]**Affected MO:** vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]**tcaAdaptorLessThan512DeltaMax**

障害コード : F33852

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan512DeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info**Cause:** threshold-crossed**mibFaultCode:** F33852**mibFaultName:** tcaAdaptorLessThan512DeltaMax**moClass:** adaptor:EthPortBySizeSmallStats**Type:** server**autoCleared:** true**Affected MO:**

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO:

vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]**Affected MO:** vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]**tcaAdaptorLessThan512DeltaAvg**

障害コード : F33853

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan512DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info**Cause:** threshold-crossed**mibFaultCode:** F33853**mibFaultName:** tcaAdaptorLessThan512DeltaAvg**moClass:** adaptor:EthPortBySizeSmallStats**Type:** server**autoCleared:** true**Affected MO:**

```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan1024Delta

障害コード : F33860

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan1024Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33860
mibFaultName: tcaAdaptorLessThan1024Delta
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan1024DeltaMin

障害コード : F33861

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan1024DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33861
mibFaultName: tcaAdaptorLessThan1024DeltaMin
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan1024DeltaMax

障害コード : F33862

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan1024DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33862
mibFaultName: tcaAdaptorLessThan1024DeltaMax
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThan1024DeltaAvg

障害コード : F33863

Message: Threshold Crossed: adaptor:EthPortBySizeSmallStats property: lessThan1024DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33863
mibFaultName: tcaAdaptorLessThan1024DeltaAvg
moClass: adaptor:EthPortBySizeSmallStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-small-stats-[trafficDirection]

```

tcaAdaptorLessThanOrEqualTo1518Delta

障害コード : F33875

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThanOrEqualTo1518Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33875
mibFaultName: tcaAdaptorLessThanOrEqualTo1518Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThanOrEqualTo1518DeltaMin

障害コード : F33876

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThanOrEqualTo1518DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33876
mibFaultName: tcaAdaptorLessThanOrEqualTo1518DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThanOrEqualTo1518DeltaMax

障害コード : F33877

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property:
lessThanOrEqualTo1518DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed

```

```

mibFaultCode: F33877
mibFaultName: tcaAdaptorLessThanOrEqualTo1518DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThanOrEqualTo1518DeltaAvg

障害コード : F33878

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThanOrEqualTo1518DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33878
mibFaultName: tcaAdaptorLessThanOrEqualTo1518DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan2048Delta

障害コード : F33885

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan2048Delta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33885
mibFaultName: tcaAdaptorLessThan2048Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
```

tcaAdaptorLessThan2048DeltaMin

障害コード : F33886

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan2048DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33886
mibFaultName: tcaAdaptorLessThan2048DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
```


Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorLessThan2048DeltaMax

障害コード : F33887

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan2048DeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33887
mibFaultName: tcaAdaptorLessThan2048DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorLessThan2048DeltaAvg

障害コード : F33888

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan2048DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33888
mibFaultName: tcaAdaptorLessThan2048DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan4096Delta

障害コード : F33895

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan4096Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33895
mibFaultName: tcaAdaptorLessThan4096Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan4096DeltaMin

障害コード : F33896

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan4096DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33896
mibFaultName: tcaAdaptorLessThan4096DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
```

tcaAdaptorLessThan4096DeltaMax

障害コード : F33897

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan4096DeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33897
mibFaultName: tcaAdaptorLessThan4096DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
```

Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorLessThan4096DeltaAvg

障害コード : F33898

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan4096DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33898
mibFaultName: tcaAdaptorLessThan4096DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorLessThan8192Delta

障害コード : F33905

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan8192Delta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33905
mibFaultName: tcaAdaptorLessThan8192Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:

```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan8192DeltaMin

障害コード : F33906

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan8192DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33906
mibFaultName: tcaAdaptorLessThan8192DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan8192DeltaMax

障害コード : F33907

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan8192DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33907
mibFaultName: tcaAdaptorLessThan8192DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan8192DeltaAvg

障害コード : F33908

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan8192DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33908
mibFaultName: tcaAdaptorLessThan8192DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan9216Delta

障害コード : F33915

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan9216Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33915
mibFaultName: tcaAdaptorLessThan9216Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan9216DeltaMin

障害コード : F33916

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan9216DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33916
mibFaultName: tcaAdaptorLessThan9216DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan9216DeltaMax

障害コード : F33917

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan9216DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33917
mibFaultName: tcaAdaptorLessThan9216DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorLessThan9216DeltaAvg

障害コード : F33918

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: lessThan9216DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33918

```



```

mibFaultName: tcaAdaptorLessThan9216DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorGreaterThanOrEqualTo9216Delta

障害コード : F33925

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: greaterThanOrEqualTo9216Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33925
mibFaultName: tcaAdaptorGreaterThanOrEqualTo9216Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```

tcaAdaptorGreaterThanOrEqualTo9216DeltaMin

障害コード : F33926

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: greaterThanOrEqualTo9216DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33926
mibFaultName: tcaAdaptorGreaterThanOrEqualTo9216DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
```

tcaAdaptorGreaterThanOrEqualTo9216DeltaMax

障害コード : F33927

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: greaterThanOrEqualTo9216DeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33927
mibFaultName: tcaAdaptorGreaterThanOrEqualTo9216DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorGreaterThanOrEqualTo9216DeltaAvg

障害コード : F33928

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: greaterThanOrEqualTo9216DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33928
mibFaultName: tcaAdaptorGreaterThanOrEqualTo9216DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorOversizedPacketsDelta

障害コード : F33940

Message: Threshold Crossed: adaptor:EthPortOversizedStats property: oversizedPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33940

```

mibFaultName: tcaAdaptorOversizedPacketsDelta
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorOversizedPacketsDeltaMin

障害コード : F33941

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33941
mibFaultName: tcaAdaptorOversizedPacketsDeltaMin
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorOversizedPacketsDeltaMax

障害コード : F33942

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33942
mibFaultName: tcaAdaptorOversizedPacketsDeltaMax
moClass: adaptor:EthPortOversizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
```

tcaAdaptorOversizedPacketsDeltaAvg

障害コード : F33943

Message: Threshold Crossed: adaptor:EthPortOversizedStats property: oversizedPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F33943
mibFaultName: tcaAdaptorOversizedPacketsDeltaAvg
moClass: adaptor:EthPortOversizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
```

tcaAdaptorOversizedGoodCrcPacketsDelta

障害コード : F33950

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedGoodCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33950
mibFaultName: tcaAdaptorOversizedGoodCrcPacketsDelta
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorOversizedGoodCrcPacketsDeltaMin

障害コード : F33951

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedGoodCrcPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33951
mibFaultName: tcaAdaptorOversizedGoodCrcPacketsDeltaMin
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

tcaAdaptorOversizedGoodCrcPacketsDeltaMax

障害コード : F33952

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedGoodCrcPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33952
mibFaultName: tcaAdaptorOversizedGoodCrcPacketsDeltaMax
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

tcaAdaptorOversizedGoodCrcPacketsDeltaAvg

障害コード : F33953

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedGoodCrcPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33953
mibFaultName: tcaAdaptorOversizedGoodCrcPacketsDeltaAvg
moClass: adaptor:EthPortOutsizedStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorOversizedBadCrcPacketsDelta

障害コード : F33960

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedBadCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33960
mibFaultName: tcaAdaptorOversizedBadCrcPacketsDelta
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorOversizedBadCrcPacketsDeltaMin

障害コード : F33961

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedBadCrcPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33961
mibFaultName: tcaAdaptorOversizedBadCrcPacketsDeltaMin
moClass: adaptor:EthPortOversizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]

```

tcaAdaptorOversizedBadCrcPacketsDeltaMax

障害コード : F33962

Message: Threshold Crossed: adaptor:EthPortOversizedStats property: oversizedBadCrcPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33962
mibFaultName: tcaAdaptorOversizedBadCrcPacketsDeltaMax
moClass: adaptor:EthPortOversizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-oversized-stats-[trafficDirection]

```

tcaAdaptorOversizedBadCrcPacketsDeltaAvg

障害コード : F33963

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: oversizedBadCrcPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33963
mibFaultName: tcaAdaptorOversizedBadCrcPacketsDeltaAvg
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedGoodCrcPacketsDelta

障害コード : F33970

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33970
mibFaultName: tcaAdaptorUndersizedGoodCrcPacketsDelta
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

tcaAdaptorUndersizedGoodCrcPacketsDeltaMin

障害コード : F33971

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33971
mibFaultName: tcaAdaptorUndersizedGoodCrcPacketsDeltaMin
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

tcaAdaptorUndersizedGoodCrcPacketsDeltaMax

障害コード : F33972

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33972
mibFaultName: tcaAdaptorUndersizedGoodCrcPacketsDeltaMax
moClass: adaptor:EthPortOutsizedStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedGoodCrcPacketsDeltaAvg

障害コード : F33973

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33973
mibFaultName: tcaAdaptorUndersizedGoodCrcPacketsDeltaAvg
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedBadCrcPacketsDelta

障害コード : F33980

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33980
mibFaultName: tcaAdaptorUndersizedBadCrcPacketsDelta
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedBadCrcPacketsDeltaMin

障害コード : F33981

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33981
mibFaultName: tcaAdaptorUndersizedBadCrcPacketsDeltaMin
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedBadCrcPacketsDeltaMax

障害コード : F33982

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedGoodCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33982
mibFaultName: tcaAdaptorUndersizedBadCrcPacketsDeltaMax
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

```

tcaAdaptorUndersizedBadCrcPacketsDeltaAvg

障害コード : F33983

Message: Threshold Crossed: adaptor:EthPortOutsizedStats property: undersizedBadCrcPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33983
mibFaultName: tcaAdaptorUndersizedBadCrcPacketsDeltaAvg
moClass: adaptor:EthPortOutsizedStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-outsized-stats-[trafficDirection]

tcaAdaptorUnicastPacketsDelta

障害コード : F33995

Message: Threshold Crossed: adaptor:EthPortMcastStats property: unicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33995
mibFaultName: tcaAdaptorUnicastPacketsDelta
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

tcaAdaptorUnicastPacketsDeltaMin

障害コード : F33996

Message: Threshold Crossed: adaptor:EthPortMcastStats property: unicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F33996
mibFaultName: tcaAdaptorUnicastPacketsDeltaMin
moClass: adaptor:EthPortMcastStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorUnicastPacketsDeltaMax

障害コード : F33997

Message: Threshold Crossed: adaptor:EthPortMcastStats property: unicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33997
mibFaultName: tcaAdaptorUnicastPacketsDeltaMax
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorUnicastPacketsDeltaAvg

障害コード : F33998

Message: Threshold Crossed: adaptor:EthPortMcastStats property: unicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F33998
mibFaultName: tcaAdaptorUnicastPacketsDeltaAvg
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorMulticastPacketsDelta

障害コード : F34005

Message: Threshold Crossed: adaptor:EthPortMcastStats property: multicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34005
mibFaultName: tcaAdaptorMulticastPacketsDelta
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorMulticastPacketsDeltaMin

障害コード : F34006

Message: Threshold Crossed: adaptor:EthPortMcastStats property: multicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34006
mibFaultName: tcaAdaptorMulticastPacketsDeltaMin
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorMulticastPacketsDeltaMax

障害コード : F34007

Message: Threshold Crossed: adaptor:EthPortMcastStats property: multicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34007
mibFaultName: tcaAdaptorMulticastPacketsDeltaMax
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

tcaAdaptorMulticastPacketsDeltaAvg

障害コード : F34008

Message: Threshold Crossed: adaptor:EthPortMcastStats property: multicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34008
mibFaultName: tcaAdaptorMulticastPacketsDeltaAvg
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

tcaAdaptorBroadcastPacketsDelta

障害コード : F34015

Message: Threshold Crossed: adaptor:EthPortMcastStats property: broadcastPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34015
mibFaultName: tcaAdaptorBroadcastPacketsDelta
moClass: adaptor:EthPortMcastStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorBroadcastPacketsDeltaMin

障害コード : F34016

Message: Threshold Crossed: adaptor:EthPortMcastStats property: broadcastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34016
mibFaultName: tcaAdaptorBroadcastPacketsDeltaMin
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorBroadcastPacketsDeltaMax

障害コード : F34017

Message: Threshold Crossed: adaptor:EthPortMcastStats property: broadcastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34017
mibFaultName: tcaAdaptorBroadcastPacketsDeltaMax
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorBroadcastPacketsDeltaAvg

障害コード : F34018

Message: Threshold Crossed: adaptor:EthPortMcastStats property: broadcastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34018
mibFaultName: tcaAdaptorBroadcastPacketsDeltaAvg
moClass: adaptor:EthPortMcastStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-mcast-stats-[trafficDirection]

```

tcaAdaptorMacDiscardedPacketsDelta

障害コード : F34030

Message: Threshold Crossed: adaptor:EthPortErrStats property: macDiscardedPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34030
mibFaultName: tcaAdaptorMacDiscardedPacketsDelta
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorMacDiscardedPacketsDeltaMin

障害コード : F34031

Message: Threshold Crossed: adaptor:EthPortErrStats property: macDiscardedPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34031
mibFaultName: tcaAdaptorMacDiscardedPacketsDeltaMin
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

tcaAdaptorMacDiscardedPacketsDeltaMax

障害コード : F34032

Message: Threshold Crossed: adaptor:EthPortErrStats property: macDiscardedPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34032
mibFaultName: tcaAdaptorMacDiscardedPacketsDeltaMax
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

tcaAdaptorMacDiscardedPacketsDeltaAvg

障害コード : F34033

Message: Threshold Crossed: adaptor:EthPortErrStats property: macDiscardedPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34033
mibFaultName: tcaAdaptorMacDiscardedPacketsDeltaAvg
moClass: adaptor:EthPortErrStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadCrcPacketsDelta

障害コード : F34040

Message: Threshold Crossed: adaptor:EthPortErrStats property: badCrcPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34040
mibFaultName: tcaAdaptorBadCrcPacketsDelta
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadCrcPacketsDeltaMin

障害コード : F34041

Message: Threshold Crossed: adaptor:EthPortErrStats property: badCrcPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34041
mibFaultName: tcaAdaptorBadCrcPacketsDeltaMin
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadCrcPacketsDeltaMax

障害コード : F34042

Message: Threshold Crossed: adaptor:EthPortErrStats property: badCrcPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34042
mibFaultName: tcaAdaptorBadCrcPacketsDeltaMax
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadCrcPacketsDeltaAvg

障害コード : F34043

Message: Threshold Crossed: adaptor:EthPortErrStats property: badCrcPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34043
mibFaultName: tcaAdaptorBadCrcPacketsDeltaAvg
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadLengthPacketsDelta

障害コード : F34050

Message: Threshold Crossed: adaptor:EthPortErrStats property: badLengthPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34050
mibFaultName: tcaAdaptorBadLengthPacketsDelta
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]

```

Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

tcaAdaptorBadLengthPacketsDeltaMin

障害コード : F34051

Message: Threshold Crossed: adaptor:EthPortErrStats property: badLengthPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34051
mibFaultName: tcaAdaptorBadLengthPacketsDeltaMin
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

tcaAdaptorBadLengthPacketsDeltaMax

障害コード : F34052

Message: Threshold Crossed: adaptor:EthPortErrStats property: badLengthPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34052
mibFaultName: tcaAdaptorBadLengthPacketsDeltaMax
moClass: adaptor:EthPortErrStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorBadLengthPacketsDeltaAvg

障害コード : F34053

Message: Threshold Crossed: adaptor:EthPortErrStats property: badLengthPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34053
mibFaultName: tcaAdaptorBadLengthPacketsDeltaAvg
moClass: adaptor:EthPortErrStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-err-stats-[trafficDirection]

```

tcaAdaptorRxFramesDelta

障害コード : F34064

Message: Threshold Crossed: adaptor:FcPortStats property: rxFramesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34064
mibFaultName: tcaAdaptorRxFramesDelta
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

tcaAdaptorRxFramesDeltaMin

障害コード : F34065

Message: Threshold Crossed: adaptor:FcPortStats property: rxFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34065
mibFaultName: tcaAdaptorRxFramesDeltaMin
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

tcaAdaptorRxFramesDeltaMax

障害コード : F34066

Message: Threshold Crossed: adaptor:FcPortStats property: rxFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34066
mibFaultName: tcaAdaptorRxFramesDeltaMax

```

moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorRxFramesDeltaAvg

障害コード : F34067

Message: Threshold Crossed: adaptor:FcPortStats property: rxFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34067
mibFaultName: tcaAdaptorRxFramesDeltaAvg
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorTxFramesDelta

障害コード : F34074

Message: Threshold Crossed: adaptor:FcPortStats property: txFramesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34074
mibFaultName: tcaAdaptorTxFramesDelta
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats

```

Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

tcaAdaptorTxFramesDeltaMin

障害コード : F34075

Message: Threshold Crossed: adaptor:FcPortStats property: txFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34075
mibFaultName: tcaAdaptorTxFramesDeltaMin
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

tcaAdaptorTxFramesDeltaMax

障害コード : F34076

Message: Threshold Crossed: adaptor:FcPortStats property: txFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34076
mibFaultName: tcaAdaptorTxFramesDeltaMax
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

tcaAdaptorTxFramesDeltaAvg

障害コード : F34077

Message: Threshold Crossed: adaptor:FcPortStats property: txFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34077
mibFaultName: tcaAdaptorTxFramesDeltaAvg
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorRxBadFramesDelta

障害コード : F34084

Message: Threshold Crossed: adaptor:FcPortStats property: rxBadFramesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34084
mibFaultName: tcaAdaptorRxBadFramesDelta
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorRxBadFramesDeltaMin

障害コード : F34085

Message: Threshold Crossed: adaptor:FcPortStats property: rxBadFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34085
mibFaultName: tcaAdaptorRxBadFramesDeltaMin
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats
```

tcaAdaptorRxBadFramesDeltaMax

障害コード : F34086

Message: Threshold Crossed: adaptor:FcPortStats property: rxBadFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34086
mibFaultName: tcaAdaptorRxBadFramesDeltaMax
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats
```

tcaAdaptorRxBadFramesDeltaAvg

障害コード : F34087

Message: Threshold Crossed: adaptor:FcPortStats property: rxBadFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
```

```

mibFaultCode: F34087
mibFaultName: tcaAdaptorRxBadFramesDeltaAvg
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorTxBadFramesDelta

障害コード : F34094

Message: Threshold Crossed: adaptor:FcPortStats property: txBadFramesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34094
mibFaultName: tcaAdaptorTxBadFramesDelta
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorTxBadFramesDeltaMin

障害コード : F34095

Message: Threshold Crossed: adaptor:FcPortStats property: txBadFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34095
mibFaultName: tcaAdaptorTxBadFramesDeltaMin
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorTxBadFramesDeltaMax

障害コード : F34096

Message: Threshold Crossed: adaptor:FcPortStats property: txBadFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34096
mibFaultName: tcaAdaptorTxBadFramesDeltaMax
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorTxBadFramesDeltaAvg

障害コード : F34097

Message: Threshold Crossed: adaptor:FcPortStats property: txBadFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34097
mibFaultName: tcaAdaptorTxBadFramesDeltaAvg
moClass: adaptor:FcPortStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-port-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/fc-port-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/fc-port-stats

```

tcaAdaptorPacketsTxDelta

障害コード : F34108

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34108
mibFaultName: tcaAdaptorPacketsTxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorPacketsTxDeltaMin

障害コード : F34109

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34109
mibFaultName: tcaAdaptorPacketsTxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true

```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorPacketsTxDeltaMax

障害コード : F34110

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34110
mibFaultName: tcaAdaptorPacketsTxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorPacketsTxDeltaAvg

障害コード : F34111

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34111
mibFaultName: tcaAdaptorPacketsTxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorPacketsRxDelta

障害コード : F34118

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34118
mibFaultName: tcaAdaptorPacketsRxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorPacketsRxDeltaMin

障害コード : F34119

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34119
mibFaultName: tcaAdaptorPacketsRxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats

```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorPacketsRxDeltaMax

障害コード : F34120

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34120
mibFaultName: tcaAdaptorPacketsRxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorPacketsRxDeltaAvg

障害コード : F34121

Message: Threshold Crossed: adaptor:VnicStats property: packetsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34121
mibFaultName: tcaAdaptorPacketsRxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats
```

tcaAdaptorBytesTxDelta

障害コード : F34128

Message: Threshold Crossed: adaptor:VnicStats property: bytesTxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34128
mibFaultName: tcaAdaptorBytesTxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorBytesTxDeltaMin

障害コード : F34129

Message: Threshold Crossed: adaptor:VnicStats property: bytesTxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34129
mibFaultName: tcaAdaptorBytesTxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorBytesTxDeltaMax

障害コード : F34130

Message: Threshold Crossed: adaptor:VnicStats property: bytesTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34130
mibFaultName: tcaAdaptorBytesTxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorBytesTxDeltaAvg

障害コード : F34131

Message: Threshold Crossed: adaptor:VnicStats property: bytesTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34131
mibFaultName: tcaAdaptorBytesTxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true

```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorBytesRxDelta

障害コード : F34138

Message: Threshold Crossed: adaptor:VnicStats property: bytesRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34138
mibFaultName: tcaAdaptorBytesRxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorBytesRxDeltaMin

障害コード : F34139

Message: Threshold Crossed: adaptor:VnicStats property: bytesRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34139
mibFaultName: tcaAdaptorBytesRxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorBytesRxDeltaMax

障害コード : F34140

Message: Threshold Crossed: adaptor:VnicStats property: bytesRxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34140
mibFaultName: tcaAdaptorBytesRxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorBytesRxDeltaAvg

障害コード : F34141

Message: Threshold Crossed: adaptor:VnicStats property: bytesRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34141
mibFaultName: tcaAdaptorBytesRxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats

```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorErrorsTxDelta

障害コード : F34148

Message: Threshold Crossed: adaptor:VnicStats property: errorsTxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34148
mibFaultName: tcaAdaptorErrorsTxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorErrorsTxDeltaMin

障害コード : F34149

Message: Threshold Crossed: adaptor:VnicStats property: errorsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34149
mibFaultName: tcaAdaptorErrorsTxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats
```

tcaAdaptorErrorsTxDeltaMax

障害コード : F34150

Message: Threshold Crossed: adaptor:VnicStats property: errorsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34150
mibFaultName: tcaAdaptorErrorsTxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
```


Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorErrorsTxDeltaAvg

障害コード : F34151

Message: Threshold Crossed: adaptor:VnicStats property: errorsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34151
mibFaultName: tcaAdaptorErrorsTxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorErrorsRxDelta

障害コード : F34158

メッセージ: しきい値 Crossed: adaptor: VnicStats プロパティ: errorsRxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34158
mibFaultName: tcaAdaptorErrorsRxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorErrorsRxDeltaMin

障害コード : F34159

Message: Threshold Crossed: adaptor:VnicStats property: errorsRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34159
mibFaultName: tcaAdaptorErrorsRxDeltaMin
moClass: adaptor:VnicStats
Type: server

```

```

autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorErrorsRxDeltaMax

障害コード : F34160

Message: Threshold Crossed: adaptor:VnicStats property: errorsRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34160
mibFaultName: tcaAdaptorErrorsRxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats

```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorErrorsRxDeltaAvg

障害コード : F34161

Message: Threshold Crossed: adaptor:VnicStats property: errorsRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34161
mibFaultName: tcaAdaptorErrorsRxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorDroppedTxDelta

障害コード : F34168

Message: Threshold Crossed: adaptor:VnicStats property: droppedTxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34168
mibFaultName: tcaAdaptorDroppedTxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorDroppedTxDeltaMin

障害コード : F34169

Message: Threshold Crossed: adaptor:VnicStats property: droppedTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34169
mibFaultName: tcaAdaptorDroppedTxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats

```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorDroppedTxDeltaMax

障害コード : F34170

Message: Threshold Crossed: adaptor:VnicStats property: droppedTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34170
mibFaultName: tcaAdaptorDroppedTxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorDroppedTxDeltaAvg

障害コード : F34171

Message: Threshold Crossed: adaptor:VnicStats property: droppedTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34171
mibFaultName: tcaAdaptorDroppedTxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats
```

tcaAdaptorDroppedRxDelta

障害コード : F34178

Message: Threshold Crossed: adaptor:VnicStats property: droppedRxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34178
mibFaultName: tcaAdaptorDroppedRxDelta
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorDroppedRxDeltaMin

障害コード : F34179

Message: Threshold Crossed: adaptor:VnicStats property: droppedRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34179
mibFaultName: tcaAdaptorDroppedRxDeltaMin
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorDroppedRxDeltaMax

障害コード : F34180

Message: Threshold Crossed: adaptor:VnicStats property: droppedRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34180
mibFaultName: tcaAdaptorDroppedRxDeltaMax
moClass: adaptor:VnicStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

```

tcaAdaptorDroppedRxDeltaAvg

障害コード : F34181

Message: Threshold Crossed: adaptor:VnicStats property: droppedRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34181
mibFaultName: tcaAdaptorDroppedRxDeltaAvg
moClass: adaptor:VnicStats
Type: server
autoCleared: true

```

Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-scsi-[id]/vnic-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vnic-stats
Affected MO: vmm/computeEp-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/hv-[uuid]/nic-[name]/vnic-stats
Affected MO: vmm/vm-[uuid]/nic-[name]/vnic-stats

tcaAdaptorInputRequestsDelta

障害コード : F34192

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputRequestsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34192
mibFaultName: tcaAdaptorInputRequestsDelta
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

tcaAdaptorInputRequestsDeltaMin

障害コード : F34193

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputRequestsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34193
mibFaultName: tcaAdaptorInputRequestsDeltaMin
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorInputRequestsDeltaMax

障害コード : F34194

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputRequestsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34194
mibFaultName: tcaAdaptorInputRequestsDeltaMax
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorInputRequestsDeltaAvg

障害コード : F34195

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputRequestsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34195
mibFaultName: tcaAdaptorInputRequestsDeltaAvg
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorOutputRequestsDelta

障害コード : F34202

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputRequestsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34202
mibFaultName: tcaAdaptorOutputRequestsDelta
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorOutputRequestsDeltaMin

障害コード : F34203

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputRequestsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34203
mibFaultName: tcaAdaptorOutputRequestsDeltaMin
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorOutputRequestsDeltaMax

障害コード : F34204

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputRequestsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info

```

```

Cause: threshold-crossed
mibFaultCode: F34204
mibFaultName: tcaAdaptorOutputRequestsDeltaMax
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorOutputRequestsDeltaAvg

障害コード : F34205

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputRequestsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34205
mibFaultName: tcaAdaptorOutputRequestsDeltaAvg
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorControlRequestsDelta

障害コード : F34212

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: controlRequestsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34212
mibFaultName: tcaAdaptorControlRequestsDelta
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorControlRequestsDeltaMin

障害コード : F34213

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: controlRequestsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34213
mibFaultName: tcaAdaptorControlRequestsDeltaMin
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorControlRequestsDeltaMax

障害コード : F34214

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: controlRequestsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34214
mibFaultName: tcaAdaptorControlRequestsDeltaMax
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorControlRequestsDeltaAvg

障害コード : F34215

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: controlRequestsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34215
mibFaultName: tcaAdaptorControlRequestsDeltaAvg
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

tcaAdaptorInputMegabytesDelta

障害コード : F34222

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputMegabytesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34222
mibFaultName: tcaAdaptorInputMegabytesDelta
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

tcaAdaptorInputMegabytesDeltaMin

障害コード : F34223

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputMegabytesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34223
mibFaultName: tcaAdaptorInputMegabytesDeltaMin
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

tcaAdaptorInputMegabytesDeltaMax

障害コード : F34224

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputMegabytesDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34224
mibFaultName: tcaAdaptorInputMegabytesDeltaMax
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorInputMegabytesDeltaAvg

障害コード : F34225

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: inputMegabytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34225
mibFaultName: tcaAdaptorInputMegabytesDeltaAvg
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats

```

tcaAdaptorOutputMegabytesDelta

障害コード : F34232

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputMegabytesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info

```



```
Cause: threshold-crossed
mibFaultCode: F34232
mibFaultName: tcaAdaptorOutputMegabytesDelta
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
```

tcaAdaptorOutputMegabytesDeltaMin

障害コード : F34233

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputMegabytesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34233
mibFaultName: tcaAdaptorOutputMegabytesDeltaMin
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
```

tcaAdaptorOutputMegabytesDeltaMax

障害コード : F34234

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputMegabytesDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34234
mibFaultName: tcaAdaptorOutputMegabytesDeltaMax
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
```

tcaAdaptorOutputMegabytesDeltaAvg

障害コード : F34235

Message: Threshold Crossed: adaptor:FcIfFC4Stats property: outputMegabytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34235
mibFaultName: tcaAdaptorOutputMegabytesDeltaAvg
moClass: adaptor:FcIfFC4Stats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-fc4-stats
```

tcaAdaptorCorrectableErrorsDelta

障害コード : F34246

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34246
mibFaultName: tcaAdaptorCorrectableErrorsDelta
moClass: adaptor:MenloBaseErrorStats
Type: server
autoCleared: true
```

tcaAdaptorCorrectableErrorsDeltaMin

障害コード : F34247

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: correctableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34247
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMin
moClass: adaptor:MenloBaseErrorStats
```

Type: server
autoCleared: true

tcaAdaptorCorrectableErrorsDeltaMax

障害コード : F34248

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: correctableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34248
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMax
moClass: adaptor:MenloBaseErrorStats
Type: server
autoCleared: true

tcaAdaptorCorrectableErrorsDeltaAvg

障害コード : F34249

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: correctableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34249
mibFaultName: tcaAdaptorCorrectableErrorsDeltaAvg
moClass: adaptor:MenloBaseErrorStats
Type: server
autoCleared: true

tcaAdaptorUncorrectableErrorsDelta

障害コード : F34256

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34256
mibFaultName: tcaAdaptorUncorrectableErrorsDelta
moClass: adaptor:MenloBaseErrorStats

Type: server
autoCleared: true

tcaAdaptorUncorrectableErrorsDeltaMin

障害コード : F34257

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: uncorrectableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34257
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMin
moClass: adaptor:MenloBaseErrorStats
Type: server
autoCleared: true

tcaAdaptorUncorrectableErrorsDeltaMax

障害コード : F34258

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: uncorrectableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34258
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMax
moClass: adaptor:MenloBaseErrorStats
Type: server
autoCleared: true

tcaAdaptorUncorrectableErrorsDeltaAvg

障害コード : F34259

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: uncorrectableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34259
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaAvg
moClass: adaptor:MenloBaseErrorStats

Type: server
autoCleared: true

tcaAdaptorDropAclDelta

障害コード : F34271

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34271
mibFaultName: tcaAdaptorDropAclDelta
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]

tcaAdaptorDropAclDeltaMin

障害コード : F34272

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34272
mibFaultName: tcaAdaptorDropAclDeltaMin
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]

tcaAdaptorDropAclDeltaMax

障害コード : F34273

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34273
mibFaultName: tcaAdaptorDropAclDeltaMax
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropAclDeltaAvg

障害コード : F34274

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34274
mibFaultName: tcaAdaptorDropAclDeltaAvg
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropOverrunDelta

障害コード : F34281

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34281
mibFaultName: tcaAdaptorDropOverrunDelta
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropOverrunDeltaMin

障害コード : F34282

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropOverrunDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34282
mibFaultName: tcaAdaptorDropOverrunDeltaMin
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropOverrunDeltaMax

障害コード : F34283

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropOverrunDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34283
mibFaultName: tcaAdaptorDropOverrunDeltaMax
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropOverrunDeltaAvg

障害コード : F34284

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34284
mibFaultName: tcaAdaptorDropOverrunDeltaAvg
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropRuntDelta

障害コード : F34291

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropRuntDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34291
mibFaultName: tcaAdaptorDropRuntDelta
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropRuntDeltaMin

障害コード : F34292

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropRuntDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34292
mibFaultName: tcaAdaptorDropRuntDeltaMin
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
```



```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropRuntDeltaMax

障害コード : F34293

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropRuntDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F34293  
mibFaultName: tcaAdaptorDropRuntDeltaMax  
moClass: adaptor:MenloMcpuStats  
Type: server  
autoCleared: true  
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorDropRuntDeltaAvg

障害コード : F34294

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropRuntDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F34294  
mibFaultName: tcaAdaptorDropRuntDeltaAvg  
moClass: adaptor:MenloMcpuStats  
Type: server  
autoCleared: true  
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorTruncateOverrunDelta

障害コード : F34301

Message: Threshold Crossed: adaptor:MenloMcpuStats property: truncateOverrunDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34301
mibFaultName: tcaAdaptorTruncateOvrerrunDelta
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]

```

tcaAdaptorTruncateOvrerrunDeltaMin

障害コード : F34302

Message: Threshold Crossed: adaptor:MenloMcpuStats property: truncateOvrerrunDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34302
mibFaultName: tcaAdaptorTruncateOvrerrunDeltaMin
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]

```

tcaAdaptorTruncateOvrerrunDeltaMax

障害コード : F34303

Message: Threshold Crossed: adaptor:MenloMcpuStats property: truncateOvrerrunDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34303
mibFaultName: tcaAdaptorTruncateOvrerrunDeltaMax
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorTruncateOverrunDeltaAvg

障害コード : F34304

Message: Threshold Crossed: adaptor:MenloMcpuStats property: truncateOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34304
mibFaultName: tcaAdaptorTruncateOverrunDeltaAvg
moClass: adaptor:MenloMcpuStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-stats-[menloMcpuIndex]
```

tcaAdaptorCorrectableErrorsDelta

障害コード : F34316

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34316
mibFaultName: tcaAdaptorCorrectableErrorsDelta
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorCorrectableErrorsDeltaMin

障害コード : F34317

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34317
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMin
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorCorrectableErrorsDeltaMax

障害コード : F34318

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34318
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMax
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorCorrectableErrorsDeltaAvg

障害コード : F34319

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34319
mibFaultName: tcaAdaptorCorrectableErrorsDeltaAvg
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:

```

```
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorPopErrorsDelta

障害コード : F34326

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34326
mibFaultName: tcaAdaptorPopErrorsDelta
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorPopErrorsDeltaMin

障害コード : F34327

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34327
mibFaultName: tcaAdaptorPopErrorsDeltaMin
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorPopErrorsDeltaMax

障害コード : F34328

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34328
mibFaultName: tcaAdaptorPopErrorsDeltaMax
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorPopErrorsDeltaAvg

障害コード : F34329

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34329
mibFaultName: tcaAdaptorPopErrorsDeltaAvg
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorPushErrorsDelta

障害コード : F34336

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: pushErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34336
mibFaultName: tcaAdaptorPushErrorsDelta
```

```

moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorPushErrorsDeltaMin

障害コード : F34337

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: pushErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34337
mibFaultName: tcaAdaptorPushErrorsDeltaMin
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorPushErrorsDeltaMax

障害コード : F34338

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: pushErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34338
mibFaultName: tcaAdaptorPushErrorsDeltaMax
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorPushErrorsDeltaAvg

障害コード : F34339

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: pushErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34339
mibFaultName: tcaAdaptorPushErrorsDeltaAvg
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorUncorrectableErrorsDelta

障害コード : F34346

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34346
mibFaultName: tcaAdaptorUncorrectableErrorsDelta
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorUncorrectableErrorsDeltaMin

障害コード : F34347

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: uncorrectableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細


```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34347
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMin
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorUncorrectableErrorsDeltaMax

障害コード : F34348

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: uncorrectableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34348
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMax
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]

```

tcaAdaptorUncorrectableErrorsDeltaAvg

障害コード : F34349

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: uncorrectableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34349
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaAvg
moClass: adaptor:MenloMcpuErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-mcpu-error-stats-[menloMcpuIndex]
```

tcaAdaptorDropOverrunDelta

障害コード : F34361

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34361
mibFaultName: tcaAdaptorDropOverrunDelta
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
```

tcaAdaptorDropOverrunDeltaMin

障害コード : F34362

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34362
mibFaultName: tcaAdaptorDropOverrunDeltaMin
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
```

tcaAdaptorDropOverrunDeltaMax

障害コード : F34363

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34363
mibFaultName: tcaAdaptorDropOverrunDeltaMax
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

tcaAdaptorDropOverrunDeltaAvg

障害コード : F34364

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34364
mibFaultName: tcaAdaptorDropOverrunDeltaAvg
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

tcaAdaptorDropRuntDelta

障害コード : F34371

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34371
mibFaultName: tcaAdaptorDropRuntDelta
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
```

tcaAdaptorDropRuntDeltaMin

障害コード : F34372

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34372
mibFaultName: tcaAdaptorDropRuntDeltaMin
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
```

tcaAdaptorDropRuntDeltaMax

障害コード : F34373

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34373
mibFaultName: tcaAdaptorDropRuntDeltaMax
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
```

tcaAdaptorDropRuntDeltaAvg

障害コード : F34374

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34374
mibFaultName: tcaAdaptorDropRuntDeltaAvg
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

```

tcaAdaptorTruncateOverrunDelta

障害コード : F34381

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34381
mibFaultName: tcaAdaptorTruncateOverrunDelta
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

```

tcaAdaptorTruncateOverrunDeltaMin

障害コード : F34382

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34382
mibFaultName: tcaAdaptorTruncateOverrunDeltaMin
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO:

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

tcaAdaptorTruncateOverrunDeltaMax

障害コード : F34383

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34383
mibFaultName: tcaAdaptorTruncateOverrunDeltaMax
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

tcaAdaptorTruncateOverrunDeltaAvg

障害コード : F34384

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34384
mibFaultName: tcaAdaptorTruncateOverrunDeltaAvg
moClass: adaptor:MenloEthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-stats-[menloEthIndex]

tcaAdaptorCorrectableErrorsDelta

障害コード : F34396

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34396
mibFaultName: tcaAdaptorCorrectableErrorsDelta
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorCorrectableErrorsDeltaMin

障害コード : F34397

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: correctableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34397
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMin
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorCorrectableErrorsDeltaMax

障害コード : F34398

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34398
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMax
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:

```

```
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorCorrectableErrorsDeltaAvg

障害コード : F34399

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: correctableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34399
mibFaultName: tcaAdaptorCorrectableErrorsDeltaAvg
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorDropAclDelta

障害コード : F34406

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: dropAclDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34406
mibFaultName: tcaAdaptorDropAclDelta
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorDropAclDeltaMin

障害コード : F34407

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: dropAclDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34407
mibFaultName: tcaAdaptorDropAclDeltaMin
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorDropAclDeltaMax

障害コード : F34408

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: dropAclDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34408
mibFaultName: tcaAdaptorDropAclDeltaMax
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorDropAclDeltaAvg

障害コード : F34409

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: dropAclDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34409
mibFaultName: tcaAdaptorDropAclDeltaAvg
```

```

moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorPopErrorsDelta

障害コード : F34416

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34416
mibFaultName: tcaAdaptorPopErrorsDelta
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorPopErrorsDeltaMin

障害コード : F34417

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: popErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34417
mibFaultName: tcaAdaptorPopErrorsDeltaMin
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorPopErrorsDeltaMax

障害コード : F34418

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34418
mibFaultName: tcaAdaptorPopErrorsDeltaMax
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorPopErrorsDeltaAvg

障害コード : F34419

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34419
mibFaultName: tcaAdaptorPopErrorsDeltaAvg
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorPushErrorsDelta

障害コード : F34426

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34426
mibFaultName: tcaAdaptorPushErrorsDelta
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorPushErrorsDeltaMin

障害コード : F34427

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34427
mibFaultName: tcaAdaptorPushErrorsDeltaMin
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorPushErrorsDeltaMax

障害コード : F34428

Message: Threshold Crossed: adaptor:MenloMcpuErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34428
mibFaultName: tcaAdaptorPushErrorsDeltaMax
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorPushErrorsDeltaAvg

障害コード : F34429

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: pushErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34429
mibFaultName: tcaAdaptorPushErrorsDeltaAvg
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorUncorrectableErrorsDelta

障害コード : F34436

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34436
mibFaultName: tcaAdaptorUncorrectableErrorsDelta
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorUncorrectableErrorsDeltaMin

障害コード : F34437

Message: Threshold Crossed: adaptor:MenloBaseErrorStats property: uncorrectableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34437
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMin
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorUncorrectableErrorsDeltaMax

障害コード : F34438

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: uncorrectableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34438
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMax
moClass: adaptor:MenloEthErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
```

tcaAdaptorUncorrectableErrorsDeltaAvg

障害コード : F34439

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: uncorrectableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34439
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaAvg
moClass: adaptor:MenloEthErrorStats
Type: server
```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-eth-error-stats-[menloEthIndex]

```

tcaAdaptorDropAclDelta

障害コード : F34451

Message: Threshold Crossed: adaptor:MenloFcStats property: dropAclDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34451
mibFaultName: tcaAdaptorDropAclDelta
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

```

tcaAdaptorDropAclDeltaMin

障害コード : F34452

Message: Threshold Crossed: adaptor:MenloFcStats property: dropAclDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34452
mibFaultName: tcaAdaptorDropAclDeltaMin
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

```

tcaAdaptorDropAclDeltaMax

障害コード : F34453

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34453
mibFaultName: tcaAdaptorDropAclDeltaMax
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropAclDeltaAvg

障害コード : F34454

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropAclDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34454
mibFaultName: tcaAdaptorDropAclDeltaAvg
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropOverrunDelta

障害コード : F34461

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34461
mibFaultName: tcaAdaptorDropOverrunDelta
moClass: adaptor:MenloFcStats
Type: server
```



```

autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

```

tcaAdaptorDropOverrunDeltaMin

障害コード : F34462

Message: Threshold Crossed: adaptor:MenloMcpuStats property: dropOverrunDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34462
mibFaultName: tcaAdaptorDropOverrunDeltaMin
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

```

tcaAdaptorDropOverrunDeltaMax

障害コード : F34463

Message: Threshold Crossed: adaptor:MenloEthStats property: dropOverrunDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34463
mibFaultName: tcaAdaptorDropOverrunDeltaMax
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

```

tcaAdaptorDropOverrunDeltaAvg

障害コード : F34464

メッセージ: しきい値 Crossed: adaptor: MenloFcStats プロパティ: dropOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34464
mibFaultName: tcaAdaptorDropOverrunDeltaAvg
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropRuntDelta

障害コード : F34471

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34471
mibFaultName: tcaAdaptorDropRuntDelta
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropRuntDeltaMin

障害コード : F34472

Message: Threshold Crossed: adaptor:MenloEthStats property: dropRuntDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34472
mibFaultName: tcaAdaptorDropRuntDeltaMin
moClass: adaptor:MenloFcStats
Type: server
```

```
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropRuntDeltaMax

障害コード : F34473

Message: Threshold Crossed: adaptor:MenloFcStats property: dropRuntDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34473
mibFaultName: tcaAdaptorDropRuntDeltaMax
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorDropRuntDeltaAvg

障害コード : F34474

Message: Threshold Crossed: adaptor:MenloFcStats property: dropRuntDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34474
mibFaultName: tcaAdaptorDropRuntDeltaAvg
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorTruncateOverrunDelta

障害コード : F34481

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34481
mibFaultName: tcaAdaptorTruncateOverrunDelta
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorTruncateOverrunDeltaMin

障害コード : F34482

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34482
mibFaultName: tcaAdaptorTruncateOverrunDeltaMin
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

tcaAdaptorTruncateOverrunDeltaMax

障害コード : F34483

Message: Threshold Crossed: adaptor:MenloEthStats property: truncateOverrunDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34483
mibFaultName: tcaAdaptorTruncateOverrunDeltaMax
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
```

Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

tcaAdaptorTruncateOverrunDeltaAvg

障害コード : F34484

Message: Threshold Crossed: adaptor:MenloFcStats property: truncateOverrunDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34484
mibFaultName: tcaAdaptorTruncateOverrunDeltaAvg
moClass: adaptor:MenloFcStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-stats-[menloFcIndex]

tcaAdaptorCorrectableErrorsDelta

障害コード : F34496

Message: Threshold Crossed: adaptor:MenloEthErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34496
mibFaultName: tcaAdaptorCorrectableErrorsDelta
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

tcaAdaptorCorrectableErrorsDeltaMin

障害コード : F34497

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34497
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMin
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorCorrectableErrorsDeltaMax

障害コード : F34498

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: correctableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34498
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMax
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorCorrectableErrorsDeltaAvg

障害コード : F34499

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: correctableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34499
mibFaultName: tcaAdaptorCorrectableErrorsDeltaAvg
moClass: adaptor:MenloFcErrorStats
Type: server
```

```
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorPopErrorsDelta

障害コード : F34506

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34506
mibFaultName: tcaAdaptorPopErrorsDelta
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorPopErrorsDeltaMin

障害コード : F34507

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: popErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34507
mibFaultName: tcaAdaptorPopErrorsDeltaMin
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorPopErrorsDeltaMax

障害コード : F34508

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: popErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34508
mibFaultName: tcaAdaptorPopErrorsDeltaMax
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorPopErrorsDeltaAvg

障害コード : F34509

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: popErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34509
mibFaultName: tcaAdaptorPopErrorsDeltaAvg
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
```

tcaAdaptorPushErrorsDelta

障害コード : F34516

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: pushErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34516
```



```

mibFaultName: tcaAdaptorPushErrorsDelta
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorPushErrorsDeltaMin

障害コード : F34517

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: pushErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34517
mibFaultName: tcaAdaptorPushErrorsDeltaMin
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorPushErrorsDeltaMax

障害コード : F34518

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: pushErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34518
mibFaultName: tcaAdaptorPushErrorsDeltaMax
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorPushErrorsDeltaAvg

障害コード : F34519

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: pushErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34519
mibFaultName: tcaAdaptorPushErrorsDeltaAvg
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorUncorrectableErrorsDelta

障害コード : F34526

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34526
mibFaultName: tcaAdaptorUncorrectableErrorsDelta
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorUncorrectableErrorsDeltaMin

障害コード : F34527

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: uncorrectableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34527
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMin
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorUncorrectableErrorsDeltaMax

障害コード : F34528

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: uncorrectableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34528
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMax
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

```

tcaAdaptorUncorrectableErrorsDeltaAvg

障害コード : F34529

Message: Threshold Crossed: adaptor:MenloFcErrorStats property: uncorrectableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34529
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaAvg
moClass: adaptor:MenloFcErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO:

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-fc-error-stats-[menloFcIndex]

tcaAdaptorDropOverrunN0Delta

障害コード : F34542

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN0Delta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34542
mibFaultName: tcaAdaptorDropOverrunN0Delta
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

tcaAdaptorDropOverrunN0DeltaMin

障害コード : F34543

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN0DeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34543
mibFaultName: tcaAdaptorDropOverrunN0DeltaMin
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

tcaAdaptorDropOverrunN0DeltaMax

障害コード : F34544

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN0DeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34544
mibFaultName: tcaAdaptorDropOverrunN0DeltaMax
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorDropOverrunN0DeltaAvg

障害コード : F34545

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN0DeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34545
mibFaultName: tcaAdaptorDropOverrunN0DeltaAvg
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorDropOverrunN1Delta

障害コード : F34552

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN1Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34552
mibFaultName: tcaAdaptorDropOverrunN1Delta
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorDropOverrunN1DeltaMin

障害コード : F34553

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN1DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34553
mibFaultName: tcaAdaptorDropOverrunN1DeltaMin
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorDropOverrunN1DeltaMax

障害コード : F34554

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN1DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34554
mibFaultName: tcaAdaptorDropOverrunN1DeltaMax
moClass: adaptor:MenloQStats
Type: server

```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

```

tcaAdaptorDropOverrunN1DeltaAvg

障害コード : F34555

Message: Threshold Crossed: adaptor:MenloQStats property: dropOverrunN1DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34555
mibFaultName: tcaAdaptorDropOverrunN1DeltaAvg
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

```

tcaAdaptorTruncateOverrunN0Delta

障害コード : F34562

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOverrunN0Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34562
mibFaultName: tcaAdaptorTruncateOverrunN0Delta
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:

```

```
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorTruncateOvrrunN0DeltaMin

障害コード : F34563

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOvrrunN0DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34563
mibFaultName: tcaAdaptorTruncateOvrrunN0DeltaMin
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorTruncateOvrrunN0DeltaMax

障害コード : F34564

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOvrrunN0DeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34564
mibFaultName: tcaAdaptorTruncateOvrrunN0DeltaMax
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorTruncateOvrrunN0DeltaAvg

障害コード : F34565

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOverrunN0DeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34565
mibFaultName: tcaAdaptorTruncateOverrunN0DeltaAvg
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorTruncateOverrunN1Delta

障害コード : F34572

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOverrunN1Delta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34572
mibFaultName: tcaAdaptorTruncateOverrunN1Delta
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorTruncateOverrunN1DeltaMin

障害コード : F34573

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOverrunN1DeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34573
mibFaultName: tcaAdaptorTruncateOvrrunN1DeltaMin
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorTruncateOvrrunN1DeltaMax

障害コード : F34574

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOvrrunN1DeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34574
mibFaultName: tcaAdaptorTruncateOvrrunN1DeltaMax
moClass: adaptor:MenloQStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorTruncateOvrrunN1DeltaAvg

障害コード : F34575

Message: Threshold Crossed: adaptor:MenloQStats property: truncateOvrrunN1DeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34575
mibFaultName: tcaAdaptorTruncateOvrrunN1DeltaAvg
moClass: adaptor:MenloQStats
Type: server

```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

```

tcaAdaptorCorrectableErrorsDelta

障害コード : F34588

Message: Threshold Crossed: adaptor:MenloQErrorStats property: correctableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34588
mibFaultName: tcaAdaptorCorrectableErrorsDelta
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

```

tcaAdaptorCorrectableErrorsDeltaMin

障害コード : F34589

Message: Threshold Crossed: adaptor:MenloQErrorStats property: correctableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34589
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMin
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:

```

```
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorCorrectableErrorsDeltaMax

障害コード : F34590

Message: Threshold Crossed: adaptor:MenloQErrorStats property: correctableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34590
mibFaultName: tcaAdaptorCorrectableErrorsDeltaMax
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorCorrectableErrorsDeltaAvg

障害コード : F34591

Message: Threshold Crossed: adaptor:MenloQErrorStats property: correctableErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34591
mibFaultName: tcaAdaptorCorrectableErrorsDeltaAvg
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorPopErrorsDelta

障害コード : F34598

Message: Threshold Crossed: adaptor:MenloQErrorStats property: popErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34598
mibFaultName: tcaAdaptorPopErrorsDelta
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorPopErrorsDeltaMin

障害コード : F34599

Message: Threshold Crossed: adaptor:MenloQErrorStats property: popErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34599
mibFaultName: tcaAdaptorPopErrorsDeltaMin
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorPopErrorsDeltaMax

障害コード : F34600

Message: Threshold Crossed: adaptor:MenloQErrorStats property: popErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34600
mibFaultName: tcaAdaptorPopErrorsDeltaMax
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorPopErrorsDeltaAvg

障害コード : F34601

Message: Threshold Crossed: adaptor:MenloQErrorStats property: popErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34601
mibFaultName: tcaAdaptorPopErrorsDeltaAvg
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorPushErrorsDelta

障害コード : F34608

Message: Threshold Crossed: adaptor:MenloQErrorStats property: pushErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34608
mibFaultName: tcaAdaptorPushErrorsDelta
moClass: adaptor:MenloQErrorStats
Type: server

```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorPushErrorsDeltaMin

障害コード : F34609

Message: Threshold Crossed: adaptor:MenloQErrorStats property: pushErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34609
mibFaultName: tcaAdaptorPushErrorsDeltaMin
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]

```

tcaAdaptorPushErrorsDeltaMax

障害コード : F34610

Message: Threshold Crossed: adaptor:MenloQErrorStats property: pushErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34610
mibFaultName: tcaAdaptorPushErrorsDeltaMax
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:

```

```
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorPushErrorsDeltaAvg

障害コード : F34611

Message: Threshold Crossed: adaptor:MenloQErrorStats property: pushErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34611
mibFaultName: tcaAdaptorPushErrorsDeltaAvg
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorUncorrectableErrorsDelta

障害コード : F34618

Message: Threshold Crossed: adaptor:MenloQErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34618
mibFaultName: tcaAdaptorUncorrectableErrorsDelta
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent] index-[menloQueueIndex]
```

tcaAdaptorUncorrectableErrorsDeltaMin

障害コード : F34619

Message: Threshold Crossed: adaptor:MenloQErrorStats property: uncorrectableErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34619
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMin
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorUncorrectableErrorsDeltaMax

障害コード : F34620

Message: Threshold Crossed: adaptor:MenloQErrorStats property: uncorrectableErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34620
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaMax
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
```

tcaAdaptorUncorrectableErrorsDeltaAvg

障害コード : F34621

Message: Threshold Crossed: adaptor:MenloQErrorStats property: uncorrectableErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34621
mibFaultName: tcaAdaptorUncorrectableErrorsDeltaAvg
moClass: adaptor:MenloQErrorStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/menlo-q-error-stats-comp-[menloQueueComponent]index-[menloQueueIndex]

```

tcaAdaptorLearnReqDropDelta

障害コード : F34633

Message: Threshold Crossed: adaptor:MenloNetEgStats property: learnReqDropDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34633
mibFaultName: tcaAdaptorLearnReqDropDelta
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorLearnReqDropDeltaMin

障害コード : F34634

Message: Threshold Crossed: adaptor:MenloNetEgStats property: learnReqDropDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34634
mibFaultName: tcaAdaptorLearnReqDropDeltaMin
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:

```

```
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorLearnReqDropDeltaMax

障害コード : F34635

Message: Threshold Crossed: adaptor:MenloNetEgStats property: learnReqDropDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34635
mibFaultName: tcaAdaptorLearnReqDropDeltaMax
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorLearnReqDropDeltaAvg

障害コード : F34636

Message: Threshold Crossed: adaptor:MenloNetEgStats property: learnReqDropDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34636
mibFaultName: tcaAdaptorLearnReqDropDeltaAvg
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropCmdDelta

障害コード : F34643

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropCmdDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34643
mibFaultName: tcaAdaptorDropCmdDelta
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropCmdDeltaMin

障害コード : F34644

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropCmdDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34644
mibFaultName: tcaAdaptorDropCmdDeltaMin
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropCmdDeltaMax

障害コード : F34645

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropCmdDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34645
mibFaultName: tcaAdaptorDropCmdDeltaMax
```

```

moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropCmdDeltaAvg

障害コード : F34646

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropCmdDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34646
mibFaultName: tcaAdaptorDropCmdDeltaAvg
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifCfgInvalidDelta

障害コード : F34653

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifCfgInvalidDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34653
mibFaultName: tcaAdaptorDropLifCfgInvalidDelta
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifCfgInvalidDeltaMin

障害コード : F34654

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifCfgInvalidDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34654
mibFaultName: tcaAdaptorDropLifCfgInvalidDeltaMin
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifCfgInvalidDeltaMax

障害コード : F34655

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifCfgInvalidDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34655
mibFaultName: tcaAdaptorDropLifCfgInvalidDeltaMax
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifCfgInvalidDeltaAvg

障害コード : F34656

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifCfgInvalidDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34656
mibFaultName: tcaAdaptorDropLifCfgInvalidDeltaAvg
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifMapNoHitDelta

障害コード : F34663

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifMapNoHitDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34663
mibFaultName: tcaAdaptorDropLifMapNoHitDelta
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropLifMapNoHitDeltaMin

障害コード : F34664

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifMapNoHitDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34664
mibFaultName: tcaAdaptorDropLifMapNoHitDeltaMin
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropLifMapNoHitDeltaMax

障害コード : F34665

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifMapNoHitDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34665
mibFaultName: tcaAdaptorDropLifMapNoHitDeltaMax
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropLifMapNoHitDeltaAvg

障害コード : F34666

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropLifMapNoHitDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34666
mibFaultName: tcaAdaptorDropLifMapNoHitDeltaAvg
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropSrcBindDelta

障害コード : F34673

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropSrcBindDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34673
mibFaultName: tcaAdaptorDropSrcBindDelta
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropSrcBindDeltaMin

障害コード : F34674

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropSrcBindDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34674
mibFaultName: tcaAdaptorDropSrcBindDeltaMin
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
```

tcaAdaptorDropSrcBindDeltaMax

障害コード : F34675

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropSrcBindDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34675
mibFaultName: tcaAdaptorDropSrcBindDeltaMax
moClass: adaptor:MenloNetEgStats
Type: server
```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorDropSrcBindDeltaAvg

障害コード : F34676

Message: Threshold Crossed: adaptor:MenloNetEgStats property: dropSrcBindDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34676
mibFaultName: tcaAdaptorDropSrcBindDeltaAvg
moClass: adaptor:MenloNetEgStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-eg-stats-[menloNetIndex]

```

tcaAdaptorFwdLookupNoHitDelta

障害コード : F34688

Message: Threshold Crossed: adaptor:MenloNetInStats property: fwdLookupNoHitDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34688
mibFaultName: tcaAdaptorFwdLookupNoHitDelta
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorFwdLookupNoHitDeltaMin

障害コード : F34689

Message: Threshold Crossed: adaptor:MenloNetInStats property: fwdLookupNoHitDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34689
mibFaultName: tcaAdaptorFwdLookupNoHitDeltaMin
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorFwdLookupNoHitDeltaMax

障害コード : F34690

Message: Threshold Crossed: adaptor:MenloNetInStats property: fwdLookupNoHitDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34690
mibFaultName: tcaAdaptorFwdLookupNoHitDeltaMax
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorFwdLookupNoHitDeltaAvg

障害コード : F34691

Message: Threshold Crossed: adaptor:MenloNetInStats property: fwdLookupNoHitDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34691
```

```

mibFaultName: tcaAdaptorFwdLookupNoHitDeltaAvg
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorDropFcMulticastDelta

障害コード : F34698

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcMulticastDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34698
mibFaultName: tcaAdaptorDropFcMulticastDelta
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorDropFcMulticastDeltaMin

障害コード : F34699

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcMulticastDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34699
mibFaultName: tcaAdaptorDropFcMulticastDeltaMin
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorDropFcMulticastDeltaMax

障害コード : F34700

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcMulticastDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34700
mibFaultName: tcaAdaptorDropFcMulticastDeltaMax
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropFcMulticastDeltaAvg

障害コード : F34701

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcMulticastDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34701
mibFaultName: tcaAdaptorDropFcMulticastDeltaAvg
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropFcLifInvalidDelta

障害コード : F34708

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcLifInvalidDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34708
mibFaultName: tcaAdaptorDropFcLifInvalidDelta
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorDropFcLifInvalidDeltaMin

障害コード : F34709

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcLifInvalidDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34709
mibFaultName: tcaAdaptorDropFcLifInvalidDeltaMin
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorDropFcLifInvalidDeltaMax

障害コード : F34710

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcLifInvalidDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34710
mibFaultName: tcaAdaptorDropFcLifInvalidDeltaMax
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropFcLifInvalidDeltaAvg

障害コード : F34711

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropFcLifInvalidDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34711
mibFaultName: tcaAdaptorDropFcLifInvalidDeltaAvg
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropNullPifDelta

障害コード : F34718

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropNullPifDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34718
mibFaultName: tcaAdaptorDropNullPifDelta
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropNullPifDeltaMin

障害コード : F34719

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropNullPifDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34719
mibFaultName: tcaAdaptorDropNullPifDeltaMin
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropNullPifDeltaMax

障害コード : F34720

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropNullPifDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34720
mibFaultName: tcaAdaptorDropNullPifDeltaMax
moClass: adaptor:MenloNetInStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
```

tcaAdaptorDropNullPifDeltaAvg

障害コード : F34721

Message: Threshold Crossed: adaptor:MenloNetInStats property: dropNullPifDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34721
mibFaultName: tcaAdaptorDropNullPifDeltaAvg
moClass: adaptor:MenloNetInStats
Type: server
```



```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-net-in-stats-[menloNetIndex]

```

tcaAdaptorRxPauseCFCDelta

障害コード : F34733

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34733
mibFaultName: tcaAdaptorRxPauseCFCDelta
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

```

tcaAdaptorRxPauseCFCDeltaMin

障害コード : F34734

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34734
mibFaultName: tcaAdaptorRxPauseCFCDeltaMin
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

```

tcaAdaptorRxPauseCFCDeltaMax

障害コード : F34735

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34735
mibFaultName: tcaAdaptorRxPauseCFCDeltaMax
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorRxPauseCFCDeltaAvg

障害コード : F34736

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34736
mibFaultName: tcaAdaptorRxPauseCFCDeltaAvg
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorRxPausePFCDelta

障害コード : F34743

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPausePFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34743
```

```

mibFaultName: tcaAdaptorRxPausePFCDelta
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

```

tcaAdaptorRxPausePFCDeltaMin

障害コード : F34744

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPausePFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34744
mibFaultName: tcaAdaptorRxPausePFCDeltaMin
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

```

tcaAdaptorRxPausePFCDeltaMax

障害コード : F34745

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPausePFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34745
mibFaultName: tcaAdaptorRxPausePFCDeltaMax
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

```

tcaAdaptorRxPausePFCDeltaAvg

障害コード : F34746

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPausePFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34746
mibFaultName: tcaAdaptorRxPausePFCDeltaAvg
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDelta

障害コード : F34753

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34753
mibFaultName: tcaAdaptorTxPauseCFCDelta
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDeltaMin

障害コード : F34754

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34754
mibFaultName: tcaAdaptorTxPauseCFCDeltaMin
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDeltaMax

障害コード : F34755

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34755
mibFaultName: tcaAdaptorTxPauseCFCDeltaMax
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDeltaAvg

障害コード : F34756

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34756
mibFaultName: tcaAdaptorTxPauseCFCDeltaAvg
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

tcaAdaptorTxPausePFCDelta

障害コード : F34763

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPausePFCDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34763
mibFaultName: tcaAdaptorTxPausePFCDelta
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

tcaAdaptorTxPausePFCDeltaMin

障害コード : F34764

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34764
mibFaultName: tcaAdaptorTxPausePFCDeltaMin
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]

tcaAdaptorTxPausePFCDeltaMax

障害コード : F34765

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34765
mibFaultName: tcaAdaptorTxPausePFCDeltaMax
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorTxPausePFCDeltaAvg

障害コード : F34766

Message: Threshold Crossed: adaptor:MenloHostPortStats property: txPausePFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34766
mibFaultName: tcaAdaptorTxPausePFCDeltaAvg
moClass: adaptor:MenloHostPortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-host-port-stats-[menloPortIndex]
```

tcaAdaptorRxPauseCFCDelta

障害コード : F34778

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34778
mibFaultName: tcaAdaptorRxPauseCFCDelta
moClass: adaptor:MenloDcePortStats
Type: server
```

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorRxPauseCFCDeltaMin

障害コード : F34779

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34779
mibFaultName: tcaAdaptorRxPauseCFCDeltaMin
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorRxPauseCFCDeltaMax

障害コード : F34780

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34780
mibFaultName: tcaAdaptorRxPauseCFCDeltaMax
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorRxPauseCFCDeltaAvg

障害コード : F34781

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34781
mibFaultName: tcaAdaptorRxPauseCFCDeltaAvg
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorRxPausePFCDelta

障害コード : F34788

Message: Threshold Crossed: adaptor:MenloDcePortStats property: rxPausePFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34788
mibFaultName: tcaAdaptorRxPausePFCDelta
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorRxPausePFCDeltaMin

障害コード : F34789

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34789
```

```

mibFaultName: tcaAdaptorRxPausePFCDeltaMin
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorRxPausePFCDeltaMax

障害コード : F34790

Message: Threshold Crossed: adaptor:MenloHostPortStats property: rxPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34790
mibFaultName: tcaAdaptorRxPausePFCDeltaMax
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorRxPausePFCDeltaAvg

障害コード : F34791

Message: Threshold Crossed: adaptor:MenloDcePortStats property: rxPausePFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34791
mibFaultName: tcaAdaptorRxPausePFCDeltaAvg
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorTxPauseCFCDelta

障害コード : F34798

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPauseCFCDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34798
mibFaultName: tcaAdaptorTxPauseCFCDelta
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDeltaMin

障害コード : F34799

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPauseCFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34799
mibFaultName: tcaAdaptorTxPauseCFCDeltaMin
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxPauseCFCDeltaMax

障害コード : F34800

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPauseCFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34800
mibFaultName: tcaAdaptorTxPauseCFCDeltaMax
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorTxPauseCFCDeltaAvg

障害コード : F34801

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPauseCFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34801
mibFaultName: tcaAdaptorTxPauseCFCDeltaAvg
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]

```

tcaAdaptorTxPausePFCDelta

障害コード : F34808

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPausePFCDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34808
mibFaultName: tcaAdaptorTxPausePFCDelta
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:

```

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxPausePFCDeltaMin

障害コード : F34809

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPausePFCDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F34809  
mibFaultName: tcaAdaptorTxPausePFCDeltaMin  
moClass: adaptor:MenloDcePortStats  
Type: server  
autoCleared: true  
Affected MO:  
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxPausePFCDeltaMax

障害コード : F34810

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPausePFCDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F34810  
mibFaultName: tcaAdaptorTxPausePFCDeltaMax  
moClass: adaptor:MenloDcePortStats  
Type: server  
autoCleared: true  
Affected MO:  
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]  
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxPausePFCDeltaAvg

障害コード : F34811

Message: Threshold Crossed: adaptor:MenloDcePortStats property: txPausePFCDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34811
mibFaultName: tcaAdaptorTxPausePFCDeltaAvg
moClass: adaptor:MenloDcePortStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/menlo-dce-port-stats-[menloPortIndex]
```

tcaAdaptorTxBytesDelta

障害コード : F34822

Message: Threshold Crossed: adaptor:EtherIfStats property: txBytesDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34822
mibFaultName: tcaAdaptorTxBytesDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorTxBytesDeltaMin

障害コード : F34823

Message: Threshold Crossed: adaptor:EtherIfStats property: txBytesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34823
mibFaultName: tcaAdaptorTxBytesDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorTxBytesDeltaMax

障害コード : F34824

Message: Threshold Crossed: adaptor:EtherIfStats property: txBytesDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34824
mibFaultName: tcaAdaptorTxBytesDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

tcaAdaptorTxBytesDeltaAvg

障害コード : F34825

Message: Threshold Crossed: adaptor:EtherIfStats property: txBytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34825
mibFaultName: tcaAdaptorTxBytesDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorTxPacketsDelta

障害コード : F34832

Message: Threshold Crossed: adaptor:EtherIfStats property: txPacketsDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34832
mibFaultName: tcaAdaptorTxPacketsDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
```



```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxPacketsDeltaMin

障害コード : F34833

Message: Threshold Crossed: adaptor:EtherIfStats property: txPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34833
mibFaultName: tcaAdaptorTxPacketsDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxPacketsDeltaMax

障害コード : F34834

Message: Threshold Crossed: adaptor:EtherIfStats property: txPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34834
mibFaultName: tcaAdaptorTxPacketsDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxPacketsDeltaAvg

障害コード : F34835

Message: Threshold Crossed: adaptor:EtherIfStats property: txPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34835
mibFaultName: tcaAdaptorTxPacketsDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxErrorsDelta

障害コード : F34842

Message: Threshold Crossed: adaptor:EtherIfStats property: txErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34842
mibFaultName: tcaAdaptorTxErrorsDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxErrorsDeltaMin

障害コード : F34843

Message: Threshold Crossed: adaptor:EtherIfStats property: txErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34843
mibFaultName: tcaAdaptorTxErrorsDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxErrorsDeltaMax

障害コード : F34844

Message: Threshold Crossed: adaptor:EtherIfStats property: txErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34844
mibFaultName: tcaAdaptorTxErrorsDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxErrorsDeltaAvg

障害コード : F34845

Message: Threshold Crossed: adaptor:EtherIfStats property: txErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34845

```

```

mibFaultName: tcaAdaptorTxErrorsDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxDroppedDelta

障害コード : F34852

Message: Threshold Crossed: adaptor:EtherIfStats property: txDroppedDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34852
mibFaultName: tcaAdaptorTxDroppedDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorTxDroppedDeltaMin

障害コード : F34853

Message: Threshold Crossed: adaptor:EtherIfStats property: txDroppedDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34853
mibFaultName: tcaAdaptorTxDroppedDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorTxDroppedDeltaMax

障害コード : F34854

Message: Threshold Crossed: adaptor:EtherIfStats property: txDroppedDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34854
mibFaultName: tcaAdaptorTxDroppedDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

tcaAdaptorTxDroppedDeltaAvg

障害コード : F34855

Message: Threshold Crossed: adaptor:EtherIfStats property: txDroppedDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34855
mibFaultName: tcaAdaptorTxDroppedDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

tcaAdaptorRxBytesDelta

障害コード : F34862

Message: Threshold Crossed: adaptor:EtherIfStats property: rxBytesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34862
mibFaultName: tcaAdaptorRxBytesDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:

```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxBytesDeltaMin

障害コード : F34863

Message: Threshold Crossed: adaptor:EtherIfStats property: rxBytesDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34863
mibFaultName: tcaAdaptorRxBytesDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxBytesDeltaMax

障害コード : F34864

Message: Threshold Crossed: adaptor:EtherIfStats property: rxBytesDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34864
mibFaultName: tcaAdaptorRxBytesDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxBytesDeltaAvg

障害コード : F34865

Message: Threshold Crossed: adaptor:EtherIfStats property: rxBytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34865
mibFaultName: tcaAdaptorRxBytesDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxPacketsDelta

障害コード : F34872

Message: Threshold Crossed: adaptor:EtherIfStats property: rxPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34872
mibFaultName: tcaAdaptorRxPacketsDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxPacketsDeltaMin

障害コード : F34873

Message: Threshold Crossed: adaptor:EtherIfStats property: rxPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34873
mibFaultName: tcaAdaptorRxPacketsDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:

```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxPacketsDeltaMax

障害コード : F34874

Message: Threshold Crossed: adaptor:EtherIfStats property: rxPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34874
mibFaultName: tcaAdaptorRxPacketsDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxPacketsDeltaAvg

障害コード : F34875

Message: Threshold Crossed: adaptor:EtherIfStats property: rxPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34875

```

```

mibFaultName: tcaAdaptorRxPacketsDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxErrorsDelta

障害コード : F34882

Message: Threshold Crossed: adaptor:EtherIfStats property: rxErrorsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34882
mibFaultName: tcaAdaptorRxErrorsDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxErrorsDeltaMin

障害コード : F34883

Message: Threshold Crossed: adaptor:EtherIfStats property: rxErrorsDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34883
mibFaultName: tcaAdaptorRxErrorsDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorRxErrorsDeltaMax

障害コード : F34884

Message: Threshold Crossed: adaptor:EtherIfStats property: rxErrorsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34884
mibFaultName: tcaAdaptorRxErrorsDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

tcaAdaptorRxErrorsDeltaAvg

障害コード : F34885

Message: Threshold Crossed: adaptor:EtherIfStats property: rxErrorsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34885
mibFaultName: tcaAdaptorRxErrorsDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

tcaAdaptorRxDroppedDelta

障害コード : F34892

Message: Threshold Crossed: adaptor:EtherIfStats property: rxDroppedDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34892
mibFaultName: tcaAdaptorRxDroppedDelta
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:

```

sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxDroppedDeltaMin

障害コード : F34893

Message: Threshold Crossed: adaptor:EtherIfStats property: rxDroppedDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34893
mibFaultName: tcaAdaptorRxDroppedDeltaMin
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats

```

tcaAdaptorRxDroppedDeltaMax

障害コード : F34894

Message: Threshold Crossed: adaptor:EtherIfStats property: rxDroppedDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34894
mibFaultName: tcaAdaptorRxDroppedDeltaMax
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```

tcaAdaptorRxDroppedDeltaAvg

障害コード : F34895

Message: Threshold Crossed: adaptor:EtherIfStats property: txDroppedDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34895
mibFaultName: tcaAdaptorRxDroppedDeltaAvg
moClass: adaptor:EtherIfStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-iscsi-[id]/vlan-[id]/ether-if-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-service-eth-[id]/vlan-[id]/ether-if-stats
```


tcaAdaptorTxFramesDelta

障害コード : F34906

Message: Threshold Crossed: adaptor:FcIfFrameStats property: txFramesDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34906
mibFaultName: tcaAdaptorTxFramesDelta
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
```

tcaAdaptorTxFramesDeltaMin

障害コード : F34907

Message: Threshold Crossed: adaptor:FcIfFrameStats property: txFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34907
mibFaultName: tcaAdaptorTxFramesDeltaMin
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
```

tcaAdaptorTxFramesDeltaMax

障害コード : F34908

Message: Threshold Crossed: adaptor:FcIfFrameStats property: txFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F34908
mibFaultName: tcaAdaptorTxFramesDeltaMax
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorTxFramesDeltaAvg

障害コード : F34909

Message: Threshold Crossed: adaptor:FcIfFrameStats property: txFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34909
mibFaultName: tcaAdaptorTxFramesDeltaAvg
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorRxFramesDelta

障害コード : F34916

Message: Threshold Crossed: adaptor:FcIfFrameStats property: rxFramesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34916
mibFaultName: tcaAdaptorRxFramesDelta
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorRxFramesDeltaMin

障害コード : F34917

Message: Threshold Crossed: adaptor:FcIfFrameStats property: rxFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34917
mibFaultName: tcaAdaptorRxFramesDeltaMin
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
```

tcaAdaptorRxFramesDeltaMax

障害コード : F34918

Message: Threshold Crossed: adaptor:FcIfFrameStats property: rxFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34918
mibFaultName: tcaAdaptorRxFramesDeltaMax
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
```

tcaAdaptorRxFramesDeltaAvg

障害コード : F34919

Message: Threshold Crossed: adaptor:FcIfFrameStats property: rxFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F34919
mibFaultName: tcaAdaptorRxFramesDeltaAvg
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorErrorFramesDelta

障害コード : F34926

Message: Threshold Crossed: adaptor:FcIfFrameStats property: errorFramesDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34926
mibFaultName: tcaAdaptorErrorFramesDelta
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorErrorFramesDeltaMin

障害コード : F34927

Message: Threshold Crossed: adaptor:FcIfFrameStats property: errorFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34927
mibFaultName: tcaAdaptorErrorFramesDeltaMin
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorErrorFramesDeltaMax

障害コード : F34928

Message: Threshold Crossed: adaptor:FcIfFrameStats property: errorFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34928
mibFaultName: tcaAdaptorErrorFramesDeltaMax
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

tcaAdaptorErrorFramesDeltaAvg

障害コード : F34929

Message: Threshold Crossed: adaptor:FcIfFrameStats property: errorFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34929
mibFaultName: tcaAdaptorErrorFramesDeltaAvg
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

tcaAdaptorDumpedFramesDelta

障害コード : F34936

Message: Threshold Crossed: adaptor:FcIfFrameStats property: dumpedFramesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34936
mibFaultName: tcaAdaptorDumpedFramesDelta
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorDumpedFramesDeltaMin

障害コード : F34937

Message: Threshold Crossed: adaptor:FcIfFrameStats property: dumpedFramesDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34937
mibFaultName: tcaAdaptorDumpedFramesDeltaMin
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorDumpedFramesDeltaMax

障害コード : F34938

Message: Threshold Crossed: adaptor:FcIfFrameStats property: dumpedFramesDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34938
mibFaultName: tcaAdaptorDumpedFramesDeltaMax
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats

```

tcaAdaptorDumpedFramesDeltaAvg

障害コード : F34939

Message: Threshold Crossed: adaptor:FcIfFrameStats property: dumpedFramesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34939
mibFaultName: tcaAdaptorDumpedFramesDeltaAvg
moClass: adaptor:FcIfFrameStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-frame-stats
```

tcaAdaptorLipCountDelta

障害コード : F34950

Message: Threshold Crossed: adaptor:FcIfEventStats property: lipCountDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34950
mibFaultName: tcaAdaptorLipCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorLipCountDeltaMin

障害コード : F34951

Message: Threshold Crossed: adaptor:FcIfEventStats property: lipCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F34951
mibFaultName: tcaAdaptorLipCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLipCountDeltaMax

障害コード : F34952

Message: Threshold Crossed: adaptor:FcIfEventStats property: lipCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34952
mibFaultName: tcaAdaptorLipCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLipCountDeltaAvg

障害コード : F34953

Message: Threshold Crossed: adaptor:FcIfEventStats property: lipCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34953
mibFaultName: tcaAdaptorLipCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```


tcaAdaptorInvalidCRCCountDelta

障害コード : F34960

Message: Threshold Crossed: adaptor:FcIfEventStats property: invalidCRCCountDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34960
mibFaultName: tcaAdaptorInvalidCRCCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorInvalidCRCCountDeltaMin

障害コード : F34961

Message: Threshold Crossed: adaptor:FcIfEventStats property: invalidCRCCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34961
mibFaultName: tcaAdaptorInvalidCRCCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorInvalidCRCCountDeltaMax

障害コード : F34962

Message: Threshold Crossed: adaptor:FcIfEventStats property: invalidCRCCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F34962
mibFaultName: tcaAdaptorInvalidCRCCCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorInvalidCRCCCountDeltaAvg

障害コード : F34963

Message: Threshold Crossed: adaptor:FcIfEventStats property: invalidCRCCCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34963
mibFaultName: tcaAdaptorInvalidCRCCCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorNOSCountDelta

障害コード : F34970

Message: Threshold Crossed: adaptor:FcIfEventStats property: nOSCountDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34970
mibFaultName: tcaAdaptorNOSCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorNOSCountDeltaMin

障害コード : F34971

Message: Threshold Crossed: adaptor:FcIfEventStats property: nOSCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34971
mibFaultName: tcaAdaptorNOSCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorNOSCountDeltaMax

障害コード : F34972

Message: Threshold Crossed: adaptor:FcIfEventStats property: nOSCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34972
mibFaultName: tcaAdaptorNOSCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorNOSCountDeltaAvg

障害コード : F34973

Message: Threshold Crossed: adaptor:FcIfEventStats property: nOSCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F34973
mibFaultName: tcaAdaptorNOSCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLinkFailureCountDelta

障害コード : F34980

Message: Threshold Crossed: adaptor:FcIfEventStats property: linkFailureCountDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34980
mibFaultName: tcaAdaptorLinkFailureCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLinkFailureCountDeltaMin

障害コード : F34981

Message: Threshold Crossed: adaptor:FcIfEventStats property: linkFailureCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34981
mibFaultName: tcaAdaptorLinkFailureCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLinkFailureCountDeltaMax

障害コード : F34982

Message: Threshold Crossed: adaptor:FcIfEventStats property: linkFailureCountDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34982
mibFaultName: tcaAdaptorLinkFailureCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

tcaAdaptorLinkFailureCountDeltaAvg

障害コード : F34983

Message: Threshold Crossed: adaptor:FcIfEventStats property: linkFailureCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F34983
mibFaultName: tcaAdaptorLinkFailureCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

tcaAdaptorLossOfSyncCountDelta

障害コード : F34990

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSyncCountDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F34990
mibFaultName: tcaAdaptorLossOfSyncCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLossOfSyncCountDeltaMin

障害コード : F34991

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSyncCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34991
mibFaultName: tcaAdaptorLossOfSyncCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLossOfSyncCountDeltaMax

障害コード : F34992

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSyncCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F34992
mibFaultName: tcaAdaptorLossOfSyncCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLossOfSyncCountDeltaAvg

障害コード : F34993

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSyncCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F34993
mibFaultName: tcaAdaptorLossOfSyncCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorLossOfSignalCountDelta

障害コード : F35000

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSignalCountDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35000
mibFaultName: tcaAdaptorLossOfSignalCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorLossOfSignalCountDeltaMin

障害コード : F35001

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSignalCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F35001
mibFaultName: tcaAdaptorLossOfSignalCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLossOfSignalCountDeltaMax

障害コード : F35002

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSignalCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35002
mibFaultName: tcaAdaptorLossOfSignalCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorLossOfSignalCountDeltaAvg

障害コード : F35003

Message: Threshold Crossed: adaptor:FcIfEventStats property: lossOfSignalCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35003
mibFaultName: tcaAdaptorLossOfSignalCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```


tcaAdaptorSeqProtocolErrCountDelta

障害コード : F35010

Message: Threshold Crossed: adaptor:FcIfEventStats property: seqProtocolErrCountDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35010
mibFaultName: tcaAdaptorSeqProtocolErrCountDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorSeqProtocolErrCountDeltaMin

障害コード : F35011

Message: Threshold Crossed: adaptor:FcIfEventStats property: seqProtocolErrCountDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35011
mibFaultName: tcaAdaptorSeqProtocolErrCountDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorSeqProtocolErrCountDeltaMax

障害コード : F35012

Message: Threshold Crossed: adaptor:FcIfEventStats property: seqProtocolErrCountDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F35012
mibFaultName: tcaAdaptorSeqProtocolErrCountDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorSeqProtocolErrCountDeltaAvg

障害コード : F35013

Message: Threshold Crossed: adaptor:FcIfEventStats property: seqProtocolErrCountDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35013
mibFaultName: tcaAdaptorSeqProtocolErrCountDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorSecondsSinceLastResetDelta

障害コード : F35020

Message: Threshold Crossed: adaptor:FcIfEventStats property: secondsSinceLastResetDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35020
mibFaultName: tcaAdaptorSecondsSinceLastResetDelta
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaAdaptorSecondsSinceLastResetDeltaMin

障害コード : F35021

Message: Threshold Crossed: adaptor:FcIfEventStats property: secondsSinceLastResetDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35021
mibFaultName: tcaAdaptorSecondsSinceLastResetDeltaMin
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorSecondsSinceLastResetDeltaMax

障害コード : F35022

Message: Threshold Crossed: adaptor:FcIfEventStats property: secondsSinceLastResetDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35022
mibFaultName: tcaAdaptorSecondsSinceLastResetDeltaMax
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
```

tcaAdaptorSecondsSinceLastResetDeltaAvg

障害コード : F35023

Message: Threshold Crossed: adaptor:FcIfEventStats property: secondsSinceLastResetDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F35023
mibFaultName: tcaAdaptorSecondsSinceLastResetDeltaAvg
moClass: adaptor:FcIfEventStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-fc-[id]/fc-if-event-stats
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-fc-[id]/fc-if-event-stats

```

tcaSwMainBoardOutlet1

障害コード : F35166

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet1

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35166
mibFaultName: tcaSwMainBoardOutlet1
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwMainBoardOutlet1Min

障害コード : F35168

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet1Min

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35168
mibFaultName: tcaSwMainBoardOutlet1Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwMainBoardOutlet1Max

障害コード : F35169

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet1Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35169
mibFaultName: tcaSwMainBoardOutlet1Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMainBoardOutlet1Avg

障害コード : F35170

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet1Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35170
mibFaultName: tcaSwMainBoardOutlet1Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMainBoardOutlet2

障害コード : F35174

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet2

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35174
mibFaultName: tcaSwMainBoardOutlet2
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMainBoardOutlet2Min

障害コード : F35176

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet2Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35176
mibFaultName: tcaSwMainBoardOutlet2Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMainBoardOutlet2Max

障害コード : F35177

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet2Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35177
mibFaultName: tcaSwMainBoardOutlet2Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMainBoardOutlet2Avg

障害コード : F35178

Message: Threshold Crossed: sw:EnvStats property: mainBoardOutlet2Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35178
mibFaultName: tcaSwMainBoardOutlet2Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet1

障害コード : F35198

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet1

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35198
mibFaultName: tcaSwFanCtrlrInlet1
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet1Min

障害コード : F35200

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet1Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35200
mibFaultName: tcaSwFanCtrlrInlet1Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet1Max

障害コード : F35201

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet1Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35201
mibFaultName: tcaSwFanCtrlrInlet1Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet1Avg

障害コード : F35202

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet1Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35202
mibFaultName: tcaSwFanCtrlrInlet1Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet2

障害コード : F35206

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet2

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35206
mibFaultName: tcaSwFanCtrlrInlet2
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet2Min

障害コード : F35208

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet2Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35208
mibFaultName: tcaSwFanCtrlrInlet2Min
moClass: sw:EnvStats
Type: generic
```



```
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet2Max

障害コード : F35209

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet2Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35209
mibFaultName: tcaSwFanCtrlrInlet2Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet2Avg

障害コード : F35210

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet2Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35210
mibFaultName: tcaSwFanCtrlrInlet2Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet3

障害コード : F35214

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet3

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35214
```

```

mibFaultName: tcaSwFanCtrlrInlet3
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwFanCtrlrInlet3Min

障害コード : F35216

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet3Min

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35216
mibFaultName: tcaSwFanCtrlrInlet3Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwFanCtrlrInlet3Max

障害コード : F35217

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet3Max

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35217
mibFaultName: tcaSwFanCtrlrInlet3Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwFanCtrlrInlet3Avg

障害コード : F35218

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet3Avg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35218
mibFaultName: tcaSwFanCtrlrInlet3Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwFanCtrlrInlet4

障害コード : F35222

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet4

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35222
mibFaultName: tcaSwFanCtrlrInlet4
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwFanCtrlrInlet4Min

障害コード : F35224

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet4Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35224
mibFaultName: tcaSwFanCtrlrInlet4Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwFanCtrlrInlet4Max

障害コード : F35225

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet4Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35225
mibFaultName: tcaSwFanCtrlrInlet4Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwFanCtrlrInlet4Avg

障害コード : F35226

Message: Threshold Crossed: sw:EnvStats property: fanCtrlrInlet4Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35226
mibFaultName: tcaSwFanCtrlrInlet4Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwMemAvailable

障害コード : F35234

Message: Threshold Crossed: sw:SystemStats property: memAvailable

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35234
mibFaultName: tcaSwMemAvailable
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemAvailableMin

障害コード : F35236

Message: Threshold Crossed: sw:SystemStats property: memAvailableMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35236
mibFaultName: tcaSwMemAvailableMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemAvailableMax

障害コード : F35237

Message: Threshold Crossed: sw:SystemStats property: memAvailableMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35237
mibFaultName: tcaSwMemAvailableMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemAvailableAvg

障害コード : F35238

Message: Threshold Crossed: sw:SystemStats property: memAvailableAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35238
mibFaultName: tcaSwMemAvailableAvg
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemCached

障害コード : F35242

Message: Threshold Crossed: sw:SystemStats property: memCached

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35242
mibFaultName: tcaSwMemCached
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemCachedMin

障害コード : F35244

Message: Threshold Crossed: sw:SystemStats property: memCachedMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35244
mibFaultName: tcaSwMemCachedMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemCachedMax

障害コード : F35245

Message: Threshold Crossed: sw:SystemStats property: memCachedMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35245
mibFaultName: tcaSwMemCachedMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwMemCachedAvg

障害コード : F35246

Message: Threshold Crossed: sw:SystemStats property: memCachedAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35246
mibFaultName: tcaSwMemCachedAvg
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwLoad

障害コード : F35250

Message: Threshold Crossed: sw:SystemStats property: load

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35250
mibFaultName: tcaSwLoad
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwLoadMin

障害コード : F35252

Message: Threshold Crossed: sw:SystemStats property: loadMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35252
mibFaultName: tcaSwLoadMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwLoadMax

障害コード : F35253

Message: Threshold Crossed: sw:SystemStats property: load

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35253
mibFaultName: tcaSwLoadMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwLoadAvg

障害コード : F35254

Message: Threshold Crossed: sw:SystemStats property: loadAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35254
mibFaultName: tcaSwLoadAvg
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaEtherTotalBytesDelta

障害コード : F35275

Message: Threshold Crossed: ether:TxStats property: totalBytesDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35275
mibFaultName: tcaEtherTotalBytesDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
```


Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalBytesDeltaMin

障害コード : F35276

Message: Threshold Crossed: ether:TxStats property: totalBytesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35276
mibFaultName: tcaEtherTotalBytesDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalBytesDeltaMax

障害コード : F35277

Message: Threshold Crossed: ether:TxStats property: totalBytesDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35277
mibFaultName: tcaEtherTotalBytesDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalBytesDeltaAvg

障害コード : F35278

Message: Threshold Crossed: ether:TxStats property: totalBytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35278
mibFaultName: tcaEtherTotalBytesDeltaAvg

```

moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherTotalPacketsDelta

障害コード : F35285

Message: Threshold Crossed: ether:TxStats property: totalPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35285
mibFaultName: tcaEtherTotalPacketsDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats

```

Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalPacketsDeltaMin

障害コード : F35286

Message: Threshold Crossed: ether:TxStats property: totalPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35286
mibFaultName: tcaEtherTotalPacketsDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalPacketsDeltaMax

障害コード : F35287

Message: Threshold Crossed: ether:TxStats property: totalPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F35287
mibFaultName: tcaEtherTotalPacketsDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherTotalPacketsDeltaAvg

障害コード : F35288

Message: Threshold Crossed: ether:TxStats property: totalPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35288
mibFaultName: tcaEtherTotalPacketsDeltaAvg
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats

```

Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherMulticastPacketsDelta

障害コード : F35295

Message: Threshold Crossed: ether:TxStats property: multicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35295
mibFaultName: tcaEtherMulticastPacketsDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherMulticastPacketsDeltaMin

障害コード : F35296

Message: Threshold Crossed: ether:TxStats property: multicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35296
mibFaultName: tcaEtherMulticastPacketsDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherMulticastPacketsDeltaMax

障害コード : F35297

Message: Threshold Crossed: ether:TxStats property: multicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35297
mibFaultName: tcaEtherMulticastPacketsDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

```

sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherMulticastPacketsDeltaAvg

障害コード : F35298

Message: Threshold Crossed: ether:TxStats property: multicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35298
mibFaultName: tcaEtherMulticastPacketsDeltaAvg
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherBroadcastPacketsDelta

障害コード : F35305

Message: Threshold Crossed: ether:TxStats property: broadcastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35305
mibFaultName: tcaEtherBroadcastPacketsDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherBroadcastPacketsDeltaMin

障害コード : F35306

Message: Threshold Crossed: ether:TxStats property: broadcastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35306
mibFaultName: tcaEtherBroadcastPacketsDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherBroadcastPacketsDeltaMax

障害コード : F35307

Message: Threshold Crossed: ether:TxStats property: broadcastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35307
mibFaultName: tcaEtherBroadcastPacketsDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherBroadcastPacketsDeltaAvg

障害コード : F35308

Message: Threshold Crossed: ether:TxStats property: broadcastPacketsDeltaAvg

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35308
mibFaultName: tcaEtherBroadcastPacketsDeltaAvg
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats
```

tcaEtherJumboPacketsDelta

障害コード：F35315

Message: Threshold Crossed: ether:TxStats property: jumboPacketsDelta

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35315
mibFaultName: tcaEtherJumboPacketsDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
```

```

sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherJumboPacketsDeltaMin

障害コード : F35316

Message: Threshold Crossed: ether:TxStats property: jumboPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35316
mibFaultName: tcaEtherJumboPacketsDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherJumboPacketsDeltaMax

障害コード : F35317

Message: Threshold Crossed: ether:TxStats property: jumboPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35317
mibFaultName: tcaEtherJumboPacketsDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats
```

tcaEtherJumboPacketsDeltaAvg

障害コード : F35318

Message: Threshold Crossed: ether:TxStats property: jumboPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35318
mibFaultName: tcaEtherJumboPacketsDeltaAvg
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
```

Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherTotalBytesDelta

障害コード : F35329

Message: Threshold Crossed: ether:RxStats property: totalBytesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35329
mibFaultName: tcaEtherTotalBytesDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherTotalBytesDeltaMin

障害コード : F35330

Message: Threshold Crossed: ether:RxStats property: totalBytesDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35330
mibFaultName: tcaEtherTotalBytesDeltaMin
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherTotalBytesDeltaMax

障害コード : F35331

Message: Threshold Crossed: ether:RxStats property: totalBytesDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35331
mibFaultName: tcaEtherTotalBytesDeltaMax

```

moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherTotalBytesDeltaAvg

障害コード : F35332

Message: Threshold Crossed: ether:RxStats property: totalBytesDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35332
mibFaultName: tcaEtherTotalBytesDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats

```


Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherTotalPacketsDelta

障害コード : F35339

Message: Threshold Crossed: ether:TxStats property: totalPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35339
mibFaultName: tcaEtherTotalPacketsDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherTotalPacketsDeltaMin

障害コード : F35340

Message: Threshold Crossed: ether:TxStats property: totalPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F35340
mibFaultName: tcaEtherTotalPacketsDeltaMin
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherTotalPacketsDeltaMax

障害コード : F35341

Message: Threshold Crossed: ether:TxStats property: totalPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35341
mibFaultName: tcaEtherTotalPacketsDeltaMax
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats

```

Affected MO:

```

sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherTotalPacketsDeltaAvg

障害コード : F35342

Message: Threshold Crossed: ether:RxStats property: totalPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35342
mibFaultName: tcaEtherTotalPacketsDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherUnicastPacketsDelta

障害コード : F35349

Message: Threshold Crossed: ether:RxStats property: unicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35349
mibFaultName: tcaEtherUnicastPacketsDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherUnicastPacketsDeltaMin

障害コード : F35350

Message: Threshold Crossed: ether:RxStats property: unicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35350
mibFaultName: tcaEtherUnicastPacketsDeltaMin
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:

```

```

sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherUnicastPacketsDeltaMax

障害コード : F35351

Message: Threshold Crossed: ether:RxStats property: unicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35351
mibFaultName: tcaEtherUnicastPacketsDeltaMax
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherUnicastPacketsDeltaAvg

障害コード : F35352

Message: Threshold Crossed: ether:RxStats property: unicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35352
mibFaultName: tcaEtherUnicastPacketsDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherMulticastPacketsDelta

障害コード : F35359

Message: Threshold Crossed: ether:RxStats property: multicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35359
mibFaultName: tcaEtherMulticastPacketsDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherMulticastPacketsDeltaMin

障害コード : F35360

Message: Threshold Crossed: ether:RxStats property: multicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35360
mibFaultName: tcaEtherMulticastPacketsDeltaMin
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherMulticastPacketsDeltaMax

障害コード : F35361

Message: Threshold Crossed: ether:RxStats property: multicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35361
mibFaultName: tcaEtherMulticastPacketsDeltaMax
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats
```

tcaEtherMulticastPacketsDeltaAvg

障害コード : F35362

メッセージ: しきい値 Crossed: イーサ: RxStats プロパティ: multicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35362
mibFaultName: tcaEtherMulticastPacketsDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
```



```

sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherBroadcastPacketsDelta

障害コード : F35369

Message: Threshold Crossed: ether:RxStats property: broadcastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35369
mibFaultName: tcaEtherBroadcastPacketsDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherBroadcastPacketsDeltaMin

障害コード : F35370

Message: Threshold Crossed: ether:RxStats property: broadcastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35370
mibFaultName: tcaEtherBroadcastPacketsDeltaMin
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherBroadcastPacketsDeltaMax

障害コード : F35371

Message: Threshold Crossed: ether:RxStats property: broadcastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35371
mibFaultName: tcaEtherBroadcastPacketsDeltaMax
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats

```

Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherBroadcastPacketsDeltaAvg

障害コード : F35372

Message: Threshold Crossed: ether:RxStats property: broadcastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35372
mibFaultName: tcaEtherBroadcastPacketsDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherJumboPacketsDelta

障害コード : F35379

Message: Threshold Crossed: ether:RxStats property: jumboPacketsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35379
mibFaultName: tcaEtherJumboPacketsDelta
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherJumboPacketsDeltaMin

障害コード : F35380

Message: Threshold Crossed: ether:RxStats property: jumboPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35380
mibFaultName: tcaEtherJumboPacketsDeltaMin

```

moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

```

tcaEtherJumboPacketsDeltaMax

障害コード : F35381

Message: Threshold Crossed: ether:RxStats property: jumboPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35381
mibFaultName: tcaEtherJumboPacketsDeltaMax
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats

```

Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaEtherJumboPacketsDeltaAvg

障害コード : F35382

Message: Threshold Crossed: ether:RxStats property: jumboPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F35382
mibFaultName: tcaEtherJumboPacketsDeltaAvg
moClass: ether:RxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/rx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/rx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/rx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/rx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/rx-stats

tcaComputeConsumedPower

障害コード : F35962

Message: Threshold Crossed: compute:MbPowerStats property: consumedPower

説明 :

推奨処置 :

障害の詳細

Severity: info

```
Cause: threshold-crossed
mibFaultCode: F35962
mibFaultName: tcaComputeConsumedPower
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeConsumedPowerMin

障害コード : F35964

Message: Threshold Crossed: compute:MbPowerStats property: consumedPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35964
mibFaultName: tcaComputeConsumedPowerMin
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeConsumedPowerMax

障害コード : F35965

Message: Threshold Crossed: compute:MbPowerStats property: consumedPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F35965
mibFaultName: tcaComputeConsumedPowerMax
moClass: compute:MbPowerStats
Type: server
```

```

autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeConsumedPowerAvg

障害コード : F35966

Message: Threshold Crossed: compute:MbPowerStats property: consumedPowerAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35966
mibFaultName: tcaComputeConsumedPowerAvg
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeFmTempSenIo

障害コード : F35974

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenIo

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35974
mibFaultName: tcaComputeFmTempSenIo
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:

```



```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats  
Affected MO: sys/rack-unit-[id]/board/temp-stats  
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats
```

tcaComputeFmTempSenIoMin

障害コード : F35976

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenIoMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F35976  
mibFaultName: tcaComputeFmTempSenIoMin  
moClass: compute:MbTempStats  
Type: server  
autoCleared: true  
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats  
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats  
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats  
Affected MO: sys/rack-unit-[id]/board/temp-stats  
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats
```

tcaComputeFmTempSenIoMax

障害コード : F35977

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenIoMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F35977  
mibFaultName: tcaComputeFmTempSenIoMax  
moClass: compute:MbTempStats  
Type: server  
autoCleared: true  
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats  
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats  
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats  
Affected MO:  
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats  
Affected MO: sys/rack-unit-[id]/board/temp-stats  
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats
```

tcaComputeFmTempSenIoAvg

障害コード : F35978

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenIoAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F35978
mibFaultName: tcaComputeFmTempSenIoAvg
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaEquipmentInputPower

障害コード : F36234

Message: Threshold Crossed: equipment:ChassisStats property: inputPower

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36234
mibFaultName: tcaEquipmentInputPower
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

```

tcaEquipmentInputPowerMin

障害コード : F36236

Message: Threshold Crossed: equipment:ChassisStats property: inputPowerMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F36236
mibFaultName: tcaEquipmentInputPowerMin
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentInputPowerMax

障害コード : F36237

Message: Threshold Crossed: equipment:ChassisStats property: inputPowerMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36237
mibFaultName: tcaEquipmentInputPowerMax
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentInputPowerAvg

障害コード : F36238

Message: Threshold Crossed: equipment:ChassisStats property: inputPowerAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36238
mibFaultName: tcaEquipmentInputPowerAvg
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentOutputPower

障害コード : F36242

Message: Threshold Crossed: equipment:ChassisStats property: outputPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36242
mibFaultName: tcaEquipmentOutputPower
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats
```

tcaEquipmentOutputPowerMin

障害コード : F36244

Message: Threshold Crossed: equipment:ChassisStats property: outputPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36244
mibFaultName: tcaEquipmentOutputPowerMin
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats
```

tcaEquipmentOutputPowerMax

障害コード : F36245

Message: Threshold Crossed: equipment:ChassisStats property: outputPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36245
mibFaultName: tcaEquipmentOutputPowerMax
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats
```

tcaEquipmentOutputPowerAvg

障害コード : F36246

Message: Threshold Crossed: equipment:ChassisStats property: outputPowerAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36246
mibFaultName: tcaEquipmentOutputPowerAvg
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentAmbientTemp

障害コード : F36266

Message: Threshold Crossed: equipment:PsuStats property: ambientTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36266
mibFaultName: tcaEquipmentAmbientTemp
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentAmbientTempMin

障害コード : F36268

Message: Threshold Crossed: equipment:PsuStats property: ambientTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36268
mibFaultName: tcaEquipmentAmbientTempMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentAmbientTempMax

障害コード : F36269

Message: Threshold Crossed: equipment:PsuStats property: ambientTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36269
mibFaultName: tcaEquipmentAmbientTempMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentAmbientTempAvg

障害コード : F36270

Message: Threshold Crossed: equipment:PsuStats property: ambientTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36270
mibFaultName: tcaEquipmentAmbientTempAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutputCurrent

障害コード : F36274

Message: Threshold Crossed: equipment:PsuStats property: outputCurrent

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36274
mibFaultName: tcaEquipmentOutputCurrent
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutputCurrentMin

障害コード : F36276

Message: Threshold Crossed: equipment:PsuStats property: outputCurrentMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36276
mibFaultName: tcaEquipmentOutputCurrentMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutputCurrentMax

障害コード : F36277

Message: Threshold Crossed: equipment:PsuStats property: outputCurrentMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36277
mibFaultName: tcaEquipmentOutputCurrentMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
```

Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutputCurrentAvg

障害コード : F36278

Message: Threshold Crossed: equipment:PsuStats property: outputCurrentAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36278
mibFaultName: tcaEquipmentOutputCurrentAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutputPower

障害コード : F36282

Message: Threshold Crossed: equipment:PsuStats property: outputPower

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36282
mibFaultName: tcaEquipmentOutputPower
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutputPowerMin

障害コード : F36284

Message: Threshold Crossed: equipment:PsuStats property: outputPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36284
mibFaultName: tcaEquipmentOutputPowerMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutputPowerMax

障害コード : F36285

Message: Threshold Crossed: equipment:PsuStats property: outputPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36285
mibFaultName: tcaEquipmentOutputPowerMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutputPowerAvg

障害コード : F36286

Message: Threshold Crossed: equipment:PsuStats property: outputPowerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36286
mibFaultName: tcaEquipmentOutputPowerAvg
moClass: equipment:PsuStats
Type: generic
```

```
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentCurrent

障害コード : F36294

Message: Threshold Crossed: equipment:PsuInputStats property: current

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36294
mibFaultName: tcaEquipmentCurrent
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentCurrentMin

障害コード : F36296

Message: Threshold Crossed: equipment:PsuInputStats property: currentMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36296
mibFaultName: tcaEquipmentCurrentMin
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentCurrentMax

障害コード : F36297

Message: Threshold Crossed: equipment:PsuInputStats property: currentMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36297
mibFaultName: tcaEquipmentCurrentMax
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentCurrentAvg

障害コード : F36298

メッセージ: しきい値 Crossed: 機器: PsuInputStats プロパティ: currentAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36298
mibFaultName: tcaEquipmentCurrentAvg
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentVoltage

障害コード : F36302

Message: Threshold Crossed: equipment:PsuInputStats property: voltage

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
```

```

mibFaultCode: F36302
mibFaultName: tcaEquipmentVoltage
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

```

tcaEquipmentVoltageMin

障害コード : F36304

Message: Threshold Crossed: equipment:PsuInputStats property: voltageMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36304
mibFaultName: tcaEquipmentVoltageMin
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

```

tcaEquipmentVoltageMax

障害コード : F36305

Message: Threshold Crossed: equipment:PsuInputStats property: voltageMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36305
mibFaultName: tcaEquipmentVoltageMax
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

```

tcaEquipmentVoltageAvg

障害コード : F36306

Message: Threshold Crossed: equipment:PsuInputStats property: voltageAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36306
mibFaultName: tcaEquipmentVoltageAvg
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentPower

障害コード : F36310

Message: Threshold Crossed: equipment:PsuInputStats property: power

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36310
mibFaultName: tcaEquipmentPower
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats
```

tcaEquipmentPowerMin

障害コード : F36312

Message: Threshold Crossed: equipment:PsuInputStats property: powerMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36312
mibFaultName: tcaEquipmentPowerMin
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

```

tcaEquipmentPowerMax

障害コード : F36313

Message: Threshold Crossed: equipment:PsuInputStats property: powerMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36313
mibFaultName: tcaEquipmentPowerMax
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

```

tcaEquipmentPowerAvg

障害コード : F36314

Message: Threshold Crossed: equipment:PsuInputStats property: powerAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F36314
mibFaultName: tcaEquipmentPowerAvg
moClass: equipment:PsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/input-stats
Affected MO: sys/fex-[id]/psu-[id]/input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/input-stats

```

Affected MO: sys/rack-unit-[id]/psu-[id]/input-stats
Affected MO: sys/switch-[id]/psu-[id]/input-stats

tcaEquipmentAmbientTemp

障害コード : F36323

Message: Threshold Crossed: equipment:FanModuleStats property: ambientTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36323
mibFaultName: tcaEquipmentAmbientTemp
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaEquipmentAmbientTempMin

障害コード : F36325

Message: Threshold Crossed: equipment:FanModuleStats property: ambientTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36325
mibFaultName: tcaEquipmentAmbientTempMin
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaEquipmentAmbientTempMax

障害コード : F36326

Message: Threshold Crossed: equipment:FanModuleStats property: ambientTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36326
mibFaultName: tcaEquipmentAmbientTempMax
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats
```

tcaEquipmentAmbientTempAvg

障害コード : F36327

Message: Threshold Crossed: equipment:FanModuleStats property: ambientTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36327
mibFaultName: tcaEquipmentAmbientTempAvg
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats
```

tcaEquipmentSpeed

障害コード : F36335

Message: Threshold Crossed: equipment:FanStats property: speed

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36335
mibFaultName: tcaEquipmentSpeed
moClass: equipment:FanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
```


Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentSpeedMin

障害コード : F36337

Message: Threshold Crossed: equipment:FanStats property: speedMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36337
mibFaultName: tcaEquipmentSpeedMin
moClass: equipment:FanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentSpeedMax

障害コード : F36338

Message: Threshold Crossed: equipment:RackUnitFanStats property: speedMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F36338
mibFaultName: tcaEquipmentSpeedMax
moClass: equipment:FanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentSpeedAvg

障害コード : F36339

Message: Threshold Crossed: equipment:FanStats property: speedAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F36339
mibFaultName: tcaEquipmentSpeedAvg
moClass: equipment:FanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats
```

tcaEquipmentOutput12v

障害コード : F37154

Message: Threshold Crossed: equipment:PsuStats property: output12v

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37154
mibFaultName: tcaEquipmentOutput12v
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutput12vMin

障害コード : F37156

Message: Threshold Crossed: equipment:PsuStats property: output12vMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

Cause: threshold-crossed
mibFaultCode: F37156
mibFaultName: tcaEquipmentOutput12vMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutput12vMax

障害コード : F37157

Message: Threshold Crossed: equipment:PsuStats property: output12vMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37157
mibFaultName: tcaEquipmentOutput12vMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutput12vAvg

障害コード : F37158

Message: Threshold Crossed: equipment:PsuStats property: output12vAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37158
mibFaultName: tcaEquipmentOutput12vAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutput3v3

障害コード : F37162

Message: Threshold Crossed: equipment:PsuStats property: output3v3

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37162
mibFaultName: tcaEquipmentOutput3v3
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutput3v3Min

障害コード : F37164

Message: Threshold Crossed: equipment:PsuStats property: output3v3Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37164
mibFaultName: tcaEquipmentOutput3v3Min
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentOutput3v3Max

障害コード : F37165

Message: Threshold Crossed: equipment:PsuStats property: output3v3Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37165
mibFaultName: tcaEquipmentOutput3v3Max
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentOutput3v3Avg

障害コード : F37166

Message: Threshold Crossed: equipment:PsuStats property: output3v3Avg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37166
mibFaultName: tcaEquipmentOutput3v3Avg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentInput210v

障害コード : F37170

Message: Threshold Crossed: equipment:PsuStats property: input210v

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37170
mibFaultName: tcaEquipmentInput210v
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats

Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentInput210vMin

障害コード : F37172

Message: Threshold Crossed: equipment:PsuStats property: input210vMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37172
mibFaultName: tcaEquipmentInput210vMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentInput210vMax

障害コード : F37173

Message: Threshold Crossed: equipment:PsuStats property: input210vMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37173
mibFaultName: tcaEquipmentInput210vMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentInput210vAvg

障害コード : F37174

Message: Threshold Crossed: equipment:PsuStats property: input210vAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37174
mibFaultName: tcaEquipmentInput210vAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentAmbientTemp

障害コード : F37269

Message: Threshold Crossed: equipment:IOCardStats property: ambientTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37269
mibFaultName: tcaEquipmentAmbientTemp
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentAmbientTempMin

障害コード : F37271

Message: Threshold Crossed: equipment:IOCardStats property: ambientTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37271
mibFaultName: tcaEquipmentAmbientTempMin
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
```

Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentAmbientTempMax

障害コード : F37272

Message: Threshold Crossed: equipment:IOCardStats property: ambientTempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37272
mibFaultName: tcaEquipmentAmbientTempMax
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentAmbientTempAvg

障害コード : F37273

Message: Threshold Crossed: equipment:IOCardStats property: ambientTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37273
mibFaultName: tcaEquipmentAmbientTempAvg
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEtherAlignDelta

障害コード : F37313

Message: Threshold Crossed: ether:ErrStats property: alignDelta

説明 :

推奨処置 :

障害の詳細


```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37313
mibFaultName: tcaEtherAlignDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherAlignDeltaMin

障害コード : F37314

Message: Threshold Crossed: ether:ErrStats property: alignDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37314
mibFaultName: tcaEtherAlignDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherAlignDeltaMax

障害コード : F37315

Message: Threshold Crossed: ether:ErrStats property: alignDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37315
mibFaultName: tcaEtherAlignDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherAlignDeltaAvg

障害コード : F37316

Message: Threshold Crossed: ether:ErrStats property: alignDeltaAvg

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37316
mibFaultName: tcaEtherAlignDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaEtherFcsDelta

障害コード：F37323

Message: Threshold Crossed: ether:ErrStats property: fcsDelta

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37323
mibFaultName: tcaEtherFcsDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
```

Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherFcsDeltaMin

障害コード : F37324

Message: Threshold Crossed: ether:ErrStats property: fcsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37324
mibFaultName: tcaEtherFcsDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherFcsDeltaMax

障害コード : F37325

Message: Threshold Crossed: ether:ErrStats property: fcsDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37325
mibFaultName: tcaEtherFcsDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherFcsDeltaAvg

障害コード : F37326

Message: Threshold Crossed: ether:ErrStats property: fcsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37326
mibFaultName: tcaEtherFcsDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherXmitDelta

障害コード : F37333

Message: Threshold Crossed: ether:ErrStats property: xmitDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37333
mibFaultName: tcaEtherXmitDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherXmitDeltaMin

障害コード : F37334

Message: Threshold Crossed: ether:ErrStats property: xmitDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37334
mibFaultName: tcaEtherXmitDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherXmitDeltaMax

障害コード : F37335

Message: Threshold Crossed: ether:ErrStats property: xmitDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37335
mibFaultName: tcaEtherXmitDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherXmitDeltaAvg

障害コード : F37336

Message: Threshold Crossed: ether:ErrStats property: xmitDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37336
mibFaultName: tcaEtherXmitDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```


Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherRcvDelta

障害コード : F37343

Message: Threshold Crossed: ether:ErrStats property: rcvDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37343
mibFaultName: tcaEtherRcvDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherRcvDeltaMin

障害コード : F37344

Message: Threshold Crossed: ether:ErrStats property: rcvDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37344
mibFaultName: tcaEtherRcvDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherRcvDeltaMax

障害コード : F37345

Message: Threshold Crossed: ether:ErrStats property: rcvDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37345
mibFaultName: tcaEtherRcvDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherRcvDeltaAvg

障害コード : F37346

Message: Threshold Crossed: ether:ErrStats property: rcvDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37346
mibFaultName: tcaEtherRcvDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherUnderSizeDelta

障害コード : F37353

Message: Threshold Crossed: ether:ErrStats property: underSizeDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37353
mibFaultName: tcaEtherUnderSizeDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherUnderSizeDeltaMin

障害コード : F37354

Message: Threshold Crossed: ether:ErrStats property: underSizeDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37354
mibFaultName: tcaEtherUnderSizeDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherUnderSizeDeltaMax

障害コード : F37355

Message: Threshold Crossed: ether:ErrStats property: underSizeDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37355
mibFaultName: tcaEtherUnderSizeDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherUnderSizeDeltaAvg

障害コード : F37356

Message: Threshold Crossed: ether:ErrStats property: underSizeDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37356
mibFaultName: tcaEtherUnderSizeDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherOutDiscardDelta

障害コード : F37363

Message: Threshold Crossed: ether:ErrStats property: outDiscardDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37363
mibFaultName: tcaEtherOutDiscardDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherOutDiscardDeltaMin

障害コード : F37364

Message: Threshold Crossed: ether:ErrStats property: outDiscardDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37364
mibFaultName: tcaEtherOutDiscardDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherOutDiscardDeltaMax

障害コード : F37365

Message: Threshold Crossed: ether:ErrStats property: outDiscardDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37365
mibFaultName: tcaEtherOutDiscardDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherOutDiscardDeltaAvg

障害コード : F37366

Message: Threshold Crossed: ether:ErrStats property: outDiscardDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37366
mibFaultName: tcaEtherOutDiscardDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats
```

tcaEtherIntMacTxDelta

障害コード : F37383

Message: Threshold Crossed: ether:ErrStats property: intMacTxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37383
mibFaultName: tcaEtherIntMacTxDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherIntMacTxDeltaMin

障害コード : F37384

Message: Threshold Crossed: ether:ErrStats property: intMacTxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37384
mibFaultName: tcaEtherIntMacTxDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherIntMacTxDeltaMax

障害コード : F37385

Message: Threshold Crossed: ether:ErrStats property: intMacTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37385
mibFaultName: tcaEtherIntMacTxDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherIntMacTxDeltaAvg

障害コード : F37386

Message: Threshold Crossed: ether:ErrStats property: intMacTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37386
mibFaultName: tcaEtherIntMacTxDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherIntMacRxDelta

障害コード : F37393

Message: Threshold Crossed: ether:ErrStats property: intMacRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37393
mibFaultName: tcaEtherIntMacRxDelta
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherIntMacRxDeltaMin

障害コード : F37394

Message: Threshold Crossed: ether:ErrStats property: intMacRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37394
mibFaultName: tcaEtherIntMacRxDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherIntMacRxDeltaMax

障害コード : F37395

Message: Threshold Crossed: ether:ErrStats property: intMacRxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37395
mibFaultName: tcaEtherIntMacRxDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherIntMacRxDeltaAvg

障害コード : F37396

Message: Threshold Crossed: ether:ErrStats property: intMacRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37396
mibFaultName: tcaEtherIntMacRxDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherSingleCollisionDelta

障害コード : F37403

Message: Threshold Crossed: ether:LossStats property: singleCollisionDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37403
mibFaultName: tcaEtherSingleCollisionDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSingleCollisionDeltaMin

障害コード : F37404

Message: Threshold Crossed: ether:LossStats property: singleCollisionDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37404
mibFaultName: tcaEtherSingleCollisionDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats
```

tcaEtherSingleCollisionDeltaMax

障害コード : F37405

Message: Threshold Crossed: ether:LossStats property: singleCollisionDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37405
mibFaultName: tcaEtherSingleCollisionDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
```


Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSingleCollisionDeltaAvg

障害コード : F37406

Message: Threshold Crossed: ether:LossStats property: singleCollisionDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37406
mibFaultName: tcaEtherSingleCollisionDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherMultiCollisionDelta

障害コード : F37413

Message: Threshold Crossed: ether:LossStats property: multiCollisionDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37413
mibFaultName: tcaEtherMultiCollisionDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

```

tcaEtherMultiCollisionDeltaMin

障害コード : F37414

Message: Threshold Crossed: ether:LossStats property: multiCollisionDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37414
mibFaultName: tcaEtherMultiCollisionDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherMultiCollisionDeltaMax

障害コード : F37415

Message: Threshold Crossed: ether:LossStats property: multiCollisionDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37415
mibFaultName: tcaEtherMultiCollisionDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherMultiCollisionDeltaAvg

障害コード : F37416

Message: Threshold Crossed: ether:LossStats property: multiCollisionDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37416
mibFaultName: tcaEtherMultiCollisionDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherLateCollisionDelta

障害コード : F37423

Message: Threshold Crossed: ether:LossStats property: lateCollisionDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37423
mibFaultName: tcaEtherLateCollisionDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

```

tcaEtherLateCollisionDeltaMin

障害コード : F37424

Message: Threshold Crossed: ether:LossStats property: lateCollisionDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37424
mibFaultName: tcaEtherLateCollisionDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherLateCollisionDeltaMax

障害コード : F37425

Message: Threshold Crossed: ether:LossStats property: lateCollisionDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37425
mibFaultName: tcaEtherLateCollisionDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherLateCollisionDeltaAvg

障害コード : F37426

Message: Threshold Crossed: ether:LossStats property: lateCollisionDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37426
mibFaultName: tcaEtherLateCollisionDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats
```

tcaEtherCarrierSenseDelta

障害コード : F37443

Message: Threshold Crossed: ether:LossStats property: carrierSenseDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37443
mibFaultName: tcaEtherCarrierSenseDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherCarrierSenseDeltaMin

障害コード : F37444

Message: Threshold Crossed: ether:LossStats property: carrierSenseDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37444
mibFaultName: tcaEtherCarrierSenseDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherCarrierSenseDeltaMax

障害コード : F37445

Message: Threshold Crossed: ether:LossStats property: carrierSenseDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37445
mibFaultName: tcaEtherCarrierSenseDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

```

tcaEtherCarrierSenseDeltaAvg

障害コード : F37446

Message: Threshold Crossed: ether:LossStats property: carrierSenseDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37446
mibFaultName: tcaEtherCarrierSenseDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherGiantsDelta

障害コード : F37453

Message: Threshold Crossed: ether:LossStats property: giantsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37453
mibFaultName: tcaEtherGiantsDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherGiantsDeltaMin

障害コード : F37454

Message: Threshold Crossed: ether:LossStats property: giantsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37454
mibFaultName: tcaEtherGiantsDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherGiantsDeltaMax

障害コード : F37455

Message: Threshold Crossed: ether:LossStats property: giantsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37455
mibFaultName: tcaEtherGiantsDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

```

tcaEtherGiantsDeltaAvg

障害コード : F37456

Message: Threshold Crossed: ether:LossStats property: giantsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37456
mibFaultName: tcaEtherGiantsDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSymbolDelta

障害コード : F37463

Message: Threshold Crossed: ether:LossStats property: symbolDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37463
mibFaultName: tcaEtherSymbolDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSymbolDeltaMin

障害コード : F37464

Message: Threshold Crossed: ether:LossStats property: symbolDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37464
mibFaultName: tcaEtherSymbolDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats
```

tcaEtherSymbolDeltaMax

障害コード : F37465

Message: Threshold Crossed: ether:LossStats property: symbolDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37465
mibFaultName: tcaEtherSymbolDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSymbolDeltaAvg

障害コード : F37466

Message: Threshold Crossed: ether:LossStats property: symbolDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37466
mibFaultName: tcaEtherSymbolDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSQETestDelta

障害コード : F37473

Message: Threshold Crossed: ether:LossStats property: SQETestDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37473
mibFaultName: tcaEtherSQETestDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

```

tcaEtherSQETestDeltaMin

障害コード : F37474

Message: Threshold Crossed: ether:LossStats property: SQETestDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37474
mibFaultName: tcaEtherSQETestDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true

```


Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSQETestDeltaMax

障害コード : F37475

Message: Threshold Crossed: ether:LossStats property: SQETestDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37475
mibFaultName: tcaEtherSQETestDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherSQETestDeltaAvg

障害コード : F37476

Message: Threshold Crossed: ether:LossStats property: SQETestDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37476
mibFaultName: tcaEtherSQETestDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherRecvPauseDelta

障害コード : F37485

Message: Threshold Crossed: ether:PauseStats property: recvPauseDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37485
mibFaultName: tcaEtherRecvPauseDelta
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

```

tcaEtherRecvPauseDeltaMin

障害コード : F37486

Message: Threshold Crossed: ether:PauseStats property: rcvPauseDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37486
mibFaultName: tcaEtherRecvPauseDeltaMin
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherRecvPauseDeltaMax

障害コード : F37487

Message: Threshold Crossed: ether:PauseStats property: recvPauseDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37487
mibFaultName: tcaEtherRecvPauseDeltaMax
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherRecvPauseDeltaAvg

障害コード : F37488

Message: Threshold Crossed: ether:PauseStats property: recvPauseDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37488
mibFaultName: tcaEtherRecvPauseDeltaAvg
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats
```

tcaEtherXmitPauseDelta

障害コード : F37495

Message: Threshold Crossed: ether:PauseStats property: xmitPauseDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37495
mibFaultName: tcaEtherXmitPauseDelta
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherXmitPauseDeltaMin

障害コード : F37496

Message: Threshold Crossed: ether:PauseStats property: xmitPauseDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37496
mibFaultName: tcaEtherXmitPauseDeltaMin
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherXmitPauseDeltaMax

障害コード : F37497

Message: Threshold Crossed: ether:PauseStats property: xmitPauseDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37497
mibFaultName: tcaEtherXmitPauseDeltaMax
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

```

tcaEtherXmitPauseDeltaAvg

障害コード : F37498

Message: Threshold Crossed: ether:PauseStats property: xmitPauseDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37498
mibFaultName: tcaEtherXmitPauseDeltaAvg
moClass: ether:PauseStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherResetsDelta

障害コード : F37505

Message: Threshold Crossed: ether:PauseStats property: resetsDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37505
mibFaultName: tcaEtherResetsDelta
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats

Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherResetsDeltaMin

障害コード : F37506

Message: Threshold Crossed: ether:PauseStats property: resetsDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37506
mibFaultName: tcaEtherResetsDeltaMin
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherResetsDeltaMax

障害コード : F37507

Message: Threshold Crossed: ether:PauseStats property: resetsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F37507
mibFaultName: tcaEtherResetsDeltaMax
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

```

tcaEtherResetsDeltaAvg

障害コード : F37508

Message: Threshold Crossed: ether:PauseStats property: resetsDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37508
mibFaultName: tcaEtherResetsDeltaAvg
moClass: ether:PauseStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/pause-stats
Affected MO: fabric/lan/[id]/pc-[portId]/pause-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats

```

Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/pause-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/pause-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/pause-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/pause-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/pause-stats

tcaEtherExcessCollisionDelta

障害コード : F37532

Message: Threshold Crossed: ether:LossStats property: excessCollisionDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37532
mibFaultName: tcaEtherExcessCollisionDelta
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherExcessCollisionDeltaMin

障害コード : F37533

Message: Threshold Crossed: ether:LossStats property: excessCollisionDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37533
mibFaultName: tcaEtherExcessCollisionDeltaMin
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats
```

tcaEtherExcessCollisionDeltaMax

障害コード : F37534

Message: Threshold Crossed: ether:LossStats property: excessCollisionDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37534
mibFaultName: tcaEtherExcessCollisionDeltaMax
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
```

Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherExcessCollisionDeltaAvg

障害コード : F37535

Message: Threshold Crossed: ether:LossStats property: excessCollisionDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37535
mibFaultName: tcaEtherExcessCollisionDeltaAvg
moClass: ether:LossStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/loss-stats
Affected MO: fabric/lan/[id]/pc-[portId]/loss-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/loss-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/loss-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/loss-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/loss-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/loss-stats

tcaEtherUnicastPacketsDelta

障害コード : F37543

メッセージ: しきい値 Crossed: イーサ: TxStats プロパティ: unicastPacketsDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37543
mibFaultName: tcaEtherUnicastPacketsDelta
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

```

tcaEtherUnicastPacketsDeltaMin

障害コード : F37544

Message: Threshold Crossed: ether:TxStats property: unicastPacketsDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37544
mibFaultName: tcaEtherUnicastPacketsDeltaMin
moClass: ether:TxStats
Type: equipment
autoCleared: true

```

Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherUnicastPacketsDeltaMax

障害コード : F37545

Message: Threshold Crossed: ether:TxStats property: unicastPacketsDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37545
mibFaultName: tcaEtherUnicastPacketsDeltaMax
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherUnicastPacketsDeltaAvg

障害コード : F37546

Message: Threshold Crossed: ether:TxStats property: unicastPacketsDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37546
mibFaultName: tcaEtherUnicastPacketsDeltaAvg
moClass: ether:TxStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/tx-stats
Affected MO: fabric/lan/[id]/pc-[portId]/tx-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/tx-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/tx-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/tx-stats

tcaEtherDeferredTxDelta

障害コード : F37553

Message: Threshold Crossed: ether:ErrStats property: deferredTxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37553
mibFaultName: tcaEtherDeferredTxDelta


```

moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaEtherDeferredTxDeltaMin

障害コード : F37554

Message: Threshold Crossed: ether:ErrStats property: deferredTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37554
mibFaultName: tcaEtherDeferredTxDeltaMin
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats

```

Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherDeferredTxDeltaMax

障害コード : F37555

Message: Threshold Crossed: ether:ErrStats property: deferredTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37555
mibFaultName: tcaEtherDeferredTxDeltaMax
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

tcaEtherDeferredTxDeltaAvg

障害コード : F37556

Message: Threshold Crossed: ether:ErrStats property: deferredTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37556
mibFaultName: tcaEtherDeferredTxDeltaAvg
moClass: ether:ErrStats
Type: equipment
autoCleared: true
Affected MO: fabric/eth-estc/[id]/pc-[portId]/err-stats
Affected MO: fabric/lan/[id]/pc-[portId]/err-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/diag/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/err-stats
Affected MO: sys/rack-unit-[id]/diag/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/err-stats

```

tcaComputeInputVoltage

障害コード : F37564

Message: Threshold Crossed: compute:MbPowerStats property: inputVoltage

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37564
mibFaultName: tcaComputeInputVoltage
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeInputVoltageMin

障害コード : F37566

Message: Threshold Crossed: compute:MbPowerStats property: inputVoltageMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37566
mibFaultName: tcaComputeInputVoltageMin
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeInputVoltageMax

障害コード : F37567

Message: Threshold Crossed: compute:MbPowerStats property: inputVoltageMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37567
mibFaultName: tcaComputeInputVoltageMax
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeInputVoltageAvg

障害コード : F37568

Message: Threshold Crossed: compute:MbPowerStats property: inputVoltageAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37568
mibFaultName: tcaComputeInputVoltageAvg
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeInputCurrent

障害コード : F37572

Message: Threshold Crossed: compute:MbPowerStats property: inputCurrent

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37572
mibFaultName: tcaComputeInputCurrent
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats
```

tcaComputeInputCurrentMin

障害コード : F37574

Message: Threshold Crossed: compute:MbPowerStats property: inputCurrentMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37574
mibFaultName: tcaComputeInputCurrentMin
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeInputCurrentMax

障害コード : F37575

Message: Threshold Crossed: compute:MbPowerStats property: inputCurrentMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37575
mibFaultName: tcaComputeInputCurrentMax
moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeInputCurrentAvg

障害コード : F37576

Message: Threshold Crossed: compute:MbPowerStats property: inputCurrentAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37576
mibFaultName: tcaComputeInputCurrentAvg

```

```

moClass: compute:MbPowerStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/power-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/power-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/power-stats
Affected MO: sys/rack-unit-[id]/board/power-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/power-stats

```

tcaComputeFmTempSenRear

障害コード : F37580

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRear

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37580
mibFaultName: tcaComputeFmTempSenRear
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaComputeFmTempSenRearMin

障害コード : F37582

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37582
mibFaultName: tcaComputeFmTempSenRearMin
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats

```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

tcaComputeFmTempSenRearMax

障害コード : F37583

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37583
mibFaultName: tcaComputeFmTempSenRearMax
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

tcaComputeFmTempSenRearAvg

障害コード : F37584

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F37584
mibFaultName: tcaComputeFmTempSenRearAvg
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

tcaMemoryTemperature

障害コード : F37600

Message: Threshold Crossed: memory:UnitEnvStats property: temperature

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37600
mibFaultName: tcaMemoryTemperature
moClass: memory:UnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/dimm-env-stats
```

tcaMemoryTemperatureMin

障害コード : F37602

Message: Threshold Crossed: memory:UnitEnvStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37602
mibFaultName: tcaMemoryTemperatureMin
moClass: memory:UnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/dimm-env-stats
```

tcaMemoryTemperatureMax

障害コード : F37603

Message: Threshold Crossed: memory:UnitEnvStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F37603
mibFaultName: tcaMemoryTemperatureMax
moClass: memory:UnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/dimm-env-stats

```

tcaMemoryTemperatureAvg

障害コード : F37604

Message: Threshold Crossed: memory:UnitEnvStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37604
mibFaultName: tcaMemoryTemperatureAvg
moClass: memory:UnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/dimm-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/dimm-env-stats

```

tcaProcessorTemperature

障害コード : F37610

Message: Threshold Crossed: processor:EnvStats property: temperature

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37610
mibFaultName: tcaProcessorTemperature
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats

```

tcaProcessorTemperatureMin

障害コード : F37612

Message: Threshold Crossed: processor:EnvStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37612
mibFaultName: tcaProcessorTemperatureMin
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaProcessorTemperatureMax

障害コード : F37613

Message: Threshold Crossed: processor:EnvStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37613
mibFaultName: tcaProcessorTemperatureMax
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaProcessorTemperatureAvg

障害コード : F37614

Message: Threshold Crossed: processor:EnvStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F37614
mibFaultName: tcaProcessorTemperatureAvg
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats

```

tcaSwPsuCtrlrInlet1

障害コード : F37771

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet1

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37771
mibFaultName: tcaSwPsuCtrlrInlet1
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwPsuCtrlrInlet1Min

障害コード : F37773

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet1Min

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F37773
mibFaultName: tcaSwPsuCtrlrInlet1Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

```

tcaSwPsuCtrlrInlet1Max

障害コード : F37774

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet1Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37774
mibFaultName: tcaSwPsuCtrlrInlet1Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwPsuCtrlrInlet1Avg

障害コード : F37775

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet1Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37775
mibFaultName: tcaSwPsuCtrlrInlet1Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwPsuCtrlrInlet2

障害コード : F37779

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet2

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37779
mibFaultName: tcaSwPsuCtrlrInlet2
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwPsuCtrlrInlet2Min

障害コード : F37781

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet2Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37781
mibFaultName: tcaSwPsuCtrlrInlet2Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwPsuCtrlrInlet2Max

障害コード : F37782

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet2Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37782
mibFaultName: tcaSwPsuCtrlrInlet2Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwPsuCtrlrInlet2Avg

障害コード : F37783

Message: Threshold Crossed: sw:EnvStats property: psuCtrlrInlet2Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F37783
mibFaultName: tcaSwPsuCtrlrInlet2Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaComputeDIIpErrors

障害コード : F38022

Message: Threshold Crossed: compute:PCIEFatalProtocolStats property: dllpErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38022
mibFaultName: tcaComputeDllpErrors
moClass: compute:PCIEFatalProtocolStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-protocol-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-protocol-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-protocol-stats
```

tcaComputeFlowControlErrors

障害コード : F38032

Message: Threshold Crossed: compute:PCIEFatalProtocolStats property: flowControlErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38032
mibFaultName: tcaComputeFlowControlErrors
moClass: compute:PCIEFatalProtocolStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-protocol-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-protocol-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-protocol-stats
```

tcaComputeUnsupportedRequestErrors

障害コード : F38044

Message: Threshold Crossed: compute:PCIEFatalReceiveStats property: unsupportedRequestErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38044
mibFaultName: tcaComputeUnsupportedRequestErrors
```

```

moClass: compute:PCIEFatalReceiveStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-receive-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-receive-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-receive-stats

```

tcaComputeErrFatalErrors

障害コード : F38054

Message: Threshold Crossed: compute:PCIEFatalReceiveStats property: errFatalErrors

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38054
mibFaultName: tcaComputeErrFatalErrors
moClass: compute:PCIEFatalReceiveStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-receive-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-receive-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-receive-stats

```

tcaComputeErrNonFatalErrors

障害コード : F38064

Message: Threshold Crossed: compute:PCIEFatalReceiveStats property: errNonFatalErrors

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38064
mibFaultName: tcaComputeErrNonFatalErrors
moClass: compute:PCIEFatalReceiveStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-receive-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-receive-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-receive-stats

```

tcaComputeUnexpectedErrors

障害コード : F38086

Message: Threshold Crossed: compute:PCIEFatalCompletionStats property: unexpectedErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38086
mibFaultName: tcaComputeUnexpectedErrors
moClass: compute:PCIEFatalCompletionStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-completion-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-completion-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-completion-stats
```

tcaComputeTimeoutErrors

障害コード : F38096

Message: Threshold Crossed: compute:PCIEFatalCompletionStats property: TimeoutErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38096
mibFaultName: tcaComputeTimeoutErrors
moClass: compute:PCIEFatalCompletionStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-completion-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-completion-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-completion-stats
```

tcaComputeAbortErrors

障害コード : F38106

Message: Threshold Crossed: compute:PCIEFatalCompletionStats property: AbortErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38106
mibFaultName: tcaComputeAbortErrors
moClass: compute:PCIEFatalCompletionStats
Type: server
```

```

autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-completion-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-completion-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-completion-stats

```

tcaComputeSurpriseLinkDownErrors

障害コード : F38128

Message: Threshold Crossed: compute:PCIEFatalStats property: surpriseLinkDownErrors

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38128
mibFaultName: tcaComputeSurpriseLinkDownErrors
moClass: compute:PCIEFatalStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-stats

```

tcaComputePoisonedTLPErrors

障害コード : F38138

Message: Threshold Crossed: compute:PCIEFatalStats property: poisonedTLPErrors

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38138
mibFaultName: tcaComputePoisonedTLPErrors
moClass: compute:PCIEFatalStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-stats

```

tcaComputeAcsViolationErrors

障害コード : F38148

Message: Threshold Crossed: compute:PCIEFatalStats property: acsViolationErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38148
mibFaultName: tcaComputeAcsViolationErrors
moClass: compute:PCIEFatalStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-stats
```

tcaComputeMalformedTLPErrors

障害コード : F38158

Message: Threshold Crossed: compute:PCIEFatalStats property: malformedTLPErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38158
mibFaultName: tcaComputeMalformedTLPErrors
moClass: compute:PCIEFatalStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-stats
```

tcaEquipmentTemp

障害コード : F38311

Message: Threshold Crossed: equipment:IOCardStats property: temp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38311
mibFaultName: tcaEquipmentTemp
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
```

Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentTempMin

障害コード : F38313

Message: Threshold Crossed: equipment:IOCardStats property: tempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38313
mibFaultName: tcaEquipmentTempMin
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentTempMax

障害コード : F38314

Message: Threshold Crossed: equipment:IOCardStats property: tempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38314
mibFaultName: tcaEquipmentTempMax
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentTempAvg

障害コード : F38315

Message: Threshold Crossed: equipment:IOCardStats property: tempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38315
mibFaultName: tcaEquipmentTempAvg
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaProcessorInputCurrent

障害コード : F38349

Message: Threshold Crossed: processor:EnvStats property: inputCurrent

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38349
mibFaultName: tcaProcessorInputCurrent
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaProcessorInputCurrentMin

障害コード : F38351

Message: Threshold Crossed: processor:EnvStats property: inputCurrentMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38351
mibFaultName: tcaProcessorInputCurrentMin
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaProcessorInputCurrentMax

障害コード : F38352

Message: Threshold Crossed: processor:EnvStats property: inputCurrentMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38352
mibFaultName: tcaProcessorInputCurrentMax
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaProcessorInputCurrentAvg

障害コード : F38353

Message: Threshold Crossed: processor:EnvStats property: inputCurrentAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38353
mibFaultName: tcaProcessorInputCurrentAvg
moClass: processor:EnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/env-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/env-stats
```

tcaMemoryInputCurrent

障害コード : F38357

Message: Threshold Crossed: memory:ArrayEnvStats property: inputCurrent

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

Cause: threshold-crossed
mibFaultCode: F38357
mibFaultName: tcaMemoryInputCurrent
moClass: memory:ArrayEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/array-env-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/array-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/array-env-stats

tcaMemoryInputCurrentMin

障害コード : F38359

Message: Threshold Crossed: memory:ArrayEnvStats property: inputCurrentMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38359
mibFaultName: tcaMemoryInputCurrentMin
moClass: memory:ArrayEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/array-env-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/array-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/array-env-stats

tcaMemoryInputCurrentMax

障害コード : F38360

Message: Threshold Crossed: memory:ArrayEnvStats property: inputCurrentMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38360
mibFaultName: tcaMemoryInputCurrentMax
moClass: memory:ArrayEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/array-env-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/array-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/array-env-stats

tcaMemoryInputCurrentAvg

障害コード : F38361

Message: Threshold Crossed: memory:ArrayEnvStats property: inputCurrentAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38361
mibFaultName: tcaMemoryInputCurrentAvg
moClass: memory:ArrayEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/array-env-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/array-env-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/array-env-stats

```

tcaAdaptorNoBreakdownGreaterThan1518Delta

障害コード : F38408

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property: noBreakdownGreaterThan1518Delta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38408
mibFaultName: tcaAdaptorNoBreakdownGreaterThan1518Delta
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

```


tcaAdaptorNoBreakdownGreaterThan1518DeltaMin

障害コード : F38409

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property:
noBreakdownGreaterThan1518DeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38409
mibFaultName: tcaAdaptorNoBreakdownGreaterThan1518DeltaMin
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
```

tcaAdaptorNoBreakdownGreaterThan1518DeltaMax

障害コード : F38410

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property:
noBreakdownGreaterThan1518DeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38410
mibFaultName: tcaAdaptorNoBreakdownGreaterThan1518DeltaMax
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaAdaptorNoBreakdownGreaterThan1518DeltaAvg

障害コード : F38411

Message: Threshold Crossed: adaptor:EthPortBySizeLargeStats property:
 noBreakdownGreaterThan1518DeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38411
mibFaultName: tcaAdaptorNoBreakdownGreaterThan1518DeltaAvg
moClass: adaptor:EthPortBySizeLargeStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/ext-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 sys/rack-unit-[id]/adaptor-[id]/host-eth-[id]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO:
 vmm/computeEp-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/hv-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]
Affected MO: vmm/vm-[uuid]/nic-[name]/eth-port-by-size-large-stats-[trafficDirection]

tcaMemoryTemperature

障害コード : F38438

Message: Threshold Crossed: memory:BufferUnitEnvStats property: temperature

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38438
mibFaultName: tcaMemoryTemperature
moClass: memory:BufferUnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]/buffer-unit-env-stats

```

tcaMemoryTemperatureMin

障害コード : F38440

Message: Threshold Crossed: memory:BufferUnitEnvStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38440
mibFaultName: tcaMemoryTemperatureMin
moClass: memory:BufferUnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]/buffer-unit-env-stats

```

tcaMemoryTemperatureMax

障害コード : F38441

Message: Threshold Crossed: memory:BufferUnitEnvStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38441
mibFaultName: tcaMemoryTemperatureMax
moClass: memory:BufferUnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]/buffer-unit-env-stats

```

tcaMemoryTemperatureAvg

障害コード : F38442

Message: Threshold Crossed: memory:BufferUnitEnvStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38442
mibFaultName: tcaMemoryTemperatureAvg
moClass: memory:BufferUnitEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/sensor-unit-[id]/buffer-unit-env-stats
Affected MO: sys/rack-unit-[id]/board/sensor-unit-[id]/buffer-unit-env-stats

```

tcaComputeTemperature

障害コード : F38451

Message: Threshold Crossed: compute:IOHubEnvStats property: temperature

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F38451
mibFaultName: tcaComputeTemperature
moClass: compute:IOHubEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub/iohub-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub/iohub-stats
Affected MO: sys/rack-unit-[id]/board/iohub/iohub-stats

```

tcaComputeTemperatureMin

障害コード : F38453

Message: Threshold Crossed: compute:IOHubEnvStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info

```

Cause: threshold-crossed
mibFaultCode: F38453
mibFaultName: tcaComputeTemperatureMin
moClass: compute:IOHubEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub/iohub-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub/iohub-stats
Affected MO: sys/rack-unit-[id]/board/iohub/iohub-stats

tcaComputeTemperatureMax

障害コード : F38454

Message: Threshold Crossed: compute:IOHubEnvStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38454
mibFaultName: tcaComputeTemperatureMax
moClass: compute:IOHubEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub/iohub-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub/iohub-stats
Affected MO: sys/rack-unit-[id]/board/iohub/iohub-stats

tcaComputeTemperatureAvg

障害コード : F38455

Message: Threshold Crossed: compute:IOHubEnvStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38455
mibFaultName: tcaComputeTemperatureAvg
moClass: compute:IOHubEnvStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/iohub/iohub-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/iohub/iohub-stats
Affected MO: sys/rack-unit-[id]/board/iohub/iohub-stats

tcaProcessorMirroringIntraSockErrors

障害コード : F38779

Message: Threshold Crossed: processor:ErrorStats property: mirroringIntraSockErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38779
mibFaultName: tcaProcessorMirroringIntraSockErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats
```

tcaProcessorMirroringInterSockErrors

障害コード : F38788

Message: Threshold Crossed: processor:ErrorStats property: mirroringInterSockErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38788
mibFaultName: tcaProcessorMirroringInterSockErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats
```

tcaProcessorSparingErrors

障害コード : F38797

Message: Threshold Crossed: processor:ErrorStats property: sparingErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

Cause: threshold-crossed
mibFaultCode: F38797
mibFaultName: tcaProcessorSparingErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats

tcaProcessorSmiLinkCorrErrors

障害コード : F38806

Message: Threshold Crossed: processor:ErrorStats property: smiLinkCorrErrors

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38806
mibFaultName: tcaProcessorSmiLinkCorrErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats

tcaProcessorSmiLinkUncorrErrors

障害コード : F38815

Message: Threshold Crossed: processor:ErrorStats property: smiLinkUncorrErrors

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38815
mibFaultName: tcaProcessorSmiLinkUncorrErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats

tcaMemoryEccMultibitErrors

障害コード : F38829

Message: Threshold Crossed: memory:ErrorStats property: eccMultibitErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38829
mibFaultName: tcaMemoryEccMultibitErrors
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats
```

tcaMemoryEccSinglebitErrors

障害コード : F38838

Message: Threshold Crossed: memory:ErrorStats property: eccSinglebitErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F38838
mibFaultName: tcaMemoryEccSinglebitErrors
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats
```

tcaMemoryAddressParityErrors

障害コード : F38847

Message: Threshold Crossed: memory:ErrorStats property: addressParityErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```


Cause: threshold-crossed
mibFaultCode: F38847
mibFaultName: tcaMemoryAddressParityErrors
moClass: memory>ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

tcaMemoryMismatchErrors

障害コード : F38856

Message: Threshold Crossed: memory>ErrorStats property: mismatchErrors

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38856
mibFaultName: tcaMemoryMismatchErrors
moClass: memory>ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

tcaComputeBufferOverflowErrors

障害コード : F38909

Message: Threshold Crossed: compute:PCIEFatalReceiveStats property: bufferOverflowErrors

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F38909
mibFaultName: tcaComputeBufferOverflowErrors
moClass: compute:PCIEFatalReceiveStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/pciefat-receive-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/pciefat-receive-stats
Affected MO: sys/rack-unit-[id]/board/pciefat-receive-stats

tcaComputeFmTempSenRearL

障害コード : F39032

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearL

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39032
mibFaultName: tcaComputeFmTempSenRearL
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaComputeFmTempSenRearLMin

障害コード : F39034

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearLMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39034
mibFaultName: tcaComputeFmTempSenRearLMin
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaComputeFmTempSenRearLMax

障害コード : F39035

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearLMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39035
mibFaultName: tcaComputeFmTempSenRearLMax
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats
```

tcaComputeFmTempSenRearLAvg

障害コード : F39036

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearLAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39036
mibFaultName: tcaComputeFmTempSenRearLAvg
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats
```

tcaComputeFmTempSenRearR

障害コード : F39040

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearR

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
```

```

mibFaultCode: F39040
mibFaultName: tcaComputeFmTempSenRearR
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaComputeFmTempSenRearRMin

障害コード : F39042

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearRMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39042
mibFaultName: tcaComputeFmTempSenRearRMin
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

```

tcaComputeFmTempSenRearRMax

障害コード : F39043

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearRMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39043
mibFaultName: tcaComputeFmTempSenRearRMax
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats

```

Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

tcaComputeFmTempSenRearRAvg

障害コード : F39044

Message: Threshold Crossed: compute:MbTempStats property: fmTempSenRearRAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39044
mibFaultName: tcaComputeFmTempSenRearRAvg
moClass: compute:MbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/ext-board-[id]/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/ext-board-[id]/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
Affected MO: sys/rack-unit-[id]/ext-board-[id]/temp-stats

tcaPowerPower

障害コード : F39240

Message: Threshold Crossed: power:GroupStats property: power

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39240
mibFaultName: tcaPowerPower
moClass: power:GroupStats
Type: generic
autoCleared: true

tcaPowerPowerMin

障害コード : F39242

Message: Threshold Crossed: power:GroupStats property: powerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39242
mibFaultName: tcaPowerPowerMin
moClass: power:GroupStats
Type: generic
autoCleared: true
```

tcaPowerPowerMax

障害コード : F39243

Message: Threshold Crossed: power:GroupStats property: powerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39243
mibFaultName: tcaPowerPowerMax
moClass: power:GroupStats
Type: generic
autoCleared: true
```

tcaPowerPowerAvg

障害コード : F39244

Message: Threshold Crossed: power:GroupStats property: powerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39244
mibFaultName: tcaPowerPowerAvg
moClass: power:GroupStats
Type: generic
autoCleared: true
```

tcaEquipmentOutlet1

障害コード : F39421

Message: Threshold Crossed: equipment:FexEnvStats property: outlet1

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39421
mibFaultName: tcaEquipmentOutlet1
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentOutlet1Min

障害コード : F39423

Message: Threshold Crossed: equipment:FexEnvStats property: outlet1Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39423
mibFaultName: tcaEquipmentOutlet1Min
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentOutlet1Max

障害コード : F39424

Message: Threshold Crossed: equipment:FexEnvStats property: outlet1Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39424
mibFaultName: tcaEquipmentOutlet1Max
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentOutlet1Avg

障害コード : F39425

Message: Threshold Crossed: equipment:FexEnvStats property: outlet1Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39425
mibFaultName: tcaEquipmentOutlet1Avg
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentOutlet2

障害コード : F39429

Message: Threshold Crossed: equipment:FexEnvStats property: outlet2

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39429
mibFaultName: tcaEquipmentOutlet2
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentOutlet2Min

障害コード : F39431

Message: Threshold Crossed: equipment:FexEnvStats property: outlet2Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39431
mibFaultName: tcaEquipmentOutlet2Min
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentOutlet2Max

障害コード : F39432

Message: Threshold Crossed: equipment:FexEnvStats property: outlet2Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39432
mibFaultName: tcaEquipmentOutlet2Max
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentOutlet2Avg

障害コード : F39433

Message: Threshold Crossed: equipment:FexEnvStats property: outlet2Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39433
mibFaultName: tcaEquipmentOutlet2Avg
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInlet

障害コード : F39437

Message: Threshold Crossed: equipment:FexEnvStats property: inlet

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39437
mibFaultName: tcaEquipmentInlet
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInletMin

障害コード : F39439

Message: Threshold Crossed: equipment:FexEnvStats property: inletMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39439
mibFaultName: tcaEquipmentInletMin
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInletMax

障害コード : F39440

Message: Threshold Crossed: equipment:FexEnvStats property: inletMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39440
mibFaultName: tcaEquipmentInletMax
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInletAvg

障害コード : F39441

Message: Threshold Crossed: equipment:FexEnvStats property: inletAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39441
mibFaultName: tcaEquipmentInletAvg
moClass: equipment:FexEnvStats
Type: generic
```

```
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInlet1

障害コード : F39445

Message: Threshold Crossed: equipment:FexEnvStats property: inlet1

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39445
mibFaultName: tcaEquipmentInlet1
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInlet1Min

障害コード : F39447

Message: Threshold Crossed: equipment:FexEnvStats property: inlet1Min

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39447
mibFaultName: tcaEquipmentInlet1Min
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats
```

tcaEquipmentInlet1Max

障害コード : F39448

Message: Threshold Crossed: equipment:FexEnvStats property: inlet1Max

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39448
```

```

mibFaultName: tcaEquipmentInlet1Max
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

```

tcaEquipmentInlet1Avg

障害コード : F39449

Message: Threshold Crossed: equipment:FexEnvStats property: inlet1Avg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39449
mibFaultName: tcaEquipmentInlet1Avg
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

```

tcaEquipmentDie1

障害コード : F39453

Message: Threshold Crossed: equipment:FexEnvStats property: die1

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39453
mibFaultName: tcaEquipmentDie1
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

```

tcaEquipmentDie1Min

障害コード : F39455

Message: Threshold Crossed: equipment:FexEnvStats property: die1Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39455
mibFaultName: tcaEquipmentDielMin
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentDielMax

障害コード : F39456

Message: Threshold Crossed: equipment:FexEnvStats property: dielMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39456
mibFaultName: tcaEquipmentDielMax
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentDielAvg

障害コード : F39457

Message: Threshold Crossed: equipment:FexEnvStats property: dielAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39457
mibFaultName: tcaEquipmentDielAvg
moClass: equipment:FexEnvStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/env-stats

tcaEquipmentTotalPower

障害コード : F39464

Message: Threshold Crossed: equipment:FexPowerSummary property: totalPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39464
mibFaultName: tcaEquipmentTotalPower
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentTotalPowerMin

障害コード : F39466

Message: Threshold Crossed: equipment:FexPowerSummary property: totalPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39466
mibFaultName: tcaEquipmentTotalPowerMin
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentTotalPowerMax

障害コード : F39467

Message: Threshold Crossed: equipment:FexPowerSummary property: totalPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39467
mibFaultName: tcaEquipmentTotalPowerMax
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentTotalPowerAvg

障害コード : F39468

Message: Threshold Crossed: equipment:FexPowerSummary property: totalPowerAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39468
mibFaultName: tcaEquipmentTotalPowerAvg
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary

tcaEquipmentReservedPower

障害コード : F39472

Message: Threshold Crossed: equipment:FexPowerSummary property: reservedPower

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39472
mibFaultName: tcaEquipmentReservedPower
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary

tcaEquipmentReservedPowerMin

障害コード : F39474

Message: Threshold Crossed: equipment:FexPowerSummary property: reservedPowerMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39474
mibFaultName: tcaEquipmentReservedPowerMin
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary

tcaEquipmentReservedPowerMax

障害コード : F39475

Message: Threshold Crossed: equipment:FexPowerSummary property: reservedPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39475
mibFaultName: tcaEquipmentReservedPowerMax
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentReservedPowerAvg

障害コード : F39476

Message: Threshold Crossed: equipment:FexPowerSummary property: reservedPowerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39476
mibFaultName: tcaEquipmentReservedPowerAvg
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentModulePower

障害コード : F39480

Message: Threshold Crossed: equipment:FexPowerSummary property: ModulePower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39480
mibFaultName: tcaEquipmentModulePower
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentModulePowerMin

障害コード : F39482

Message: Threshold Crossed: equipment:FexPowerSummary property: ModulePowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39482
mibFaultName: tcaEquipmentModulePowerMin
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentModulePowerMax

障害コード : F39483

Message: Threshold Crossed: equipment:FexPowerSummary property: ModulePower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39483
mibFaultName: tcaEquipmentModulePowerMax
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentModulePowerAvg

障害コード : F39484

Message: Threshold Crossed: equipment:FexPowerSummary property: ModulePowerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39484
mibFaultName: tcaEquipmentModulePowerAvg
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentAvailablePower

障害コード : F39488

Message: Threshold Crossed: equipment:FexPowerSummary property: availablePower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39488
mibFaultName: tcaEquipmentAvailablePower
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentAvailablePowerMin

障害コード : F39490

Message: Threshold Crossed: equipment:FexPowerSummary property: availablePowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39490
mibFaultName: tcaEquipmentAvailablePowerMin
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary
```

tcaEquipmentAvailablePowerMax

障害コード : F39491

Message: Threshold Crossed: equipment:FexPowerSummary property: availablePowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39491
mibFaultName: tcaEquipmentAvailablePowerMax
moClass: equipment:FexPowerSummary
Type: generic
```

autoCleared: true
Affected MO: sys/fex-[id]/power-summary

tcaEquipmentAvailablePowerAvg

障害コード : F39492

Message: Threshold Crossed: equipment:FexPowerSummary property: availablePowerAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39492
mibFaultName: tcaEquipmentAvailablePowerAvg
moClass: equipment:FexPowerSummary
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/power-summary

tcaEquipmentCurrent

障害コード : F39498

Message: Threshold Crossed: equipment:FexPsuInputStats property: current

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39498
mibFaultName: tcaEquipmentCurrent
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentCurrentMin

障害コード : F39500

Message: Threshold Crossed: equipment:FexPsuInputStats property: currentMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39500
mibFaultName: tcaEquipmentCurrentMin
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

```

tcaEquipmentCurrentMax

障害コード : F39501

Message: Threshold Crossed: equipment:FexPsuInputStats property: currentMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39501
mibFaultName: tcaEquipmentCurrentMax
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

```

tcaEquipmentCurrentAvg

障害コード : F39502

Message: Threshold Crossed: equipment:FexPsuInputStats property: currentMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39502
mibFaultName: tcaEquipmentCurrentAvg
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats

```

Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentVoltage

障害コード : F39506

Message: Threshold Crossed: equipment:FexPsuInputStats property: voltage

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39506
mibFaultName: tcaEquipmentVoltage
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentVoltageMin

障害コード : F39508

Message: Threshold Crossed: equipment:FexPsuInputStats property: voltageMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39508
mibFaultName: tcaEquipmentVoltageMin
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentVoltageMax

障害コード : F39509

Message: Threshold Crossed: equipment:FexPsuInputStats property: voltageMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39509
mibFaultName: tcaEquipmentVoltageMax
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats
```

tcaEquipmentVoltageAvg

障害コード : F39510

Message: Threshold Crossed: equipment:FexPsuInputStats property: voltageAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39510
mibFaultName: tcaEquipmentVoltageAvg
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats
```

tcaEquipmentPower

障害コード : F39514

Message: Threshold Crossed: equipment:FexPsuInputStats property:

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39514
mibFaultName: tcaEquipmentPower
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentPowerMin

障害コード : F39516

Message: Threshold Crossed: equipment:FexPsuInputStats property: powerMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39516
mibFaultName: tcaEquipmentPowerMin
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

tcaEquipmentPowerMax

障害コード : F39517

Message: Threshold Crossed: equipment:FexPsuInputStats property: powerMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39517
mibFaultName: tcaEquipmentPowerMax
moClass: equipment:FexPsuInputStats
Type: generic

```

autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

```

tcaEquipmentPowerAvg

障害コード : F39518

Message: Threshold Crossed: equipment:FexPsuInputStats property: powerAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39518
mibFaultName: tcaEquipmentPowerAvg
moClass: equipment:FexPsuInputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/fex-psu-input-stats
Affected MO: sys/fex-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/fex-psu-input-stats
Affected MO: sys/switch-[id]/psu-[id]/fex-psu-input-stats

```

tcaEquipmentAmbientTemp

障害コード : F39525

Message: Threshold Crossed: equipment:RackUnitPsuStats property: ambientTemp

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39525
mibFaultName: tcaEquipmentAmbientTemp
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```


tcaEquipmentAmbientTempMin

障害コード : F39527

Message: Threshold Crossed: equipment:RackUnitPsuStats property: ambientTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39527
mibFaultName: tcaEquipmentAmbientTempMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentAmbientTempMax

障害コード : F39528

Message: Threshold Crossed: equipment:RackUnitPsuStats property: ambientTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39528
mibFaultName: tcaEquipmentAmbientTempMax
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentAmbientTempAvg

障害コード : F39529

Message: Threshold Crossed: equipment:RackUnitPsuStats property: ambientTempAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39529
mibFaultName: tcaEquipmentAmbientTempAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputCurrent

障害コード : F39533

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputCurrent

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39533
mibFaultName: tcaEquipmentOutputCurrent
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputCurrentMin

障害コード : F39535

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputCurrentMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39535
mibFaultName: tcaEquipmentOutputCurrentMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats

```

Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

tcaEquipmentOutputCurrentMax

障害コード : F39536

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputCurrentMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39536
mibFaultName: tcaEquipmentOutputCurrentMax
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

tcaEquipmentOutputCurrentAvg

障害コード : F39537

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputCurrentAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39537
mibFaultName: tcaEquipmentOutputCurrentAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

tcaEquipmentOutputPower

障害コード : F39541

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39541
mibFaultName: tcaEquipmentOutputPower
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentOutputPowerMin

障害コード : F39543

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39543
mibFaultName: tcaEquipmentOutputPowerMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentOutputPowerMax

障害コード : F39544

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39544
mibFaultName: tcaEquipmentOutputPowerMax
moClass: equipment:RackUnitPsuStats
Type: generic
```

```

autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputPowerAvg

障害コード : F39545

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputPowerAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39545
mibFaultName: tcaEquipmentOutputPowerAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentInputPower

障害コード : F39549

Message: Threshold Crossed: equipment:PsuStats property: inputPower

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39549
mibFaultName: tcaEquipmentInputPower
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentInputPowerMin

障害コード : F39551

Message: Threshold Crossed: equipment:PsuStats property: inputPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39551
mibFaultName: tcaEquipmentInputPowerMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentInputPowerMax

障害コード : F39552

Message: Threshold Crossed: equipment:PsuStats property: inputPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39552
mibFaultName: tcaEquipmentInputPowerMax
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentInputPowerAvg

障害コード : F39553

Message: Threshold Crossed: equipment:PsuStats property: inputPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
```

```

mibFaultCode: F39553
mibFaultName: tcaEquipmentInputPowerAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputVoltage

障害コード : F39557

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputVoltage

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39557
mibFaultName: tcaEquipmentOutputVoltage
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputVoltageMin

障害コード : F39559

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputVoltageMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F39559
mibFaultName: tcaEquipmentOutputVoltageMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

```

tcaEquipmentOutputVoltageMax

障害コード : F39560

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputVoltageMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39560
mibFaultName: tcaEquipmentOutputVoltageMax
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentOutputVoltageAvg

障害コード : F39561

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputVoltageAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39561
mibFaultName: tcaEquipmentOutputVoltageAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentInputVoltage

障害コード : F39565

Message: Threshold Crossed: equipment:RackUnitPsuStats property: inputVoltage

説明 :

推奨処置 :

障害の詳細


```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39565
mibFaultName: tcaEquipmentInputVoltage
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentInputVoltageMin

障害コード : F39567

Message: Threshold Crossed: equipment:RackUnitPsuStats property: outputVoltageMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39567
mibFaultName: tcaEquipmentInputVoltageMin
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats
```

tcaEquipmentInputVoltageMax

障害コード : F39568

Message: Threshold Crossed: equipment:RackUnitPsuStats property: inputVoltageMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39568
mibFaultName: tcaEquipmentInputVoltageMax
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
```

Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

tcaEquipmentInputVoltageAvg

障害コード : F39569

Message: Threshold Crossed: equipment:RackUnitPsuStats property: inputVoltageAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39569
mibFaultName: tcaEquipmentInputVoltageAvg
moClass: equipment:RackUnitPsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/fex-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/rackunit-power-stats
Affected MO: sys/switch-[id]/psu-[id]/rackunit-power-stats

tcaEquipmentSpeed

障害コード : F39575

Message: Threshold Crossed: equipment:RackUnitFanStats property: speed

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F39575
mibFaultName: tcaEquipmentSpeed
moClass: equipment:RackUnitFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentSpeedMin

障害コード : F39577

Message: Threshold Crossed: equipment:RackUnitFanStats property: speedMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39577
mibFaultName: tcaEquipmentSpeedMin
moClass: equipment:RackUnitFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats
```

tcaEquipmentSpeedMax

障害コード : F39578

Message: Threshold Crossed: equipment:RackUnitFanStats property: speedMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39578
mibFaultName: tcaEquipmentSpeedMax
moClass: equipment:RackUnitFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats
```

tcaEquipmentSpeedAvg

障害コード : F39579

Message: Threshold Crossed: equipment:RackUnitFanStats property: speedAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F39579
mibFaultName: tcaEquipmentSpeedAvg
```

```

moClass: equipment:RackUnitFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaComputeFrontTemp

障害コード : F40092

Message: Threshold Crossed: compute:RackUnitMbTempStats property: frontTemp

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40092
mibFaultName: tcaComputeFrontTemp
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeFrontTempMin

障害コード : F40094

Message: Threshold Crossed: compute:RackUnitMbTempStats property: frontTempMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40094
mibFaultName: tcaComputeFrontTempMin
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeFrontTempMax

障害コード : F40095

Message: Threshold Crossed: compute:RackUnitMbTempStats property: frontTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40095
mibFaultName: tcaComputeFrontTempMax
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeFrontTempAvg

障害コード : F40096

Message: Threshold Crossed: compute:RackUnitMbTempStats property: frontTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40096
mibFaultName: tcaComputeFrontTempAvg
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeRearTemp

障害コード : F40100

Message: Threshold Crossed: compute:RackUnitMbTempStats property: rearTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40100
mibFaultName: tcaComputeRearTemp
moClass: compute:RackUnitMbTempStats
Type: server
```

```

autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeRearTempMin

障害コード : F40102

Message: Threshold Crossed: compute:RackUnitMbTempStats property: rearTempMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40102
mibFaultName: tcaComputeRearTempMin
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeRearTempMax

障害コード : F40103

Message: Threshold Crossed: compute:RackUnitMbTempStats property: rearTempMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40103
mibFaultName: tcaComputeRearTempMax
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeRearTempAvg

障害コード : F40104

Message: Threshold Crossed: compute:RackUnitMbTempStats property: rearTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40104
mibFaultName: tcaComputeRearTempAvg
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

tcaComputeAmbientTemp

障害コード : F40108

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ambientTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40108
mibFaultName: tcaComputeAmbientTemp
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

tcaComputeAmbientTempMin

障害コード : F40110

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ambientTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40110
mibFaultName: tcaComputeAmbientTempMin
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

tcaComputeAmbientTempMax

障害コード : F40111

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ambientTempMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40111
mibFaultName: tcaComputeAmbientTempMax
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeAmbientTempAvg

障害コード : F40112

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ambientTempAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40112
mibFaultName: tcaComputeAmbientTempAvg
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats

```

tcaComputeIoh1Temp

障害コード : F40116

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh1Temp

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40116

```



```
mibFaultName: tcaComputeIoh1Temp
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeloh1TempMin

障害コード : F40118

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh1TempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40118
mibFaultName: tcaComputeIoh1TempMin
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeloh1TempMax

障害コード : F40119

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh1TempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40119
mibFaultName: tcaComputeIoh1TempMax
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeloh1TempAvg

障害コード : F40120

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh1TempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40120
mibFaultName: tcaComputeIoh1TempAvg
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeloh2Temp

障害コード : F40124

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh2Temp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40124
mibFaultName: tcaComputeIoh2Temp
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeloh2TempMin

障害コード : F40126

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh2TempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40126
mibFaultName: tcaComputeIoh2TempMin
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeIoh2TempMax

障害コード : F40127

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh2TempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40127
mibFaultName: tcaComputeIoh2TempMax
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaComputeIoh2TempAvg

障害コード : F40128

Message: Threshold Crossed: compute:RackUnitMbTempStats property: ioh2TempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40128
mibFaultName: tcaComputeIoh2TempAvg
moClass: compute:RackUnitMbTempStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/temp-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/temp-stats
Affected MO: sys/rack-unit-[id]/board/temp-stats
```

tcaEquipmentCurrent

障害コード : F40547

Message: Threshold Crossed: equipment:PsuOutputStats property: current

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40547
```

```

mibFaultName: tcaEquipmentCurrent
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

```

tcaEquipmentCurrentMin

障害コード : F40549

Message: Threshold Crossed: equipment:PsuOutputStats property: currentMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40549
mibFaultName: tcaEquipmentCurrentMin
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

```

tcaEquipmentCurrentMax

障害コード : F40550

Message: Threshold Crossed: equipment:PsuOutputStats property: currentMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40550
mibFaultName: tcaEquipmentCurrentMax
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

```

tcaEquipmentCurrentAvg

障害コード : F40551

Message: Threshold Crossed: equipment:PsuOutputStats property: current

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40551
mibFaultName: tcaEquipmentCurrentAvg
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats
```

tcaEquipmentVoltage

障害コード : F40555

Message: Threshold Crossed: equipment:PsuOutputStats property: voltage

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40555
mibFaultName: tcaEquipmentVoltage
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats
```

tcaEquipmentVoltageMin

障害コード : F40557

Message: Threshold Crossed: equipment:PsuOutputStats property: voltageMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40557
mibFaultName: tcaEquipmentVoltageMin
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

```

tcaEquipmentVoltageMax

障害コード : F40558

Message: Threshold Crossed: equipment:PsuOutputStats property: voltageMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40558
mibFaultName: tcaEquipmentVoltageMax
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

```

tcaEquipmentVoltageAvg

障害コード : F40559

Message: Threshold Crossed: equipment:PsuOutputStats property: voltageAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40559
mibFaultName: tcaEquipmentVoltageAvg
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats

```

Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

tcaEquipmentPower

障害コード : F40563

Message: Threshold Crossed: equipment:PsuOutputStats property: power

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40563
mibFaultName: tcaEquipmentPower
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

tcaEquipmentPowerMin

障害コード : F40565

Message: Threshold Crossed: equipment:PsuOutputStats property: powerMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40565
mibFaultName: tcaEquipmentPowerMin
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats

tcaEquipmentPowerMax

障害コード : F40566

Message: Threshold Crossed: equipment:PsuOutputStats property: powerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40566
mibFaultName: tcaEquipmentPowerMax
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats
```

tcaEquipmentPowerAvg

障害コード : F40567

Message: Threshold Crossed: equipment:PsuOutputStats property: powerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40567
mibFaultName: tcaEquipmentPowerAvg
moClass: equipment:PsuOutputStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/output-stats
Affected MO: sys/fex-[id]/psu-[id]/output-stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/output-stats
Affected MO: sys/rack-unit-[id]/psu-[id]/output-stats
Affected MO: sys/switch-[id]/psu-[id]/output-stats
```

tcaEquipmentSpeed

障害コード : F40574

Message: Threshold Crossed: equipment:NetworkElementFanStats property: speed

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F40574
mibFaultName: tcaEquipmentSpeed
moClass: equipment:NetworkElementFanStats
Type: generic
```



```

autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaEquipmentSpeedMin

障害コード : F40576

Message: Threshold Crossed: equipment:NetworkElementFanStats property: speedMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40576
mibFaultName: tcaEquipmentSpeedMin
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaEquipmentSpeedMax

障害コード : F40577

Message: Threshold Crossed: equipment:NetworkElementFanStats property: speed

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40577
mibFaultName: tcaEquipmentSpeedMax
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaEquipmentSpeedAvg

障害コード : F40578

Message: Threshold Crossed: equipment:NetworkElementFanStats property: speedAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40578
mibFaultName: tcaEquipmentSpeedAvg
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaEquipmentDrivePercentage

障害コード : F40582

Message: Threshold Crossed: equipment:NetworkElementFanStats property: drivePercentage

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F40582
mibFaultName: tcaEquipmentDrivePercentage
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaEquipmentDrivePercentageMin

障害コード : F40584

Message: Threshold Crossed: equipment:NetworkElementFanStats property: drivePercentageMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40584
mibFaultName: tcaEquipmentDrivePercentageMin
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentDrivePercentageMax

障害コード : F40585

Message: Threshold Crossed: equipment:NetworkElementFanStats property: drivePercentageMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40585
mibFaultName: tcaEquipmentDrivePercentageMax
moClass: equipment:NetworkElementFanStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

tcaEquipmentDrivePercentageAvg

障害コード : F40586

Message: Threshold Crossed: equipment:NetworkElementFanStats property: drivePercentageAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F40586
mibFaultName: tcaEquipmentDrivePercentageAvg
moClass: equipment:NetworkElementFanStats
Type: generic

```

autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/fex-[id]/fan-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/fan-[id]/stats

```

tcaSwSlotOutlet1

障害コード : F41199

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet1

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41199
mibFaultName: tcaSwSlotOutlet1
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

```

tcaSwSlotOutlet1Min

障害コード : F41201

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet1Min

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41201
mibFaultName: tcaSwSlotOutlet1Min
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

```

tcaSwSlotOutlet1Max

障害コード : F41202

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet1Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41202
mibFaultName: tcaSwSlotOutlet1Max
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet1Avg

障害コード : F41203

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet1Avg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41203
mibFaultName: tcaSwSlotOutlet1Avg
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet2

障害コード : F41207

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet2

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41207
mibFaultName: tcaSwSlotOutlet2
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet2Min

障害コード : F41209

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet2Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41209
mibFaultName: tcaSwSlotOutlet2Min
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet2Max

障害コード : F41210

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet2Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41210
mibFaultName: tcaSwSlotOutlet2Max
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet2Avg

障害コード : F41211

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet2Avg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41211
mibFaultName: tcaSwSlotOutlet2Avg
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet3

障害コード : F41215

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet3

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41215
mibFaultName: tcaSwSlotOutlet3
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet3Min

障害コード : F41217

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet3Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41217
mibFaultName: tcaSwSlotOutlet3Min
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet3Max

障害コード : F41218

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet3Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41218
mibFaultName: tcaSwSlotOutlet3Max
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats

tcaSwSlotOutlet3Avg

障害コード : F41219

Message: Threshold Crossed: sw:CardEnvStats property: SlotOutlet3Avg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F41219
mibFaultName: tcaSwSlotOutlet3Avg
moClass: sw:CardEnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/cardenvstats
```

tcaEtherPacketsTxDelta

障害コード : F41289

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsTxDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F41289
mibFaultName: tcaEtherPacketsTxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanepc-[portId]/fcoe-interface-stats
Affected MO:
```



```

fabric/san/[id]/fcoesanep-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanep-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherPacketsTxDeltaMin

障害コード : F41290

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41290
mibFaultName: tcaEtherPacketsTxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:

```

```

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherPacketsTxDeltaMax

障害コード : F41291

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41291
mibFaultName: tcaEtherPacketsTxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats**Affected MO:**

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherPacketsTxDeltaAvg

障害コード : F41292

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info**Cause:** threshold-crossed**mibFaultCode:** F41292**mibFaultName:** tcaEtherPacketsTxDeltaAvg**moClass:** ether:FcoeInterfaceStats**Type:** server**autoCleared:** true**Affected MO:**

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherPacketsRxDelta

障害コード : F41299

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41299

mibFaultName: tcaEtherPacketsRxDelta

moClass: ether:FcoeInterfaceStats

Type: server

```

autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherPacketsRxDeltaMin

障害コード : F41300

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41300
mibFaultName: tcaEtherPacketsRxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherPacketsRxDeltaMax

障害コード : F41301

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsRxDeltaMax

説明：

推奨処置：

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F41301
mibFaultName: tcaEtherPacketsRxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanepc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanepc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanepc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
```

tcaEtherPacketsRxDeltaAvg

障害コード : F41302

Message: Threshold Crossed: ether:FcoeInterfaceStats property: packetsRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41302
mibFaultName: tcaEtherPacketsRxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```


Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherBytesTxDelta

障害コード : F41309

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesTxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41309

mibFaultName: tcaEtherBytesTxDelta

moClass: ether:FcoeInterfaceStats

Type: server

autoCleared: true

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

```

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherBytesTxDeltaMin

障害コード : F41310

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41310
mibFaultName: tcaEtherBytesTxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherBytesTxDeltaMax

障害コード : F41311

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41311
mibFaultName: tcaEtherBytesTxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherBytesTxDeltaAvg

障害コード : F41312

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41312

mibFaultName: tcaEtherBytesTxDeltaAvg

moClass: ether:FcoeInterfaceStats

Type: server

autoCleared: true

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

```

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherBytesRxDelta

障害コード : F41319

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesRxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41319
mibFaultName: tcaEtherBytesRxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherBytesRxDeltaMin

障害コード : F41320

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesRxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41320
mibFaultName: tcaEtherBytesRxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherBytesRxDeltaMax

障害コード : F41321

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesRxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

```

mibFaultCode: F41321
mibFaultName: tcaEtherBytesRxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherBytesRxDeltaAvg

障害コード : F41322

Message: Threshold Crossed: ether:FcoeInterfaceStats property: bytesRxDeltaAvg

説明 :

推奨処置：

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41322
mibFaultName: tcaEtherBytesRxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsTxDelta

障害コード : F41329

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsTxDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41329
mibFaultName: tcaEtherErrorsTxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsTxDeltaMin

障害コード : F41330

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsTxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41330

mibFaultName: tcaEtherErrorsTxDeltaMin

moClass: ether:FcoeInterfaceStats

Type: server

autoCleared: true

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

```

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherErrorsTxDeltaMax

障害コード : F41331

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41331
mibFaultName: tcaEtherErrorsTxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsTxDeltaAvg

障害コード : F41332

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41332
mibFaultName: tcaEtherErrorsTxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsRxDelta

障害コード : F41339

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41339
mibFaultName: tcaEtherErrorsRxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:

```

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherErrorsRxDeltaMin

障害コード : F41340

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsRxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41340
mibFaultName: tcaEtherErrorsRxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsRxDeltaMax

障害コード : F41341

Message: Threshold Crossed: ether:FcoeInterfaceStats property: errorsRxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41341
mibFaultName: tcaEtherErrorsRxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherErrorsRxDeltaAvg

障害コード : F41342

メッセージ: しきい値 Crossed: イーサ: FcoeInterfaceStats プロパティ: errorsRxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

```

mibFaultCode: F41342
mibFaultName: tcaEtherErrorsRxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherDroppedTxDelta

障害コード : F41349

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDelta

説明 :

推奨処置：

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41349
mibFaultName: tcaEtherDroppedTxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherDroppedTxDeltaMin

障害コード : F41350

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41350
mibFaultName: tcaEtherDroppedTxDeltaMin
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherDroppedTxDeltaMax

障害コード : F41351

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41351

mibFaultName: tcaEtherDroppedTxDeltaMax

moClass: ether:FcoeInterfaceStats

Type: server

autoCleared: true

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

```

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherDroppedTxDeltaAvg

障害コード : F41352

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41352
mibFaultName: tcaEtherDroppedTxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherDroppedRxDelta

障害コード : F41359

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedRxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41359
mibFaultName: tcaEtherDroppedRxDelta
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherDroppedRxDeltaMin

障害コード : F41360

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

mibFaultCode: F41360

mibFaultName: tcaEtherDroppedRxDeltaMin

moClass: ether:FcoeInterfaceStats

Type: server

autoCleared: true

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:


```

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

tcaEtherDroppedRxDeltaMax

障害コード : F41361

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedRxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F41361
mibFaultName: tcaEtherDroppedRxDeltaMax
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

```

Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/lanmon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/sanmon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats
Affected MO:
 fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherDroppedRxDeltaAvg

障害コード : F41362

Message: Threshold Crossed: ether:FcoeInterfaceStats property: droppedTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F41362
mibFaultName: tcaEtherDroppedRxDeltaAvg
moClass: ether:FcoeInterfaceStats
Type: server
autoCleared: true
Affected MO:
 fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/eth-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/fc-estc/[id]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/fc-estc/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lan/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/lammon/[id]/eth-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO: fabric/san/[id]/fcoesanpc-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/fcoesanpc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/san/[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/sammon/[id]/fc-mon-[name]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/pc-[portId]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoe-slot-[slotId]-port-[portId]/fcoe-interface-stats

Affected MO:

fabric/server/sw-[id]/slot-[slotId]-aggr-port-[aggrPortId]/phys-fcoesanep-slot-[slotId]-port-[portId]/fcoe-interface-stats

tcaEtherFrameTxDelta

障害コード : F43294

Message: Threshold Crossed: ether:NiErrStats property: frameTxDelta

説明 :

推奨処置 :

障害の詳細

Severity: info

Cause: threshold-crossed

```

mibFaultCode: F43294
mibFaultName: tcaEtherFrameTxDelta
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherFrameTxDeltaMin

障害コード : F43295

Message: Threshold Crossed: ether:NiErrStats property: frameTxDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43295
mibFaultName: tcaEtherFrameTxDeltaMin
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:

```

```

sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherFrameTxDeltaMax

障害コード : F43296

Message: Threshold Crossed: ether:NiErrStats property: frameTxDeltaMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43296
mibFaultName: tcaEtherFrameTxDeltaMax
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherFrameTxDeltaAvg

障害コード : F43297

Message: Threshold Crossed: ether:NiErrStats property: frameTxDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43297
mibFaultName: tcaEtherFrameTxDeltaAvg
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
```

tcaEtherTooLongDelta

障害コード : F43304

Message: Threshold Crossed: ether:NiErrStats property: tooLongDelta

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43304
mibFaultName: tcaEtherTooLongDelta
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
```

Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherTooLongDeltaMin

障害コード : F43305

Message: Threshold Crossed: ether:NiErrStats property: tooLongDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F43305
mibFaultName: tcaEtherTooLongDeltaMin
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherTooLongDeltaMax

障害コード : F43306

Message: Threshold Crossed: ether:NiErrStats property: tooLongDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F43306
mibFaultName: tcaEtherTooLongDeltaMax
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherTooLongDeltaAvg

障害コード : F43307

Message: Threshold Crossed: ether:NiErrStats property: tooLongDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed


```

mibFaultCode: F43307
mibFaultName: tcaEtherTooLongDeltaAvg
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherTooShortDelta

障害コード : F43314

Message: Threshold Crossed: ether:NiErrStats property: tooShortDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43314
mibFaultName: tcaEtherTooShortDelta
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:

```

```

sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherTooShortDeltaMin

障害コード : F43315

Message: Threshold Crossed: ether:NiErrStats property: tooShortDeltaMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43315
mibFaultName: tcaEtherTooShortDeltaMin
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherTooShortDeltaMax

障害コード : F43316

Message: Threshold Crossed: ether:NiErrStats property: tooShortDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43316
mibFaultName: tcaEtherTooShortDeltaMax
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
```

tcaEtherTooShortDeltaAvg

障害コード : F43317

Message: Threshold Crossed: ether:NiErrStats property: tooShortDeltaAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43317
mibFaultName: tcaEtherTooShortDeltaAvg
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
```

Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherCrcDelta

障害コード : F43324

Message: Threshold Crossed: ether:NiErrStats property: crcDelta

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F43324
mibFaultName: tcaEtherCrcDelta
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherCrcDeltaMin

障害コード : F43325

Message: Threshold Crossed: ether:NiErrStats property: crcDeltaMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F43325
mibFaultName: tcaEtherCrcDeltaMin
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherCrcDeltaMax

障害コード : F43326

Message: Threshold Crossed: ether:NiErrStats property: crcDeltaMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed

```

mibFaultCode: F43326
mibFaultName: tcaEtherCrcDeltaMax
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherCrcDeltaAvg

障害コード : F43327

Message: Threshold Crossed: ether:NiErrStats property: crcDeltaAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43327
mibFaultName: tcaEtherCrcDeltaAvg
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:

```

```

sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherInRangeDelta

障害コード : F43334

Message: Threshold Crossed: ether:NiErrStats property: inRangeDelta

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F43334
mibFaultName: tcaEtherInRangeDelta
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

```

tcaEtherInRangeDeltaMin

障害コード : F43335

Message: Threshold Crossed: ether:NiErrStats property: inRangeDeltaMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43335
mibFaultName: tcaEtherInRangeDeltaMin
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
```

tcaEtherInRangeDeltaMax

障害コード : F43336

Message: Threshold Crossed: ether:NiErrStats property: inRangeDeltaMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F43336
mibFaultName: tcaEtherInRangeDeltaMax
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
```


Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEtherInRangeDeltaAvg

障害コード : F43337

Message: Threshold Crossed: ether:NiErrStats property: inRangeDeltaAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F43337
mibFaultName: tcaEtherInRangeDeltaAvg
moClass: ether:NiErrStats
Type: equipment
autoCleared: true
Affected MO:
 sys/chassis-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/slot-[id]/shared-io-module/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/slot-[id]/shared-io-module/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/chassis-[id]/sw-slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/fex-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/fex-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats
Affected MO:
 sys/switch-[id]/slot-[id]/[type]/aggr-port-[aggrPortId]/port-[portId]/ni-err-stats

Affected MO: sys/switch-[id]/slot-[id]/[type]/pc-[portId]/ni-err-stats
Affected MO: sys/switch-[id]/slot-[id]/[type]/port-[portId]/ni-err-stats

tcaEquipmentProcTemp

障害コード : F44131

Message: Threshold Crossed: equipment:IOCardStats property: procTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44131
mibFaultName: tcaEquipmentProcTemp
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentProcTempMin

障害コード : F44133

Message: Threshold Crossed: equipment:IOCardStats property: procTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44133
mibFaultName: tcaEquipmentProcTempMin
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentProcTempMax

障害コード : F44134

Message: Threshold Crossed: equipment:IOCardStats property: procTempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44134
mibFaultName: tcaEquipmentProcTempMax
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentProcTempAvg

障害コード : F44135

Message: Threshold Crossed: equipment:IOCardStats property: procTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44135
mibFaultName: tcaEquipmentProcTempAvg
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentDimmTemp

障害コード : F44139

Message: Threshold Crossed: equipment:IOCardStats property: dimmTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44139
mibFaultName: tcaEquipmentDimmTemp
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

tcaEquipmentDimmTempMin

障害コード : F44141

Message: Threshold Crossed: equipment:IOCardStats property: dimmTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44141
mibFaultName: tcaEquipmentDimmTempMin
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentDimmTempMax

障害コード : F44142

Message: Threshold Crossed: equipment:IOCardStats property: dimmTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44142
mibFaultName: tcaEquipmentDimmTempMax
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentDimmTempAvg

障害コード : F44143

Message: Threshold Crossed: equipment:IOCardStats property: dimmTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44143
```

```

mibFaultName: tcaEquipmentDimmTempAvg
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats

```

tcaStorageTemperature

障害コード : F44217

Message: Threshold Crossed: storage:DiskEnvStats property: temperature

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F44217
mibFaultName: tcaStorageTemperature
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

```

tcaStorageTemperatureMin

障害コード : F44219

Message: Threshold Crossed: storage:DiskEnvStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F44219
mibFaultName: tcaStorageTemperatureMin

```

```

moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

```

tcaStorageTemperatureMax

障害コード : F44220

Message: Threshold Crossed: storage:DiskEnvStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F44220
mibFaultName: tcaStorageTemperatureMax
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

```

tcaStorageTemperatureAvg

障害コード : F44221

Message: Threshold Crossed: storage:DiskEnvStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44221
mibFaultName: tcaStorageTemperatureAvg
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats
```

tcaStorageWearPercentage

障害コード : F44225

Message: Threshold Crossed: storage:DiskEnvStats property: wearPercentage

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44225
mibFaultName: tcaStorageWearPercentage
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

tcaStorageWearPercentageMin

障害コード : F44227

Message: Threshold Crossed: storage:DiskEnvStats property: wearPercentageMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44227
mibFaultName: tcaStorageWearPercentageMin
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

tcaStorageWearPercentageMax

障害コード : F44228

Message: Threshold Crossed: storage:DiskEnvStats property: wearPercentageMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F44228


```

mibFaultName: tcaStorageWearPercentageMax
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

```

tcaStorageWearPercentageAvg

障害コード : F44229

Message: Threshold Crossed: storage:DiskEnvStats property: wearPercentageAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F44229
mibFaultName: tcaStorageWearPercentageAvg
moClass: storage:DiskEnvStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/disk-env-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/disk-env-stats

```

tcaEquipmentInputPower

障害コード : F44564

Message: Threshold Crossed: equipment:PsuStats property: inputPower

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44564
mibFaultName: tcaEquipmentInputPower
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentInputPowerMin

障害コード : F44566

Message: Threshold Crossed: equipment:PsuStats property: inputPowerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44566
mibFaultName: tcaEquipmentInputPowerMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentInputPowerMax

障害コード : F44567

Message: Threshold Crossed: equipment:PsuStats property: inputPowerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44567
mibFaultName: tcaEquipmentInputPowerMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentInputPowerAvg

障害コード : F44568

Message: Threshold Crossed: equipment:PsuStats property: inputPowerAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44568
mibFaultName: tcaEquipmentInputPowerAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentChassisI2CErrors

障害コード : F44728

Message: Threshold Crossed: equipment:ChassisStats property: ChassisI2CErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44728
mibFaultName: tcaEquipmentChassisI2CErrors
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats
```

tcaEquipmentIomI2CErrors

障害コード : F44738

Message: Threshold Crossed: equipment:IOCardStats property: IomI2CErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44738
mibFaultName: tcaEquipmentIomI2CErrors
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentPsuI2CErrors

障害コード : F44748

Message: Threshold Crossed: equipment:PsuStats property: PsuI2CErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F44748
mibFaultName: tcaEquipmentPsuI2CErrors
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaSwDonner

障害コード : F45019

Message: Threshold Crossed: sw:EnvStats property: donner

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```
Cause: threshold-crossed
mibFaultCode: F45019
mibFaultName: tcaSwDonner
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwDonnerMin

障害コード : F45021

Message: Threshold Crossed: sw:EnvStats property: donnerMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45021
mibFaultName: tcaSwDonnerMin
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwDonnerMax

障害コード : F45022

Message: Threshold Crossed: sw:EnvStats property: donnerMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45022
mibFaultName: tcaSwDonnerMax
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats
```

tcaSwDonnerAvg

障害コード : F45023

Message: Threshold Crossed: sw:EnvStats property: donnerAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45023
mibFaultName: tcaSwDonnerAvg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTd2

障害コード : F45027

Message: Threshold Crossed: sw:EnvStats property: td2

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45027
mibFaultName: tcaSwTd2
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTd2Min

障害コード : F45029

Message: Threshold Crossed: sw:EnvStats property: td2Min

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45029
mibFaultName: tcaSwTd2Min
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTd2Max

障害コード : F45030

Message: Threshold Crossed: sw:EnvStats property: td2Max

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45030
mibFaultName: tcaSwTd2Max
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTd2Avg

障害コード : F45031

Message: Threshold Crossed: sw:EnvStats property: td2Avg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45031
mibFaultName: tcaSwTd2Avg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTiburon

障害コード : F45035

Message: Threshold Crossed: sw:EnvStats property: tiburon

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45035
mibFaultName: tcaSwTiburon
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTiburonMin

障害コード : F45037

Message: Threshold Crossed: sw:EnvStats property: tiburonMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45037
mibFaultName: tcaSwTiburonMin
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTiburonMax

障害コード : F45038

Message: Threshold Crossed: sw:EnvStats property: tiburonMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45038
mibFaultName: tcaSwTiburonMax
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwTiburonAvg

障害コード : F45039

Message: Threshold Crossed: sw:EnvStats property: tiburonAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45039
mibFaultName: tcaSwTiburonAvg
moClass: sw:EnvStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/envstats

tcaSwKernelMemTotal

障害コード : F45043

Message: Threshold Crossed: sw:SystemStats property: kernelMemTotal

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45043
mibFaultName: tcaSwKernelMemTotal
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemTotalMin

障害コード : F45045

Message: Threshold Crossed: sw:SystemStats property: kernelMemTotalMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45045
mibFaultName: tcaSwKernelMemTotalMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemTotalMax

障害コード : F45046

Message: Threshold Crossed: sw:SystemStats property: kernelMemTotalMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45046
mibFaultName: tcaSwKernelMemTotalMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemTotalAvg

障害コード : F45047

Message: Threshold Crossed: sw:SystemStats property: kernelMemTotalAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45047
mibFaultName: tcaSwKernelMemTotalAvg
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemFree

障害コード : F45051

Message: Threshold Crossed: sw:SystemStats property: kernelMemFree

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45051
mibFaultName: tcaSwKernelMemFree
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemFreeMin

障害コード : F45053

Message: Threshold Crossed: sw:SystemStats property: kernelMemFreeMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45053
mibFaultName: tcaSwKernelMemFreeMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemFreeMax

障害コード : F45054

Message: Threshold Crossed: sw:SystemStats property: kernelMemFreeMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45054
mibFaultName: tcaSwKernelMemFreeMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwKernelMemFreeAvg

障害コード : F45055

Message: Threshold Crossed: sw:SystemStats property: kernelMemFreeAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45055
mibFaultName: tcaSwKernelMemFreeAvg
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaEquipmentMemAvailable

障害コード : F45154

Message: Threshold Crossed: equipment:FexSystemStats property: memAvailable

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45154
mibFaultName: tcaEquipmentMemAvailable
moClass: equipment:FexSystemStats
Type: generic
```

```
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentMemAvailableMin

障害コード : F45156

Message: Threshold Crossed: equipment:FexSystemStats property: memAvailableMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45156
mibFaultName: tcaEquipmentMemAvailableMin
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentMemAvailableMax

障害コード : F45157

Message: Threshold Crossed: equipment:FexSystemStats property: memAvailableMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45157
mibFaultName: tcaEquipmentMemAvailableMax
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentMemAvailableAvg

障害コード : F45158

Message: Threshold Crossed: equipment:FexSystemStats property: memAvailableAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45158
```

mibFaultName: tcaEquipmentMemAvailableAvg
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentMemCached

障害コード : F45162

Message: Threshold Crossed: equipment:FexSystemStats property: memCached

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45162
mibFaultName: tcaEquipmentMemCached
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentMemCachedMin

障害コード : F45164

Message: Threshold Crossed: equipment:FexSystemStats property: memCachedMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45164
mibFaultName: tcaEquipmentMemCachedMin
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentMemCachedMax

障害コード : F45165

Message: Threshold Crossed: equipment:FexSystemStats property: memCachedMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45165
mibFaultName: tcaEquipmentMemCachedMax
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentMemCachedAvg

障害コード : F45166

Message: Threshold Crossed: equipment:FexSystemStats property: memCachedAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45166
mibFaultName: tcaEquipmentMemCachedAvg
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentLoad

障害コード : F45170

Message: Threshold Crossed: equipment:FexSystemStats property: load

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45170
mibFaultName: tcaEquipmentLoad
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentLoadMin

障害コード : F45172

Message: Threshold Crossed: equipment:FexSystemStats property: loadMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45172
mibFaultName: tcaEquipmentLoadMin
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentLoadMax

障害コード : F45173

Message: Threshold Crossed: equipment:FexSystemStats property: loadMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45173
mibFaultName: tcaEquipmentLoadMax
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentLoadAvg

障害コード : F45174

Message: Threshold Crossed: equipment:FexSystemStats property: loadAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45174
mibFaultName: tcaEquipmentLoadAvg
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats

tcaEquipmentKernelMemTotal

障害コード : F45178

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemTotal

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45178
mibFaultName: tcaEquipmentKernelMemTotal
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemTotalMin

障害コード : F45180

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemTotalMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45180
mibFaultName: tcaEquipmentKernelMemTotalMin
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemTotalMax

障害コード : F45181

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemTotalMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45181
mibFaultName: tcaEquipmentKernelMemTotalMax
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemTotalAvg

障害コード : F45182

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemTotalAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45182
mibFaultName: tcaEquipmentKernelMemTotalAvg
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemFree

障害コード : F45186

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemFree

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45186
mibFaultName: tcaEquipmentKernelMemFree
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemFreeMin

障害コード : F45188

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemFreeMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45188
mibFaultName: tcaEquipmentKernelMemFreeMin
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemFreeMax

障害コード : F45189

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemFreeMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45189
mibFaultName: tcaEquipmentKernelMemFreeMax
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaEquipmentKernelMemFreeAvg

障害コード : F45190

Message: Threshold Crossed: equipment:FexSystemStats property: kernelMemFreeAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45190
mibFaultName: tcaEquipmentKernelMemFreeAvg
moClass: equipment:FexSystemStats
Type: generic
autoCleared: true
Affected MO: sys/fex-[id]/sys-stats
```

tcaSwCorrectableParityError

障害コード : F45211

Message: Threshold Crossed: sw:SystemStats property: CorrectableParityError

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45211
mibFaultName: tcaSwCorrectableParityError
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwCorrectableParityErrorMin

障害コード : F45213

Message: Threshold Crossed: sw:SystemStats property: CorrectableParityErrorMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45213
mibFaultName: tcaSwCorrectableParityErrorMin
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwCorrectableParityErrorMax

障害コード : F45214

Message: Threshold Crossed: sw:SystemStats property: CorrectableParityErrorMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45214
mibFaultName: tcaSwCorrectableParityErrorMax
moClass: sw:SystemStats
Type: generic
autoCleared: true
Affected MO: sys/switch-[id]/sysstats
```

tcaSwCorrectableParityErrorAvg

障害コード : F45215

Message: Threshold Crossed: sw:SystemStats property: CorrectableParityErrorAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45215
mibFaultName: tcaSwCorrectableParityErrorAvg
moClass: sw:SystemStats
Type: generic
```

autoCleared: true
Affected MO: sys/switch-[id]/sysstats

tcaEquipmentChassisI2CErrorsMin

障害コード : F45266

Message: Threshold Crossed: equipment:ChassisStats property: ChassisI2CErrorsMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45266
mibFaultName: tcaEquipmentChassisI2CErrorsMin
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentChassisI2CErrorsMax

障害コード : F45267

Message: Threshold Crossed: equipment:ChassisStats property: ChassisI2CErrorsMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45267
mibFaultName: tcaEquipmentChassisI2CErrorsMax
moClass: equipment:ChassisStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/stats

tcaEquipmentChassisI2CErrorsAvg

障害コード : F45268

Message: Threshold Crossed: equipment:ChassisStats property: ChassisI2CErrorsAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45268

```
mibFaultName: tcaEquipmentChassisI2CErrorsAvg  
moClass: equipment:ChassisStats  
Type: generic  
autoCleared: true  
Affected MO: sys/chassis-[id]/stats
```

tcaEquipmentIomI2CErrorsMin

障害コード : F45272

Message: Threshold Crossed: equipment:IOCardStats property: IomI2CErrorsMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F45272  
mibFaultName: tcaEquipmentIomI2CErrorsMin  
moClass: equipment:IOCardStats  
Type: generic  
autoCleared: true  
Affected MO: sys/chassis-[id]/slot-[id]/stats  
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats  
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentIomI2CErrorsMax

障害コード : F45273

Message: Threshold Crossed: equipment:IOCardStats property: IomI2CErrorsMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info  
Cause: threshold-crossed  
mibFaultCode: F45273  
mibFaultName: tcaEquipmentIomI2CErrorsMax  
moClass: equipment:IOCardStats  
Type: generic  
autoCleared: true  
Affected MO: sys/chassis-[id]/slot-[id]/stats  
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats  
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentIomI2CErrorsAvg

障害コード : F45274

Message: Threshold Crossed: equipment:IOCardStats property: IomI2CErrorsAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45274
mibFaultName: tcaEquipmentIomI2CErrorsAvg
moClass: equipment:IOCardStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/stats
Affected MO: sys/chassis-[id]/sw-slot-[id]/stats
Affected MO: sys/fex-[id]/slot-[id]/stats
```

tcaEquipmentPsuI2CErrorsMin

障害コード : F45278

Message: Threshold Crossed: equipment:PsuStats property: PsuI2CErrorsMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45278
mibFaultName: tcaEquipmentPsuI2CErrorsMin
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats
```

tcaEquipmentPsuI2CErrorsMax

障害コード : F45279

Message: Threshold Crossed: equipment:PsuStats property: PsuI2CErrorsMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45279
mibFaultName: tcaEquipmentPsuI2CErrorsMax
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
```

Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentPsuI2CErrorsAvg

障害コード : F45280

Message: Threshold Crossed: equipment:PsuStats property: PsuI2CErrorsAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45280
mibFaultName: tcaEquipmentPsuI2CErrorsAvg
moClass: equipment:PsuStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/psu-[id]/stats
Affected MO: sys/fex-[id]/psu-[id]/stats
Affected MO: sys/rack-enclosure-[id]/psu-[id]/stats
Affected MO: sys/rack-unit-[id]/psu-[id]/stats
Affected MO: sys/switch-[id]/psu-[id]/stats

tcaEquipmentFanModuleI2CErrors

障害コード : F45284

Message: Threshold Crossed: equipment:FanModuleStats property: FanModuleI2CErrors

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45284
mibFaultName: tcaEquipmentFanModuleI2CErrors
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaEquipmentFanModuleI2CErrorsMin

障害コード : F45286

Message: Threshold Crossed: equipment:FanModuleStats property: FanModuleI2CErrorsMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45286
mibFaultName: tcaEquipmentFanModuleI2CErrorsMin
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaEquipmentFanModuleI2CErrorsMax

障害コード : F45287

Message: Threshold Crossed: equipment:FanModuleStats property: FanModuleI2CErrorsMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45287
mibFaultName: tcaEquipmentFanModuleI2CErrorsMax
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaEquipmentFanModuleI2CErrorsAvg

障害コード : F45288

Message: Threshold Crossed: equipment:FanModuleStats property: FanModuleI2CErrorsAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45288
mibFaultName: tcaEquipmentFanModuleI2CErrorsAvg
moClass: equipment:FanModuleStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/rack-enclosure-[id]/fan-module-[tray]-[id]/stats

Affected MO: sys/rack-unit-[id]/fan-module-[tray]-[id]/stats
Affected MO: sys/switch-[id]/fan-module-[tray]-[id]/stats

tcaStorageRightInletTemp

障害コード : F45374

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightInletTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45374
mibFaultName: tcaStorageRightInletTemp
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageRightInletTempMin

障害コード : F45376

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightInletTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45376
mibFaultName: tcaStorageRightInletTempMin
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats

Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageRightInletTempMax

障害コード : F45377

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightInletTempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45377
mibFaultName: tcaStorageRightInletTempMax
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageRightInletTempAvg

障害コード : F45378

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightInletTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45378
mibFaultName: tcaStorageRightInletTempAvg
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats

Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftInletTemp

障害コード : F45382

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftInletTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45382
mibFaultName: tcaStorageLeftInletTemp
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftInletTempMin

障害コード : F45384

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftInletTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45384
mibFaultName: tcaStorageLeftInletTempMin
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

```

tcaStorageLeftInletTempMax

障害コード : F45385

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftInletTempMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F45385
mibFaultName: tcaStorageLeftInletTempMax
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

```

tcaStorageLeftInletTempAvg

障害コード : F45386

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftInletTempAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F45386
mibFaultName: tcaStorageLeftInletTempAvg
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats

```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageRightOutletTemp

障害コード : F45390

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightOutletTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45390
mibFaultName: tcaStorageRightOutletTemp
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageRightOutletTempMin

障害コード : F45392

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightOutletTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45392
mibFaultName: tcaStorageRightOutletTempMin
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:

```
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats
```

tcaStorageRightOutletTempMax

障害コード : F45393

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightOutletTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45393
mibFaultName: tcaStorageRightOutletTempMax
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats
```

tcaStorageRightOutletTempAvg

障害コード : F45394

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: rightOutletTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45394
mibFaultName: tcaStorageRightOutletTempAvg
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
```

Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftOutletTemp

障害コード : F45398

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftOutletTemp

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45398
mibFaultName: tcaStorageLeftOutletTemp
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftOutletTempMin

障害コード : F45400

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftOutletTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45400
mibFaultName: tcaStorageLeftOutletTempMin
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats

Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftOutletTempMax

障害コード : F45401

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftOutletTempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45401
mibFaultName: tcaStorageLeftOutletTempMax
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats

tcaStorageLeftOutletTempAvg

障害コード : F45402

Message: Threshold Crossed: storage:HddMotherBoardTempStats property: leftOutletTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45402
mibFaultName: tcaStorageLeftOutletTempAvg
moClass: storage:HddMotherBoardTempStats
Type: generic
autoCleared: true
Affected MO:


```
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/hdd-mobo-temp-stats
Affected MO: sys/rack-unit-[id]/enc-[id]/hdd-mobo-temp-stats
```

tcaEquipmentRearTemp

障害コード : F45506

Message: Threshold Crossed: equipment:SiocTempStats property: rearTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45506
mibFaultName: tcaEquipmentRearTemp
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentRearTempMin

障害コード : F45508

Message: Threshold Crossed: equipment:SiocTempStats property: rearTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45508
mibFaultName: tcaEquipmentRearTempMin
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentRearTempMax

障害コード : F45509

Message: Threshold Crossed: equipment:SiocTempStats property: rearTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45509
mibFaultName: tcaEquipmentRearTempMax
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentRearTempAvg

障害コード : F45510

Message: Threshold Crossed: equipment:SiocTempStats property: rearTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45510
mibFaultName: tcaEquipmentRearTempAvg
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentFrontTemp

障害コード : F45514

Message: Threshold Crossed: equipment:SiocTempStats property: frontTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45514
mibFaultName: tcaEquipmentFrontTemp
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentFrontTempMin

障害コード : F45516

Message: Threshold Crossed: equipment:SiocTempStats property: frontTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45516
mibFaultName: tcaEquipmentFrontTempMin
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentFrontTempMax

障害コード : F45517

Message: Threshold Crossed: equipment:SiocTempStats property: frontTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45517
mibFaultName: tcaEquipmentFrontTempMax
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentFrontTempAvg

障害コード : F45518

Message: Threshold Crossed: equipment:SiocTempStats property: frontTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45518
mibFaultName: tcaEquipmentFrontTempAvg
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentMidTemp

障害コード : F45522

Message: Threshold Crossed: equipment:SiocTempStats property: midTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45522
mibFaultName: tcaEquipmentMidTemp
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentMidTempMin

障害コード : F45524

Message: Threshold Crossed: equipment:SiocTempStats property: midTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45524
mibFaultName: tcaEquipmentMidTempMin
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentMidTempMax

障害コード : F45525

Message: Threshold Crossed: equipment:SiocTempStats property: midTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45525
mibFaultName: tcaEquipmentMidTempMax
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentMidTempAvg

障害コード : F45526

Message: Threshold Crossed: equipment:SiocTempStats property: midTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45526
mibFaultName: tcaEquipmentMidTempAvg
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentCmcTemp

障害コード : F45530

Message: Threshold Crossed: equipment:SiocTempStats property: cmcTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45530
mibFaultName: tcaEquipmentCmcTemp
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentCmcTempMin

障害コード : F45532

Message: Threshold Crossed: equipment:SiocTempStats property: cmcTempMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45532
mibFaultName: tcaEquipmentCmcTempMin
moClass: equipment:SiocTempStats
Type: generic
```

```
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentCmcTempMax

障害コード : F45533

Message: Threshold Crossed: equipment:SiocTempStats property: cmcTempMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45533
mibFaultName: tcaEquipmentCmcTempMax
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentCmcTempAvg

障害コード : F45534

Message: Threshold Crossed: equipment:SiocTempStats property: cmcTempAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45534
mibFaultName: tcaEquipmentCmcTempAvg
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats
```

tcaEquipmentVicTemp

障害コード : F45538

Message: Threshold Crossed: equipment:SiocTempStats property: vicTemp

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45538
```

mibFaultName: tcaEquipmentVicTemp
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats

tcaEquipmentVicTempMin

障害コード : F45540

Message: Threshold Crossed: equipment:SiocTempStats property: vicTempMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45540
mibFaultName: tcaEquipmentVicTempMin
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats

tcaEquipmentVicTempMax

障害コード : F45541

Message: Threshold Crossed: equipment:SiocTempStats property: vicTempMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45541
mibFaultName: tcaEquipmentVicTempMax
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats

tcaEquipmentVicTempAvg

障害コード : F45542

Message: Threshold Crossed: equipment:SiocTempStats property: vicTempAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45542
mibFaultName: tcaEquipmentVicTempAvg
moClass: equipment:SiocTempStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/slot-[id]/temp-stats

tcaStorageTemperature

障害コード : F45647

Message: Threshold Crossed: storage:NvmeStats property: temperature

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45647
mibFaultName: tcaStorageTemperature
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

tcaStorageTemperatureMin

障害コード : F45649

Message: Threshold Crossed: storage:NvmeStats property: temperatureMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45649
mibFaultName: tcaStorageTemperatureMin
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

tcaStorageTemperatureMax

障害コード : F45650

Message: Threshold Crossed: storage:NvmeStats property: temperatureMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45650
mibFaultName: tcaStorageTemperatureMax
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats
```

tcaStorageTemperatureAvg

障害コード : F45651

Message: Threshold Crossed: storage:NvmeStats property: temperatureAvg

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F45651
mibFaultName: tcaStorageTemperatureAvg
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats
```

tcaStorageDriveLifeUsedPercentage

障害コード : F45655

Message: Threshold Crossed: storage:NvmeStats property: driveLifeUsedPercentage

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F45655
mibFaultName: tcaStorageDriveLifeUsedPercentage
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

```

tcaStorageDriveLifeUsedPercentageMin

障害コード : F45657

Message: Threshold Crossed: storage:NvmeStats property: driveLifeUsedPercentageMin

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F45657
mibFaultName: tcaStorageDriveLifeUsedPercentageMin
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

```

tcaStorageDriveLifeUsedPercentageMax

障害コード : F45658

Message: Threshold Crossed: storage:NvmeStats property: driveLifeUsedPercentageMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F45658
mibFaultName: tcaStorageDriveLifeUsedPercentageMax
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats

```

Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

tcaStorageDriveLifeUsedPercentageAvg

障害コード : F45659

Message: Threshold Crossed: storage:NvmeStats property: driveLifeUsedPercentageAvg

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F45659
mibFaultName: tcaStorageDriveLifeUsedPercentageAvg
moClass: storage:NvmeStats
Type: generic
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/nvme-stats
Affected MO: sys/chassis-[id]/storage-[type]-[id]/nvme-stats
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/nvme-stats

tcaStoragePowerOnHours

障害コード : F46020

Message: Threshold Crossed: storage:SsdHealthStats property: powerOnHours

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F46020
mibFaultName: tcaStoragePowerOnHours
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

tcaStoragePowerOnHoursMin

障害コード : F46022

Message: Threshold Crossed: storage:SsdHealthStats property: powerOnHoursMin

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F46022
mibFaultName: tcaStoragePowerOnHoursMin
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
 sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

tcaStoragePowerOnHoursMax

障害コード : F46023

Message: Threshold Crossed: storage:SsdHealthStats property: powerOnHoursMax

説明 :

推奨処置 :

障害の詳細

Severity: info
Cause: threshold-crossed
mibFaultCode: F46023
mibFaultName: tcaStoragePowerOnHoursMax
moClass: storage:SsdHealthStats
Type: server

```

autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePowerOnHoursAvg

障害コード : F46024

Message: Threshold Crossed: storage:SsdHealthStats property: powerOnHoursAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46024
mibFaultName: tcaStoragePowerOnHoursAvg
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStorageWearStatusInDays

障害コード : F46028

Message: Threshold Crossed: storage:SsdHealthStats property: wearStatusInDays

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46028
mibFaultName: tcaStorageWearStatusInDays
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
```

tcaStorageWearStatusInDaysMin

障害コード : F46030

Message: Threshold Crossed: storage:SsdHealthStats property: wearStatusInDaysMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46030
mibFaultName: tcaStorageWearStatusInDaysMin
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStorageWearStatusInDaysMax

障害コード : F46031

Message: Threshold Crossed: storage:SsdHealthStats property: wearStatusInDaysMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46031
mibFaultName: tcaStorageWearStatusInDaysMax
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStorageWearStatusInDaysAvg

障害コード : F46032

Message: Threshold Crossed: storage:SsdHealthStats property: wearStatusInDaysAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46032
mibFaultName: tcaStorageWearStatusInDaysAvg
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePowerCycleCount

障害コード : F46036

Message: Threshold Crossed: storage:SsdHealthStats property: powerCycleCount

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46036
mibFaultName: tcaStoragePowerCycleCount
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:

```



```
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
```

tcaStoragePowerCycleCountMin

障害コード : F46038

Message: Threshold Crossed: storage:SsdHealthStats property: powerCycleCountMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46038
mibFaultName: tcaStoragePowerCycleCountMin
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
```

tcaStoragePowerCycleCountMax

障害コード : F46039

Message: Threshold Crossed: storage:SsdHealthStats property: powerCycleCountMax

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46039
mibFaultName: tcaStoragePowerCycleCountMax
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
```

```

sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePowerCycleCountAvg

障害コード : F46040

Message: Threshold Crossed: storage:SsdHealthStats property: powerCycleCountAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46040
mibFaultName: tcaStoragePowerCycleCountAvg
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePercentageLifeLeft

障害コード : F46044

Message: Threshold Crossed: storage:SsdHealthStats property: percentageLifeLeft

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46044
mibFaultName: tcaStoragePercentageLifeLeft
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
```

tcaStoragePercentageLifeLeftMin

障害コード : F46046

Message: Threshold Crossed: storage:SsdHealthStats property: percentageLifeLeftMin

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46046
mibFaultName: tcaStoragePercentageLifeLeftMin
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
```

```

sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePercentageLifeLeftMax

障害コード : F46047

Message: Threshold Crossed: storage:SsdHealthStats property: percentageLifeLeftMax

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46047
mibFaultName: tcaStoragePercentageLifeLeftMax
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaStoragePercentageLifeLeftAvg

障害コード : F46048

Message: Threshold Crossed: storage:SsdHealthStats property: percentageLifeLeftAvg

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed

```

```

mibFaultCode: F46048
mibFaultName: tcaStoragePercentageLifeLeftAvg
moClass: storage:SsdHealthStats
Type: server
autoCleared: true
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/blade-[slotId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/blade-[slotId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/chassis-[id]/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/board/storage-[type]-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO:
sys/rack-unit-[id]/board/storage-[type]-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]
Affected MO: sys/rack-unit-[id]/enc-[id]/disk-[id]/ssd-health-stats-[id]

```

tcaMemoryDramWriteDataCorrectableCRCErrors

障害コード : F46248

Message: Threshold Crossed: memory:ErrorStats property: DramWriteDataCorrectableCRCErrors

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46248
mibFaultName: tcaMemoryDramWriteDataCorrectableCRCErrors
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

```

tcaMemoryDramWriteDataUncorrectableCRCErrors

障害コード : F46259

Message: Threshold Crossed: memory:ErrorStats property: DramWriteDataUncorrectableCRCErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
```

```

Cause: threshold-crossed
mibFaultCode: F46259
mibFaultName: tcaMemoryDramWriteDataUnCorrectableCRCErrors
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

```

tcaMemoryAddressParityErrorsCorrectable

障害コード : F46270

Message: Threshold Crossed: memory:ErrorStats property: addressParityErrorsCorrectable

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46270
mibFaultName: tcaMemoryAddressParityErrorsCorrectable
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

```

tcaMemoryAddressParityErrorsUnCorrectable

障害コード : F46281

Message: Threshold Crossed: memory:ErrorStats property: addressParityErrorsUnCorrectable

説明 :

推奨処置 :

障害の詳細

```

Severity: info
Cause: threshold-crossed
mibFaultCode: F46281
mibFaultName: tcaMemoryAddressParityErrorsUnCorrectable
moClass: memory:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/memarray-[id]/mem-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/memarray-[id]/mem-[id]/error-stats

```

tcaProcessorCorrectableLinkCRCErrors

障害コード : F46345

Message: Threshold Crossed: processor:ErrorStats property: CorrectableLinkCRCErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46345
mibFaultName: tcaProcessorCorrectableLinkCRCErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats
```

tcaProcessorUncorrectableLinkCRCErrors

障害コード:F46356

Message: Threshold Crossed: processor:ErrorStats property: UncorrectableLinkCRCErrors

説明 :

推奨処置 :

障害の詳細

```
Severity: info
Cause: threshold-crossed
mibFaultCode: F46356
mibFaultName: tcaProcessorUncorrectableLinkCRCErrors
moClass: processor:ErrorStats
Type: server
autoCleared: true
Affected MO: sys/chassis-[id]/blade-[slotId]/board/cpu-[id]/error-stats
Affected MO:
sys/chassis-[id]/cartridge-[slotId]/server-[serverInstanceId]/board/cpu-[id]/error-stats
Affected MO: sys/rack-unit-[id]/board/cpu-[id]/error-stats
```

