

SPA300 및 SPA500 Series IP Phone에서 오디오 입력 게인 구성

목표

Audio Input Gain 구성은 SPA300 및 SPA500 시리즈 IP 전화의 데시벨 측면에서 사운드를 증폭하거나 증폭 시킬 수 있습니다.

이 문서의 목적은 SPA300 및 SPA500 시리즈 IP 전화에서 볼륨 설정을 조정하는 방법을 보여주는 것입니다.

참고: Audio Input Gain의 매개변수를 변경하려면 Signaling Protocol을 IP Phone의 Call Control Settings 아래에서 SIP로 설정합니다. Signaling Protocol이 SCCP이면 오디오 입력 게인 매개변수만 볼 수 있습니다.

적용 가능한 디바이스

·SPA500 시리즈

오디오 입력 게인 구성 단계

1단계. 웹 구성 유ти리티에 로그인하고 음성 > 전화를 선택합니다.

The screenshot shows the SPA500 IP Phone configuration interface. The top navigation bar has tabs for Voice, Wi-Fi, Bluetooth, Personal Address Book, Call History, Speed Dials, and Firmware Upgrade. Below this is a sub-navigation bar with tabs for Info, System, SIP, Provisioning, Regional, Phone, Ext 1, Ext 2, Ext 3, Ext 4, Ext 5, User, and Att Console. The 'Phone' tab is selected. At the bottom of the sub-navigation bar are links for Attendant Console Status, User Login, basic, and advanced. The main configuration area is divided into sections: General, BluePhone, Line Key 1, Line Key 2, and Line Key 3. The 'General' section contains fields for Station Name, Station Display Name, and Voice Mail Number. The 'BluePhone' section contains fields for Bluetooth Mode (set to Phone), Line (set to 5), Short Name, User Friendly ID, and PIN Code. The 'Line Key 1', 'Line Key 2', and 'Line Key 3' sections each contain fields for Extension (set to 1), Short Name (set to \$USER), Share Call Appearance (set to private), and Extended Function.

Audio Input Gain (dB)			
Handset Input Gain:	0	Headset Input Gain:	0
Speakerphone Input Gain:	0	Bluetooth Input Gain:	0

2단계. 구성하려는 *Audio Input Gain (dB)*(오디오 입력 게인(dB)) 영역 아래에서 항목을 선택합니다.

Audio Input Gain (dB)			
Handset Input Gain:	0	Headset Input Gain:	0
Speakerphone Input Gain:	-6	Bluetooth Input Gain:	0
Extension Mobility	0	6	9

3단계. 특정 옵션 드롭다운 목록에서 -6에서 +6(데시벨)까지의 값을 선택합니다. 양수 값은 볼륨을 늘리고 음수 값은 볼륨을 줄입니다. *Audio Input Gain (dB)* 영역 아래에 네 가지 옵션이 있습니다.

- 핸드셋 입력 게인 — 핸드셋 볼륨을 변경하는 데 사용할 수 있습니다.
- 헤드셋 입력 게인 — 헤드셋 볼륨을 변경하는 데 사용할 수 있습니다.
- 스피커폰 입력 게인 — 스피커 폰 볼륨을 변경하는 데 사용할 수 있습니다.
- Bluetooth 입력 게인 — Bluetooth 볼륨을 변경하는 데 사용할 수 있습니다.

Releasing Key List:	endcall 2;
Hold Key List:	resume 1;endcall 2;newcall 3;redial;dir;cfwd;dnd;
Ringing Key List:	answer 1;ignore 2;
Shared Active Key List:	newcall 1;barge 2;cfwd 3;dnd 4;
Shared Held Key List:	resume 1;barge 2;cfwd 3;dnd 4;
PSK 1:	
PSK 2:	
PSK 3:	
PSK 4:	
PSK 5:	
PSK 6:	

4단계. **Submit All Changes(모든 변경 사항 제출)**를 클릭하여 설정을 저장합니다.