

Procedimento de recuperação de senha para os Cisco 7200 Series Routers

ID do Documento: 12730

Atualizado em: dezembro 14, 2006



[Transferência PDF](#)



[Imprimir](#)

[Feedback](#)

Produtos Relacionados

- [Cisco 7200 Series Routers](#)

Índice

[Introdução](#)

[Pré-requisitos](#)

[Requisitos](#)

[Componentes Utilizados](#)

[Produtos Relacionados](#)

[Convenções](#)

[Procedimento Passo a Passo](#)

[Exemplo de procedimento de recuperação de senha](#)

[Informações Relacionadas](#)

[Cisco relacionado apoia discussões da comunidade](#)

Introdução

Este documento descreve como recuperar as senhas **enable password** e **enable secret**. Essas senhas protegem o acesso aos modos EXEC privilegiado e de configuração. A senha **enable password** pode ser recuperada, mas a senha **enable secret** é criptografada e deve ser substituída por uma nova senha. Utilize o procedimento descrito neste documento para substituir a **senha enable secret**.

Pré-requisitos

Requisitos

Não existem requisitos específicos para este documento.

Componentes Utilizados

A informação neste documento é baseada nos Cisco 7200 Series Router.

As informações neste documento foram criadas a partir de dispositivos em um ambiente de laboratório específico. Todos os dispositivos utilizados neste documento foram iniciados com uma configuração (padrão) inicial. Se a sua rede estiver ativa, certifique-se de que entende o impacto potencial de qualquer comando.

Produtos Relacionados

Consulte [Procedimentos de Recuperação de Senhas](#) para obter informações sobre como recuperar senhas para os produtos relacionados.

Convenções

Consulte as [Convenções de Dicas Técnicas da Cisco](#) para obter informações sobre convenções de documentos.

Procedimento Passo a Passo

Siga estes passos para recuperar a sua senha:

1. Conecte um terminal ou PC com emulação de terminal à porta de console do roteador. Utilize estas configurações de terminal: taxa de baud 9600 Sem paridade 8 bits de dados 1 bit de parada Nenhum controle de fluxo Consulte estes documentos para obter informações sobre como cabear e conectar um terminal à porta de console ou à porta AUX: [Manual de cabeamento para console e portas AUX](#) [Conexão de um Terminal à Porta de Console dos Switches Catalyst](#) [Conexão de um Terminal aos Catalyst 2948G-L3, 4908G-L3 e 4840G Series Switches](#)
2. Se você puder acessar o roteador, digite **show version** no prompt e registre a opção de registro de configuração. Consulte [Exemplo de Procedimento de Recuperação de Senhas](#) para ver a saída de um comando **show version** **Nota:** O registro de configuração é geralmente definido como 0x2102 ou 0x102. Se você não for mais capaz de acessar o roteador (devido a um login ou senha de TACACS esquecidos), poderá afirmar com segurança que seu registro de configuração está definido como 0x2102.
3. Use a chave liga/desliga para desligar o roteador. Em seguida, ligue-o novamente. **Notas Importantes:** Para simular este passo em um Cisco 6400, remova e reinsira a placa Node Route Processor (NRP) ou Node Switch Processor (NSP). Para simular este passo em um Cisco 6x00 com NI-2, remova e reinsira a placa NI-2.
4. Pressione **Break** no teclado do terminal em até 60 segundos após o equipamento ser ligado para colocar o roteador em ROMMON. Se a sequência de interrupção não funcionar, consulte [Combinações de Sequências de Teclas de Interrupção Padrão Durante a Recuperação de Senhas](#) para obter outras combinações de chaves.
5. Digite **confreg 0x2142** no prompt rommon 1> para inicializar da Flash. Este passo ignora a configuração de inicialização onde as senhas são armazenadas.
6. Digite **reset** no prompt rommon 2>. O roteador é reinicializado, mas ignora a configuração salva.

7. Digite **no** após cada pergunta de instalação ou pressione **Ctrl-C** para pular o procedimento de configuração inicial.
8. Digite **enable** no prompt Router>. Você está no modo enable e deve ver o prompt Router#.
9. Digite **configure memory** ou **copy startup-config running-config** para copiar a RAM não volátil (NVRAM) para a memória. **Importante:** *Não* digite **copy running-config startup-config** ou **write**. Esses comandos apagam sua configuração de inicialização.
10. Digite **show running-config**. O comando show running-config exibe a configuração do roteador. Nesta configuração, o comando **shutdown** é mostrado em todas as interfaces, o que indica que todas as configurações estão desativadas no momento. Além disso, as senhas (enable password, enable secret, vty, console) podem estar em um formato criptografado ou não criptografado. Você pode reutilizar senhas não criptografadas. No entanto, as senhas criptografadas devem ser alteradas para um novo valor.
11. Digite **configure terminal**. O prompt hostname(config)# é exibido.
12. Digite **enable secret <password>** para alterar a senha **enable secret**. Por exemplo: hostname(config)#enable secret cisco
13. Execute o comando **no shutdown** em cada interface usada. Se você executar um comando **show ip interface brief**, todas as interfaces que você deseja usar deverão exibir *up up*.
14. Digite **config-register <configuration_register_setting>**. Onde **configuration_register_setting** é o valor que você registrou no passo 2 ou **0x2102**. Por exemplo: hostname(config)#config-register 0x2102
15. Pressione **Ctrl-z** ou **end** para sair do modo de configuração. O prompt hostname# é exibido.
16. Digite **write memory** ou **copy running-config startup-config** para confirmar as alterações.

[Exemplo de procedimento de recuperação de senha](#)

Esta seção fornece um exemplo do procedimento de recuperação de senhas. Esse exemplo foi criado com um Cisco 2600 Series Router. Mesmo se você não utiliza um Cisco 2600 Series Router, a saída fornece um exemplo do que você deve encontrar em seu produto.

```
Router>enable
Password:
Password:
Password:
% Bad secrets
```

```
Router>show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8
```

```
ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
```

```
Router uptime is 3 minutes
System returned to ROM by abort at PC 0x802D0B60
System image file is "flash:c2600-is-mz.120-7.T"
```

```
cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
```

2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)

Configuration register is 0x2102

Router>

!--- The router was just powercycled, and during bootup a !--- break sequence was sent to the router. ! *** System received an abort due to Break Key *** signal= 0x3, code= 0x500, context= 0x813ac158 PC = 0x802d0b60, Vector = 0x500, SP = 0x80006030 rommon 1 > **confreg 0x2142**

You must reset or power cycle for new config to take effect

rommon 2 > **reset**

System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)
Copyright (c) 1999 by cisco Systems, Inc.
TAC:Home:SW:IOS:Specials for info
C2600 platform with 32768 Kbytes of main memory

program load complete, entry point: 0x80008000, size: 0x6fdb4c

Self decompressing the image : #####

[OK]

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) of the Commercial Computer Software - Restricted Rights clause at FAR sec. 52.227-19 and subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS sec. 252.227-7013.

cisco Systems, Inc.
170 West Tasman Drive
San Jose, California 95134-1706

Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8

cisco 2611 (MPC860) processor (revision 0x202) with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.
2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.

8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)

--- System Configuration Dialog ---

Would you like to enter the initial configuration dialog? [yes/no]: **n**

Press RETURN to get started!

00:00:19: %LINK-3-UPDOWN: Interface BRI0/0, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Ethernet0/1, changed state to up
00:00:19: %LINK-3-UPDOWN: Interface Serial0/0, changed state to down
00:00:19: %LINK-3-UPDOWN: Interface Serial0/1, changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0,
changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to up

Router>

00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1,
changed state to up
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0,
changed state to down
00:00:20: %LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/1,
changed state to down

00:00:50: %SYS-5-RESTART: System restarted --
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye

00:00:50: %LINK-5-CHANGED: Interface BRI0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Ethernet0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Serial0/0,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Ethernet0/1,
changed state to administratively down
00:00:52: %LINK-5-CHANGED: Interface Serial0/1,
changed state to administratively down
00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to down
00:00:53: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/1,
changed state to down

Router>

Router>**enable**

Router#**copy startup-config running-config**

Destination filename [running-config]?

1324 bytes copied in 2.35 secs (662 bytes/sec)

Router#

00:01:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:1,
changed state to down
00:01:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface BRI0/0:2,
changed state to down

Router#**configure terminal**

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#**enable secret < password >**

Router(config)#**^Z**

00:01:54: %SYS-5-CONFIG_I: Configured from console by console

Router#**show ip interface brief**

Interface	IP-Address	OK?	Method	Status	Protocol
Ethernet0/0	10.200.40.37	YES	TFTP	administratively down	down

```
Serial0/0    unassigned      YES  TFTP      administratively down  down
BRI0/0      193.251.121.157 YES  unset     administratively down  down
BRI0/0:1    unassigned      YES  unset     administratively down  down
BRI0/0:2    unassigned      YES  unset     administratively down  down
Ethernet0/1 unassigned      YES  TFTP      administratively down  down
Serial0/1    unassigned      YES  TFTP      administratively down  down
Loopback0    193.251.121.157 YES  TFTP      up                    up
```

Router#**configure terminal**

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#**interface Ethernet0/0**

Router(config-if)#**no shutdown**

Router(config-if)#

00:02:14: %LINK-3-UPDOWN: Interface Ethernet0/0, changed state to up

00:02:15: %LINEPROTO-5-UPDOWN: Line protocol on Interface Ethernet0/0,
changed state to up

Router(config-if)#**interface BRI0/0**

Router(config-if)#**no shutdown**

Router(config-if)#

00:02:26: %LINK-3-UPDOWN: Interface BRI0/0:1, changed state to down

00:02:26: %LINK-3-UPDOWN: Interface BRI0/0:2, changed state to down

00:02:26: %LINK-3-UPDOWN: Interface BRI0/0, changed state to up

00:02:115964116991: %ISDN-6-LAYER2UP: Layer 2 for Interface BR0/0,
TEI 68 changed to up

Router(config-if)#**^Z**

Router#

00:02:35: %SYS-5-CONFIG_I: Configured from console by console

Router#**copy running-config startup-config**

Destination filename [startup-config]?

Building configuration...

[OK]

Router#**show version**

Cisco Internetwork Operating System Software

IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)

Copyright (c) 1986-1999 by cisco Systems, Inc.

Compiled Tue 07-Dec-99 02:21 by phanguye

Image text-base: 0x80008088, data-base: 0x80C524F8

ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)

Router uptime is 3 minutes

System returned to ROM by abort at PC 0x802D0B60

System image file is "flash:c2600-is-mz.120-7.T"

cisco 2611 (MPC860) processor (revision 0x202)

with 26624K/6144K bytes of memory.

Processor board ID JAB031202NK (3878188963)

M860 processor: part number 0, mask 49

Bridging software.

X.25 software, Version 3.0.0.

Basic Rate ISDN software, Version 1.1.

2 Ethernet/IEEE 802.3 interface(s)

2 Serial(sync/async) network interface(s)

1 ISDN Basic Rate interface(s)

32K bytes of non-volatile configuration memory.

8192K bytes of processor board System flash partition 1 (Read/Write)

8192K bytes of processor board System flash partition 2 (Read/Write)

Configuration register is 0x2142

Router#**configure terminal**

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#**config-register 0x2102**

Router(config)#**^Z**

00:03:20: %SYS-5-CONFIG_I: Configured from console by console

```
Router#show version
Cisco Internetwork Operating System Software
IOS (tm) C2600 Software (C2600-IS-M), Version 12.0(7)T, RELEASE SOFTWARE (fc2)
Copyright (c) 1986-1999 by cisco Systems, Inc.
Compiled Tue 07-Dec-99 02:21 by phanguye
Image text-base: 0x80008088, data-base: 0x80C524F8

ROM: System Bootstrap, Version 11.3(2)XA4, RELEASE SOFTWARE (fc1)

Router uptime is 3 minutes
System returned to ROM by abort at PC 0x802D0B60
System image file is "flash:c2600-is-mz.120-7.T"

cisco 2611 (MPC860) processor (revision 0x202)
with 26624K/6144K bytes of memory.
Processor board ID JAB031202NK (3878188963)
M860 processor: part number 0, mask 49
Bridging software.
X.25 software, Version 3.0.0.
Basic Rate ISDN software, Version 1.1.

2 Ethernet/IEEE 802.3 interface(s)
2 Serial(sync/async) network interface(s)
1 ISDN Basic Rate interface(s)
32K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash partition 1 (Read/Write)
8192K bytes of processor board System flash partition 2 (Read/Write)

Configuration register is 0x2142 (will be 0x2102 at next reload)
```

Router#

[Informações Relacionadas](#)

- [Procedimentos de recuperação de senhas](#)
- [Manual de cabeamento para console e portas AUX](#)
- [Conexão de um Terminal à Porta de Console dos Switches Catalyst](#)
- [Conexão de um Terminal aos Catalyst 2948G-L3, 4908G-L3 e 4840G Series Switches](#)
- [Combinações de sequência chave de ruptura padrão durante a recuperação de senha](#)
- [Suporte Técnico - Cisco Systems](#)

Era este documento útil? [Sim](#) [nenhum](#)

Obrigado para seu feedback.

[Abra um caso de suporte](#) (exige um [contrato de serviço Cisco](#).)

Cisco relacionado apoia discussões da comunidade

[Cisco apoia a comunidade](#) é um fórum para que você faça e responda a perguntas, sugestões da parte, e colabora com seus pares.

Refira [convenções dos dicas técnicas da Cisco](#) para obter informações sobre das convenções

usadas neste documento.

Atualizado em: dezembro 14, 2006

ID do Documento: 12730