

# Estatísticas wireless da vista no RV110W

## Objetivos

A página wireless das estatísticas mostra o total de todos os dados enviados e recebidos em todas as redes Wireless. Esta informação pode ser útil para pesquisar defeitos e considerar o que foram mal, e nos que rede.

Este documento explica como ver a página wireless das estatísticas no RV110W.

## Dispositivos aplicáveis

- RV110W

## Estatísticas wireless

Etapa1. No utilitário de configuração com base na Web, escolha o **estado > estatísticas wireless**. A página *wireless das estatísticas* abre.

**Wireless Statistics**

Refresh Rate: No Refresh ▾

Show Simplified Statistic Data:

SSID Name	Packet		Byte		Error		Dropped		Multicast	Collisions
	Received	Sent	Received	Sent	Received	Sent	Received	Sent		
ciscosb1	0	0	0	0	0	0	0	0	0	0
ciscosb2	0	0	0	0	0	0	0	0	0	0
ciscosb3	0	0	0	0	0	0	0	0	0	0
ciscosb4	0	0	0	0	0	0	0	0	0	0
Total	0	0	0	0	0	0	0	0	0	0

Etapa 2. No menu suspenso da taxa de atualização, escolha quanto tempo você quer o dispositivo esperar antes de atualizar as estatísticas de porta.

### Wireless Statistics

Refresh Rate:

Show Simplified Statistic Data:

SSID Name	Packet		Byte		Error		Dropped		Multicast	Collisions
	Received	Sent	Received	Sent	Received	Sent	Received	Sent		
ciscosb1	0	0	0	0	0	0	0	0	0	0
ciscosb2	0	0	0	0	0	0	0	0	0	0
ciscosb3	0	0	0	0	0	0	0	0	0	0
ciscosb4	0	0	0	0	0	0	0	0	0	0
Total	0	0	0	0	0	0	0	0	0	0

Etapa 3. Verifique a caixa **simplificada mostra dos dados da estatística** para mostrar dados em etiquetas simplificadas. Ex: kB em vez dos bytes.

### Wireless Statistics

Refresh Rate:

Show Simplified Statistic Data:

SSID Name	Packet		Byte		Error		Dropped		Multicast	Collisions
	Received	Sent	Received	Sent	Received	Sent	Received	Sent		
ciscosb1	0	0	0	0	0	0	0	0	0	0
ciscosb2	0	0	0	0	0	0	0	0	0	0
ciscosb3	0	0	0	0	0	0	0	0	0	0
ciscosb4	0	0	0	0	0	0	0	0	0	0
Total	0	0	0	0	0	0	0	0	0	0

Etapa 4. Os dados são indicados na tabela estatística wireless.

- Nome SSID — O nome da rede Wireless.
- Pacote — O número de pacotes wireless enviados e recebidos.
- Byte — O número de bytes enviado e recebido.
- Erro — O número de erros enviada e do pacote recebido.
- Deixado cair — O número de enviado e pacotes recebidos que foram deixados cair.
- Multicast — Os números de pacote multicast enviados.
- Colisões — O número de colisões do sinal nesta porta.

### Wireless Statistics

Refresh Rate:  ▾

Show Simplified Statistic Data:

SSID Name	Packet		Byte		Error		Dropped		Multicast	Collisions
	Received	Sent	Received	Sent	Received	Sent	Received	Sent		
ciscosb1	0	0	0	0	0	0	0	0	0	0
ciscosb2	0	0	0	0	0	0	0	0	0	0
ciscosb3	0	0	0	0	0	0	0	0	0	0
ciscosb4	0	0	0	0	0	0	0	0	0	0
Total	0	0	0	0	0	0	0	0	0	0

Etapa 5. Clique o botão **claro da contagem** para cancelar todas as estatísticas gravadas.

Etapa 6. **Salv guarda** do clique.