

Установка сервера NTP на SPA3102

Содержание

[Введение](#)

[Как установить сервер NTP на SPA3102?](#)

[Дополнительные сведения](#)

Введение

Эта статья входит в серию статей, освещающих вопросы настройки, наладки и обслуживания продуктов Cisco для малого бизнеса.

[Вопрос. . Как установить сервер NTP на SPA3102? О.](#)

Установите Сервер NTP на SPA3102

Шаг 1:

Обратитесь к интернет-странице по настройке SPA3102. Для инструкций [щелкнуть здесь](#).

Шаг 2:

Когда интернет-страница по настройке появится, нажмите **Admin Login**.



Шаг 3:

Нажмите **Wan Setup**, затем **усовершенствованный**.

Шаг 4. :

Под **Основным Сервером NTP** введите адрес сервера NTP в предоставленное поле.

The screenshot shows the Linksys Phone Adapter Configuration interface. At the top left is the Linksys logo and "A Division of Cisco Systems, Inc.". The page title is "Linksys Phone Adapter Configuration". There are two yellow callout boxes: one pointing to the "Wan Setup" tab in the navigation menu with the text "Click Wan Setup.", and another pointing to the "advanced" link in the top right with the text "Click advanced.". The navigation menu includes "Status", "Wan Setup", "Lan Setup", and "Application". The "User Login" section has links for "basic" and "advanced". The main content area is titled "Internet Connection Settings" and includes sections for "Connection Type" (set to DHCP), "Static IP Settings", "PPPoE Settings", and "Optional Settings". In the "Optional Settings" section, the "DNS Server Order" is set to "Manual". A yellow callout box points to the "Primary NTP Server" field with the text "Enter the Primary NTP Server here."

Шаг 5. :

Нажать

[Дополнительные сведения](#)

- [Cisco Systems – техническая поддержка и документация](#)