

无法对会话到NME-WAE WAAS

目录

[简介](#)

[问题](#)

[解决方案](#)

[相关的思科支持社区讨论](#)

简介

本文描述对网络模块引擎的问题(NME)的验证看上去发生故障。

尝试对会话到从路由器的NME-WAE-502显示登录提示，但是与WAAS (广域应用服务)凭证的登录发生故障如下(在示例NME-WAE在slot 1)：

```
router# service-module integrated-Service-Engine 1/0 session
Trying 192.0.2.2, 2066 ... Open
```

```
User Access Verification
```

```
Username: admin
```

```
Password:
```

```
% Authentication failed
```

问题

如果已经输入正确WAAS凭证，此问题可能归结于在路由器的身份验证配置。注意到登录标识没有“Cisco广域应用服务引擎控制台”，检查路由器是否有AAA (验证，授权，认为)配置，参见下面的路由器配置示例。

```
router# show run | inc aaa
aaa new-model
aaa authentication login default group tacacs+ enable
```

使用路由器credentials，在这种情况下您首先需要登陆，按<ENTER>使用WAAS凭证，并且第二个登录提示那时将显示是您能登陆。

解决方案

显示的登录提示来自路由器，不是NME-WAE。您首先需要给路由器凭证，然后按<ENTER>，并且实际WAAS登录提示那时将出现：

```
router# service-module integrated-Service-Engine 1/0 session
Trying 192.0.2.2, 2066 ... Open
```

User Access Verification

Username: <-- router-username
Password: <-- router-password

<-- Hit <ENTER>

Cisco Wide Area Application Services Engine Console

Username: <-- waas-username
Password: <-- waas-password

Device is configured with a (well known) default username/password for ease of initial configuration. This default username/password should be changed in order to avoid unwanted access to the device.

System Initialization Finished.

WAAS#

在看到Cisco正常WAAS凭证以后的登录提示能使用(默认 : **username** : admin/密码 : 默认)。