

环设置的配置在PAP2T和SPA3102的

客观

能更改PAP2T和SPA3102的环设置允许您定制它到您的特定需要。

本文目标将显示您如何更改PAP2T和SPA3102电话的环设置。

可适用的设备

- PAP2T
- SPA3102

环设置的配置

第 1 步：在Web配置工具中，请选择Admin洛金>Advanced >Voice >用户1.移下来到环设置地区。

The screenshot displays the Linksys Phone Adapter Configuration web interface. The top navigation bar includes 'Router' and 'Voice'. The main navigation area shows 'Info', 'System', 'SIP', 'Regional', 'Line 1', 'PSTN Line', 'User 1', and 'PSTN User'. The 'User 1' section is active, and the 'basic' tab is selected. The 'Call Forward Settings' section includes fields for 'Cfwd All Dest:', 'Cfwd No Ans Dest:' (19498236475), 'Cfwd Busy Dest:', and 'Cfwd No Ans Delay:' (10). The 'Selective Call Forward Settings' section includes fields for 'Cfwd Sel1 Caller:' through 'Cfwd Sel8 Caller:', 'Cfwd Sel1 Dest:' through 'Cfwd Sel8 Dest:', 'Cfwd Last Caller:', and 'Accept Last Caller:'. The 'Ring Settings' section includes fields for 'Default Ring:' (1), 'Hold Reminder Ring:' (8), 'Cfwd Ring Splash Len:' (0), 'VMWI Ring Splash Len:' (0), 'Ring On No New VM:' (no), 'Default CWT:' (1), 'Call Back Ring:' (7), 'Cblk Ring Splash Len:' (0), and 'VMWI Ring Policy:' (New VM Available). At the bottom, there are 'Undo All Changes' and 'Submit All Changes' buttons.

Step 2.从默认振铃下拉列表，请选择其中一默认振铃的铃音。选项第1-8。

第 3 步：从默认CWT下拉列表，请选择其中一呼叫等待电话环的铃音。选项第1-8。

第 4 步：从 **暂挂提示环** 下拉列表，请选择暂挂其中一的铃音将设置作为呼叫的提示。选项第 1-8，或者选项不可以被选择设置环。

第 5 步：从 **呼叫**，当有呼叫时，请 **敲响** 下拉列表，选择其中一铃音将设置为。选项第 1-8。

第 6 步。在 **Cfwd** 环飞溅 **LEN** 字段，请进入 0-10 之间的时间(以秒钟)处于环飞溅的，当传送时呼叫。

第 7 步：在 **Cibk** 环飞溅 **LEN** 字段，请进入 0-10 之间的时间(以秒钟)处于环飞溅的，当呼叫被阻拦时。

第 8 步。在 **VMWI** 环飞溅 **LEN**，请进入 0-10 之间的时间(以秒钟)处于环飞溅的，当一个新的消息到达时，在语音消息等待指示器信号适用前。

步骤 9. 从 **VMWI** 环策略下拉列表，为环语音邮件的飞溅设置选择其中一个下面选项。

- 可用新的 VM 一环，当有 1 或更加未经阅读的语音邮件。
- 新的 VM 变得可用一环，当语音邮件的数量更改从 0 到 1。
- 新的 VM 到达一环，当语音邮件的数量增加。

Note: 上述选项只是可用的在 SPA3102。

第 10 步。从 **在没有新的 VM** 下拉列表的环，**是** 请选择播放环飞溅，每当 ATA 不接受 SIP 通知消息和那里未经阅读的语音邮件或者选择不关闭环飞溅通知。

Note: 上述选项只是可用的在 SPA3102。

步骤 11. 点击 **提交所有更改** 保存设置或者点击 **取消所有更改** 丢弃设置。