

Software Error 364

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Components Used](#)

[Conventions](#)

[Software Error 364](#)

[Related Information](#)

[Introduction](#)

本文解释Software Error 364。此错误可能出现在IPX、IGX或者BPX交换机上。

[Prerequisites](#)

[Requirements](#)

There are no specific requirements for this document.

[Components Used](#)

This document is not restricted to specific software and hardware versions.

[Conventions](#)

Refer to [Cisco Technical Tips Conventions](#) for more information on document conventions.

[Software Error 364](#)

软件错误(swerr) 364被记录，当连接路由Trunk时，并且连接负载设备从Trunk被去除。这导致一个负值。错误是一个不正确加载视图的结果在记录它的节点的。

swerr数据域指示一致不的节点和Trunk与，因为此示例显示：

No.	Type	Number	Data(Hex)	PC(Hex)	PROC	SwRev	Date	Time
1.	Error	364	080E0001	3004D17A	TRNS	9.3.45	08/18/03	21:51:06

01 = number of conns.
00 = local domain (01 = GTWY_DOMAIN)

0E = trunk number
08 = node number

发出dspload命令在记录错误和节点在冲突显示负荷不一致的节点的Trunk的。

[Related Information](#)

- [新的名称和颜色指南广域网交换产品的](#)
- [广域网交换软件\(仅限注册用户\)](#)
- [Technical Support & Documentation - Cisco Systems](#)