

更改思科小型企业VoIP路由器密码

目录

[简介](#)

[如何更改思科小型企业VoIP路由器密码？](#)

[相关信息](#)

简介

本文是一系列协助设置、排错和维护Cisco小型企业产品文档中的一篇。

Q. [如何更改思科小型企业VoIP路由器密码？](#)

A.

当您访问路由器的基于Web的设置页，请求路由器的用户名和密码的登录画面将出现。应该用于安全性目的更改默认用户名和密码“admin”。

必须更改路由器的密码对：

防止不需要的用户访问路由器的基于Web的设置页。
启用远程管理。

更改路由器的密码

步骤 1：

访问路由器的基于Web的设置页。如需指导，请点击[这里](#)。

步骤 2：

当路由器的基于Web的设置页出版时，请点击[管理](#)。

步骤 3：

进入在[路由器密码](#)的新密码并且重新输入确认字段。

LINKSYS
A Division of Cisco Systems, Inc.

Click
Administration.

Administration

Setup Wireless Security Access Restrictions Applications & Gaming Administration Status Voice

Management Log Factory Defaults Diagnostics

Router Password

Local Router Access

User Name: admin

Router Password: [password field]

Re-enter to confirm: [password field]

Idle Timeout: 10 minutes

Remote Router Access

Web: Enabled Disabled

Administration Port: 8080

Secure Shell (SSH): Enabled Disabled

UPnP

UPnP: Enabled Disabled

Management

Local Router Access

Router Password
Enter the password you choose for this Router. This is needed to gain access to the Web-based Utility.

Re-enter to confirm
Enter the password chosen above to confirm that you properly entered the password.

[More...](#)

Enter the new password on both fields.

步骤 4：

单击。

注意：当下次您登录到路由器的基于Web的设置页，请使用新密码。

[相关信息](#)

- [技术支持和文档 - Cisco Systems](#)