

更改思科 S 系列 VoIP 路由器密码

目录

[简介](#)

[如何更改思科S系列VoIP路由器的密码？](#)

[相关信息](#)

简介

本文是一系列协助设置、排错和维护Cisco小型企业产品文档中的一篇。

[问：如何更改思科S系列VoIP路由器的密码？](#) A.

当您访问路由器的基于Web的设置页时，将出现一个登录屏幕，要求输入路由器的用户名和密码。出于安全考虑，应更改默认用户名和密码“admin”。

路由器的口令必须更改为：

阻止不需要的用户访问路由器的基于Web的设置页。

启用 远程管理。

更改路由器的口令

步骤 1：

访问路由器的基于Web的设置页。如需指导，请点击[这里](#)。

步骤 2：

当显示路由器的基于Web的设置页时，单击Administration。

步骤 3：

在Router Password (路由器密码) 和Re-enter(重新输入)中输入新密码以确认字段。

LINKSYS®
A Division of Cisco Systems, Inc.

Click Administration.

Administration

Setup Wireless Security Access Restrictions Applications & Gaming Administration Status Voice

Management Log Factory Defaults Diagnostics

Router Password

Local Router Access

User Name: admin

Router Password: [password field]

Re-enter to confirm: [password field]

Idle Timeout: 10 minutes

Web: Enabled Disabled

Administration Port: 8080

Secure Shell (SSH): Enabled Disabled

UPnP: Enabled Disabled

Management

Local Router Access

Router Password
Enter the password you choose for this Router. This is needed to gain access to the Web-based Utility.

Re-enter to confirm
Enter the password chosen above to confirm that you properly entered the password.

[More...](#)

步骤 4 :

单击。 **Save Settings**

注意：下次登录路由器的基于Web的设置页时，请使用新密码。

相关信息

- [技术支持和文档 - Cisco Systems](#)