

---

# 目录

## 简介

[如何在思科小型企业 VoIP 路由器上更改无线网络使用的信道？](#)

[相关信息](#)

## 简介

本文是一系列协助设置、排错和维护Cisco小型企业产品文档中的一篇。

### Q. [如何在思科小型企业 VoIP 路由器上更改无线网络使用的信道？](#)

A.

在美国，很多无线产品都与思科小型企业路由器一样，配备默认信道 6。如果遇到其他设备的干扰，请更改信道以避免这些干扰。要更改您的无线网络使用的信道，请转到路由器基于网络的设置页。

#### 更改路由器信道

##### 步骤 1：

访问路由器的基于Web的设置页。如需指导，请点击[这里](#)。

##### 步骤 2：

当路由器的基于Web的设置页出现时，请点击**Wireless**。

##### 步骤 3：

查找 **Wireless Channel**，并将其更改为您所需的信道。推荐信道为 1、6 或 11，因为这些信道被视为非重叠信道。

LINKSYS®  
A Division of Cisco Systems, Inc.

Click **Wireless**.

**Wireless**

Setup | **Wireless** | Security | Access Restrictions | Applications & Gaming | Administration | Status | Voice

Basic Wireless Settings | Wireless Security | Wireless MAC Filter | Advanced Wireless Settings

**Wireless Settings**

Wireless Network Mode: Disabled

Wireless Network Name (SSID):

Wireless Channel: 1

Wireless SSID Broadcast:  Enable  Dis

Select 1, 6 or 11 then click **Save Settings**.

**Basic Wireless Settings**

The Wireless screen allows you to customize data transmission settings. In most cases, the advanced settings on this screen should remain at their default values

[More...](#)

Save Settings | Cancel Changes

CISCO SYSTEMS

步骤 4 :

单击。

## 相关信息

- [技术支持和文档 - Cisco Systems](#)