

---

# 目录

## [简介](#)

### [如何在思科小型企业 VoIP 路由器上设置无线设置？](#)

#### [相关信息](#)

## [简介](#)

本文是一系列协助设置、排错和维护Cisco小型企业产品文档中的一篇。

### **Q. [如何能在思科小型企业 VoIP 路由器上设置无线设置？](#)**

#### **A.**

为了设置和改善您的无线网络信号，请更改您的无线网络名称 (SSID) 并/或尝试使用一个不同的信道。有关说明，请完成以下步骤：

#### **更改您的路由器的 SSID 和信道**

##### **步骤 1：**

访问路由器的基于Web的设置页。如需指导，请点击[这里](#)。

##### **步骤 2：**

当路由器的基于Web的设置页出现时，请点击**Wireless**。

##### **步骤 3：**

查找**无线网络名称 (SSID)**。如果其仍然设置为“linksys”，请将其更改为唯一的名称。然后点击**Save Settings**。

##### **步骤 4：**

更改 SSID 后，请尝试更换信道以避免干扰。首选信道为 **1、6 和 11**，因为这些信道被视为非重叠信道。

LINKSYS®  
A Division of Cisco Systems, Inc.

Click **Wireless**.

**Wireless**

Setup **Wireless** Security Access Restrictions Applications & Gaming Administration Status Voice

Basic Wireless Settings | Wireless Security | Wireless MAC Filter | Advanced Wireless Settings

**Wireless Settings**

Wireless Network Mode: Disabled

Wireless Network Name (SSID): linksys

Wireless Channel: 1

Wireless SSID Broadcast:  Disable

This is your SSID. If this is set to "linksys," change this to something unique.

Select 1, 6 or 11 then click **Save Settings**.

Save Settings Cancel Changes

CISCO SYSTEMS

步骤 5：

单击。

## [相关信息](#)

- [技术支持和文档 - Cisco Systems](#)