



---

## A

Activate/Deactivate button, toggling [2-2, 2-4](#)

Activate CLI command [2-2, 2-4](#)

---

## B

batch file

example [1-3](#)

for CLI commands [1-3](#)

using [1-3](#)

---

## C

case insensitivity, for CLI commands [2-1](#)

channel

*See* PTT channel

ClearAllDebug CLI command [2-2, 2-5](#)

ClearDebug CLI command [2-2, 2-5](#)

CLI

about [1-1](#)

issuing commands [1-2](#)

CLI command

Activate [2-2, 2-4](#)

case insensitivity [2-1](#)

ClearAllDebug [2-2, 2-5](#)

ClearDebug [2-2, 2-5](#)

DownVolume [2-2, 2-6](#)

GetDebug [2-2, 2-7](#)

GetLog [2-2, 2-9](#)

GetSkin [2-2, 2-10](#)

GetVolume [2-2, 2-11](#)

IsActive [2-2, 2-12](#)

IsConfigured [2-13](#)

IsEnabled [2-2, 2-13](#)

IsLatch [2-3, 2-14](#)

issuing [1-2](#)

IsTraffic [2-3, 2-15](#)

IsTxMuted [2-3, 2-15](#)

Play [2-3, 2-16](#)

Ptt [2-3, 2-17](#)

return code [1-3](#)

SetAllDebug [2-3, 2-18](#)

SetDebug [2-3, 2-19](#)

SetVolume [2-3, 2-20](#)

StartLog [2-3, 2-21](#)

StopLog [2-3, 2-22](#)

UpVolume [2-3, 2-23](#)

command

*See* CLI command

## Command Line Interface

*See* CLI

---

**D**

## debug options

clearing [2-2, 2-5](#)

determining state [2-2, 2-7](#)

selecting [2-3, 2-18, 2-19](#)

Decrease Volume button [2-6](#)

DownVolume CLI command [2-2, 2-6](#)

---

**E**

ERRORLEVEL environment variable [1-3](#)

---

**G**

GetDebug CLI command [2-2, 2-7](#)

GetLog CLI command [2-2, 2-9](#)

GetSkin CLI command [2-2, 2-10](#)

GetVolume CLI command [2-2, 2-11](#)

---

**I**

Increase Volume button [2-23](#)

IsActive CLI command [2-2, 2-12](#)

IsConfigured CLI command [2-13](#)

IsEnabled CLI command [2-2, 2-13](#)

IsLatch CLI command [2-3, 2-14](#)

IsTraffic CLI command [2-3, 2-15](#)

IsTxMuted CLI command [2-3, 2-15](#)

---

**L**

## log file

determining state [2-2, 2-9](#)

turning off logging to [2-3, 2-22](#)

turning on logging to [2-3, 2-21](#)

---

**P**

Play CLI command [2-3, 2-16](#)

## PMC

active PTT channel [2-2, 2-12](#)

affected by CLI command [1-2](#)

configured PTT channel [2-2, 2-13, 2-15](#)

enabled PTT channel [2-2, 2-13](#)

issuing CLI command to [1-2](#)

muted [2-3](#)

## PTT button

latching and unlatching [2-3, 2-17](#)

state [2-3, 2-14](#)

## PTT channel

active [2-2, 2-12](#)

configured [2-2, 2-13, 2-15](#)

enabled [2-2, 2-13](#)

muted [2-3](#)

traffic on [2-3, 2-15](#)

Ptt CLI command [2-3, 2-17](#)

Push-to-Talk Management Center

*See* PMC

---

## R

receive (RX) traffic, on PTT channel [2-3, 2-15](#)

return code

about [1-3](#)

for GetDebug command [2-8](#)

for GetLog command [2-9](#)

for GetSkin command [2-10](#)

for GetVolume command [2-11](#)

for IsAvtive command [2-12](#)

for IsConfigured command [2-13](#)

for IsEnabled command [2-14](#)

for IsLatch command [2-14](#)

for IsTraffic command [2-15](#)

for IsTxMuted command [2-16](#)

for SetVolume command [2-20](#)

in ERRORLEVEL environment variable [1-3](#)

obtaining through batch file [1-3](#)

---

## S

SetAllDebug CLI command [2-3, 2-18](#)

SetDebug CLI command [2-3, 2-19](#)

SetVolume CLI command [2-3, 2-20](#)

skin, currently selected [2-2, 2-10](#)

StartLog CLI command [2-3, 2-21](#)

StopLog CLI command [2-3, 2-22](#)

---

## T

traffic, on PTT channel [2-3, 2-15](#)

transmit (TX) traffic, on PTT channel [2-3, 2-15](#)

---

## U

UpVolume CLI command [2-3, 2-23](#)

---

## V

volume

current [2-2, 2-11](#)

decreasing [2-2, 2-6](#)

increasing [2-3, 2-23](#)

setting [2-3, 2-20](#)

---

## W

wave file, playing on PTT channel [2-3, 2-16](#)

