Cloud Native BNG User Plane Configuration Guide for Cisco ASR 9000 Series Routers, IOS XR Release 7.10.x

First Published: 2023-08-18

Americas Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
http://www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED “AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2023 Cisco Systems, Inc. All rights reserved.

CONTENTS

PREFACE

Preface vii

Changes to This Document vii

Communications, Services, and Additional Information vii

CHAPTER 1

New and Changed Cloud Native BNG User Plane Features 1

Cloud Native BNG User Plane Features Added or Modified in IOS XR Release 7.10.x 1

CHAPTER 2

YANG Data Models for Cloud Native BNG User Plane Features 3

Using YANG Data Models 3

CHAPTER 3

Cloud Native BNG Overview 5

Overview 5

Evolution of cnBNG 6

cnBNG Architecture 6

cnBNG Components 8

Subscriber Microservices Infrastructure 8

cnBNG Control Plane 9

cnBNG User Plane 10

License Information 10

Standard Compliance 11

Limitations and Restrictions 11

CHAPTER 4

Cloud Native BNG User Plane Overview 13

Control and User Plane Separation 13

cnBNG User Plane Overview 15

cnBNG User Plane Architecture 16

cnBNG User Plane and Control Plane Reachability 17
Software and Hardware Requirements 17
Access Types and Subscriber Types 18
Subscriber Features 19
High Availability 22
Usage Guidelines 23
Restrictions 23

CHAPTER 5 **Installing Cloud Native BNG User Plane Packages** 25
Installing and Activating the cnBNG Package on the User Plane 25

CHAPTER 6 **Configuring Cloud Native BNG User Plane and Key Features** 27
Configure cnBNG User Plane 27
Configure Basic User Plane Settings 27
Configure Access-Interface 29
Configure Loopback Interface 30
Configure DHCP 34
Configure Subscriber Gateway Address and Subnet Route 35
Configure Route Summary 38
Export Routes to Core Network 38
Configure ARP Scale Mode 39
Configure Cloud Native BNG over Pseudowire Headend 40
Verify cnBNG User Plane Configuration 42
Verify cnBNG NAL Process Information 42
Verify Control Plane Connection Status 43
Verify Subscriber Information 44
Verify cnBNG NAL Counters 53

CHAPTER 7 **Subscriber Management** 57
Subscriber Session Overview 57
IPoE Session 57
PPP over Ethernet (PPPoE) 59
PPPoE PPP Terminated and Aggregation Sessions (PPPoE-PTA) 60
Configure PPPoE-PTA Session 60

L2TP Access Concentrator Sessions (LAC) 61
Limitations for LAC Sessions 63
Configure LAC Sessions 64
L2TP Network Server Sessions (LNS) 65
Limitations for LNS Sessions 67
Configure LNS Sessions 67
RADIUS-Based Policing - QoS shape-rate parameterization 68
Limitations of configuring RADIUS-Based Policing 69
Configure QoS shape-rate parameterization 69
Shared Policy Instance 72
Limitations of configuring Shared Policy Instance 72
Configure Shared Policy Instance 73
Configure a QoS policy with SPI using a feature template 73
Configure a QoS policy with SPI using a RADIUS server 75

CHAPTER 8 **Geo Redundancy (Subscriber Redundancy Group) 79**
Overview 80
SRG Modes 80
Subscriber Session Set up Call Flow 84
Benefits of BNG Geo Redundancy 86
Supported Features in BNG Geo Redundancy 87
Unsupported Features and Restrictions for cnBNG Geo Redundancy 87
Guidelines to Configure SRG 88
Configure SRG 89

CHAPTER 9 **IPV6 Neighbor Discovery 97**
IPv6 Neighbor Discovery 97
Configure IPv6 Neighbor Discovery 99

Preface

The Cisco IOS XR Software Release 7.3.1 introduces the support for cloud native broadband network gateway (cnBNG) user plane for the Cisco IOS XR platform. cnBNG is an architectural evolution that is based on Control and User Plane Separation (CUPS), where the control plane (CP) and user plane (UP) run in distinct and independent environments. This book describes the cnBNG user plane functionality and related configurations on Cisco ASR 9000 Series Routers.

For details on the commands related to the cnBNG user plane, see the Cloud Native Broadband Network Gateway User Plane Command Reference for Cisco ASR 9000 Series Routers.

For details on cnBNG deployment, the control plane functionality and the related configurations, see the *Cloud Native Broadband Network Gateway Control Plane Configuration Guide*.

To know more about physical BNG on the Cisco IOS XR platform, see the *Cisco ASR 9000 Series Aggregation Services Router Broadband Network Gateway Configuration Guide*.

This preface contains these sections:

- Changes to This Document, on page vii
- Communications, Services, and Additional Information, on page vii

Changes to This Document

Date	Summary
August 2023	Initial release of this document

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business results you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit Cisco DevNet.
- To obtain general networking, training, and certification titles, visit Cisco Press.

- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



CHAPTER 1

New and Changed Cloud Native BNG User Plane Features

This table summarizes the new and changed feature information for the *Cloud Native BNG User Plane Configuration Guide for Cisco ASR 9000 Series Routers*, and tells you where they are documented.

- Cloud Native BNG User Plane Features Added or Modified in IOS XR Release 7.10.x , on page 1

Cloud Native BNG User Plane Features Added or Modified in IOS XR Release 7.10.x

Feature	Description	Changed in Release	Where Documented
IPv6 Neighbor Discovery	This feature was introduced.	Release 7.10.1	IPV6 Neighbor Discovery, on page 97



CHAPTER 2

YANG Data Models for Cloud Native BNG User Plane Features

This chapter provides information about the YANG data models for Cloud Native BNG User Plane features.

- Using YANG Data Models, on page 3

Using YANG Data Models

Cisco IOS XR supports a programmatic way of configuring and collecting operational data of a network device using YANG data models. Although configurations using CLIs are easier and human-readable, automating the configuration using model-driven programmability results in scalability.

The data models are available in the release image, and are also published in the Github repository. Navigate to the release folder of interest to view the list of supported data models and their definitions. Each data model defines a complete and cohesive model, or augments an existing data model with additional XPaths. To view a comprehensive list of the data models supported in a release, navigate to the **Available-Content.md** file in the repository.

You can also view the data model definitions using the YANG Data Models Navigator tool. This GUI-based and easy-to-use tool helps you explore the nuances of the data model and view the dependencies between various containers in the model. You can view the list of models supported across Cisco IOS XR releases and platforms, locate a specific model, view the containers and their respective lists, leaves, and leaf lists presented visually in a tree structure. This visual tree form helps you get insights into nodes that can help you automate your network.

To get started with using the data models, see the *Programmability Configuration Guide*.



CHAPTER 3

Cloud Native BNG Overview

The Cloud Native Broadband Network Gateway (cnBNG) redefines the traditional physical BNG by decoupling the subscriber management and forwarding functions of the control plane (CP) and user plane (UP) to give better flexibility and scalability for the service providers. The cnBNG architecture is based on Control and User Plane Separation (CUPS), where the CP performs the policy and charging rule function (PCRF), whereas the UP performs policy enforcement function (PEF) of the overall BNG subscriber management solution. The cnBNG solution provides optimum scale dimensioning in terms of the number of subscriber sessions and forwarding capacity and aims at rapid deployment of multi-access services for the users. It also acts as a step forward towards converging the fixed line and mobile networks at all network layers.

- Overview, on page 5
- License Information, on page 10
- Standard Compliance, on page 11
- Limitations and Restrictions, on page 11

Overview

The Broadband Network Gateway (BNG) is the access point for subscribers, through which they connect to the broadband network. When a connection is established between BNG and Customer Premise Equipment (CPE), the subscriber can access the broadband services provided by the Network Service Provider (NSP) or Internet Service Provider (ISP).

BNG establishes and manages subscriber sessions. When a session is active, BNG aggregates traffic from various subscriber sessions from an access network, and routes it to the network of the service provider.

BNG is deployed by the service provider and is present at the first aggregation point in the network, such as the edge router. An edge router, like the Cisco ASR 9000 Series Router, needs to be configured to act as the BNG. Because the subscriber directly connects to the edge router, BNG effectively manages subscriber access, and subscriber management functions such as:

- Authentication, Authorization, and Accounting (AAA) of subscriber sessions
- Address assignment
- Security
- Policy management
- Quality of Service (QoS)

Implementing the BNG provides the following benefits:

- Communicates with authentication, authorization, and accounting (AAA) server to perform session management and billing functions besides the routing function. This feature makes the BNG solution more comprehensive.
- Provides different network services to the subscriber. This enables the service provider to customize the broadband package for each customer based on their needs.

Cisco provides two BNG solutions:

- **Physical BNG** where the BNG Control Plane (CP) and the User Plane (UP) are tightly coupled inside a Cisco IOS XR platform where the CP runs on an x86 CPU and the UP runs on a physical NPU or ASIC.

  For more information about the physical BNG, refer to the latest version of the *Broadband Network Gateway Configuration Guide* for Cisco ASR 9000 Series Routers.
- **Virtual BNG (vBNG)** where the BNG CP and UP run in separate VM-based Cisco IOS XR software on general purpose x86 UCS servers.

Evolution of cnBNG

The Cisco Cloud Native Broadband Network Gateway (cnBNG) provides a new dimension to the Control Plane and User Plane Separation (CUPS) architecture of the Broadband Network Gateway (BNG), enabling flexibility and rapid scaling for Internet Service Providers (ISPs).

Figure 1: Evolution of BNG to cnBNG



The architectural change is an evolution from an integrated traditional BNG running on a single router to a disaggregated solution, where the centralized subscriber management runs on an elastic and scalable Cloud Native Control Plane (CP) and the User Plane (UP) delivers the forwarding functionality.

cnBNG Architecture

In the cnBNG architecture, the CPs and UPs are clearly and cleanly separated from each other and run in completely distinct and independent environments.

The BNG CP is moved out to a container-based microservice cloud environment.

The UP can be on any of the physical platforms that supports the BNG UP, like Cisco ASR 9000 Series Routers.

The following figure illustrates the overall cnBNG architecture.

Figure 2: cnBNG Architecture



Features and Benefits

The cnBNG supports the following features:

- **Path to convergence**: With shared Subscriber Management infrastructure, common microservices across the policy layer and shared UPs for BNG and Mobile back-haul, cnBNG paves the way for real Fixed Mobile Convergence (FMC).
- **Flexibility of scaling**: cnBNG architecture provides flexibility by decoupling the required scalability dimensions. The CP can be scaled with requirement of number of subscribers to be managed and UPs can be augmented based on the bandwidth requirements. Instead of building the CP for peak usage, the orchestrator can be triggered to deploy the relevant microservices as needed to handle the increased rate of transactions.
- **Distributed UPs**: With reduced operational complexity and minimal integration efforts with centralize CP, UPs can be distributed, closer to end-users to offload traffic to nearest peering points and CDNs. This feature reduces the core transport costs.
- **Cost effective and Leaner User planes**: With the subscriber management functions moved to cloud, you can choose cost-effective UP models for optimized deployment requirements.

The benefits of the cnBNG architecture are:

- Simplified and unified BNG CP
- Platform independent and Network Operation System (NOS) agnostic BNG CP
- Unified Policy interface across both BNG and mobility
- Common infrastructure across wireline and mobility
- Seamless migration from existing deployments
- Leverage the common infrastructure across access technologies
- Standardized model driven interface with the UP
- Data externalization for North-bound interfaces (NBI)
- Highly available and fault tolerant
- Simplified Subscriber Geo redundancy
- Horizontally scalable CP
- Independent CP and UP upgrades
- Feature agility with CI and CD
- Manageability and Operational Simplification

cnBNG Components

The cnBNG solution comprises of the following components:

Subscriber Microservices Infrastructure

The Cisco Ultra Cloud Core Subscriber Microservices Infrastructure (SMI) is a layered stack of cloud technologies that enable the rapid deployment, and seamless life-cycle operations for microservices-based applications.

The SMI stack consists of the following:

- SMI Cluster Manager—Creates the Kubernetes (K8s) cluster, creates the software repository, and provides ongoing LCM for the cluster including deployment, upgrades, and expansion.
- Kubernetes Management—Includes the K8s master and etcd functions, which provide LCM for the NF applications deployed in the cluster. This component also provides cluster health monitoring and resources scheduling.
- Common Execution Environment (CEE)—Provides common utilities and OAM functionalities for Cisco cloud native NFs and applications, including licensing and entitlement functions, configuration management, telemetry and alarm visualization, logging management, and troubleshooting utilities. Additionally, it provides consistent interaction and experience for all customer touch points and integration points in relation to these tools and deployed applications.
- Common Data Layer (CDL)—Provides a high performance, low latency, stateful data store, designed specifically for 5G and subscriber applications. This next generation data store offers HA in local or geo-redundant deployments.

- Service Mesh—Provides sophisticated message routing between application containers, enabling managed interconnectivity, additional security, and the ability to deploy new code and new configurations in low risk manner.
- NB Streaming—Provides Northbound Data Streaming service for billing and charging systems.
- NF/Application Worker nodes—The containers that comprise an NF application pod.
- NF/Application Endpoints (EPs)—The NF's/application's interfaces to other entities on the network.
- Application Programming Interfaces (APIs)—SMI provides various APIs for deployment, configuration, and management automation.

For more information on SMI components, refer to the "Overview" chapter of the *Ultra Cloud Core Subscriber Microservices Infrastructure* documentation—*Deployment Guide*.

For information on the Cisco Ultra Cloud Core, see https://www.cisco.com/c/en/us/products/collateral/wireless/packet-core/datasheet-c78-744630.html.

cnBNG Control Plane

The Cisco cnBNG CP is built on Cisco® Cloud Native Infrastructure, which is a Kubernetes-based platform that provides a common execution environment for container-based applications. This CP is built on principles of stateless microservices, to scale at-ease, introduce services much faster and more cost-effective.

Figure 3: cnBNG Control Plane Architecture



The CP runs as a Virtual Machine (VM) to adapt to existing service provider-deployed virtual infrastructure. It is built ground-up on a clean-slate architecture with a view on ‘Converged Subscriber Services’ and is aligned to 3gpp and BBF standards.

The cnBNG CP effectively manages the subscriber management functions such as:

- Authentication, authorization, and accounting of subscriber sessions
- IP Address assignment
- In-built DHCP Server

- Security
- Policy management
- Quality of Service (QoS)

Service providers can choose from wide choice of available ASR 9000 form factors, based on exact deployment requirements. The CUPS architecture allows to run these UPs in a distributed mode, to the edge of network, for early traffic offloads.

For more information about the cnBNG control plane, refer to the *Cloud Native Broadband Network Gateway Control Plane Configuration Guide.*

cnBNG User Plane

The UP delivers the forwarding functionality of the entire cnBNG solution. With the CP handling the subscriber management functionality, the cnBNG architecture enables the UP to be more distributed and interoperable with cnBNG CP with minimal integration efforts. The cnBNG Subscriber Provisioning Agent (SPA), which is the common interface between UP and CP, is bundled with the existing Cisco IOS XR image to transform an integrated physical BNG router to a cnBNG user plane.

For more information about the cnBNG UP, see the *Cloud Native BNG User Plane Overview* chapter.

License Information

cnBNG supports the following licenses:

License	Description
Application Base	Per cluster
Session (Increments)	Network-wide

These are the software license PIDs for cnBNG:

Cisco cnBNG Control Plane:

Product IDs	Description
CN-BNG-BASE-L	Base PID for cnBNG Control Plane (per cluster)
CN-BNG-100k-L	Session scale for 100,000 subscribers (network-wide) base licenses
CN-BNG-400k-L	Session scale for 400,000 subscribers (network-wide) base licenses
CN-BNG-1M-L	Session scale for 1,000,000 subscribers (network-wide) base licenses
CN-BNG-2M-L	Session scale for 2,000,000 subscribers (network-wide) base licenses

Cisco cnBNG User Planes:

Refer the ASR9000 data sheet for ordering information:
https://www.cisco.com/c/en/us/products/routers/asr-9000-series-aggregation-services-routers/datasheet-listing.html

Standard Compliance

cnBNG solution is aligned with the following standard:

TR-459 Control and User Plane Separation for a disaggregated BNG

Limitations and Restrictions

The cnBNG has the following limitations and restrictions in this release:

- High availability on CP is not supported.
- Only one subnet is supported per VRF.
- QoS provisioning is supported only through service.



CHAPTER 4

Cloud Native BNG User Plane Overview

In the cnBNG architecture, which is based on Control and User Plane Separation (CUPS), the CP handles the subscriber management functionality and the UP handles the forwarding functionality of the entire BNG solution. This chapter focuses on the functionality and architecture of the cnBNG user plane.

For more details on the cnBNG control plane, see the *Cloud Native Broadband Network Gateway Control Plane Configuration Guide*.

- Control and User Plane Separation, on page 13
- cnBNG User Plane Overview, on page 15
- cnBNG User Plane Architecture, on page 16
- cnBNG User Plane and Control Plane Reachability, on page 17
- Software and Hardware Requirements, on page 17
- Access Types and Subscriber Types, on page 18
- Subscriber Features, on page 19
- High Availability, on page 22
- Usage Guidelines, on page 23
- Restrictions, on page 23

Control and User Plane Separation

cnBNG is an architectural evolution that is based on Control and User Plane Separation (CUPS), where the CP and UP run in distinct and independent environments. cnBNG redefines the traditional physical BNG by decoupling the BNG CP and UP functions to give better flexibility and scalability for the service providers. In cnBNG, the centralized subscriber management functionality of BNG runs on CP infrastructure and the user plane delivers the forwarding functionality.



Physical BNG

Cloud Native BNG

Figure 4: Eps



In Cisco cnBNG solution, a physical Cisco IOS XR platform like Cisco ASR 9000 Series Routers provides the UP functionality. Whereas Cisco Ultra Cloud Core Subscriber Microservices Infrastructure (SMI)—a container-based microservice cloud environment, provides the CP functionality.

Why CUPS?

CUPS provides the capability to independently scale the CP and UP in an efficient and dynamic manner. CUPS enables network operators to optimize data center costs by hosting the CP and UP in different geographic locations. CUPS thus saves on backhaul (the access to core connection) costs by terminating data at the edge of the network. The network operators can then easily adapt to the evolving demands of mobile networks without incurring extra capital expenditures (CapEx) and operating expenditures (OpEx). The CUPS solution thus promotes a more cost-effective approach to core mobile architecture and future-proofs the network for 5G.

cnBNG User Plane Overview

Sample Network Topology for Cloud Native BNG using CUPS

Figure 5: EPS



In cloud native BNG (cnBNG), the CP provides the service policies that are sourced from the north-bound systems such as the RADIUS server or the policy and charging rules function (PCRF) node. Whereas the UP performs policy enforcement function (PEF) of the overall BNG subscriber management solution. The BNG CP protocols: RADIUS, DHCPv4, DHCPv6, PPPoE, PPP, and IP address pool management run on the CP. Whereas the non-BNG-specific protocols: IPv6 neighbor discovery (ND), ARP, routing protocols (like ISIS or BGP) that export subscriber subnet routes, and UDP or IP protocols that transport DHCPv4 or DHCPv6 payloads run on the UP.

The cnBNG UP models each subscriber as a unique flow. The system applies the subscriber features like quality of service (QoS), Hierarchial Quality of Service (HQoS),access control list (ACL), policy-based routing (PBR), lawful intercept (LI), accounting, and so on, on this flow. The DHCPv4, DHCPv6, PPPoE, and PPP protocols trigger the BNG subscriber flow. The UP presents these protocol packets to the cnBNG CP for authentication and authorization, and for evaluating policy and charging rules. Once the subscriber is accepted, the UP creates the subscriber flow and applies features on this flow. The subscriber flow can also have multiple sub-flows, and you can apply specific features to these sub-flows.

Key Features and Benefits of cnBNG User Plane

The key features and benefits of the cnBNG user plane are:

- **Distributed**: With reduced operational complexity and minimal integration efforts with centralized CP, you can distribute the UPs closer to end users. This feature helps to offload the traffic to the nearest peering points and content delivery networks (CDNs) and reduces the core transport costs.

- **Cost-effective and leaner**: With the subscriber management functions moved to cloud, you can choose cost-effective UP models for optimized deployment requirements.

cnBNG User Plane Architecture

The Cisco IOS XR platforms have a distributed hardware architecture that uses a switch fabric to interconnect a series of chassis slots. Each slot can hold one of several types of line cards (LCs). Each line card in these routers has integrated input-output and forwarding engines. The system can identify and handle the subscriber flow either on the route processor (RP) or on the LC. This architecture thereby provides multiple levels of redundancy and scalability for the subscriber management functionality in cnBNG.

Figure 6: Cloud Native BNG User Plane Architecture



The cnBNG UP architecture is designed to interoperate with cnBNG CP with minimal integration efforts. The main components of cnBNG user plane on the Cisco IOS XR platform are:

- **Subscriber Provisioning Agent (SPA)**—is the common interface to the control plane that is bundled with the existing Cisco IOS XR image. This interface helps to have a minimal configuration requirement to transform from an integrated physical BNG router to a cnBNG user plane. SPA consists of a transport layer at the top that interfaces with the CP, and an API layer at the bottom that isolates the network operating system (NOS) and the CP. This isolation from the NOS helps to make the control plane hardware-agnostic and portable across multicloud environments.

  The functionality of SPA includes:

- The support for standard PFCP port for a single UP connection.
- The support for nonstandard ports for both PFCP and GTPv1-U for multiple connections.
- UP to CP keep alive (KA) to detect any communication channel faults between CP-UP.

- **NOS Adaptation Layer (NAL)**—translates the CP instructions or messages coming to the UP to Cisco IOS XR-defined format. It is the Cisco IOS XR implementation of cnBNG APIs that interfaces with Cisco IOS XR infra components for various functions. These functions include input-output of packets, interface creation and deletion, subscriber feature provisioning, route operations, subscriber interface statistics and notifications. NAL also manages the subscriber flow on the Cisco IOS XR platform and handles the high availability (HA) requirements of Cisco IOS XR infrastructure.

  The **cnbng-nal** is the internal process that provisions all the above NAL functionalities. For details on commands that are related to NAL, see the *Configuring Cloud Native BNG User Plane* chapter and the *Verifying Cloud Native BNG User Plane Configurations* chapter.

- **Platform-specific Layer**—is the API adaptation layer that helps to plug-in different types of hardware architectures to the common Cisco IOS XR infrastructure. This layer in turn helps to extend the user plane functionality to other Cisco IOS XR platforms without altering the basic infrastructure.

  Platform-specific layer defines the forward API calls that each underlying platform of the user plane has to implement. The system uses these APIs to provision the following BNG functions:

  - IPoE subscriber traffic classification—for L2-connected subscribers that are based on port, MAC, and VLAN.
  - PPPoE subscriber traffic classification—for L2-connected subscribers that are based on port and PPPoE session-ID.

cnBNG User Plane and Control Plane Reachability

Starting from Release 24.3.1, we support IPv6 transport for the interface between cnBNG and user plane.

For network functionality and interoperability, it is essential to ensure reachability between user plane and control plane using both IPv4 and IPv6. You can set up the user plane to reach control plane either using IPv4 or IPv6 transport, and not both. However, control plane supports multiple user planes configured with IPv4 or IPv6 transport simultaneously.

The protocols used for control plane and user plane communication for exchanging subscriber provisioning messages and protocol packets are:

- PFCP
- GTP-U

Software and Hardware Requirements

The support for cnBNG user plane functionality on Cisco ASR 9000 Series Routers is compatible with the following line card (LC), route switch processors (RSPs), and modular port adapters (MPAs).

Note The Cisco IOS XR Software Release 7.3.1 supports cnBNG UP only on Cisco ASR 9000 High Density 100GE Ethernet line cards. See the table for the list of supported PIDs.

Table 1: Software and Hardware Requirements for cnBNG User Plane

Cisco IOS XR Software Release	LC	RSP	MPA
Cisco IOS XR Software Release 7.3.1	• A9K-24X10GE-1G-SE • A9K-48X10GE-1G-SE • A9K-4X100GE-SE • A9K-MOD200-SE • A9K-MOD200-CM • A9K-MOD400-SE • A9K-MOD400-CM	• A9K-RSP880-SE • A9K-RSP880-LT-SE • A99-RP-SE and A99-RP2-SE (on the Cisco ASR 9912 and the Cisco ASR 9922 chassis) • A99-RSP-SE (on the Cisco ASR 9910 and the Cisco ASR 9906 chassis) • A9K-RSP5-SE	• A9K-MPA-1X100GE • A9K-MPA-2X100GE • A9K-MPA-4X10GE • A9K-MPA-8X10GE • A9K-MPA-20X10GE • A9K-MPA-20X1GE • A9K-MPA-1X40GE • A9K-MPA-2X40GE

Access Types and Subscriber Types

Access Types

The cnBNG user plane on Cisco IOS XR platform supports sub-interface Bundle-Ethernet access type with these encapsulations:

- **Single Dot1q**—which is the IEEE 802.1Q networking standard to support VLANs on an Ethernet network.
- **Double-tagged VLANs**—where two VLAN ID tags (inner tag and outer tag) are inserted into a single data frame. This encapsulation enables users to use their own VLANs inside the VLAN provided by the service provider.
- **Ambiguous VLANs**—that use a range or group of VLAN IDs that enables you to create multiple sessions on a single access-interface.

Subscriber Types

The IP subscriber sessions that connect through a Layer-2 aggregation network are called **L2-connected** sessions. Subscriber sessions where an IPv4 address and an IPv6 address co-exist for the same subscriber are called **dual-stack** subscriber sessions.

The cnBNG UP on Cisco IOS XR platform supports two types of **L2-connected dual-stack** subscriber sessions:

- **IPoE-DHCP dual-stack sessions**: In IP over Ethernet (IPoE) sessions, subscribers run IPv4 or IPv6 on the CPE device and connect to the BNG through an L2 aggregation network. These sessions rely on the DHCP protocol for assigning IP address for the subscriber.
- **PPPoE-DHCPv6 dual-stack PTA sessions**: The PPP over Ethernet (PPPoE) subscriber session is established using the point-to-point protocol (PPP) that runs between the CPE and BNG. These sessions rely on the standard PPP negotiations for subscriber authentication and IP address assignment.

  In a PPP Termination and Aggregation (PTA) session, the PPP encapsulation terminates on BNG. After that the BNG routes the traffic to the service provider using IP routing.

Subscriber Features

Table 2: Feature History Table

Feature Name	Release Information	Feature Description
Increased Granularity for Cloud Native BNG Traffic Management with Hierarchical QoS (H-QOS)	Release 7.4.2	This feature allows you to specify QoS behavior at multiple policy levels for Internet Protocol over Ethernet (IPoE), Point-to-Point Protocol over Ethernet (PPPoE), PPP Termination and Aggregation (PTA), and LNS (L2TP Network Server) sessions and provides a high degree of granularity in traffic management. Use the first level of the traffic policy, the parent traffic policy, to control the traffic at the main interface or sub-interface level. Use the second level, the child traffic policy, for additional control over a specific traffic stream or class.
Multiple Framed IPv4 and IPv6 Routes for Customer PremisesEquipment (CPE)	Release 7.4.2	You can configure multiple framed routes for IPv4 and IPv6 traffic across CPE. This functionality allows you to route multiple customer networks through a single customer broadband connection, thus enabling the LAN network subscriber to use a different subnet from WAN.

Feature Name	Release Information	Feature Description
Cloud Native BNG feature extension to 5th Generation Line Card	Release 7.4.2	The A99-32X100GE-X-SE, A9K-20HG-FLEX-SE , and A9K-8HG-FLEX-SE line cards now support the following Cloud Native BNG functionalities: • IPoE subscriber sessions that run both IPv4, IPv6 on the CPE device. • PPP over Ethernet PPP Termination and Aggregation (PPPoE PTA) sessions • DHCPv6 support for PPPoE sessions • Cloud Native BNG over Bundle Ether interface • Quality of Service (QoS) • Policy-based Routing (PBR) • Access Control List (ACL) • ICMP unreachable • Lawful Intercept (LI) This enhancement enables BNG features to leverage the higher throughput of the 5th generation of line cards.

This section lists the set of subscriber features that cnBNG user plane on the Cisco IOS XR platform supports.

- **IPv4 or IPv6**:
  - **Maximum Transmission Unit (MTU)**—that defines the maximum size of each packet that you can transmit during the subscriber session.
  - **Unicast Reverse Path Forwarding (URPF)**—that ensures that the system does not accept any traffic on the subscriber interface from malformed or forged IP source addresses.
  - **Internet Control Message Protocol (ICMP)**—a supporting protocol that networking devices use to send error messages and operational information to the originator of transmission.
- **Access Control List (ACL)**—that performs packet filtering to control the traffic flow into and out of network interfaces. It helps to define the access rights such as, filtering the content, blocking access to various resources and so on, for a subscriber .

  Supported ACL types are:
  - Input ACL (IPv4 or IPv6)

- Output ACL (IPv4 or IPv6)

- **QoS**:
  - **Policing (input and output)**—that allows you to control the maximum rate of traffic sent or received on an interface. It also allows to partition a network into multiple priority levels or class of service (CoS).
  - **Shaping (output)**—that allows you to control the traffic flow that exits an interface to match its transmission to the speed of the remote target interface. It also ensures that the traffic conforms to policies contracted for it.
  - **Policy Merging**—that merges multiple QoS policies on a single subscriber. The UP supports a maximum of 6 policy-maps and 10 class-maps, including the default ones.

- **Hierarchical QoS (H-QoS)**—that allows you to specify QoS behavior at multiple policy levels, which provides a high degree of granularity in traffic management. cnBNG supports the following two-level hierarchical policy for deploying QoS:
  - Parent policy:
  - Child policy

  H-QoS is applied on the router interface using nested traffic policies. The first level of traffic policy, the parent traffic policy, is used for controlling the traffic at the main interface or sub-interface level. The second level of traffic policy, the child traffic policy, is used for additional control over a specific traffic stream or class. The child traffic policy, is a previously defined traffic policy, that is referenced within the parent traffic policy. Two-level H-QoS is supported on both ingress and egress directions on all line cards and on physical or bundle main interfaces and sub-interfaces.

  To know more about H-QOS, refer the *Configuring Hierarchical Modular QoS* chapter in the *Modular QoS Configuration Guide for Cisco ASR 9000 Series Routers*

- **HTTP Redirect using PBR** (for input policy)—that redirects subscriber traffic to a destination other than to its original destination. Policy-based Routing (PBR) makes packet forwarding decisions based on the policy configurations, instead of routing protocols.
- **Accounting:** cnBNG UP supports periodic accounting for these accounting types:
  - **Session Accounting**—which is the statistics of a subscriber session.
  - **Service Accounting:**—which is the statistics for each service (collection of features) that is enabled for a subscriber.

Note
- You cannot enable service accounting without session accounting.
- You cannot have different periodicity for session and service accounting.

- **Lawful Intercept** (for mediation device in default or non-default VRF)—that allows Law Enforcement Agencies (LEA) to conduct electronics surveillance as authorized by judicial or administrative order.
- **Multiple Framed Route**—allows a large number of customer networks to reach through framed routes through a single broadband connection. Framed Route is supported on both IPoE and PPPoE sessions.

There’s no limit enforced to the number of framed routes per session. You don't have to configure or enable Framed Route through command line interface as it is downloaded from RADIUS.

Read more about these features in the *Cisco ASR 9000 Series Aggregation Services Router Broadband Network Gateway Configuration Guide*.

Supported Parameter Limit for Subscriber Features

The cnBNG user plane on Cisco IOS XR platform supports a maximum of:

- 32 IP subnet pools
- 32 secondary IP addresses
- Eight QoS services
- Eight class-maps
- Six actions for multi-action change-of-authorization (MA-CoA)

  (MA-CoA is a feature which enables the service providers to activate and deactivate multiple subscriber services using a single CoA request).

High Availability

High Availability (HA) enables network-wide protection by providing fast recovery from faults that may occur in any part of the network. The cnBNG user plane does not delete the subscriber state, summary subnet route state, subscriber route state, and so on, in a stable system except in a few scenarios. These scenarios can be either explicit execution of CLI commands to clear the session, process restart of peer process, mark and sweep procedure (an internal clean-up process which detects and reclaims the memory that is used by unused objects) of *cnbng-nal* process, route processor fail over (RPFO), or deletion of parent interface.

This section describes the expected behavior if a high availability event such as a router reload or RPFO occurs on the cnBNG user plane:

- NAL restores the last stable (check-pointed) session state with best effort after the HA event.
- To ensure data and session integrity between NAL and peer processes, the system triggers a mark and sweep procedure during *cnbng-nal* process restart. During this process, the NAL might not be able to restore the sessions due to unforeseen issues from the feature or from the IOS XR infra components. In that case, the system deletes those sessions and sends a notification to the CP.
- The *cnbng-nal* process restart does not initiate automatic reconciliation procedure between the CP and the UP. The CP triggers this explicitly using a CLI configuration.
- The Cisco IOS XR platform has active and standby hardware level support (active RSP and standby RSP) on logical interface subscriber. The data sync between these nodes is not real time. The *cnbng-nal* process periodically syncs for various internal data on a best-effort basis. There can be a few cases where session data is out of sync between route processors which leads to session recreate failure after RFPO. These cases maybe for recently created sessions or inflight sessions. The system deletes those sessions at UP and sends a notification to the CP.
- The CP acts on these notification events to make sure that the subscriber state is in sync. If not, it leads to out of sync sessions between the UP and the CP in such scenarios.

- During process restart or RPFO, mark and sweep procedure might lead to subscriber session deletion on UP.
- The UP might not push the final statistics if a process restart or RPFO happens while a subscriber or service deletion is in progress. In that case, the CP considers the last collected statistics PCRF or back-end statistics as the final statistics.

Usage Guidelines

These guidelines apply to using the cnBNG user plane functionality on the Cisco IOS XR platform:

- You must not perform these actions on the fly while active subscriber sessions are present on the router:
  - Removal of configurations
  - Enabling or disabling service accounting
  - Deletion or modification of parent interface properties (such as IPv4 or IPv6 address, MTU, DHCPv4 initiator, PPPoE, DHCPv6 initiator, enable L2TP and LNS, and so on)
  - Deactivation of cnBNG package
  - Deletion or modification of VRF and loopback
  - Modification of service profile, and IPv4 or IPv6 address
- PPP keep alive (KA)—the user plane generates the PPP KA messages to the CPE to make packet transport more efficient between the CP and the UP. You must ensure that the duration of PPP keep alive is large enough (in tens of minutes) to have better CPU performance in scenarios with large subscriber scale.
- If an update request having service deactivation fails, the UP reactivates the service as part of rollback and starts the statistics afresh from zero.
- The CP-UP communication loss might cause the CP and UP to be in out of sync. There is no automated recovery mechanism for such scenarios.

Restrictions

The cnBNG user plane functionality on the Cisco IOS XR platform does not support these functionalities:

- Standalone PPP use case with cnBNG enabled
- Per pool or VRF tag support for IP pool subnet routes installed with a specific tag for the entire UP
- Back-to-back RPFO or switchover without graceful shutdown
- LC-based subscribers
- Subscriber redundancy group (SRG) for Bundle-Ethernet
- Enabling service accounting without session accounting
- Different periodicity for session and service accounting



CHAPTER 5

Installing Cloud Native BNG User Plane Packages

This chapter describes the procedure for installing cloud native BNG user plane packages on Cisco IOS XR platform.

- Installing and Activating the cnBNG Package on the User Plane, on page 25

Installing and Activating the cnBNG Package on the User Plane

Before you begin:

You must follow these guidelines before installing cnBNG package on the user plane:

- The cnBNG user plane functionality requires two packages to be installed on the router—the BNG support package (**asr9k-bng-supp-x64-*.rpm**) and the cnBNG package **(asr9k-cnbng-x64-*.rpm**).
- You can install cnBNG as an optional package on the router. The standard Cisco Golden ISO (GISO) image does not contain the cnBNG package.
- The physical BNG package (**asr9k-bng-x64*.rpm**) and the cnBNG package (**asr9k-cnbng-x64*.rpm**) are mutually exclusive. You cannot install both the packages on the router. The install operation fails if tried.
- You must uninstall and remove the physical BNG package and reboot the router prior to installing the cnBNG package on a router which is already being used as a physical BNG.
- You can either activate the BNG support package and the cnBNG package together as a single step or activate the BNG support package first and then activate the cnBNG package.
- The system does not support standalone PPP use case with cnBNG enabled. You must remove any PPP configuration before activating cnBNG on the router.

Installing and Activating the cnBNG Package on the User Plane

- **Step 1**: Install both the BNG support package and the cnBNG package from the RPM location to the router

  Use the **install add source** command.

```
Router#install add source tftp://209.165.200.225/test-path/
asr9k-bng-supp-x64-1.0.0.0-r73105I.x86_64.rpm asr9k-cnbng-x64-1.0.0.0-r73105I.x86_64.rpm
```

This step adds the BNG support package (**asr9k-bng-supp-x64-1.0.0.0-r73105I.x86_64.rpm**) and the cnBNG package (**asr9k-cnbng-x64-1.0.0.0-r73105I.x86_64.rpm**) from the source location of the RPMs (**tftp://209.165.200.225/test-path/**) to the router.

- **Step 2:** Activate the packages

  Use the **install activate** *activate-id* command.

  Where, *activate-id* is the ID that you see on the router console once the **install add** operation in the previous step is completed.

```
Router#install activate 1
```

  This step activates both the BNG support package and the cnBNG package which were installed as part of step 1.

- **Step 3:** Verify the activated packages.

  Use the **show install active** command.

```
Router#show install active
Sun Apr 19 09:49:34.041 UTC
Node 0/RSP0/CPU0 [RP]
  Boot Partition: xr_lv0
  Active Packages: 5
        asr9k-xr-7.3.1.05I version=7.3.1.05I [Boot image]
        asr9k-bng-supp-x64-1.0.0.0-r73105I
        asr9k-cnbng-x64-1.0.0.0-r73105I

Node 0/0/CPU0 [LC]
  Boot Partition: xr_lv0
  Active Packages: 5
        asr9k-xr-7.3.1.05I version=7.3.1.05I [Boot image]
        asr9k-bng-supp-x64-1.0.0.0-r73105I
        asr9k-cnbng-x64-1.0.0.0-r73105I

Node 0/1/CPU0 [LC]
  Boot Partition: xr_lv0
  Active Packages: 5
        asr9k-xr-7.3.1.05I version=7.3.1.05I [Boot image]
        asr9k-bng-supp-x64-1.0.0.0-r73105I
        asr9k-cnbng-x64-1.0.0.0-r73105I

Node 0/3/CPU0 [LC]
  Boot Partition: xr_lv0
  Active Packages: 5
        asr9k-xr-7.3.1.05I version=7.3.1.05I [Boot image]
        asr9k-bng-supp-x64-1.0.0.0-r73105I
        asr9k-cnbng-x64-1.0.0.0-r73105I
```

  The *Active Packages* parameter in the show command output lists the BNG support package and the cnBNG package. This shows successful activation of the packages.

This step completes the installation and activation of cnBNG package on the user plane.



CHAPTER 6

Configuring Cloud Native BNG User Plane and Key Features

This chapter describes the configuration procedures to achieve the cnBNG user plane functionality on Cisco ASR 9000 Series Routers.

For details on cnBNG user plane commands, see the *Cloud Native BNG Command Reference for Cisco ASR 9000 Series Routers*.

- Configure cnBNG User Plane, on page 27
- Verify cnBNG User Plane Configuration, on page 42

Configure cnBNG User Plane

Before you begin:

You must follow these guidelines for configuring cnBNG user plane:

- You must perform a complete reimage followed by a reboot of the router if you are switching between physical BNG to cnBNG, or the other way around.
- Ensure that the cnBNG package is installed and activated on the user plane. See the *Installing Cloud Native BNG User Plane Packages* chapter for detailed procedure.
- The system does not support the removal of configurations while active sessions are present. You must delete all active sessions and dissociate the CP-UP connection prior to any configuration change or commit replace procedure.

Configuration Procedure

You must perform the following tasks for the UP to spawn the NAL process, to establish connection with the CP, and to provision the subscriber requests.

Configure Basic User Plane Settings

The basic user plane configuration for cnBNG involves these high-level tasks:

- Configuring the server endpoints of CP to which UP can send PFCP or GTP-U messages to enable cnBNG on the router.
- Configuring a loopback interface for each VRF.
- Configuring a route tag for subscriber summary routes.
- Configuring the access-interface to enable IPoE and PPPoE subscribers.

The cnBNG endpoint configurations on the UP are delivered to the cnBNG SPA component for initiating connection with the CP.

Configuration Procedure

This section describes the steps for the basic user plane configuration, which include certain mandatory and optional configurations.

Mandatory Configurations:

- Specifying a unique name for the UP-server instance.
- Specifying the details of the UP server (such as IP address, GTP port, and PFCP port) to which the CP can send PFCP or GTP-U messages.
- Specifying the details of CP server to which the UP can send PFCP or GTP-U messages.
- Specifying the retry count for CP-UP association.
- Enabling secondary address programming.
- Specifying a name for the auto-loopback VRF.
- Configuring a loopback interface to associate with the above VRF.
- Specifying a primary address for the loopback interface.

Optional Configuration:

- Configuring a route summary tag for the routes to add in the routing table

Configuration Example

Configuration example with IPv4 transport.

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal-local)#hostidentifier asr9k-1
Router(config-cnbng-nal-local)#cp-server primary ipv4 198.51.100.1
Router(config-cnbng-nal-local)#up-server ipv4 192.0.2.1 gtp-port 15002 pfcp-port 15003 vrf
 default
Router(config-cnbng-nal-local)#secondary-address-update-enable
Router(config-cnbng-nal-local)#cp-association retry-count 10
Router(config—cnbng-nal-local)#auto-loopback vrf test
Router(config—cnbng-nal-local-auto-loopback-vrf)#interface Loopback2
Router(config—cnbng-nal-local-auto-loopback-vrf-int)#primary-address 127.0.0.1
Router(config—cnbng-nal-local-auto-loopback-vrf-int)#exit
Router(config—cnbng-nal-local-auto-loopback-vrf)#exit
/* Auto-loopback configuration for default VRF */
Router(config—cnbng-nal-local)#auto-loopback vrf default
```

```
Router(config—cnbng-nal-local-auto-loopback-vrf)#interface Loopback1
Router(config—cnbng-nal-local-auto-loopback-vrf-int)#primary-address 10.0.0.1
Router(config—cnbng-nal-local-auto-loopback-vrf-int)#exit
Router(config—cnbng-nal-local-auto-loopback-vrf)#exit
Router(config-cnbng-nal-local)#route-summary tag 4
Router(config-cnbng-nal-local)#commit
```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
 hostidentifier asr9k-1
 up-server ipv4 192.0.2.1 vrf default
  gtp-port 15002
  pfcp-port 15003
 cp-server primary ipv4 198.51.100.1
 secondary-address-update-enable
cp-association retry-count 10
auto-loopback vrf test
 interface Loopback2
  primary-address 127.0.0.1
 !
!
auto-loopback vrf default
 interface Loopback1
  primary-address 10.0.0.1
 !
!
route-summary tag 4
!
```

Configure Access-Interface

This section describes how to configure the access-interface and to enable PPPoE on the cnBNG user plane.

Configuration Example

```
Router#configure
Router(config)#interface Bundle-Ether1.1
Router(config-subif)#ipv4 point-to-point
Router(config-subif)#ipv4 unnumbered Loopback1
Router(config-subif)#ipv6 enable
Router(config-subif)#encapsulation dot1q 1
Router(config-subif)#ipsubscriber
Router(config-cnbng-nal-ipsub)#ipv4 l2-connected
Router(config-cnbng-nal-ipsub-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-l2conn)#exit
Router(config-cnbng-nal-ipsub)#ipv6 l2-connected
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#exit
Router(config-cnbng-nal-ipsub)#exit

/* Enable PPPoE */
Router(config-subif)#pppoe enable
Router(config-subif)#commit
```

Running Configuration

```
Router#show running-config interface be1.1
interface Bundle-Ether1.1
 ipv4 point-to-point
 ipv4 unnumbered Loopback1
 ipv6 enable
 encapsulation dot1q 1
 ipsubscriber
  ipv4 l2-connected
   initiator dhcp
  !
  ipv6 l2-connected
   initiator dhcp
  !
 !
 pppoe enable
!
```

Configure Loopback Interface

This section describes how to configure the loopback interface for cnBNG user plane.

Note You must not configure any IP address under loopback interface.

Configuration Example

```
Router#configure
Router(config)#interface loopback 2
Router(config-if)#ipv6 enable
Router(config-if)#commit
```

Running Configuration

```
Router#show running-config interface loopback 2
interface Loopback2
 ipv6 enable
!
```

Enable Multiple Loopback Interfaces for Cloud Native BNG

Table 3: Feature History Table

Feature Name	Release Information	Feature Description
Multiple Loopback Interfaces for Cloud Native BNG	Release 7.6.2	By configuring multiple loopbacks under the same VRF and splitting a large network into smaller chunks, you can increase the number of IP addresses using IP subnet pools, thus improving address allocation and managing network bandwidth efficiently. In earlier releases, Cloud Native BNG supported only a single loopback for a given VRF.

You can configure multiple loopback interfaces under *cnbng-nal* configuration mode for default and non-default VRF.

Note A maximum of 47 loopback interfaces are supported under the *cnbng-nal* configuration mode.

Configuration for default VRF

```
Router#configure
Router(config)#cnbng-nal location 0/rsp0/CPU0
Router(config-cnbng-nal-local)#auto-loopback vrf default
Router(config-cnbng-nal-auto-loopback-vrf)#interface loopback 0
Router(config-cnbng-nal-auto-lb-vrf-int)#primary-address 10.0.0.1
Router(config-cnbng-nal-auto-lb-vrf-int)#exit
Router(config-cnbng-nal-auto-loopback-vrf)#interface loopback 1
Router(config-cnbng-nal-auto-lb-vrf-int)#primary-address 10.0.0.2
Router(config-cnbng-nal-auto-lb-vrf-int)#exit
Router(config-cnbng-nal-auto-loopback-vrf)#interface loopback 2
Router(config-cnbng-nal-auto-lb-vrf-int)#primary-address 10.0.0.3
Router(config-cnbng-nal-auto-lb-vrf-int)#
```

Running Configuration

```
/* Configuration for default VRF */
cnbng-nal location 0/rsp0/CPU0
 auto-loopback vrf default
  interface loopback 0
    primary-address 10.0.0.1
    !
  interface loopback 1
    primary-address 10.0.0.2
    !
  interface loopback 2
    primary-address 10.0.0.3
    !
```

Configuration for non-default VRF

```
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal-local)# hostidentifier cnBNG-SRG1
Router(config-cnbng-nal-local)# up-server ipv4 10.1.1.1 vrf default
Router(config-cnbng-nal-local)# cp-server primary ipv4 201.201.201.65
Router(config-cnbng-nal-local)# auto-loopback vrf vrftwo
Router(config-cnbng-nal-auto-loopback-vrf)# interface Loopback16
Router(config-cnbng-nal-auto-lb-vrf-int)# primary-address 10.0.0.1
Router(config-cnbng-nal-auto-lb-vrf-int)# interface Loopback17
Router(config-cnbng-nal-auto-lb-vrf-int)# primary-address 10.0.0.2
Router(config-cnbng-nal-auto-lb-vrf-int)# interface Loopback18
Router(config-cnbng-nal-auto-lb-vrf-int)# primary-address 10.0.0.3
Router(config-cnbng-nal-auto-lb-vrf-int)#
```

Running Configuration

```
cnbng-nal location 0/RSP0/CPU0
 hostidentifier cnBNG-SRG1
 up-server ipv4 19.1.1.1 vrf default
 cp-server primary ipv4 201.201.201.65
 auto-loopback vrf RJIL-VRF-OLT-MGMT
  interface Loopback16
   primary-address 1.1.0.1
  !
  interface Loopback17
   primary-address 2.1.0.1
  !
  interface Loopback18
   primary-address 3.1.0.1
```

Verification

```
/* Verification for default VRF */
Router#show cnbng-nal dynamic-routes summary

Location: 0/RSP0/CPU0
-----------------------

Counter Name            Value
--------------------------------
V4 OC Entries           64
V6 OC Entries           0
V4 Primary Entries      0
V4 Secondary Entries    64      <<< This the total secondary addresses pushed from CP for
each subnet
V4 RIB Entries          64      <<< This is the total number of v4 subnets pushed from CP
V6 RIB Entries          128     <<< This is the total number of v4 subnets pushed from CP
OC replay entry count   96
```

The following example shows the details of each route entry:

```
/* Verification for non-default VRF */
Router#show cnbng-nal dynamic-routes afi ipv4

Location: 0/RSP0/CPU0
-----------------------

Index                    : 1
Interface                : Loopback24
VRF                      : vrfone
AFI                      : IPv4
Prefix                   : 10.0.0.0/20
Secondary address        : 10.0.0.1
Route tag                : 41
```

```
State                    : RIB_REQ_COMPLETE
SRG group name           :
Route metric             : 0


[Event History]
| Event Name                              | Time Stamp

| Route OC request sent                   | Jun 15 15:29:10.144
| Added secon V4 addrs on lb              | Jun 15 15:29:10.144
| Route update succeed                    | Jun 15 15:29:10.144
| V4 route add success                    | Jun 15 15:29:10.144
==========================================

Router#show cnbng-nal dynamic-routes afi ipv6
Thu Jun 16 08:06:25.312 GMT

Location: 0/RSP0/CPU0
----------------------

Index                    : 1
Interface                : Loopback20
VRF                    : vrfone
AFI                      : IPv6
Prefix                   : 4001::/52
Secondary address        : NA
Route tag                : 31
State                    : RIB_REQ_COMPLETE
SRG group name           :
Route metric             : 0


[Event History]
| Event Name                              | Time Stamp

| Added secon V6 addrs on lb              | Jun 15 15:29:05.152
| Skip V6 rt install (standby)            | Jun 15 15:29:05.152
| Route update succeed                    | Jun 15 15:29:05.152
==========================================

/* Verification for non-default VRF */
Router#nshow cnbng-nal dynamic-routes afi ipv4
Mon Aug  8 05:13:59.576 GMT

Location: 0/RSP0/CPU0
----------------------

Index                    : 1
Interface                : Loopback16
VRF                      : vrftwo
AFI                      : IPv4
Prefix                   : 10.0.0.0/20
Secondary address        : 10.0.0.1
Route tag                : 32
State                    : RIB_REQ_COMPLETE
SRG group name           : group32
Route metric             : 0


[Event History]
| Event Name                              | Time Stamp

| Route OC request sent                   | Aug  4 15:39:24.288
| Added secon V4 addrs on lb              | Aug  4 15:39:24.288
```

```
| Route update succeed                    | Aug  4 15:39:24.416
| V4 route add success                    | Aug  4 15:39:24.416
==========================================

Index                   : 2
Interface               : Loopback17
VRF                     : vrftwo
AFI                     : IPv4
Prefix                  : 10.0.0.0/20
Secondary address       : 10.0.0.1
Route tag               : 32
State                   : RIB_REQ_COMPLETE
SRG group name          : group32
Route metric            : 0


[Event History]
| Event Name                              | Time Stamp

| Route OC request sent                   | Aug  4 15:39:26.976
| Added secon V4 addrs on lb              | Aug  4 15:39:26.976
| Route update succeed                    | Aug  4 15:39:26.976
| V4 route add success                    | Aug  4 15:39:26.976
==========================================
```

Configure DHCP

This section describes the steps to configure DHCP for cnBNG BNG user plane.

The basic DHCP configurations include these steps:

- Creating a cnBNG profile
- Assigning the cnBNG profile to access-interfaces

Configuration Example

```
Router(config)#dhcp ipv4
/* Create a cnBNG profile */
Router(config-dhcpv4)#profile cnbng_1 cnbng
Router(config-dhcpv4-cnbng-profile)#exit
/* Assign the cnBNG profile to access-interfaces */
Router(config-dhcpv4)#interface bundle-Ether 1.1 cnbng profile cnbng_1
Router(config-dhcpv4)#interface bundle-Ether 2.1 cnbng profile cnbng_1
Router(config-dhcpv4)#commit
```

Similarly, you can configure the DHCP IPv6 profiles.

Running Configuration

```
Router#show run dhcp ipv4
Wed Oct 14 16:48:56.814 UTC
dhcp ipv4
 profile cnbng_1 cnbng
 !
 interface Bundle-Ether1.1 cnbng profile cnbng_1
 interface Bundle-Ether2.1 cnbng profile cnbng_1
```

```
!


Router#show run dhcp ipv6
Wed Oct 14 16:49:19.095 UTC
dhcp ipv6
 profile cnbng_1 cnbng
 !
 interface Bundle-Ether1.1 cnbng profile cnbng_1
 interface Bundle-Ether2.1 cnbng profile cnbng_1
!
```

Configure Subscriber Gateway Address and Subnet Route

Table 4: Feature History Table

Feature Name	Release Information	Feature Description
Disable Notifications for Dynamic Programming of Subscriber Gateway Address	Release 7.4.2	This feature allows you to disable the notifications exchanged internally between software components when the user plane (UP) of a cloud-native BNG (cnBNG) network programs the gateway address for its subscriber. It prevents excessive notifications when many active subscribers are on the UP, thus reducing the overhead on UP resources. The feature introduces the following command: • **disable-secondary-address-notification**

In cnBNG, the IP address management is more dynamic. Hence, the loopback interface for IPoE or PPPoE subscribers isn't provisioned in the user profile of the subscriber with static configuration. cnBNG user plane selects the loopback based on the subnet allocated to a loopback dynamically at cnBNG user plane.

Note For every VRF, one loopback must be present on the UP.

Consider this example,

```
On RSP0:
Tue Jul 28 05:55:13.015 UTC
cnbng-nal location 0/RSP0/CPU0
hostidentifier asr9k-1
up-server ipv4 192.0.2.1 vrf default
cp-server primary ipv4 198.51.100.1
auto-loopback vrf default
  interface Loopback1
   primary-address 10.0.0.1
```

```
  !
!
On RSP1:
Tue Jul 28 05:56:13.015 UTC
cnbng-nal location 0/RSP1/CPU0
hostidentifier asr9k-1
up-server ipv4 192.0.2.1 vrf default
cp-server primary ipv4 198.51.100.1
auto-loopback vrf default
  interface Loopback1
   primary-address 10.0.0.1
  !
!
```

In this example, the CP assigns 10.11.12.0/24 as subnet, and 10.11.12.1/32 as gateway address to subscribers under the default VRF. This gateway address serves as the DHCPv4 server address for DHCPv4 OFFER or ACK messages. The *cnbng-nal* process uses Operations Center (OC) to configure this gateway address as secondary IP address on the loopback and route provision APIs to program the entry in the L3 routing table.

Note The system supports a maximum of 32 secondary IP addresses under an interface.

```
Router#show ipv4 interface loopback 1
Tue Jul 28 05:29:58.741 UTC
Loopback1 is Up, ipv4 protocol is Up
  Vrf is default (vrfid 0x60000000)
  Internet address is 10.0.0.1/32
  Secondary address 10.11.12.1/32


Router#show route vrf all ipv4 subscriber
A    10.11.12.0/24 [1/0] via 0.0.0.0, 00:10:29
```

Note The dynamic programming of the subnet (secondary gateway) under the loopback causes a major churn on the UP if large scale of active subscribers is present on the node. Hence, the secondary address programming is disabled, by default.

Enable Secondary Address Programming

It's mandatory to enable the secondary address programming on cnBNG user plane. To enable that, use the **secondary-address-update enable** command under the cnbng-nal configuration mode.

Configuration Example

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal)#secondary-address-update enable
Router(config-cnbng-nal)#commit
```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
 secondary-address-update enable
!
```

Note From Release 7.4.2 onwards, you can disable internal notifications on the UP while it programs the secondary address on the loopback interface by configuring the command **disable-secondary-address-notification**.

Disable Notifications for Dynamic Programming of Subscriber Gateway Address

In a cnBNG network, the CP assigns the gateway address for each subscriber. The UP dynamically programs gateway address assigned to each subscriber as a secondary IP address on its loopback interface. During this configuration, UP internally exchanges notification messages between various software components. The more the number of active subscribers on the UP, the more the notifications. To preserve valuable time and resources of the UP, you can disable notifications using the command **disable-secondary-address-notification** in the **cnbng-nal-local** config mode.

Configuration Example

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal-local)#disable-secondary-address-notification
Router(config-cnbng-nal-local)#commit
```

Running Configuration

The following running configuration on cnBNG UP includes basic UP configuration as well:

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/1/CPU0
 hostidentifier RTR1
 auto-loopback vrf test
  interface Loopback1
   primary-address 10.1.1.1
  !
 !
 auto-loopback vrf default
  interface Loopback0
   primary-address 10.30.30.1
  !

 !

 up-server ipv4 10.11.11.1 gtp-port 15002 pfcp-port 15003 vrf default
 cp-server primary ipv4 10.11.11.2
 enable-test-server
 disconnect-history file-logging-enable
 secondary-address-update enable
 disable-secondary-address-notification
 route-summary tag 111
 cp-association retry-count 5
!
```

Configure Route Summary

This section describes the steps to configure route summary for the cnBNG user plane.

The NAL handles the following routes:

- Individual subscriber routes
- Summary routes for subscriber pool subnet

The subscriber routes are part of the subscriber provisioning message, which includes:

- WAN IP address (/32 or /128 subnet)
- LAN IP (prefix delegation)

The summary routes are for the subscriber pool subnet which are exported to the core network to download traffic towards the subscriber. On physical BNG, the subscriber pool subnets were configured as static routes and redistributed through BGP or IGP. With cnBNG and auto-loopback selection, these subnets for the subscribers are added dynamically to the loopback. Every time a new subscriber pool subnet is added to the loopback, the same is added to the RIB with the tag that is provided by the CP. If tag is '0', the NAL uses the tag configured under the cnbng-nal. Routes with this tag can be exported to the core using the Routing Protocol for Low-Power and Lossy Networks (RPLs).

To configure route summary, use the **route-summary** command under the cnbng-nal configuration mode.

Configuration Example

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal)#route-summary tag 10
Router(config-cnbng-nal)#commit
```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
 route-summary tag 10
!
```

After the first subnet is installed on NAL, the following routes are added to the system:

```
A 10.11.12.0/24 [1/0] via 0.0.0.0, 0d01h
```

Export Routes to Core Network

This section describes how to export routes to core network as part of enabling cnBNG user plane functionality.

Configuration Example

```
Router#configure
Router(config)#route-policy test-policy-cnbng
```

```
Router(config-rpl)#if tag eq 10 then
Router(config-rpl-if)#set community (123:100)
Router(config-rpl-if)#done
Router(config-rpl-if)#endif
Router(config-rpl)#end-policy
Router(config)#commit

Router(config)#router ospf 10
Router(config-ospf)#vrf test-vrf-cnbng
Router(config-ospf-vrf)#redistribute subscriber route-policy test-policy-cnbng
Router(config-ospf-vrf)#commit
```

Running Configuration

```
Router#show running-config route-policy test-policy-cnbng
route-policy test-policy-cnbng

     if tag eq 10  then

       set community (123:100)

       done

     endif

   end-policy
   !

Router#show running-config router ospf
router ospf 10
 vrf test-vrf-cnbng
  redistribute subscriber route-policy test-policy-cnbng
  !
```

Configure ARP Scale Mode

This section describes the steps to configure ARP scale mode for the cloud-native BNG user plane.

To disable interface entry creation by ARP for each subscriber interface on the data plane (line cards), you must enable ARP scale mode for the subscriber using the **arp scale-mode-enable** command in subscriber configuration mode.

Configuration Example

```
Router#configure
Router(config)#subscriber
Router(config-subscriber)#arp scale-mode-enable
Router(config-subscriber)#commit
```

Running Configuration

```
Router#show running-config subscriber
Sat Aug 22 06:36:21.422 UTC
subscriber
arp scale-mode-enable
```

!

Configure Cloud Native BNG over Pseudowire Headend

Table 5: Feature History Table

Feature Name	Release Information	Feature Description
Establishing Cloud Native BNG Sessions over Pseudowire Headend (PWHE)	Release 7.4.2	This feature establishes Cloud Native BNG subscriber sessions on PWHE interfaces. PWHE enables an easy and scalable mechanism for tunneling cnBNG traffic into a common IP, MPLS, or L2 network.

Cloud Native BNG provides subscriber support over Pseudowire Headend (PWHE). PWHE provides L3 connectivity to customer edge nodes through a pseudowire connection. PWHE terminates the L2VPN circuits that exist between the access-provide edge (A-PE) nodes, to a virtual interface, and performs routing on the native IP packet. Each virtual interface can use one or more physical interfaces towards the access cloud to reach customer Router through the A-PE nodes.

This figure shows a sample topology for Cloud Native BNG over Pseudowire Headend:

Figure 7: Sample Topology for Cloud Native BNG over Pseudowire Headend:



Restrictions

You can not configure eight ECMP links on the same PE device.

Configuration Example

This section provides the sample configurations for BNG over Pseudowire Headend:

The following is the sample configuration to allow IPOE or PPPOE subsciber to bring up from the PWHE access interface on the cnBNG:

```
Router#configure
Router(config)#interface PW-Ether100.102
Router(config-subif)#ipv4 unnumbered Loopback100
Router(config-subif)#ipv6 enable
Router(config-subif)#load-interval 30
Router(config-subif)#ipsubscriber
Router(config-cnbng-nal-ipsub)#ipv4 l2-connected
Router(config-cnbng-nal-ipsub-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-l2conn)#exit
Router(config-cnbng-nal-ipsub)#ipv6 l2-connected
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#exit
Router(config-cnbng-nal-ipsub)#exit
Router(config-subif)#pppoe enable
Router(config-subif)#encapsulation ambiguous dot1q any second-dot1q 102
Router(config-subif)#commit
```

This example shows the configuration of DHCPv4 on PWHE interfaces:

```
Router#configure
Router(config)#dhcp ipv4
Router(config-dhcpv4)#profile cn4 cnbng
Router(config-dhcpv4-cnbng-profile)#exit
Router(config-dhcpv4)#interface PW-Ether100.102 cnbng profile cn4
Router(config-dhcpv4)#interface PW-Ether100.103 cnbng profile cn4
Router(config-dhcpv4)#interface PW-Ether100.104 cnbng profile cn4
Router(config-dhcpv4)#commit
```

This example shows the configuration of DHCPv6 on PWHE interface:

```
Router#configure
Router(config)#dhcp ipv6
Router(config-dhcpv6)#profile cn4 cnbng
Router(config-dhcpv6-cnbng-profile)#exit
Router(config-dhcpv6)#interface PW-Ether100.102 cnbng profile cn6
Router(config-dhcpv6)#interface PW-Ether100.103 cnbng profile cn6
Router(config-dhcpv6)#commit
```

Running Configuration

The following example displays the running configuration of pw-ether interface.

```
Router#show running-config interface PW-Ether 100.102
Thu Feb  3 11:33:58.450 IST
interface PW-Ether100.102
 ipv4 unnumbered Loopback100
 ipv6 enable
 load-interval 30
 ipsubscriber
  ipv4 l2-connected
   initiator dhcp
  !
  ipv6 l2-connected
   initiator dhcp
  !
 !
 pppoe enable
```

```
 encapsulation ambiguous dot1q any second-dot1q 102
!
```

Configure DHCPv4 on PWHE interface:

```
Router#show run dhcp ipv4
Thu Feb  3 11:55:01.903 IST
dhcp ipv4
 profile cn4 cnbng
 !
 interface PW-Ether100.102 cnbng profile cn4
 interface PW-Ether100.103 cnbng profile cn4
 interface PW-Ether100.104 cnbng profile cn4
!
```

Configure DHCPv6 on PWHE interface:

```
Router#show run dhcp ipv6
Thu Feb  3 11:55:07.906 IST
dhcp ipv6
 profile cn6 cnbng
 !
 interface PW-Ether100.102 cnbng profile cn6
 interface PW-Ether100.103 cnbng profile cn6
!
```

Verify cnBNG User Plane Configuration

This section describes the show commands to be executed on the router to verify cloud native BNG user plane configuration.

For details on cnBNG commands, see the *Cloud Native BNG Command Reference for Cisco ASR 9000 Series Routers*.

Verify cnBNG NAL Process Information

You can use the following commands to verify the NAL process information on cnBNG user plane.

-
```
Router#show cnbng-nal process-info location 0/RSP0/CPU0
Mon Aug  3 00:12:42.080 UTC

Location: 0/RSP0/CPU0

 HA Pre_Init Role          : PRIMARY
 HA Role                   : PRIMARY
 Restart-flag              : FALSE
 card_type                 : 0
 Node-Id                   : 0
 Disc-Hist File-logging    : FALSE
 Test-server config-enabled: FALSE

 Proc-flags     : 8000FFBF

    OT Connection Status: UP
    IM Connection Status: UP
```

```
    IPv4 RIB Connection Status: UP
    IPv6 RIB Connection Status: UP
    SUBDB Connection Status: UP
```

- ```
  Router#show cnbng-nal process-readiness
  Mon Aug  3 00:12:00.778 UTC

  Location: 0/RSP1/CPU0

  NAL resync pending flags:
          Service Resync Pending
          Interface Resync Pending
          IPv4 Route Resync Pending
          IPv6 Route Resync Pending

  SIR status: not ready

  Location: 0/RSP0/CPU0
  NAL resync pending flags:
          NONE

  SIR status: ready
  ```

- ```
  Router#show processes cnbng_nal
  Fri Sep 11 09:22:45.139 UTC
                   Job Id: 456
                      PID: 1543

  Router#show processes memory 1543
  Fri Sep 11 09:24:12.398 UTC
  JID      Text(KB)   Data(KB)  Stack(KB) Dynamic(KB) Process
  ------ ---------- ---------- ---------- ----------- ------------------------------
  456           992    1700604        200       19999 cnbng_nal
  ```

Verify Control Plane Connection Status

You can use the following command to verify the connection status of cnBNG control plane.

- ```
  Router#show cnbng-nal cp connection status
  Fri Feb 19 11:27:31.178 UTC

  Location: 0/RSP0/CPU0


  User-Plane configurations:
  --------------------------
  IP             : 10.105.227.96
   GTP Port       : 2152
  PFCP Port      : 8805
  VRF            : default


  Control-Plane configurations:
  -----------------------------
  PRIMARY IP     : 10.84.102.235
   GTP Port       : 2152
  ```
  ```

```
PFCP Port      : 8805

 Association retry count: 10

Connection Status: Up
Connection Status time stamp: Thu Feb 11 12:46:19 2021

Connection Prev Status : Down
Connection Prev Status time stamp: Thu Feb 11 12:44:55 2021

Association status: Active
Association status time stamp: Thu Feb 11 12:46:18 2021
```

Verify Subscriber Information

You can use the following commands to verify subscriber information on the cnBNG user plane.

-

```
Router#show cnbng-nal subscriber access-interface bundle-Ether 1.1
Mon Aug  3 00:04:42.558 UTC
=====================
Location: 0/RSP0/CPU0
=====================

               Type            PPPoE           IPoE
               ====            =====           ====

Session Counts by State:
        initializing            0               0
          connecting            0               0
           connected            0               0
           activated            0               8000
                idle            0               0
       disconnecting            0               0
               Total:           0               8000


Session Counts by Address-Family:
               none             0               0
               ipv4             0               0
               ipv6             0               8000
               dual             0               0
              Total:            0               8000


=====================
Location: 0/RSP1/CPU0
=====================

               Type            PPPoE           IPoE
               ====            =====           ====

Session Counts by State:
        initializing            0               0
          connecting            0               0
           connected            0               0
           activated            0               8000
                idle            0               0
       disconnecting            0               0
               Total:           0               8000
```

```
Session Counts by Address-Family:
               none            0               0
               ipv4            0               0
               ipv6            0               8000
               dual            0               0
             Total:            0               8000
```

-

```
Router#show cnbng-nal subscriber all
Fri Sep 11 06:07:52.343 UTC
   Codes: CN - Connecting, CD - Connected, AC - Activated,

        ID - Idle, DN - Disconnecting, IN - Initializing



CPID(hex)Interface            State Mac Address    Subscriber IP Addr / Prefix (Vrf)
Ifhandle
-------------------------------------------------------------------------------------------

1005ca0  BE2.500.ip2149474448 AC    0010.942e.3b00 13.0.92.160 (default) 0x225e60

                                                   1:4::5c9f (IANA)

                                                   2003:db0:0:5c9e::/64 (IAPD)

10053b2  BE2.500.ip2149466000 AC    0010.942e.3689 13.0.83.175 (default) 0xfdfe0

                                                   1:4::53b1 (IANA)

                                                   2003:db0:0:53b0::/64 (IAPD)

1004c81  BE2.600.ip2149013936 AC    0010.942e.5230 13.0.76.129 (default) 0x4079a0

                                                   1:4::4c80 (IANA)

                                                   2003:db0:0:4c7f::/64 (IAPD)

1004aaa  BE2.500.ip2149353232 AC    0010.942e.3205 13.0.74.169 (default) 0x5192e0

                                                   1:4::4aa9 (IANA)

                                                   2003:db0:0:4aa8::/64 (IAPD)

1004927  BE2.600.ip2149518576 AC    0010.942e.50b1 13.0.73.116 (default) 0x219ba0

                                                   1:4::4926 (IANA)

                                                   2003:db0:0:4925::/64 (IAPD)

10047e4  BE2.800.ip2149422928 AC    0010.9431.a7c7 13.0.71.228 (default) 0x41ff60

                                                   1:4::47e4 (IANA)

                                                   2003:db0:0:47e2::/64 (IAPD)

1004777  BE2.600.ip2149520224 AC    0010.942e.5021 13.0.71.115 (default) 0x41420

                                                   1:4::4776 (IANA)
```

```
                                                    2003:db0:0:4775::/64 (IAPD)
1003a6d  BE2.800.ip2149369728 AC    0010.9431.a3a1 13.0.58.105 (default) 0x141360
                                                    1:4::3a6d (IANA)
                                                    2003:db0:0:3a6a::/64 (IAPD)
10038b7  BE2.600.ip2149362240 AC    0010.942e.4bb2 13.0.56.178 (default) 0x259aa0
                                                    1:4::38b6 (IANA)
                                                    2003:db0:0:38b5::/64 (IAPD)
10028ba  BE2.500.ip2149210768 AC    0010.942e.2873 13.0.40.185 (default) 0x129620
                                                    1:4::28b9 (IANA)
                                                    2003:db0:0:28b8::/64 (IAPD)
100247b  BE2.600.ip2149396320 AC    0010.942e.46a3 13.0.36.113 (default) 0x4b8e0
                                                    1:4::2471 (IANA)
                                                    2003:db0:0:2470::/64 (IAPD)
100207a  BE2.500.ip2149356496 AC    0010.942e.2663 13.0.32.117 (default) 0x1a9460
                                                    1:4::2079 (IANA)
                                                    2003:db0:0:2078::/64 (IAPD)
1001d3f  BE2.600.ip2149251360 AC    0010.942e.44d4 13.0.29.61 (default) 0xcc760
```

-
```
Router#show cnbng-nal subscriber all summary
Sun Aug  2 16:26:44.281 UTC
=====================
Location: 0/RSP0/CPU0
=====================

               Type            PPPoE           IPoE
               ====            =====           ====

Session Counts by State:
        initializing           0               0
          connecting           0               0
           connected           0               0
           activated           0               130
                idle           0               0
       disconnecting           0               0
               Total:          0               130

Session Counts by Address-Family:
               none            0               0
               ipv4            0               130
               ipv6            0               0
               dual            0               0
              Total:           0               130

=====================
```

```
Location: 0/RSP0/CPU0

====================


                Type         PPPoE       IPoE

                ====         =====       ====


Session Counts by State:

        initializing         0           0

          connecting         0           0

           connected         226         0

           activated         31774       0

                idle         0           0

       disconnecting         0           0

              Total:         32000       0


Session Counts by Address-Family:

                none         226         0

                ipv4         7774        0

                ipv6         0           0

                dual         24000       0

              Total:         32000       0
```

-
```
Router#show cnbng-nal subscriber all detail
Mon Aug  3 00:00:14.624 UTC
Location: 0/2/CPU0
====================
Location: 0/RSP1/CPU0
====================
Interface:                Bundle-Ether1.1.ip2148413040
UPID:                     0x800e2e70
CPID:                     0x0100918f
PPPOE Session Id:         0x0000
Type:                     IPoE
IPv4 Address:             0.0.0.0
IPv4 Framed Route:
  Prefix:                 0.0.0.0/0
  Next Hop:               0.0.0.0
  Tag:                    0
IPv6 IANA Address:        1:5::345c
IPv6 IAPD Prefix:         2004:cd0:0:188d::/64
CPE link local Address:   ::
```

```
IPv6 Framed Route:
  Prefix:                  ::/0
  Next Hop:                ::
  Tag:                     0
IPv6 State:                UP, Sat Jul 25 02:09:55 2020
Mac Address:               5065.aaab.d864
Inner VLAN ID:             Not Set
Outer VLAN ID:             100
Outer VLAN Cos:            0
Outer VLAN DEI:            1
Created:                   Sat Jul 25 02:09:54 2020
State:                     Activated
Ifhandle:                  0x000b75a0
VRF:                       default
Access-interface:          Bundle-Ether1.1
 Attribute List: 0x5556aed3f878
1:  ipv6-enable     len=  4  value= 1(1)
2:  ipv4-unnumbered len=  9  value= Loopback1
3:  strict-rpf      len=  4  value= 1(1)
4:  ipv6-strict-rpf len=  4  value= 1(1)
5:  ipv4-icmp-unreachable len=  4  value= 1(1)
6:  ipv6-unreachable len=  4  value= 1(1)
7:  ipv4-mtu        len=  4  value= 1500(5dc)
8:  ipv6-mtu        len=  4  value= 1500(5dc)
Session Accounting:        enabled
Interim Interval:          1800 secs
Last interim timestamp:    Sun Aug  2 23:39:46 2020
Interim fail count: None
Last interim failed reason: NA
Last stats:
  BytesIn: 0
  BytesOut: 384570
  BytesInGiga: 0
  BytesOutGiga: 0
Feature IDs activated :
  0x800e2e71
  0x800e2e72
```

-

```
Router#show cnbng-nal subscriber type ipoe summary
Mon Aug  3 00:06:15.032 UTC
=====================
Location: 0/RSP0/CPU0
=====================

               Type            PPPoE           IPoE
               ====            =====           ====

Session Counts by State:
        initializing           0               0
          connecting           0               0
           connected           0               0
           activated           0               8000
                idle           0               0
       disconnecting           0               0
              Total:           0               8000

Session Counts by Address-Family:
               none            0               0
               ipv4            0               0
               ipv6            0               8000
               dual            0               0
              Total:           0               8000
```

```
======================
Location: 0/RSP1/CPU0
======================

                Type            PPPoE           IPoE
                ====            =====           ====

Session Counts by State:
        initializing            0               0
          connecting            0               0
           connected            0               0
           activated            0               8000
                idle            0               0
       disconnecting            0               0
              Total:            0               8000

Session Counts by Address-Family:
                none            0               0
                ipv4            0               0
                ipv6            0               8000
                dual            0               0
              Total:            0               8000

Router#
```

-
```
Router#show cnbng-nal subscriber type pppoe summary
Mon Aug  3 00:06:15.032 UTC
======================
Location: 0/RSP0/CPU0
======================

                Type            PPPoE           IPoE
                ====            =====           ====

Session Counts by State:
        initializing            0               0
          connecting            0               0
           connected            0               0
           activated            31031           0
                idle            0               0
       disconnecting            0               0
              Total:            31031           0

Session Counts by Address-Family:
                none            0               0
                ipv4            31031           0
                ipv6            0               0
                dual            0               0
              Total:            31031           0

Router#
```

-
```
Router#show cnbng-nal subscriber disconnect-history unique
Mon Aug  3 00:07:22.716 UTC

Location: 0/RSP1/CPU0

| Count|       Last Interface        | Disconnected Reason |            Last Time
                                                                        Disconnected

 Location: 0/1/CPU0
 Location: 0/RSP0/CPU0
```

```
| Count|       Last Interface        | Disconnected Reason |            Last Time
                                                                        Disconnected
35494    Bundle-Ether1.1.ip2148328848  Disconnect by CP                 Sat Jul 25
                                                                        02:04:55 2020

14154    Bundle-Ether1.1.ip2148324096  Disconnect by clear CLI          Sat Jul 25
                                                                        02:05:48 2020

 2777    Bundle-Ether1.1.ip2148194512  Disconnect due to create failure Sat Jul 25
                                                                        01:38:29 2020
```

-

```
Router#show cnbng-nal subscriber disconnect-history last location
Mon Aug  3 00:08:42.655 UTC

Disconnect-reason:         Disconnect by clear CLI
Disconnect-timestamp:      Sat Jul 25 02:05:48 2020
  Message Txn ID: 55663
  Session Txn ID: 1
  Failed at: Sat Jul 25 01:57:03 2020
  Feature Mask: 0x0
  SVM State: 0
  IPSUB flags: 0x600a200
  Pending callback: 0x2
  Data:

Interface:                 Bundle-Ether1.1.ip2148324096
UPID:                      0x800cd300
CPID:                      0x01007bd8
PPPOE Session Id:          0x0000
Type:                      IPoE
IPv4 Address:              0.0.0.0
IPv4 Framed Route:
  Prefix:                  0.0.0.0/0
  Next Hop:                0.0.0.0
  Tag:                     0
IPv6 IANA Address:         1:5::3de5
IPv6 IAPD Prefix:          2004:cd0:0:616::/64
CPE link local Address:    ::
IPv6 Framed Route:
  Prefix:                  ::/0
  Next Hop:                ::
  Tag:                     0
IPv6 State:                UP, Sat Jul 25 01:57:03 2020
Mac Address:               5065.aaab.cfbb
Inner VLAN ID:             Not Set
Outer VLAN ID:             100
Outer VLAN Cos:            0
Outer VLAN DEI:            1
Created:                   Sat Jul 25 02:05:48 2020
State:                     Init
Ifhandle:                  0x000323a0
VRF:                       default
Access-interface:          Bundle-Ether1.1
 Attribute List: 0x559125764408
1:  ipv6-enable     len=  4  value= 1(1)
2:  ipv4-unnumbered len=  9  value= Loopback1
3:  strict-rpf      len=  4  value= 1(1)
4:  ipv6-strict-rpf len=  4  value= 1(1)
5:  ipv4-icmp-unreachable len=  4  value= 1(1)
6:  ipv6-unreachable len=  4  value= 1(1)
7:  ipv4-mtu        len=  4  value= 1500(5dc)
8:  ipv6-mtu        len=  4  value= 1500(5dc)
```

```
Session Accounting:        enabled
Interim Interval:          1800 secs
Last interim timestamp:    Sat Jul 25 02:05:47 2020
Interim fail count: None
Last interim failed reason: NA
Last stats:
  BytesIn: 0
  BytesOut: 540
  BytesInGiga: 0
  BytesOutGiga: 0
Feature IDs activated :
  0x800cd301
  0x800cd302

[Event History]
UPID:  0x800cd300

| Event Name               | Time Stamp             | S, M
| Create                   | Jul 25 01:57:02.999679 | 0, 0
| New Session Request      | Jul 25 01:57:02.999686 | 0, 0
| Interface create         | Jul 25 01:57:02.999823 | 0, 0
| SVM create               | Jul 25 01:57:03.018268 | 0, 0
| UP Install(req)          | Jul 25 01:57:03.018321 | 0, 0
| UP Install(CB)           | Jul 25 01:57:03.019220 | 0, 0
| Last Assoc(req)          | Jul 25 01:57:03.019232 | 0, 0
| Last Assoc(CB)           | Jul 25 01:57:03.020160 | 0, 1
| Produce done(req)        | Jul 25 01:57:03.020233 | 0, 0
| IPv4 Caps Up             | Jul 25 01:57:03.188034 | 0, 0
| IPv6 Caps Up             | Jul 25 01:57:03.233210 | 0, 0
| Init data req            | Jul 25 01:57:03.254482 | 0, 1
| Init data cb             | Jul 25 01:57:03.369027 | 0, 1
| Client Session up        | Jul 25 01:57:03.379152 | 0, 0
| Produce done             | Jul 25 01:57:03.977629 | 0, 0
| IPv6 Up                  | Jul 25 01:57:03.977643 | 0, 0
| Session up notified      | Jul 25 01:57:03.977650 | 0, 0
| Stats start              | Jul 25 01:57:03.977841 | 0, 0
| Disconnect notified      | Jul 25 02:05:47.548202 | 0, 0
| Disconnect ack           | Jul 25 02:05:47.550293 | 0, 0
| IPv4 Caps Down           | Jul 25 02:05:47.652232 | 0, 0
| IPv6 Caps Down           | Jul 25 02:05:47.652333 | 0, 0
| Final stats              | Jul 25 02:05:47.753805 | 0, 0
| SVM delete               | Jul 25 02:05:47.780713 | 0, 0
| SVM cleanup              | Jul 25 02:05:48.283050 | 0, 0
Help: S - Sticky Event, M - Multiple Occurrence
```

-

```
Router#show cnbng-nal subscriber fadb
Mon Aug  3 00:03:12.858 UTC

Location: 0/RSP1/CPU0
==================

UPID:       0x800ec810
Service-ID: 0x04000003  Service-Name: JHV_VOICE
Feature-ID: 0x800ec812
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 805306413(3000002d)
Accounting:                enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
```

```
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:       0x800e9470
Service-ID: 0x04000003  Service-Name: JHV_VOICE
Feature-ID: 0x800e9472
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 805306413(3000002d)
Accounting:               enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:       0x800e7ee0
Service-ID: 0x04000003  Service-Name: JHV_VOICE
Feature-ID: 0x800e7ee2
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 805306413(3000002d)
Accounting:               enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:       0x800e16e0
Service-ID: 0x04000004  Service-Name: LIVE_TV
Feature-ID: 0x800e16e1
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 0(0)
Accounting:               disabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:       0x800dda90
Service-ID: 0x04000003  Service-Name: JHV_VOICE
Feature-ID: 0x800dda91
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 805306413(3000002d)
Accounting:               enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:       0x800dd4e0
Service-ID: 0x04000004  Service-Name: LIVE_TV
Feature-ID: 0x800dd4e1
 Attribute List: 0x559cba6d0008
1:  feature-acct-bitmask len=  4  value= 0(0)
```

```
Accounting:                disabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0
```

Verify cnBNG NAL Counters

You can use the following commands to verify various NAL counters on the cnBNG user plane:

-

```
Router#show cnbng-nal counters type all
Sun Aug  2 20:42:49.548 UTC

Location: 0/RSP0/CPU0

Subscriber Counters
-------------------

Counter name                      Value
============                      =====
INTF Delete                       500
IPv4 caps down                    500
IPv6 caps down                    500
IPv4 Rou del                      500
IPv6 Rou del                      500
Blkdis q empty                    1
DB cache hit                      17113

Error Counters
--------------

Counter name                      Value
============                      =====

Accounting Counters
-------------------

Counter name                      Value
============                      =====
Sess Stop req                     500
Feat Stop req                     500
Stop req                          3000
Stop cb                           3000
Final cb                          3000
Feat Final cb                     500
Sess Final cb                     2500

SVM Counters
------------

Counter name                      Value
============                      =====
Sess deleted                      500
Delete CB                         500
Feat deleted                      1000
Cleanup                           500
Sess stats, before svm            500
```

```
Feat stats, before svm             500

SPA Counters
------------

Counter name                       Value
=============                      =====
SPA Delete Req                     500
SPA Update Req                     500
Sub Delete Res                     500
Sub Update Res                     500
Blkdic adm more                    39
GTPu pkt sent                      1000
PFCP pkt sent                      1463
GTPu pkt punt                      500
PFCP pkt punt                      1463
DHCPv4 pkt punt                    500
DHCPv6 pkt punt                    500
DHCPv6 pkt inj                     500
Alloc count                        3463
Free count                         3463
Mutex lock                         6741
Mutex unlock                       6741
Timer start                        463
Timer expiry                       463
Sub Update IPOE OK                 500
Sub Delete IPOE OK                 500

CP Recon Counters
-----------------

Counter name                       Value
=============                      =====

Histogram/API Performance Stats
-------------------------------

API name       1ms       10ms  100ms  1s  5s  10s  20s  50s  100s
========       ===       ====  =====  ==  ==  ===  ===  ===  ====
Per trans      410       90    0      500 0   0    0    0    0
Sub Create     0         0     0      0   0   0    0    0    0
Sub Update     445       55    0      0   0   0    0    0    0
Sub Delete     0         0     0      500 0   0    0    0    0
IPOE Int Crt   0         0     0      0   0   0    0    0    0
IPOE Int Upd   0         0     0      0   0   0    0    0    0
IPOE Int Del   0         0     0      500 0   0    0    0    0
PPPOE Int Crt  0         0     0      0   0   0    0    0    0
PPPOE Int Upd  0         0     0      0   0   0    0    0    0
PPPOE Int Del  0         0     0      0   0   0    0    0    0
Sess Create    0         0     0      0   0   0    0    0    0
Sess Update    0         0     0      0   0   0    0    0    0
Sess Delete    0         0     10     490 0   0    0    0    0
V4 RT Inst     0         0     0      0   0   0    0    0    0
V4 RT Del      0         6     320    174 0   0    0    0    0
V4 FR Inst     0         0     0      0   0   0    0    0    0
V4 FR Del      0         0     0      0   0   0    0    0    0
V6 RT Inst     0         0     0      0   0   0    0    0    0
V6 RT Del      0         6     310    184 0   0    0    0    0
V6 PD RT Inst  0         0     0      0   0   0    0    0    0
V6 PD RT Del   0         0     0      0   0   0    0    0    0
V6 FR Inst     0         0     0      0   0   0    0    0    0
V6 FR Del      0         0     0      0   0   0    0    0    0
CDM Lookup     0         0     0      0   0   0    0    0    0
CDM Insert     0         0     0      0   0   0    0    0    0
```

```
CDM Update     1469      31    0      0   0   0    0    0    0
Eval Lookup    0         0     0      0   0   0    0    0    0
```

-
```
Router#show cnbng-nal counters type all | beg SPA LIB
Sun Aug  2 20:44:07.902 UTC
SPA LIB Counters
----------------

Counter name                        Value
=============                       =====
pfcp_rx_counter                     6899
pfcp_tx_counter                     6900
gtpu_tx_counter                     9048
gtpu_rx_counter                     7510
pfcp_keepalive_tx_counter           891
pfcp_keepalive_rx_counter           890

SPA API counters
-----------------------
```

-
```
Router#show cnbng-nal counters type spa
Sun Aug  2 20:42:13.703 UTC

Location: 0/RSP0/CPU0

SPA Counters
------------

Counter name                        Value
=============                       =====
SPA Delete Req                      500
SPA Update Req                      500
Sub Delete Res                      500
Sub Update Res                      500
Blkdic adm more                     39
GTPu pkt sent                       1000
PFCP pkt sent                       1461
GTPu pkt punt                       500
PFCP pkt punt                       1461
DHCPv4 pkt punt                     500
DHCPv6 pkt punt                     500
DHCPv6 pkt inj                      500
Alloc count                         3461
Free count                          3461
Mutex lock                          6727
Mutex unlock                        6727
Timer start                         461
Timer expiry                        461
Sub Update IPOE OK                  500
Sub Delete IPOE OK                  500
```



CHAPTER 7

Subscriber Management

This chapter provides information about various types of subscriber sessions, namely IPoE and PPPoE, and IP addressing by DHCP. Also, on how the point-point frames are tunnelled across the network using the Layer 2 Tunneling Protocol.

- Subscriber Session Overview, on page 57
- IPoE Session, on page 57
- PPP over Ethernet (PPPoE), on page 59
- RADIUS-Based Policing - QoS shape-rate parameterization, on page 68
- Shared Policy Instance, on page 72

Subscriber Session Overview

To enable subscribers to access the network resources, the network has to establish a session with the subscriber. A subscriber session represents the logical connection between the customer premise equipment (CPE) and the network resource. Each session establishment comprises the following phases:

- Establishing a connection—in this phase CPE finds the cnBNG with which to communicate.
- Authenticating and authorizing the subscriber—in this phase, cnBNG authenticates the subscribers and authorizes them to use the network. This phase is performed with the help of the RADIUS server.
- Giving the subscriber an identity—in this phase, the subscriber is assigned an identity, the IP address.
- Monitoring the session—in this phase, cnBNG ascertains that the session is up and running.

The subscriber sessions are established over the subscriber interfaces, which are virtual interfaces. It's possible to create only one interface for each subscriber session. A port can contain multiple VLANs, each of which can support multiple subscribers. cnBNG creates subscriber interfaces for each kind of session. These interfaces are named based on the parent interface, such as bundle-ether 2.100.pppoe312. The subscribers on bundle interfaces (or bundle-VLANs) allow redundancy and are managed on the cnBNG route processor (RP).

There are two mechanisms to establish a subscriber session, namely, IPoE and PPPoE.

IPoE Session

In an Internet over Ethernet (IPoE) subscriber session, subscribers run IPv4 or IPv6 on the CPE device and connect to the cnBNG through a Layer-2 aggregation. IP subscriber sessions that connect through a Layer-2

aggregation network are called L2-connected. IPoE subscriber sessions are always terminated on cnBNG and then routed into the service provider network. IPoE relies on DHCP to assign the IP address.

Figure 8: IPoE Session



cnBNG supports both DHCP v4 and DHCP v6 subscriber sessions.

Limitations

The following are the limitations:

- L3 routed subscribers are not supported.
- Geo redundancy or subscriber redundancy is not supported.
- Line card or physical port termination-based subscribers are not supported.

Configuration Example

```
Router#configure
Router(config)#interface Bundle-Ether1.1
Router(config-subif)#ipv4 point-to-point
Router(config-subif)#ipv4 unnumbered Loopback1
Router(config-subif)#ipv6 enable
Router(config-subif)#encapsulation dot1q 1
Router(config-subif)#ipsubscriber
Router(config-cnbng-nal-ipsub)#ipv4 l2-connected
Router(config-cnbng-nal-ipsub-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-l2conn)#exit
Router(config-cnbng-nal-ipsub)#ipv6 l2-connected
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#commit
```

Running Configuration

```
Router#show running-config interface be1.1
interface Bundle-Ether1.1
 ipv4 point-to-point
 ipv4 unnumbered Loopback1
 ipv6 enable
 encapsulation dot1q 1
 ipsubscriber
  ipv4 l2-connected
   initiator dhcp
  !
  ipv6 l2-connected
   initiator dhcp
```

!
!

PPP over Ethernet (PPPoE)

The Point-to-Point Protocol (PPP) is used for communications between two nodes, like a client and a server. The PPP provides a standard method for transporting multiprotocol datagrams over point-to-point links. It defines an encapsulation scheme, a link layer control protocol (LCP), and a set of network control protocols (NCPs) for different network protocols that can be transmitted over the PPP link.

One of the methods to establish PPP connection is by the use of PPPoE. In a PPPoE session, the PPP protocol runs between the CPE and cnBNG. The Home Gateway (which is part of the CPE) adds a PPP header (encapsulation) that is terminated at the cnBNG.

PPPoE Discovery

The PPPoE discovery-stage protocol consists of basic packet exchange between the subscriber and server (cnBNG). The following is the list of the various PPPoE Active Discovery (PAD) messages:

- PPPoE Active Discovery Initiation (PADI)—The CPE broadcasts to initiate the process to discover cnBNG.
- PPPoE Active Discovery Offer (PADO)—The cnBNG responds with an offer.
- PPPoE Active Discovery Request (PADR)—The CPE requests to establish a connection.
- PPPoE Active Discovery Session confirmation (PADS)—cnBNG accepts the request and responds by assigning a session identifier (Session-ID).
- PPPoE Active Discovery Termination (PADT)—Either CPE or cnBNG terminates the session.

PPoE Sessions

The PPPoE sessions are of the following types:

- PPPoE PPP Terminated sessions Terminated (PTA)
- PPPoE L2TP Access Concentrator Sessions (LAC)
- L2TP Network Server Sessions (LNS)

Majority of the digital subscriber line (DSL) broadband deployments use Point-to-Point Protocol over Ethernet (PPPoE) sessions to provide subscriber services. These sessions terminate the Point-to-Point Protocol (PPP) link and provide all the features, service, and billing on the same node. These sessions are called PPP Terminated (PTA) sessions. See PPPoE PPP Terminated and Aggregation Sessions (PPPoE-PTA), on page 60.

There are some wireline subscriber deployments in the wholesale retail model where ISPs work with others to provide the access and core services separately. In such cases, the subscribers are tunneled between wholesale and retail ISPs using the Layer 2 Tunneling Protocol (L2TP), a client-server protocol. See L2TP Access Concentrator Sessions (LAC), on page 61 and L2TP Network Server Sessions (LNS), on page 65.

Note For the functioning of PPP PTA and PPP LAC session, the RADIUS server must be set up to authenticate and forward sessions as necessary. There's no local authentication available on cnBNG.

PPPoE PPP Terminated and Aggregation Sessions (PPPoE-PTA)

In a PPPoE-PPP Termination and Aggregation (PTA) session, the PPP encapsulation is terminated on cnBNG. After it's terminated, cNBNG routes the traffic to the service provider using IP routing. A typical PTA session is depicted in this figure.

Figure 9: PPPoE-PTA Session



PPPoE session configuration information is contained in PPPoE profiles. After a profile is defined, it's assigned to an access interface. Multiple PPPoE profiles can be created and assigned to multiple interfaces. A global PPPoE profile can also be created; the global profile serves as the default profile for any interface that has not been assigned a specific PPPoE profile.

The PPP PTA session is typically used in the Network Service Provider (retail) model where the same service operator provides the broadband connection to the subscriber and also manages the network services.

Limitations

The following are the limitations:

- L3 routed subscribers are not supported.
- Geo redundancy or subscriber redundancy is not supported.
- Line card or physical port termination-based subscribers aren't supported.

Configure PPPoE-PTA Session

The following section describes the steps to configure PPPoE-PTA sessions:

- Configure the access-interface
- Enable PPPoE

Configuration Example

```
Router#configure
Router(config)#interface Bundle-Ether1.1
Router(config-subif)#ipv4 point-to-point
Router(config-subif)#ipv4 unnumbered Loopback1
Router(config-subif)#ipv6 enable
Router(config-subif)#encapsulation dot1q 1

/* Enable PPPoE */
```

```
Router(config-subif)#pppoe enable
Router(config-subif)#commit
```

Running Configuration

```
Router#show running-config interface be1.1
interface Bundle-Ether1.1
 ipv4 point-to-point
 ipv4 unnumbered Loopback1
 ipv6 enable
 encapsulation dot1q 1

 pppoe enable
!
```

L2TP Access Concentrator Sessions (LAC)

Table 6: Feature History Table

Feature Name	Release Information	Feature Description
Enable LAC on Cloud Native BNG	Release 7.4.2	This feature enables the cloud native BNG user plane to become an L2TP access concentrator (LAC), allowing you to tunnel point-to-point frames between the remote system or LAC client and an LNS located at a wholesaler. This functionality provides highly flexible deployments options to suit different customer use-cases and needs. To enable this feature, use the **l2tp enable** command.

L2TP encapsulates and tunnels the PPP Layer 2 frames through a Layer 3 network. With L2TP, you can have a layer 2 connection to an access concentrator. The concentrator then tunnels individual PPP frames to the Network Access Server (NAS). This allows the processing of PPP packets on different devices. L2TP can be used to make all multilink channels terminate at a single NAS. Thus-allowing multilink operation even when the calls are spread across distinct physical NASs.

In cnBNG, L2TP uses the following two components to perform the hand-off task of the subscriber traffic to the Internet service provider (ISP).

- L2TP Access Concentrator (LAC)—The L2TP enables subscribers to dial into the LAC, which extends the PPP session to the LNS. cnBNG provides LAC.
- L2TP Network Server (LNS)—The L2TP extends PPP sessions over an arbitrary network to a remote network server that is, the LNS. The ISP provides LNS.

The following image depicts the overall topology of LAC and LNS:

Figure 10: Topology of LAC and LNS



The remote user initiates a PPP connection across the cloud to a LAC. The LAC acts as a client and then tunnels the PPP connection across the Internet to an LNS that acts as a server.

L2TP utilizes two types of messages, control messages and data messages. Control messages are used in the establishment, maintenance, and clearing of tunnels and calls. Data messages are used to encapsulate PPP frames over the tunnel.

```
+--------------------+
| PPP Frames         |
+--------------------+    +-----------------------+
| L2TP Data Messages|    | L2TP Control Messages |
+--------------------+    +-----------------------+
| L2TP Data Channel |    | L2TP Control Channel  |
| (unreliable)      |    | (reliable)            |
+-------------------------------------------------+
|      Packet Transport (UDP, FR, ATM)     |
+-------------------------------------------------+
```

PPP frames are passed over an unreliable data channel that is encapsulated first by an L2TP header. Then a Packet Transport such as UDP. Control messages are sent over a reliable L2TP Control Channel, which transmits packets in-band over the same Packet Transport.

During a PPP LAC session, the PPPoE encapsulation terminates on cnBNG; however, the PPP packets travel beyond cnBNG to LNS through the L2TP tunnel. A typical LAC session is depicted in the following figure.

Figure 11: LAC Session



Both LAC and LNS sessions use L2TP protocol for negotiation and creation of L2TP sessions.

For more information on the LAC high-level work flow, see the *L2TP Subscriber Management* chapter in the *Cloud Native BNG Control Plane Configuration Guide*.

The PPP LAC session is used in the wholesaler model, where the network service provider is a separate entity from the local access network provider. In this kind of setup, the access network provider owns the LAC and the network service provider owns the LNS.

- Network service provider performs access authentication, manage and provide IP addresses to subscribers, and are responsible for overall service.
- The access network prover is responsible for providing the last-mile digital connectivity to the customer, and for passing on the subscriber traffic to the service provider.

Limitations for LAC Sessions

The following are the limitations for the LAC sessions:

- Tunnel specific statistics are not supported.
- LAC and LNS cannot coexist on the same node.
- IPv6 L2TP tunnel is not supported.
- L2TP tunnel keep alive or hello packet offload is not supported.
- Setting of type of service is not supported.
- Multicast group is not supported.
- L2TP packet segmentation or reassemble is not supported.
- The following features aren’t supported:
  - Access Control List (ACL)

- Quality of Service (QoS)
- Policy-based Routing (PBR)
- Unicast Reverse Path Forwarding (uRPF)
- ICMP unreachable

Configure LAC Sessions

This section describes how to configure the LAC session on the cnBNG user plane.

- Enable L2TP
- Establish PPPoE connection

Configuration Example

Enable L2TP:

```
Router#configure
Router(config)#cnbng-nal location 0/1/CPU0

Router(config-cnbng-nal-local)#hostidentifier RTR1

Router(config-cnbng-nal-local)#up-server ipv4 192.0.2.1 gtp-port 15002 pfcp-port 15003
vrf default
Router(config-cnbng-nal-local)#cp-server primary ipv4 198.51.100.1

Router(config-cnbng-nal-local)#enable-test-server

Router(config-cnbng-nal-local)#disconnect-history file-logging-enable

Router(config-cnbng-nal-local)#cp-association retry-count 5

Router(config-cnbng-nal-local)#l2tp enable

Router(config-cnbng-nal-local)#l2tp-tcp-mss-adjust 1400
```

Establish PPPoE connection:

```
Router(config-cnbng-nal-local)#interface Bundle-Ether1.1

Router(config-subif)#ipv4 address 192.11.1.1 255.255.255.0

Router(config-subif)#ipv6 enable

Router(config-subif)#encapsulation dot1q 1

Router(config-subif)#ppoe enable
Router(config-subif)#commit
Router(config-subif)#exit
Router(config)#exit
```

Running Configuration

```
Router#show running-config

cnbng-nal location preconfigure 0/1/CPU0
 l2tp-tcp-mss-adjust 1400
 hostidentifier RTR1
 up-server ipv4 192.0.2.1 gtp-port 15002 pfcp-port 15003 vrf default
 cp-server primary ipv4 198.51.100.1
 disconnect-history file-logging-enable
 cp-association retry-count 5
 l2tp enable
 enable-test-server
!
interface Bundle-Ether1
!
interface Bundle-Ether1.1
 ipv4 address 192.11.1.1 255.255.255.0
 ipv6 enable
 encapsulation dot1q 1
 pppoe enable
!
```

L2TP Network Server Sessions (LNS)

Table 7: Feature History Table

Feature Name	Release Information	Feature Description
Shared policy database (SPD) support on bundle main interfaces	Release 25.3.1	You can now support a larger number of shaper-based subscribers on bundle main interfaces across all Cisco ASR 9000 5th Generation High-Density Ethernet line cards.

Feature Name	Release Information	Feature Description
Enable LNS on Cloud Native BNG	Release 25.2.1	You can now enable the cloud-native BNG (cnBNG) to act as an L2TP Network Server (LNS), allowing the termination of tunnels or subscriber sessions initiated by the LAC client on the following Cisco ASR 9000 5th Generation High-Density Ethernet line cards: • A99-32X100GE-X-SE • A9K-20HG-FLEX-SE • A9K-8HG-FLEX-SE • A9K-4HG-FLEX-SE This feature is also supported on these fixed routers: • Cisco ASR 9902 Router • Cisco ASR 9903 Router
Enable LNS on Cloud Native BNG	Release 7.4.2	This feature enables cloud native BNG (cnBNG) to act as an L2TP Network Server (LNS) located at the wholesaler and allows you to terminate the tunnel or the subscriber sessions initiated by the LAC client. The cnBNG LNS solution offers control and user plane separation (CUPS) and cloud-native advantages for next-generation subscriber services in operator networks where subscribers connect directly to a retailer. To enable this feature, use the **lns enable** command.

L2TP Network Server (LNS) resides at one end of an L2TP tunnel and acts as a peer to the LAC. An LNS acts like an L2TP server that terminates the incoming tunnel from the L2TP LAC. An LNS is the logical termination point of the PPP session that is being tunneled from the client by the LAC.

LNS sessions are similar to PTA sessions in the overall functionality. Instead of the PPPoE protocol, here the First-Sign-Of-Life (FSOL) packets are the L2TP Incoming-Call-Request (ICRQ) messages.

For more information on the LNS high-level workflow, see the *L2TP Subscriber Management* chapter in the *Cloud Native BNG Control Plane Configuration Guide*.

Limitations for LNS Sessions

The following are the limitations for the LNS sessions:

- IPv6 L2TP tunnel is not supported.
- L2TP tunnel keep alive or hello packet offload is not supported.
- Tunnel statistics are not supported.
- Termination on non bundle-ether is not supported (for example, PWHE, physical interface).
- Termination of the VLAN interface is not supported.
- Supports parent interface only and not subinterface.
- L2TP packet segmentation or reassemble is not supported.
- Parent interface SVLAN policy must be different for other interfaces on the chassis.
- The following features are not supported:
  - Unicast Reverse Path Forwarding (uRPF)
  - Lawful Intercept (LI)
- If more than one bundle main interface (for example, BE1 and BE2) is configured with the same resource-id and their bundle members are from the same NP, the maximum number of subscribers that can be supported on that NP is limited to 1,500.

Configure LNS Sessions

This section describes how to configure the LNS session on the cnBNG user plane.

Configuration Example

To enable L2TP:

```
Router#configure
Router(config)#cnbng-nal location 0/0/CPU0
Router(config-cnbng-nal-local)#hostidentifier RTR1
Router(config-cnbng-nal-local)#up-server ipv4 192.0.2.1 gtp-port 15002 pfcp-port 15003
vrf default
Router(config-cnbng-nal-local)#cp-server primary ipv4 198.51.100.1
Router(config-cnbng-nal-local)#enable-test-server
Router(config-cnbng-nal-local)#disconnect-history file-logging-enable
Router(config-cnbng-nal-local)#cp-association retry-count 5
Router(config-cnbng-nal-local)#l2tp enable << Enble L2TP
Router(config-cnbng-nal-local)#commit
Router(config-cnbng-nal-local)#exit
Router(config)#
```

To establish the LNS session:

```
Router(config)#interface bundle-ether 1.1
Router(config-subif)#service-policy output SVLAN subscriber-parent subscriber-group
resourceid 4 << To allow maximum capacicty on the linecard
Router(config-subif)#ipv4 address 192.5.1.1 255.255.255.0
```

```
Router(config-subif)#ipv6 enable
Router(config-subif)#lns enable << Establish LNS session
Router(config-subif)#commit
Router(config-subif)#exit
```

Note To allow maximum capacity on the linecard, we recommend you to use the **service-policy output SVLAN subscriber-parent subscriber-group resourceid** command in the main interface.

Running Configuration

```
Router#show running-config

cnbng-nal location preconfigure 0/0/CPU0
 hostidentifier RTR1
 up-server ipv4 192.0.2.1 gtp-port 15002 pfcp-port 15003 vrf default
 cp-server primary ipv4 198.51.100.1
 disconnect-history file-logging-enable
 cp-association retry-count 5
 l2tp enable
 enable-test-server
!
interface Bundle-Ether1.1
 service-policy output SVLAN subscriber-parent subscriber-group resourceid 4
 ipv4 address 192.11.1.1 255.255.255.0
 ipv6 enable
 lns enable
!
```

RADIUS-Based Policing - QoS shape-rate parameterization

RADIUS-Based Policing (RaBaPol) is a network management method that allows the activation of cnBNG subscriber services using customized parameters rather than default settings.

Table 8: Feature history

Feature Name	Release Information	Description
RADIUS-Based Policing - QoS shape-rate parameterization	Release 25.2.1	You can now dynamically manage your cnBNG subscriber services through RADIUS-based activation. With RADIUS-Based Policing (RaBaPol), you can customize service parameters, such as the QoS shape-rate, according to your requirements, giving you greater control over service management.

Parameterization of QoS shape-rate

RaBaPol supports the customization of the QoS shape-rate parameter. This parameter can be sent to the cnBNG Control Plane (CP) by the RADIUS server either during the initial connection setup as Cisco VSAs in an Access Accept message, or through Change of Authorization (CoA) messages.

Handling service changes and errors

If a service associated with a subscriber needs a change in the variable list, deactivate the current service using CoA Session-Disconnect and activate the updated service using CoA Session-Activate process. If an error occurs during feature activation, the cnBNG UP reverts all features and associated variable lists to their previous states.

Benefits of RADIUS-Based Policing

The RADIUS-Based Policing feature provides these benefits.

- **Dynamic activation**: Enables dynamic and flexible service activation based on RADIUS messages.
- **QoS customization**: Allows for the customization of QoS parameters to meet specific subscriber needs.
- **Policy merging**: Supports the merging of QoS policies from multiple dynamic templates for a subscriber.
- **Error rollback**: Provides rollback capabilities to previous states in case of errors during service activation.

Use case for QoS-based service activation

This use case illustrates how to manage and customize network QoS settings when a subscriber starts a session.

1. **Subscriber session initiation**: A user starts a session with specific credentials and settings, such as a username, password, and protocol type. For example,

```
user-cpe@abc.com         Password="abc"
            Framed-Protocol=PPP,
            Service-Type=Framed-User
              .....
               Cisco-avpair = "subscriber:sa=DEFAULT-QOS(shape-rate=120000)
```

2. **AAA server communication**: The Authentication, Authorization, and Accounting (AAA) server sends an Access-Accept message to the cnBNG. This message specifies the service name, action type, and a list of variables with their values, like the QoS shape-rate.
3. **Policy configuration**: The service name from the AAA message maps to a feature-template on the cnBNG's control plane, and the specified QoS shape-rate is used to override the default settings on the cnBNG's user plane. The policy merges these custom values with default values, retaining defaults where no specific values are provided.
4. **Service activation via CoA**: Alternatively, service activation can be achieved using CoA, which involves removing the old policy and configuring a new, merged policy in the hardware.

Limitations of configuring RADIUS-Based Policing

This limitation applies to the RADIUS-Based Policing feature:

- Service modifications with different RaBaPol configurations are not supported.

Configure QoS shape-rate parameterization

To establish QoS shape-rate parameterization, use the **shape average $var_name = value** command in the policy-map class configuration mode on the cnBNG User Plane (UP). This customization is feature-dependent and requires specific syntax and semantics. For QoS, a dollar sign ($) is added as a prefix to the **shape-rate** variable, and the default value, along with the variables, is configured in the policy-map definition.

Follow these steps to configure QoS shape-rate parameterization.

Procedure

Step 1 Define a feature template with the desired QoS configuration on the cnBNG CP.

Example:

```
config
  profile feature-template feature_template_name
    qos
        in-policy qos_input_policy_name
        out-policy qos_output_policy_name
        merge-level integer
     exit
  exit
```

This is a sample configuration.

```
config
  profile feature-template DEFAULT-QOS
    qos
     in-policy hqos-policy1
     out-policy hqos-policy2
     merge-level 10
   exit
  exit
```

Step 2 Configure the policy map with a shape-rate value, on the cnBNG UP.

Example:

```
config
  policy-map policy_map_name
      class class-default
          shape average $shape-rate =  rate (units)
      exit
      end-policy-map
  exit
```

This is a sample configuration.

```
config
  policy-map hqos-policy2
      class class-default
          shape average $shape-rate = 100000 kbps
      exit
      end-policy-map
  exit
```

This example enables QoS features for DEFAULT-QOS and configures the associated template with outgoing policies. The default value of shape-rate (the rate at which traffic is shaped) is set to 100000 kbps.

Step 3 Add the user profile to the USER file in the RADIUS server.

Example:

```
user-cpe@example.com         Password="abc"
               Framed-Protocol=PPP,
               Service-Type=Framed-User
                        .....
               Cisco-avpair = "subscriber:sa=DEFAULT-QOS(shape-rate=120000)”
```

This specified QoS shape-rate value (for example, 120000) overrides the default value configured on the cnBNG UP.

Step 4 Use the **show subscriber session detail** command on the Control Plane to verify the configuration.

Example:

```
show subscriber session detail
```

```
subscriber-details
{
  "subResponses": [
    {
      "subLabel": "16777218",
      "mac": "cc11.0000.0001",
      "acct-sess-id": "01000002",
      "upf": "asr9k-1",
      "port-id": "Bundle-Ether1",
      "up-subs-id": "1",
      "sesstype": "ppp",
      "state": "established",
      "subCreateTime": "Fri, 15 Nov 2024 03:34:47 UTC",
      "pppAuditId": 3,
      "transId": "2",
      "subcfgInfo": {
      "activatedServices": [
          {
            "serviceName": "DEFAULT-QOS",
            "serviceAttrs": {
              "attrs": {
                "accounting-list": "automation-aaaprofile",
                "acct-interval": "900",
                "service-acct-enabled": "true",
                "service-parameters": "shape-rate=120000",
                "sub-qos-policy-in": "hqos-policy1",
                "sub-qos-policy-out": "hqos-policy2"
              }
} } ] } } ] }
```

Step 5 Use the **show policy-map applied interface** command on the User Plane to view sessions configured with RaBaPol.

Example:

```
bng# show policy-map applied interface Bundle-Ether1.1.pppoe100

Input policy-map applied to Bundle-Ether1.1.pppoe100:

  policy-map hqos-policy1
   class class-default
    police rate 200 kbps
    !
   !

Output policy-map applied to Bundle-Ether1.1.pppoe100:

  policy-map hqos-policy2
   class class-default
```

```
 shape average $shape-rate = 100000 kbps
!
```

Shared Policy Instance

A shared policy instance (SPI) is a policy-driven QoS mechanism that

- enables the allocation of a single set of QoS resources to groups of BNG subscriber sessions
- allows these groups to share the allocated QoS resources collectively, and
- facilitates efficient resource management for multiple BNG subscriber sessions.

Table 9: Feature History Table

Feature Name	Release Information	Feature Description
Shared Policy Instance	Release 25.2.1	You can now allocate and share a single set of QoS resources across multiple cnBNG sub-interfaces and bundle sub-interfaces. By using a single QoS policy instance across multiple sub-interfaces, you can enable aggregate shaping to one rate, promoting streamlined bandwidth management.

Efficient QoS policy sharing across sub-interfaces

SPI allows you to share a single QoS policy instance among multiple sub-interfaces to maintain a unified rate through aggregate shaping. Sub-interfaces sharing the QoS policy must belong to the same physical interface. The number of sub-interfaces can range from two to the maximum supported by the port.

Limitations of configuring Shared Policy Instance

Session consistency within S-VLAN interface

Sessions sharing the same SPI must remain within the same S-VLAN interface.

Session consistency within S-VLAN interface

Sessions sharing the same SPI must remain within the same S-VLAN interface.

Service accounting

Service accounting is not supported for services configured with an SPI.

SPI name change requirements

- If you modify the policy-map associated with an SPI, you must also change the SPI name.
- Avoid the following scenarios:
  - Applying a new policy with the same policy-map name but a different SPI name to a subscriber who already has an SPI policy applied. The system will reject this configuration.

- Applying a new policy with a different policy-map name but the same SPI name. The system will reject this configuration as well.

Supported interfaces

- The SPI feature is supported only for bundle subscribers.

CoA service-update request limitation

When a service policy with a user profile configuration that includes an SPI is enabled, you cannot simultaneously use an SPI in a CoA service-update request.

Percentage-based QoS allocation for shared policy instances

Configure Shared Policy Instance

To implement SPI, you must configure a complete hierarchical policy-map that includes both parent and child policies. The SPI name can be defined and linked to a feature template or downloaded from a RADIUS server.

There are two main ways to configure these policies:

- Using a feature template
- Using a RADIUS server

Configure a QoS policy with SPI using a feature template

Follow these steps to configure a QoS policy with shared policy instance in the input and output direction using a feature template.

Procedure

Step 1 Define a feature template on the Control Plane (CP) that includes the SPI configuration.

Example:

```
config
  profile feature-template feature_template_name
    qos
         in-policy qos_input_policy_name
           in-shared-policy-instance spi_name
         out-policy qos_output_policy_name
           out-shared-policy-instance spi_name
     exit
  exit
```

This is a sample configuration on the cnBNG CP.

```
config
   profile feature-template DEFAULT-QOS
      qos
         in-policy hqos-policy1
```

```
          in-shared-policy-instance spi1
        out-policy hqos-policy2
          out-shared-policy-instance spi2
    exit
  exit
```

Step 2 Configure traffic policing on the cnBNG UP to monitor the traffic rate and apply actions (such as dropping or remarking packets) when the traffic exceeds the allowed limit.

Example:

```
config
  policy-map policy_map_name
     class class-default
        police rate value
     exit
     end-policy-map
  exit
```

This is a sample configuration.

```
policy-map hqos-policy1
  class class-default
    police rate 1024 kbps
  exit
  end-policy-map
exit
```

Step 3 Configure traffic shaping for a specific interface on the cnBNG UP.

Example:

```
config
  policy-map policy_map_name
     class class-default
        shape average value
     exit
     end-policy-map
  exit
```

This is a sample configuration.

```
policy-map hqos-policy2
  class class-default
    shape average 4096 kbps
  exit
  end-policy-map
exit
```

Step 4 Use the **show subscriber session detail** command on the Control Plane to verify the configuration.

Example:

```
bng# show subscriber session detail
subscriber-details
{
  "subResponses": [
    {
      "subLabel": "16777220",
      "mac": "0011.9400.0001",
      "acct-sess-id": "01000004",
      "upf": "asr9k-1",
```

```
"port-id": "Bundle-Ether1.1",
"up-subs-id": "3",
"sesstype": "ppp",
"state": "established",
"subCreateTime": "Fri, 15 Nov 2024 04:18:51 UTC",
"pppAuditId": 3,
"transId": "2",
"subcfgInfo": {
  "committedAttrs": {
  "activatedServices": [
    {
      "serviceName": "DEFAULT-QOS",
      "serviceAttrs": {
        "attrs": {
          "accounting-list": "aaaprofile",
          "acct-interval": "900",
          "service-acct-enabled": "true",
          "sub-qos-policy-in": "hqos-policy1",
          "sub-qos-policy-out": "hqos-policy2",
          "sub-qos-spi-in": "spi1",
          "sub-qos-spi-out": "spi2"
        }
      } } ] } ] }
```

Configure a QoS policy with SPI using a RADIUS server

Follow these steps to configure a QoS policy with SPI using a RADIUS server.

Procedure

Step 1 Configure a policy map that can be shared to one or more interfaces to specify a service policy, on the cnBNG UP.

Example:

```
Router# config
Router(config)# policy-map hqos-policy1
Router(config-pmap)# class class-default
Router(config-pmap-c)# police rate 1024 kbps
Router(config-pmap-c)# exit
Router(config-pmap)# end-policy-map
Router(config)# exit

Router(config)# policy-map hqos-policy2
Router(config-pmap)# class class-default
Router(config-pmap-c)# shape average 4096 kbps
Router(config-pmap-c)# exit
Router(config-pmap)# end-policy-map
Router(config)# exit
```

This is a sample configuration.

```
config
  policy-map hqos-policy1
      class class-default
          police rate 1024 kbps
```

```
    !
    end-policy-map
!
policy-map hqos-policy2
    class class-default
        shape average 4096 kbps
    !
    end-policy-map
!
```

Step 2 Add the QoS policy with the SPI name to the USER file in the RADIUS server.

Example:

```
abc@example.com Cleartext-Password:= "xyz"
cisco-avpair += "sub-qos-policy-in=hqos-policy1 shared-policy-instance spi1",
cisco-avpair += "sub-qos-policy-out=hqos-policy2 shared-policy-instance spi2",
```

Step 3 Use the **show subscriber session detail** command to verify the configuration of a subscriber with a user-profile that includes both QoS and SPI settings, on the cnBNG CP.

Example:

```
bng# show subscriber session detail
subscriber-details
      {
      "subResponses": [
      {
      "subLabel": "16777221",
      "mac": "cc11.0000.0001",
      "acct-sess-id": "01000005",
      "upf": "asr9k-1",
      "port-id": "Bundle-Ether1",
      "up-subs-id": "4",
      "sesstype": "ppp",
      "state": "established",
      "subCreateTime": "Fri, 15 Nov 2024 04:35:15 UTC",
      "pppAuditId": 3,
      "transId": "2",
      "subcfgInfo": {
        "committedAttrs": {
          "attrs": {
            "accounting-list": "aaaprofile",
            "acct-interval": "900",
            "addr-pool": "pool-ISP",
            "ppp-authentication": "pap,chap",
            "ppp-ipcp-reneg-ignore": "true",
            "ppp-ipv6cp-reneg-ignore": "true",
            "ppp-lcp-delay-seconds": "1",
            "ppp-lcp-reneg-ignore": "true",
            "service-type": "Framed(2)",
            "session-acct-enabled": "true",
            "sub-qos-policy-in": "hqos-policy1 shared-policy-instance spi1",
            "sub-qos-policy-out": "hqos-policy2 shared-policy-instance spi2",
            "vrf": "default"
          }
        } } } ] }
```

Step 4 Use the **show cnbng-nal subscriber all detail** command to display sessions with user-profile having QoS and SPI, on the cnBNG UP.

Example:

```
show cnbng-nal subscriber all detail
Interface:                Bundle-Ether1.1.pppoe4
```

```
UPID:                       0x00000004
CPID:                       0x01000005
Type:                       PPPoE
PPPOE Session Id:           00000006

Attribute List: 0x175d470
1:  ipv4-unnumbered len=  9  value= Loopback0
2:  sub-qos-policy-in len= 59  value= hqos-policy1 shared-policy-instance spi1
3:  sub-qos-policy-out len= 63  value= hqos-policy2 shared-policy-instance spi2
```

CHAPTER 8

Geo Redundancy (Subscriber Redundancy Group)

This chapter provides information about the support of geographical redundancy through subscriber redundancy groups (SRGs).

Table 10: Feature History Table

Feature Name	Release Information	Feature Description
Subscriber Redundancy Group on Cloud Native BNG	Release 7.8.1	You can now enable redundancy for subscriber sessions across two or more cnBNG user planes spread across different geographical locations by configuring redundancy for that subscriber group. Subscriber Redundancy Group (SRG) provides flexible redundancy pairing on an access link by mirroring the subscriber session to a standby node. When SRG is enabled, subscriber sessions are unaffected during the failure of the access link, and maintenance downtimes as the switchover happen from an active to a standby user plane automatically, or the BNG control plane assigns the active role to the user plane. This feature introduces these changes: **subscriber-redundancy**

- Overview, on page 80
- SRG Modes, on page 80
- Subscriber Session Set up Call Flow, on page 84

- Benefits of BNG Geo Redundancy, on page 86
- Supported Features in BNG Geo Redundancy, on page 87
- Unsupported Features and Restrictions for cnBNG Geo Redundancy, on page 87
- Guidelines to Configure SRG, on page 88
- Configure SRG, on page 89

Overview

Using Subscriber Redundancy Group (SRG), you can now provide redundancy for the subscriber sessions across multiple BNGs located in multiple geographical locations with L3 connectivity over a shared core network through IP or MPLS routing.

SRG provides flexible redundancy pairing on access-link and performs automatic switchovers during dynamic failures or planned events such as maintenance, upgrades, and transitions.

SRG also termed Geo redundancy is a powerful technology that allows session synchronization between two nodes. An active session on one node is mirrored on a standby node, so that when the active link fails, the standby BNG can take over and continue to forward the subscriber session information without any service interruption to the user.

When the subscriber session is up on cnBNG, the control plane BNG synchronizes the state from the active to the backup User Plane (UP) cnBNG. The sessions are mirrored on the standby UP for redundancy by transferring the relevant session state from active UP to standby UP, which can then help in failover (FO) or planned switchover (SO) of sessions from one UP to another. SRG, which is a set of access-interface (or a single access-interface) is introduced in cnBNG, and all subscribers in an SRG would FO or SO as a group.

For more information about the cnBNG control plane, refer to the *Cloud Native BNG Control Plane Configuration Guide*.

CPEs are agnostic to redundancy. When you enable SRG, CPE peers with the same MAC address and node ID to fall back when there is a failover.

Control plane cNBNG initiates the SRG switchover to the standby node during:

- Access link failure
- Core network link failure
- RP failures
- Chassis failure

SRG Modes

The SRG has two modes of operation:

- Hot-standby
- Warm-standby

However, we support only Hot-Standy mode.

The Hot-standby mode supports 1:1 and M:N submodes.

1:1 Hot-standby

In this mode, 50 percent of the groups are in the active state and 50 percent of the groups are in the standby state.

In this topology, access network AN1 is dual homed to UP1 and UP2. All subscribers from AN1 are grouped under the RG1 group. Access network AN2 is dual homed to UP1 and UP2 and all subscribers from AN2 are grouped under the RG2 group.

cnBNG CP elects RG1 group as active in UP1 and standby in UP2. SRG is configured such that each UP is active for 50 percent of the groups and back up 50 percent of the groups in this mode.



1:1 Hot-standby mode supports the following submodes:

Mode	Description	Illustration
Active-active	In this mode, one cnBNG UP is active for some SRGs and its peer cnBNG UP is active for other SRGs.	

Mode	Description	Illustration
Active-standby	In this mode, a cnBNG UP can be a dedicated standby for multiple SRGs from different cnBNG UPs that are active for those respective SRGs.	

M:N Hot-standby

In this mode, two nodes are active (M) and one node is standby (N) in the ratio M: N.

In this topology, access network AN1 is dual homed to UP1 and UP2. All subscribers from AN1 are grouped under the RG1 group. Access network AN2 is dual homed to UP1 and UP2 and all subscribers from AN2 are grouped under the RG2 group. Access network AN3 is dual homed to UP1 and UP3 and all subscribers from AN3 are grouped under RG3 group

cnBNG CP elects RG1 group as active in UP1 and standby in UP2. RG2 group is elected as active in UP2 and standby in UP3. Similarly, cnBNG elects RG3 as active in UP3 and standby in UP1.

In this example, we've three active nodes (M) and three standby nodes (N).

- M denotes an active node. As there are two active nodes, it takes the value 3.
- N denotes a standby node. As there is only one standby node, it takes the value 3.

So, M: N depicts the ratio 3: 3 (active: standby ratio).



Subscriber Session Set up Call Flow

The following section graphs out the call flow and messaging between cnBNG SRG devices and the session.

Subscriber Session Creation Call flow for SRG

The following call flow illustrates the SRG subscriber session, where UP1 is the active node and UP2 is the standby node.

1. cnBNG CP triggers the session creation on UP1 after it receives the DHCP request from the CPE.
2. After the subscriber session is established, UP1 sends a response back to cnBNG CP with the subscriber session details.
3. cnBNG CP now sends the request to UP2 to mirror the subscriber session.

Figure 12: Subscriber Session Creation for SRG



Subscriber Session attributes Modification Call flow for SRG

RADIUS Co-A (Change of Authorization) allows a RADIUS server to adjust an active client session. The following is the flow for modifying the subscriber session attributes for SRG:

1. When there's a COA request from RADIUS, cnBNG CP triggers UP1 to modify the session attributes.
2. After the subscribers session attributes are modified, UP1 sends a response back to cNBNG CP with the subscriber session attribute details.
3. cnBNG CP now sends the COA response back to Radius and also triggers the UP2 that has a standby role.
4. UP2 modifies the session attributes and sends back the response to cnBNG CP.

Figure 13: Subscriber Session attributes Modification for SRG



Subscriber Session Deletion Call flow for SRG

Figure 14: Subscriber Session Deletion Call flow for SRG



Benefits of BNG Geo Redundancy

- Provides flexible redundancy pairing on access-link
- Supports multiple access networks such as dual-home and OLT rings
- Supports various types of subscribers such as IPv4, IPv6, and dual-stack IPoE sessions
- Supports RP (bundle and virtual access-links) based subscribers
- Provides failure protection to access link failures, LC failures, RP failures, and chassis failures

- Performs automatic switchovers during dynamic failures or planned events such as maintenance, upgrades, and transitions
- Provides fast convergence and rapid setup of sessions, with minimal subscriber impact during switchover
- Provides automatic routing convergence towards core and efficient address pool management
- Provides seamless switchover for subscriber CPE without the need for any signaling

Supported Features in BNG Geo Redundancy

These access topologies are supported:

- SRG active–active mode without any access protocol
- Dual-home bundle interfaces with SRG vMAC using CFM or EFD fault detection
- Ring bundle interfaces with SRG vMAC using CFM or EFD fault detection
- MC-LAG access topology
- nV Satellite access topology

These base geo redundancy features are supported:

- RP-based subscribers with Bundle-Ether and PWHE as access interfaces
- Multiple SRG groups to different peer routers.
- Dynamic failure detection using object tracking (link up-down).
- Dampening timer supported
- Full BNG scale support (that is, half the scale number with redundancy).
- G.8032 (dual-home and ring) access technologies.
- SRG for ambiguous VLAN BNG session is supported only for IPoE subscriber sessions over bundle interface.

Unsupported Features and Restrictions for cnBNG Geo Redundancy

cnBNG Geo Redundancy does not support the following:

- PPPOE-PTA
- MC-LAG
- IPoE packet-triggered sessions
- Routed (L3 connected) sessions
- Multicast

- LC subscriber sessions with or with out SRG is not supported with PPPoE-PTA, LAC, IPoE Dual stack sessions
- RP (Bundle Ether or PWHE) based subscriber sessions with SRG is not supported with LAC sessions
- ARP scale mode

Guidelines to Configure SRG

- Atleast one VLAN group must be configured to create SRG.
- For successful synchronization and setup of subscriber sessions between the two BNGs, it is mandatory that the relevant BNG configurations must be identical on the two routers and on the access-interfaces pairs in the SRG.
- While the access-interfaces or their types (or both) may vary between the paired BNGs, their outer-VLAN tag (that is, S-VLAN imposed by the access or aggregation devices) must be identical.
- Inconsistencies in base BNG or SRG configurations may result in synchronization failure and improper setup of sessions on the subordinate.
- You must use the access-tracking mechanism under the SRG to ensure that its BNG role is always in synchronization with its access-link. Without this, the data or control traffic may get dropped.
- The access-tracking object used by the SRG must be same as the one used in the routing configuration for conditional advertisement of one or more subscriber summary routes corresponding to that SRG's subscriber address or subnet pools.
- Including multiple access-links (which do not fail or switchover their roles) together into a single SRG may be challenging, unless mechanisms are implemented to ensure that all these links change state even when one of them fails.
- Synchronization of the framed IPv6 prefix addresses in the SRG scenario is not supported on satellite bundle access interfaces in dual-homed satellite topology.
- Redistribution of individual subscriber routes into the routing protocol is not recommended because it slows convergence in failure or switchover events.
- Recommended design option is to conditionally advertise the summary static route for the subscriber address or subnet pool of the SRG into the core routing protocol, through access-tracking.
- You can also advertise from both routers with different preferences and use various fast-reroute techniques.
- To avoid core routing changes in certain failure conditions, there are options to reroute the traffic from the subordinate to the primary (for example, a tunnel or interchassis link) for transient or prolonged intervals.
- Routing convergence and its correlation with access failures or convergence is a key to the overall end-to-end service impact for subscribers. Multiple options exist to achieve subsecond intervals.

Fast switchover is a mechanism that minimizes traffic disruption during SRG role transitions. It is enabled by default and is typically used with SRG HOT mode to preserve subscriber forwarding continuity during standby to active role change.

When fast switchover is enabled, the system creates a Backup VRF (`srg_<group_id>`, where the group ID is internally generated) for each SRG group. This backup VRF is used to temporarily forward traffic during a role change.

The **fast-switchover-disable** option is not recommended by default. You can enable **fast-switchover-disable** only when traffic convergence is not a critical requirement.

This table summarizes subscriber route installation behavior with fast switchover enabled and disabled:

Configuration	Route Type	Main Table (Active)	Main Table (Standby)	Backup Table (Active)	Backup Table (Standby)
Enabled (Default)	Subscriber Routes	INSTALLED	NOT INSTALLED	INSTALLED	INSTALLED
Disabled	Subscriber Routes	INSTALLED	INSTALLED	NA	NA
N/A (Independent)	Framed/Subnet Routes	INSTALLED	NOT INSTALLED	NA	NA

Configure SRG

Perform the following task to configure SRG:

```
/* Configure SRG and associate it with the access interface */
Router#configure
Router(config)#cnbng-nal location 0/0/CPU0
Router(config-cnbng-nal-local)#subscriber-redundancy
Router(config-cnbng-nal-sub-red)#group group1
Router(config-cnbng-nal-srg-grp)#virtual-mac 0xxx.xxxx.0c01
Router(config-cnbng-nal-srg-grp)# core-tracking core1
Router(config-cnbng-nal-srg-grp)#access-tracking track1
Router(config-cnbng-nal-srg-grp)#access-interface-list
Router(config-cfg-srg-grp-intf)#interface Bundle-Ether1.1
Router(config-cfg-srg-grp-intf)# exit

Router(config-cnbng-nal-sub-red)#group group2
Router(config-cnbng-nal-srg-grp)#virtual-mac 0xxx.0xxx.0a02
Router(config-cnbng-nal-srg-grp)#core-tracking core1
Router(config-cnbng-nal-srg-grp)#access-tracking track1
Router(config-cnbng-nal-srg-grp)#access-interface-list
Router(config-cfg-srg-grp-intf)#interface Bundle-Ether1.2
Router(config-cfg-srg-grp-intf)# exit

Router(config-cnbng-nal-srg-grp-red)#group group3
Router(config-cnbng-nal-srg-grp)#virtual-mac 0xxx.0xxx.0a03
Router(config-cnbng-nal-srg-grp)#core-tracking core1
Router(config-cnbng-nal-srg-grp)#access-tracking track1
Router(config-cnbng-nal-srg-grp)#access-interface-list
Router(config-cfg-srg-grp-intf)#interface Bundle-Ether1.3
Router(config-cfg-srg-grp-intf)#exit


Router#show running-config cnbng-nal location 0/0/CPU0
cnbng-nal location 0/0/CPU0
hostidentifier RTR1
up-server ipv4 10.11.11.1 gtp-port 15002 pfcp-port 15003 vrf default
cp-server primary ipv4 10.11.11.2
```

```
auto-loopback vrf test
  interface Loopback1
  !
!
auto-loopback vrf default
  interface Loopback0
  !
!
disconnect-history file-logging-enable
spa-req-resp-history file-logging-enable
disable-secondary-address-notification
cp-association retry-count 5
ipoe fsol-flow-control 60
pppoe fsol-flow-control 60
subscriber-redundancy
  group group1
   virtual-mac 0xxx.0xxx.0c01
   core-tracking core1
   access-tracking track1
   access-interface-list
    interface Bundle-Ether1.1
   !

  group group2
   virtual-mac 0xxx.0xxx.0a02
   core-tracking core1
   access-tracking track1
   access-interface-list
    interface Bundle-Ether1.2
   !
```

Verification

The following show output shows the list of SRG groups that you created and its role:

```
Router#show cnbng-nal srg-group

====================
Location: 0/0/CPU0
====================

Group-name               SRG role  Access OT  Core OT  Subs Count V4 routes V6 routes
----------               --------  ---------  -------- ---------- --------- ---------
group1                   Active    Up         Up       1          2         2
group2                   Active    Up         Up       1          2         2
group3                   Active    Up         Up       1          2         2

Total Entries : 3

Summary
-------

Category                  Total      Active     Standby    None
-------------------------------------------------------------------
Groups                    3          3          0          0
Subscribers               4          4          0          0
V4 subnet routes          16         16         0          0
V6 subnet routes          16         16         0          0
```

The following show output displays the detailed information about SRG that includes group name, role, ID, subscriber count, and so on.

```
Router#show cnbng-nal srg-group group1 detail

====================
Location: 0/0/CPU0
====================

SRG group name                    : group1
SRG group admin state             : UP_CP_Configured
SRG group state                   : Up
SRG role                          : Active
SRG ID                            : 0x00000fa1
UP Instance ID                    : 0
SRG VRF name                      : **srg_4001

Last SRG role update time         : Mar 24 15:36:43.405702
Virtual mac                       : 0xxx.0xxx.0c01
V4 Table Id                       : 0xe0000012
V6 Table Id                       : 0xe0800012
V4 Proto Id                       : 0x00000001
V6 Proto Id                       : 0x00000003
Subscriber count                  : 0
Warm Subscriber count             : 0
IPV4 route count                  : 5
IPV6 route count                  : 5
Damping timer interval            : 120 Sec
Subnet route tag                  : 0
Route export on Standby enable    : False
Fast switchover enable            : True
Ready for role change             : Yes [Success]
FSM State                         : COMPLETE
Update Request State              : IDLE
Stats state                       : IDLE
Sub disconnect resp pend          : NA
Sub count for keep alive start    : 0


Access tracking object
----------------------
    Object name                   : track1
    Tracking state                : Up
    Last tracking state update time : Mar 24 15:36:11.820461

Core tracking object
--------------------
    Object name                   : core1
    Tracking state                : Up
    Last tracking state update time : Mar 24 15:36:11.820429

Access Interfaces
-----------------
    Bundle-Ether1.1
    Bundle-Ether1.2

IM counters
------------
    Total errors                  : 0

RIB counters
------------
    Total entries                 : 10
    Pending                       : 0
    Total errors                  : 0

Terminate counters
```

```
------------------
    IM terminate                    : 0
    RIB terminate                   : 0
    Stats terminate                 : 0

Flags
-----
Value: [0x0000007C]

 [VRF_CREATE | V4_RIB_CREATE | V6_RIB_CREATE |
  V4_RIB_COMPLETE | V6_RIB_COMPLETE]


Checkpoint Flags
----------------
Value: [0x00000000]
 None

CP Recon data
-------------
    Duration                        : 0 secs
    Replay reqs in progress         : 0
    Replay subs in progress         : 0
    CP Recon Flags                  : 0x0

Subscriber transaction Info
---------------------------
    Subscribers in transaction      : 0
    Subscribers in AF down queue    : 0
    Subscribers in disc queue       : 0

Group role switchover stats Info
--------------------------------
    Last stats interaction time(A->S)   : 0.060 secs
    Last stats interaction time(S->A)   : 0.060 secs
    Max stats interaction time(A->S)    : 0.060 secs (NA)
    Max stats interaction time(S->A)    : 0.060 secs (NA)

Group role switchover RIB Info
------------------------------
    Last rib interaction time(A->S)     : 0.060 secs
    Last rib interaction time(S->A)     : 0.060 secs
    Max rib interaction time(A->S)      : 0.060 secs (NA)
    Max rib interaction time(S->A)      : 0.060 secs (NA)

    Active role change count            : 1
    Standby role change count           : 1

[SRG-GROUP-EVENTS]

| Event Name                              | Time Stamp              | User Data
| Group create                            | Mar 24 15:36:11.818142  | -- NA --
| V4 backup vrf create                    | Mar 24 15:36:11.818355  | -- NA --
| V6 backup vrf create                    | Mar 24 15:36:11.818386  | -- NA --
| V4 backup vrf create rsp                | Mar 24 15:36:12.824602  | -- NA --
| V4 backup rib tbl create                | Mar 24 15:36:12.824629  | -- NA --
| V6 backup vrf create rsp                | Mar 24 15:36:12.824633  | -- NA --
| V6 backup rib tbl create                | Mar 24 15:36:12.824643  | -- NA --
| V4 backup rib tbl create rsp            | Mar 24 15:36:12.829051  | -- NA --
| V6 backup rib tbl create rsp            | Mar 24 15:36:12.838257  | -- NA --
| Role standby start                      | Mar 24 15:36:28.245876  | -- NA --
| Role standby                            | Mar 24 15:36:28.245876  | -- NA --
| Role standby end                        | Mar 24 15:36:28.246024  | -- NA --
| CP action add                           | Mar 24 15:36:28.246025  | -- NA --
```

```
| Role active                              | Mar 24 15:36:43.405701  | -- NA --
| Role active start                        | Mar 24 15:36:43.405737  | -- NA --
| Sent srg role response to CP             | Mar 24 15:36:43.405751  |
in_prog:T,comp:F,role:act,state:up
| Role active end                          | Mar 24 15:36:43.414395  | -- NA --
| Notify: State Up                         | Mar 24 15:36:48.405904  |
in_prog:F,comp:T,role:act,state:up
| State change ack'ed                      | Mar 24 15:36:48.406016  | -- NA --
| Fast swo timer expiry, Role Active       | Mar 24 15:36:53.406337  | -- NA --

=========================================================================
```

The following example shows a sample configuration for MC-LAG on both BNG devices.

```
/* This the configuration on BNG1:*\:
redundancy
 iccp
  group 100
   mlacp node 1
   mlacp system mac 1001.2000.3015
   mlacp system priority 1
   mlacp connect timeout 0
   member
    neighbor 188.1.1.1
   !
   backbone
    interface Bundle-Ether131
   !
   isolation recovery-delay 300
  !
 group 500
   member
    neighbor 188.1.1.1
   !
   backbone
    interface Bundle-Ether131
   !
   isolation recovery-delay 100
   nv satellite
    system-mac 1001.4000.3015
   !
  !
interface Bundle-Ether10
 mtu 9000
 lacp switchover suppress-flaps 100
 mlacp iccp-group 100
 mlacp switchover recovery-delay 60
 mlacp port-priority 10
 mac-address 10f3.1153.5a01
 bundle wait-while 0
 bundle load-balancing hash dst-ip
 bundle minimum-active links 1
 load-interval 30
!
interface Bundle-Ether10.1
 service-policy output SVLAN subscriber-parent resource-id 0
 vrf pppoe_vrf
 ipv4 point-to-point
 ipv4 unnumbered Loopback517
 arp learning disable
 ipv4 unreachables disable
 ipv6 nd cache-limit 5000
 ipv6 nd other-config-flag
 ipv6 nd managed-config-flag
```

```
 ipv6 address 2006::c353/128
 ipv6 address 2007::c353/128
 ipv6 enable
 ipv6 unreachables disable
 encapsulation dot1q 10 second-dot1q 1
 cnbng-nal ipv6 nd
  ra-initial 0 4
  slaac
 !
 ipsubscriber
  ipv4 l2-connected
   initiator dhcp
  !
  ipv6 l2-connected
   initiator dhcp
  !
 !
 pppoe enable
!

interface TenGigE0/2/0/0
 nv
  satellite-fabric-link satellite 300
   redundancy
    iccp-group 500
   !
   remote-ports TenGigE 0/0/0-30
  !
 !
!

/* This the configuration on BNG2:*\
redundancy
 iccp
  group 100
   mlacp node 2
   mlacp system mac 1001.2000.3015
   mlacp system priority 1
   mlacp connect timeout 0
   member
    neighbor 177.1.1.1
   !
   backbone
    interface Bundle-Ether431
   !
   isolation recovery-delay 300
  !
  group 500
   member
    neighbor 177.1.1.1
   !
   backbone
    interface Bundle-Ether431
   !
   isolation recovery-delay 100
   nv satellite
    system-mac 1001.4000.3015
   !
  !
interface Bundle-Ether10
 mtu 9000
 lacp switchover suppress-flaps 100
 mlacp iccp-group 100
 mlacp switchover recovery-delay 60
```

```
 mlacp port-priority 5
 mac-address 10f3.1153.5a01
 bundle wait-while 0
 bundle load-balancing hash dst-ip
 bundle minimum-active links 1
 load-interval 30
!
interface Bundle-Ether10.1
 service-policy output SVLAN subscriber-parent resource-id 0
 vrf pppoe_vrf
 ipv4 point-to-point
 ipv4 unnumbered Loopback517
 arp learning disable
 ipv4 unreachables disable
 ipv6 nd cache-limit 5000
 ipv6 nd other-config-flag
 ipv6 nd managed-config-flag
 ipv6 address 2007::c353/128
 ipv6 enable
 ipv6 unreachables disable
 encapsulation dot1q 10 second-dot1q 1
 cnbng-nal ipv6 nd
  ra-initial 0 4
  slaac
 !
 ipsubscriber
  ipv4 l2-connected
   initiator dhcp
  !
  ipv6 l2-connected
   initiator dhcp
  !
 !
 pppoe enable
!
interface TenGigE0/1/0/7
 nv
  satellite-fabric-link satellite 300
   redundancy
    iccp-group 500
   !
   remote-ports TenGigE 0/0/0-30
  !
 !
!
```



CHAPTER 9

IPV6 Neighbor Discovery

This chapter provides information about the IPV6 Neighbor Discovery.

Table 11: Feature History Table

Feature Name	Release Information	Feature Description
IPv6 Neighbor Discovery	Release 7.10.1	You can now configure IPv6 Neighbor Discovery (ND) parameters on the access interface that facilitates address resolution, router discovery, and duplicate address detection. The IPv6 ND protocol discovers and establishes communication with neighboring IPv6 nodes within a local network. This feature introduces the following changes: • **CLI**: **cnbng ipv6 nd** commands • **YANG** `Cisco-IOS-XR-um-asr9k-cnbng-nal-cfg` (see GitHub, YANG Data Models Navigator):

• IPv6 Neighbor Discovery, on page 97

IPv6 Neighbor Discovery

IPv6 Neighbor Discovery (ND) is a protocol used to determine the link-layer addresses of neighboring nodes, such as customer routers to forward IPv6 traffic.

IPv6 ND enables cloud native BNG to act as a router and uses IPv6 ND to learn the link-layer addresses of customer routers connected to it. IPv6 ND maintains the information about other devices in the IPV6 network and tracks the presence of neighboring devices, and determines its reachability to those devices.

To communicate with neighboring nodes, IPv6 ND uses the following set of messages:

- IPv6 Router Solicitation Message (RS) is an IPv6 message sent by a host to request Router Advertisements (RA) from routers on the network. Router solicitation messages are sent on the local link when a host wants to determine the link-layer address of another node on the same local link. The ICMP packet header has a value of 135 in the Type field to identify the RS message.
- Router Advertisement (RA) is an IPv6 message sent periodically by routers or in response to an RS message sent by a host. The RA message advertises the presence of routers on the network to provide hosts with configuration information. RA contains prefixes used to determine whether another host shares the same link. The ICMP packet header has a value of 134 in the Type field to identify the RA message. An ambiguous VLAN does not have an association with any particular VLAN; therefore, a unicast router advertisement message is sent for ambiguous VLAN interfaces.

  To enable IPv6 unicast router advertisement, use the **cnBNG NAL ipv6 nd ra-unicast** command in the `cnbng-nal` configuration mode.
- Neighbor Solicitation (NS) is an IPv6 message sent by a node to determine the link-layer address of a neighbor, or to verify that a neighbor is still reachable through a cached link-layer address. NS messages also checks the Duplicate Address Detection (DAD) if the IPv6 address configured is already in-use by another node on the same link.
- Neighbor Advertisement (NA) is an IPv6 message sent in response to a Neighbor Solicitation (NS) message to notify its link-layer address neighbors. When a node receives an NS message, it responds with an NA message that includes its link-layer address. The NA message is sent to the source address of the NS message and can be either unicast or multicast.
- Redirect is an IPv6 message that routers use to notify hosts of an optimal first-hop router for a given destination. When a host sends a packet to a destination router, and the router receiving the packet determines that the next hop is not the best one, the router sends a Redirect message to the host. The Redirect message includes the IP address of the destination router and the IP address of the new next-hop router that the host must use instead. The ICMP packet header has a value of 137 in the Type field to identify the redirect message.

How IPv6 Neighbor Discovery Works?

In an IPv6 network, during the communication with a neighboring device:

- The host (P1) sends an Neighbor Solicitation (NS) message to the link-local multicast address requesting the MAC address of the destination router (P2) with the specified IPv6 address.



- The neighbor responds with a Router Advertisement (RA) message that includes its link-layer address. This exchange allows the routers to establish a mapping between the IPv6 address of the neighbors and link-layer address for communication to occur.



IPv6 neighbor discovery uses Duplicate Address Detection (DAD) to ensure that no two devices on the same network have the same IPv6 address. When a device joins the network or configures a new IPv6 address, the host sends a neighbor solicitation message with its IPv6 address as the target. If the host receives a neighbor advertisement message in response, the host knows that another device on the network, which is already using that IPv6 address, and the host must choose a different IPv6 address.

You have the flexibility to configure the IPv6 ND parameters such as the frequency of RA messages or the interval between NS and NA messages. according to your network design under the access interface.

Configure IPv6 Neighbor Discovery

Based on your requirements, configure the following IPv6 ND parameters:

```
Router#configure
Router(config)#interface Bundle-Ether1.1

/*Set the managed address configuration flag in IPv6 router advertisements*\
Router(config-subif)# cnbng-nal ipv6 nd managed-config-flag

/*Configure the interval between IPv6 neighbor solicitation retransmissions on an interface
 *\
Router(config-subif)# cnbng-nal ipv6 nd ns-interval 1999

/*Enable the IPv6 neighbor un-reachability detection (NUD) *\
Router(config-subif)#cnbng-nal ipv6 nd  nud-enable

/*Set the other stateful configuration flag in IPv6 router advertisements *\
Router(config-subif)# cnbng-nal ipv6 nd other-config-flag

/*Set the IPv6 initial router advertisement count and interval *\
Router(config-subif)# cnbng-nal ipv6 nd ra-initial 9 4

/*Configure the interval between IPv6 router advertisement transmissions on an interface
*\
Router(config-subif)# cnbng-nal ipv6 nd ra-interval 888000 8000

/* Configure the router lifetime value in IPv6 router advertisements on an interface*\
Router(config-subif)# cnbng-nal ipv6 nd ra-lifetime 777

/* Enable the IPv6 unicast router advertisement (RA)*\
Router(config-subif)# cnbng-nal ipv6 nd ra-unicast

/*Configure the amount of time that a remote IPv6 node is considered reachable after some
```

```
reachability confirmation event has occurred*\
Router(config-subif)# cnbng-nal ipv6 nd reachable-time 9000

/*Automatically send IPv6 router advertisements to a subscriber interface after configuring
 IPv6 *\
Router(config-subif)# cnbng-nal ipv6 nd start-ra-on-ipv6-enable

/* Suppress IPv6 router advertisement transmissions on a LAN interface *\
Router(config-subif)# cnbng-nal ipv6 nd suppress-ra

/* Suppress cache learning for IPv6 neighbor discovery*\
Router(config-subif)# cnbng-nal ipv6 nd suppress-cache-learning

/* Set the managed address configuration flag in IPv6 router advertisements*\
Router(config-subif)# cnbng-nal ipv6 nd managed-config-flag

/* configure the IPv6 ND router advertisement hop-limit on the VLAN*\
Router(config-subif)# cnbng-nal ipv6 nd ipv6 nd hop-limit unspecified

/* Set the IPv6 neighbor discovery router preference *\
Router(config-subif)# cnbng-nal ipv6 nd router-preference high

/* Suppress the MTU option in IPv6 Neighbor Discovery (ND) Router Advertisement (RA) header
 *\
Router(config-subif)# cnbng-nal ipv6 nd mtu suppress
```

Verification

Verify the configured parameters appear in the output.

```
Router#%show ipv6 nd idb interface Gi0/2/0/2.1.ip536870944 detail location 0/2/CPU0;

 ifname: Gi0/2/0/2.1.ip536870944, ifh: 0x1000100, iftype: 65, VI-type: 0, Pseudo IDB: FALSE

 vrf-id: 0x60000000, table-id: 0xe0800000
 Mac Addr: xxxx.xxx.xxx, size: 6, VLan tag set: FALSE

 Media Name: ipsub_base, Media Encap: 0xe (IPSUB)
 Mac Length: 1, Media Header Len: 4, Media Proto: 0xdd86
 Current  Encap: 0xe (IPSUB), Mcast  Encap : 0xe (IPSUB)

 IPV6 Interface: Enabled, IPV6: Enabled,  MPLS: Disabled
 Link local address: xxxx::xx:xxxx:xxxx:xxxx, Global Addr count: 0
 Default Prefix Address: ::, Prefix Addr Count: 0,

 RA Specific Route Count: 0,

 RA DNS Servers Addr Count: 0,

 RA DNS Search List Count: 0,

 DAD Attempts: 0, DAD pending 0,

 RA flag: 0x0, Unicast RA send: TRUE, Initial RA count: 9, RA pkts sent count: 0
 Initial RA interval: 999000 msec,
 Time of Last RA sent: N/A, Next Scheduled Periodic RA Time due in: N/A
 RA Managed flag 0x1, RA Other flag 0x1, RA Hop limit 0x1
 RA Suppress MTU: 0x1, RA Lifetime: 777 sec
 RA interval min: 888000, max 8000 msec
 RA Router Preference: Low

 Reachable time: 9000 msec, Reachable delay: 8000 msec
 RA retransmits: 1999 msec,  NS retransmits interval: 1999 msec
```

```
 AIB stats time interval: 1000 msec

 ND Redirects: 0x0, NUD Conform: 0, MTU: 1500, IDB Flags: 0x1024

 Cache entry limit: 1000000000, Last over limit count: 0
 Complete protocol count: 0, Complete glean count: 0
 Incomplete protocol count: 0, Incomplete glean count: 0
 Dropped protocol req count: 0, Dropped glean req count: 0

 IPC notification handle: 0, Config Flags: 0xcfc0fd, Parent if: GigabitEthernet0_2_0_2.1
(0x10000c0)
 Refresh from RP: FALSE,
 IM call for IDB: Success, Mac addr changed:  TRUE
 IM error recover retries count: 0
 Check point Obj ID: 0x2e80, Framed IPv6 prefix pool name:
 Subscriber status flag: 0x0, Supressed cache learning: TRUE
 BNG nud: Enabled, Master Node: (0xddddddddddddddd)
 Global Mac Accounting: Disabled, IDB Mac Accounting : Disabled, Marked: No
 Notfn sent to iedge - Up: No, Down: No
                       Update: No
                       Last notif reason:None
 SRG Stby Role : FALSE , SRG peer route-disable : FALSE, SRG EOMS sync pending : FALSE
 Subscriber Label : 0x0
 Prefix Address from Iedged: ::,
 Input Bytes: 0, Input Bytes Pkts: 0
 Output Bytes: 0, Output Bytes Pkts: 0
.........    IDB Statistics     .........
Service    Attribute   Operation  Success Failure Avg Min Max

IM          MAC         Reg            1     0    0    0    0
IM          MAC         Notfn          1     0    0    0    0
IM          MTU         Notfn          1     0    0    0    0
IM          MPLS        Notfn          1     0    0    0    0

NETIO       NA          Sent           1     0    0    0    0

IPV6-MA     IDB         Add            1     0    0    0    0

CHKPT       IDB         Add            5     0    0    0    0
------------------------------EVT-HISTORY-------------------------------------
    Nov 17 12:20:32.576 idb-calloc-happened
    Nov 17 12:20:32.576 idb-bng-srg-master-or-none
    Nov 17 12:20:32.576 idb-bng-srg-slave-route-enable
    Nov 17 12:20:32.576 idb-bng-srg-eoms-sync-not-pend
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-bng-subdb-strt-ra
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.576 idb-apply-func
    Nov 17 12:20:32.704 idb-im-create-notification
    Nov 17 12:20:32.704 idb-ma-state-enabled
    Nov 17 12:20:32.704 idb-chkpt-save [many]
```