

Access the NFVIS portal

Access the NFVIS portal through a web browser using the local Ethernet management network connection.

Procedure

Step 1 Connect your laptop to the local Ethernet management network. In your web browser address bar, enter https://**NFVIS IP address**.

We recommend using Google Chrome.

Step 2 Log in to the NFVIS portal using the username `admin` and the newly generated password.

You have successfully accessed the NFVIS portal. The NFVIS dashboard appears and provides a summary of activities on the device.

- Accessibility, on page 1
- Internationalization, on page 2

Accessibility

Objective

The NFVIS GUI includes accessibility enhancements designed to support users with disabilities and improve overall interface usability through keyboard navigation, screen reader compatibility, visual clarity improvements, and assistive technology integration.

Impact of accessibility enhancements

Impact of accessibility enhancements

- Keyboard Accessibility: Improved portal usability for customers who rely on keyboard-only navigation.
- Inclusive Experience: Enhanced support for screen readers and other assistive technologies like ARIA roles and descriptive labels.
- Visual Clarity: Improved readability of interface elements through better color contrast alignment.

- Workflow Efficiency: Streamlined forms and workflows through clearer labeling and logical structure.
- Equivalent Information Access: Provided meaningful text alternatives for icons and visual elements, ensuring all users receive the same information.
- User Independence: Empowered customers to complete tasks more efficiently and independently across the portal.

Internationalization

Objective

NFVIS Portal also supports Internationalization for Japanese (4.18) and French Canadian (26.2) onwards.