Secondary IP and Source Interface Commands

- system settings wan secondary, on page 2
- system settings source-interface , on page 3

system settings wan secondary

To configure secondary IP on the WAN interface, use the **system settings wan secondary** command in global configuration mode.

system settings wan secondary *ip address*

Syntax Description

ip address	Specifies the IP address.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
3.5.1	This command was introduced.

Example

The following example configures the secondary WAN.

```
nfvis(config)# system settings wan secondary ip address 1.1.2.3 255.255.255.0
```

system settings source-interface

To configure source interface, use the **system settings source-interface** command in global configuration mode.

system settings source-interface *ip address*

Syntax Description

ip address	Specifies the IP address.

Command Default

None

Command Modes

Global configuration mode

Command History

Release	Modification
3.5.1	This command was introduced.

Example

The following example configures the source interface.

```
nfvis(config)# system settings source-interface 1.1.2.3
```