INDEX

A

adding DNS server 25

B

backing up module configuration settings 17

C

checking Cisco IOS release 6
Cisco IOS command
- service-module integrated-service-engine 93
- show controller integrated-service-engine 95
- show interfaces integrated-service-engine 100

Cisco IOS commands 47
Cisco IOS software 2
Cisco ISR 2
CLI environment
- entering 7
- exiting 8

closing a module session 12
command
- description (storages iscsi) 49
- event poll-interval 51, 61
- format storages 53
- format storages iscsi 55
- format storages local 57
- login (storages iscsi) 59
- service-module 8
- session 8
- show storages all filesystem 62
- show storages iscsi configuration 65
- show storages iscsi filesystem 64
- show storages iscsi parameter 67
- show storages iscsi status 69
- show storages nfs configuration 72
- show storages nfs filesystem 73
- show storages nfs status 74
- show video-surveillance 76
- state (storages iscsi) 78
- state (storages nfs) 80
- storages nfs 81
- switch-on-fail (storages nfs) 82
- target-ip (storages iscsi) 84
- target-ip (storages nfs) 86
- telnet 7
- timeout-node-session (storages iscsi) 88
- video-surveillance task 90

configuration mode, definition 7
configuration tasks, configuring module interface 10
configuring module interface 10

D

description (storages iscsi) command 49
diagnostic commands 20
disk partition SNMP threshold 24
DNS server
- adding 25
- cache policy 25

E

entering CLI environment 7
event poll-interval command 51

exiting CLI environment 8

F

format storages command 53
format storages iscsi command 55
format storages local command 57
free swap space SNMP threshold 24

I

idle CPU SNMP threshold 24
IOS command. See Cisco IOS command.

L

Linux-based application 2
location of module in router 6
logging commands 20
login (storages iscsi) command 59

M

modes, user EXEC, privileged EXEC, and configuration 7
module location in router 6

O

opening a module session 12

P

privileged EXEC mode, definition 7

R

restoring module configuration settings 17

S

service-module command 8
service-module integrated-service-engine Cisco IOS command 93
session command 8
show controller integrated-service-engine Cisco IOS command 95
show event poll-interval command 61
show interfaces integrated-service-engine Cisco IOS command 100
show storages all filesystem command 62
show storages iscsi configuration command 65
show storages iscsi filesystem command 64
show storages iscsi parameter command 67
show storages iscsi status command 69
show storages nfs configuration command 72
show storages nfs filesystem command 73
show storages nfs status command 74
show video-surveillance command 76
shutting down the network module 16
SNMP
  disk partition threshold 24
  free swap space threshold 24
  idle CPU threshold 24
starting up the network module 16
state (storages iscsi) command 78
state (storages nfs) command 80
storage 65
storages nfs command 81
switch-on-fail (storages nfs) command 82
syslog 21

T

target-ip (storages iscsi) command 84
target-ip (storages nfs) command 86
telnet command 7
Telnet session 7
timeout-node-session (storages iscsi) command 88

trace logs 21

U

user EXEC mode, definition 7

V

verifying system status 18
video-surveillance task command 90