

# Table of Contents

<b><u>Configuring CNR to Respond to a Set–Top Box with the Vendor Specific Information Option (Option 43)</u></b> .....	<b>1</b>
<u>Document ID: 12193</u> .....	1
<u>Introduction</u> .....	1
<u>Prerequisites</u> .....	1
<u>Requirements</u> .....	2
<u>Components Used</u> .....	2
<u>Conventions</u> .....	2
<u>The Vendor Class Identifier (Option 60)</u> .....	2
<u>The Vendor Specific Information (Option 43) DHCP Option</u> .....	2
<u>Configuring CNR to Respond with a Start Page for a Motorola DCT5000 Set–Top Box</u> .....	3
<u>Manually Configuring the Vendor Specific Option in CNR Versions Prior to 5.0</u> .....	6
<u>Verification of the Configuration</u> .....	7
<u>NetPro Discussion Forums – Featured Conversations</u> .....	8
<u>Related Information</u> .....	8

# Configuring CNR to Respond to a Set–Top Box with the Vendor Specific Information Option (Option 43)

Document ID: 12193

---

**Introduction**

**Prerequisites**

Requirements

Components Used

Conventions

**The Vendor Class Identifier (Option 60)**

**The Vendor Specific Information (Option 43) DHCP Option**

**Configuring CNR to Respond with a Start Page for a Motorola DCT5000 Set–Top Box**

**Manually Configuring the Vendor Specific Option in CNR Versions Prior to 5.0**

**Verification of the Configuration**

**NetPro Discussion Forums – Featured Conversations**

**Related Information**

---

## Introduction

A set–top box in a Data–over–Cable Service Interface Specifications (DOCSIS) cable plant is a special case of a cable modem (CM). The set–top box uses the same procedures to come online and receive network connectivity. However, a set–top box typically has extra levels of functionality that standard CMs do not, such as television services, pay–per–view, and an electronic program guide.

For this reason, a set–top box can require that the provisioning system supply it with extra pieces of information to help initialize or configure the extra functionality.

In this document, the example of a Motorola DCT5000 set–top box is described. When this device obtains a DHCP lease from the provisioning system, it also needs to be supplied with a URL which acts as a start page for the device. Otherwise, this particular brand of set–top box does not properly use all levels of functionality.

**Note:** Please do not use this document as a reference for provisioning a Motorola DCT5000 set–top box. Refer to the Motorola documentation as the canonical reference.

In this document, the DHCP server system used is Cisco Network Registrar (CNR) version 5.06. It is possible to use earlier CNR releases, but the process is different. You are required to enter the information in ASCII format, which can be a time consuming and complex procedure.

**Note:** It is recommended to use the process described in this document instead of manually defining the value for Option 43, as seen in earlier versions of CNR.

## Prerequisites

## Requirements

There are no specific requirements for this document.

## Components Used

The information in this document is based on the CNR version 5.06.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

## Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

## The Vendor Class Identifier (Option 60)

Vendor Class Identifier (Option 60) can be used by DHCP clients to identify the vendor and functionality of a DHCP client. The information is a variable length string of characters or octets which has a meaning specified by the vendor of the DHCP client.

One method that a DHCP client can communicate that it is using a certain type of hardware or firmware, is to set a value in its DHCP requests called the Vendor Class Identifier (VCI) (Option 60). For example, DOCSIS 1.0 based CMs must set the value of this DHCP option to the string **docsis1.0**, whereas DOCSIS 1.1 based CMs set this value to **docsis1.1**. This method has a DHCP server differentiate between the two kinds of CMs and process the requests from the two types of modems appropriately.

Some types of set-top boxes also set the VCI (Option 60) to inform the DHCP server about the hardware type and functionality of the device. The value that this option is set to gives the DHCP server a hint about any required extra information that this client needs in a DHCP response.

Code	Len	Vendor Class Identifier		
60	n	i1	i2	.....

**Note:** Option 60 is defined in RFC 2132 .

## The Vendor Specific Information (Option 43) DHCP Option

The most common option that set-top boxes expect additional vendor specific information, based on the sent VCI to be returned, is via a DHCP option called the Vendor Specific Information Option (Option 43). The format for this option is defined in RFC 2132 . However, the definition of the values returned by this option are specified by the vendor involved.

According to Section 8.4 of RFC 2132 , this option is typically formatted in a **type, length, value** (TLV) style where different pieces of information can be represented by different suboption types. The meaning of the **value** field is defined by the manufacturer of the end device.

Code	Len	Data Item			Code	Len	Data Item		
T1	n	d1	d2	.....	T2	n	D1	D2	.....

## Configuring CNR to Respond with a Start Page for a Motorola DCT5000 Set-Top Box

When a Motorola DCT5000 set-top box sends a DHCP request, it sets the VCI (Option 60) to a value **dct5000.008X**. The **X** can be a hexadecimal digit from 0 to F depending on the capabilities of the set-top box. CNR uses this information to determine that a DHCP client is indeed a DCT5000 set-top box.

When CNR recognizes that a DHCP request is from a DCT5000, CNR needs to return a start URL in the DHCP response in order for a Motorola DCT5000 to correctly initialize. Motorola has decided that this start URL needs to be sent as a suboption type 2 in the Vendor Specific Information Option (Option 43).

Code	Len	Data Item
2	61	http://172.16.1.10/dtv/app/servicemanager/servicemanager.html

The first step that needs to take place within CNR is to tell CNR about the VCIs used by the set-top box. This is accomplished by issuing the **nrcmd** command in the CNR command line interface utility: **vendor-option <vendor-option-name> create <Vendor-class-identifier>** .

**Note:** This configuration can only be performed using the **nrcmd** command. It is not possible to use the GUI interface for these commands.

Where:

- **vendor-option-name** The identifier representing the type of client that sends the VCI.
- **Vendor-class-identifier** The value that Vendor Information Option (Option 60) is set to by a particular type of device.

**Note:** The **vendor-option-name** field in the command should be specified in all lower case. If upper case letters are used, they are converted to lower case. The **Vendor-class-identifier** field can have upper and lower case letters.

In the case for DCT5000 set-top boxes, these are the defined vendor options that reflect the different types of DCT5000s:

```
Vendor-option dct5000_80 create dct5000.0080
vendor-option dct5000_81 create dct5000.0081
vendor-option dct5000_82 create dct5000.0082
vendor-option dct5000_83 create dct5000.0083
vendor-option dct5000_84 create dct5000.0084
vendor-option dct5000_85 create dct5000.0085
vendor-option dct5000_86 create dct5000.0086
vendor-option dct5000_87 create dct5000.0087
vendor-option dct5000_88 create dct5000.0088
vendor-option dct5000_89 create dct5000.0089
vendor-option dct5000_8a create dct5000.008A
vendor-option dct5000_8b create dct5000.008B
vendor-option dct5000_8c create dct5000.008C
vendor-option dct5000_8d create dct5000.008D
```

```
vendor-option dct5000_8e create dct5000.008E
vendor-option dct5000_8f create dct5000.008F
```

If other types of set-top boxes are deployed in your network in the future, and if these set-top boxes use different VCI, then these can be defined later.

At present, there is no solution in CNR to amalgamate these different VCIs into one entry. CNR treats them as completely separate entities.

The next step is to define suboption type 2 as being a valid type for each of these VCIs.

Suboption types are created by using the **nrcmd** command, **vendor-option <vendor-option-name> definesuboption <suboption-name> <suboption-type-number> <option-data-type> .**

Where:

- **vendor-option-name** The identifier chosen to represent the client type.
- **suboption-name** The name of the suboption being created. This should be representative of the function of the suboption.
- **suboption-type-number** The suboption type number for this suboption.
- **option-data-type** The data type that this suboption uses. For example, IPADDR, STRING, BYTE\_ARRAY. Other types can be seen using the **nrcmd** command, **option-datatype list**.

**Note:** The **vendor-option-name** and **suboption-name** field in this command should be specified in all lower case. If upper case letters are used, then they are converted to lower case. The **option-data-type** field can have upper and lower case letters.

For this example, you need to define suboption type number 2 for the start URL. Since the URL is a text string, issue the **type STRING** command as the option-data-type.

```
Vendor-option dct5000_80 definesuboption start_url 2 STRING
vendor-option dct5000_81 definesuboption start_url 2 STRING
vendor-option dct5000_82 definesuboption start_url 2 STRING
vendor-option dct5000_83 definesuboption start_url 2 STRING
vendor-option dct5000_84 definesuboption start_url 2 STRING
vendor-option dct5000_85 definesuboption start_url 2 STRING
vendor-option dct5000_86 definesuboption start_url 2 STRING
vendor-option dct5000_87 definesuboption start_url 2 STRING
vendor-option dct5000_88 definesuboption start_url 2 STRING
vendor-option dct5000_89 definesuboption start_url 2 STRING
vendor-option dct5000_8a definesuboption start_url 2 STRING
vendor-option dct5000_8b definesuboption start_url 2 STRING
vendor-option dct5000_8c definesuboption start_url 2 STRING
vendor-option dct5000_8d definesuboption start_url 2 STRING
vendor-option dct5000_8e definesuboption start_url 2 STRING
vendor-option dct5000_8f definesuboption start_url 2 STRING
```

If extra functionality is defined on the set-top box in the future, and other suboptions need to be defined, then these can be specified in a similar manner at a later stage.

The final step in the process is to associate the defined vendor option with a policy, and to specify the values that individual suboptions should take. This is performed with the **nrcmd** command, **policy <policy-name> setvendoroption <vendor-option-name> <suboption-name> <suboption-value> .**

Where:

- ***policy-name*** The name of the DHCP policy from which set-top boxes receive options. This has been configured previously.
- ***vendor-option-name*** The identifier chosen to represent the client type.
- ***suboption-name*** The name of the suboption.
- ***suboption-value*** The value given to the suboption in DHCP responses. This should be entered as per the option-data-type specified when defining the suboption.

**Note:** The ***vendor-option-name*** and ***suboption-name*** fields are case sensitive. It is important to make sure that these fields are specified in all lower case. The ***suboption-value*** field can be specified in upper or lower case. The ***suboption-value*** field is only case sensitive if the client receiving the suboption needs it to be case sensitive.

For this example, assume that a policy for set-top Boxes has been created and is called **STB\_policy**. Also, specify a start URL for each of these types of Set Top Boxes as

**http://172.16.1.10/dtv/app/servicemanager/servicemanager.html****http://www.lookuptables.com/.**

This is performed with these **nrcmd** commands:

```
policy STB_policy setvendoroption dct5000_80 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_81 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_82 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_83 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_84 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_85 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_86 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_87 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_88 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_89 start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8a start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8b start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8c start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8d start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8e start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
policy STB_policy setvendoroption dct5000_8f start_url http://172.16.1.10/dtv/app/
servicemanager/servicemanager.html
```

If other suboption types of VCI are specified, they can be associated with policies and assigned values in a similar manner.

At this stage, the configuration changes are saved and the DHCP server can be reloaded in order to apply the changes. This can be accomplished issuing **nrcmd** with these commands: **dhcp save** and **reload**.

# Manually Configuring the Vendor Specific Option in CNR Versions Prior to 5.0

In earlier versions of CNR, the advance vendor specific information option functionality was not available. Instead, the Vendor Specific Option (Option 43) had to be manually configured in a policy. This can not be done in CNR 5.0. If a value in Option 43 needs to be received, you must issue the **vendor-option** and **policy setvendoroption** suite of commands.

In CNR versions prior to 5.0, in order to configure a policy to supply a value for the Vendor Specific Information Option (Option 43), you issue the command **policy <policy-name> setoption vendor-encapsulated-option <value-byte-array>** .

Where:

- **policy-name** The name of the DHCP policy from which Set Top Boxes receive options. This has been configured previously.
- **value-byte-array** The value taken by the whole of the returned Vendor Specific Information Option (Option 43) specified as an array of hexadecimal bytes.

Since the value contained in the Vendor Specific Information Option (Option 43) is listed as an array of hexadecimal bytes, and since no subtype definitions are put in place, the whole of the required field must be decoded into appropriate ASCII codes.

Using a text to ASCII hex conversion table, such as the one at <http://www.lookuptables.com/> , you can convert the URL, **http://172.16.1.10/dtv/app/servicemanager/servicemanager.html**, to equivalent hexadecimal values.

This URL becomes this value:

```
68:74:74:70:3a:2f:2f:31:37:32:2e:31:36:2e:31:2e:31:30:2f:64:
74:76:2f:61:70:70:2f:73:65:72:76:69:63:65:6d:61:6e:61:67:65:
72:2f:73:65:72:76:69:63:65:6d:61:6e:61:67:65:72:2e:68:74:6d:6c
```

In order to properly format the Vendor Specific Information Option (Option 43), you need to add the **type** and **length** fields at the beginning of this array.

Code	Len	Data Item
2	61	http://172.16.1.10/dtv/app/servicemanager/servicemanager.html

Code	Len	Data Item
02	3d	68:74:74:70:3a:2f:2f:31:37:32:2e:31:36:2e:31:2e:31:30:2f:64:74:76:2f:61:70:70:2f:73:65:72:76:69:63:65:6d:61:6e:61:67:65:72:2f:73:65:72:76:69:63:65:6d:61:6e:61:67:65:72:2e:68:74:6d:6c

As seen in this table, the hexadecimal bytes 61:3d need to be prepended to the hexadecimal string representing the start URL. You can specify the entire value for the Vendor Specific Information Option (Option 43) by issuing this **nrcmd** command:

**policy STB\_policy setoption vendor-encapsulated-option**

02:3d:68:74:74:70:3a:2f:2f:31:37:32:2e:31:36:2e:31:2e:31:30:2f:64:74:76:2f:61:70:70:2f:73:65:72:76:69:63:65:6d:61:

6e:61:67:65:72:2f:73:65:72: 76:69:63:65:6d:61:6e:61:67:65:72:2e:68:74:6d:6c

**Note:** This entire command is performed on one line.

## Verification of the Configuration

To verify that the configuration commands were entered properly, you can issue **nrcmd** commands.

The first command is **vendor-option list**. As seen in this output, the output of this command provides a list of the vendor options, giving the vendor-option-name, the vendor-class-id, and the vendor-option feature read\_only.

```
nrcmd> vendor-option list
100 Ok
dct5000_80:
  name = dct5000_80
  read-only = disabled
  vendor-class-id = dct5000.0080
dct5000_81:
  name = dct5000_81
  read-only = disabled
  vendor-class-id = dct5000.0081
dct5000_82:
  name = dct5000_82
  read-only = disabled
  vendor-class-id = dct5000.0082
dct5000_83:
  name = dct5000_83
  read-only = disabled
  vendor-class-id = dct5000.0083
dct5000_84:
  name = dct5000_84
  read-only = disabled
  vendor-class-id = dct5000.0084
dct5000_85:
  name = dct5000_85
  read-only = disabled
  vendor-class-id = dct5000.0085
dct5000_86:
  name = dct5000_86
  read-only = disabled
  vendor-class-id = dct5000.0086
dct5000_87:
  name = dct5000_87
  read-only = disabled
  vendor-class-id = dct5000.0087
dct5000_88:
  name = dct5000_88
  read-only = disabled
  vendor-class-id = dct5000.0088
dct5000_89:
  name = dct5000_89
  read-only = disabled
  vendor-class-id = dct5000.0089
dct5000_8a:
  name = dct5000_8a
  read-only = disabled
  vendor-class-id = dct5000.008A
dct5000_8b:
```

```

    name = dct5000_8b
    read-only = disabled
    vendor-class-id = dct5000.008B
dct5000_8c:
    name = dct5000_8c
    read-only = disabled
    vendor-class-id = dct5000.008C
dct5000_8d:
    name = dct5000_8d
    read-only = disabled
    vendor-class-id = dct5000.008D
dct5000_8e:
    name = dct5000_8e
    read-only = disabled
    vendor-class-id = dct5000.008E
dct5000_8f:
    name = dct5000_8f
    read-only = disabled
    vendor-class-id = dct5000.008F

```

**Note:** The vendor-option read-only feature is disabled by default. If you want to enable this, issue the **vendor-option name enable read-only** command. The read-only feature of the vendor-specific DHCP option should be enabled before you use the option in a **policy name setVendoroption** command to set the data for the option.

To verify the list of suboptions given to each vendor option, issue the command **vendor-option vendor-option-name listsuboptions**. With this command, you can see the suboption type and value. In this output, it is **string** type and the value is **start\_url**.

```

nrcmd> vendor-option dct5000_80 listsuboptions
100 OK
    start_url(2) : string

nrcmd> vendor-option dct5000_81 listsuboptions
100 OK
    start_url(2) : string

```

In order to verify that the correct values for the Vendor Specific Information Option (Option 43) are being returned to end clients, it is possible to activate extended debugging in CNR to view the contents of DHCP options in DHCP responses to clients. Refer to Troubleshooting DHCP Problems in Cable Networks using Cisco Network Registrar Debugs for more information on turning on extended debugging in CNR.

## NetPro Discussion Forums – Featured Conversations

Networking Professionals Connection is a forum for networking professionals to share questions, suggestions, and information about networking solutions, products, and technologies. The featured links are some of the most recent conversations available in this technology.

NetPro Discussion Forums – Featured Conversations for Cable
---

Network Infrastructure: Remote Access
---------------------------------------

## Related Information

- [RFC 2132](#)
- [Cable CNR FAQ](#)

- **Troubleshooting DHCP Problems in Cable Networks using Cisco Network Registrar Debugs**
  - **Using the Nrcmd Commands in CNR5.0**
  - **Technical Support & Documentation – Cisco Systems**
- 

All contents are Copyright © 1992–2006 Cisco Systems, Inc. All rights reserved. Important Notices and Privacy Statement.

---

Updated: May 30, 2006

Document ID: 12193

---