

How to Change the Sendmail IP Address on the CSS 11000 and CSS 11500

Document ID: 12660

Introduction

Prerequisites

Requirements

Components Used

Conventions

Information

Related Information

Introduction

This document describes how to change the sendmail IP address on the Cisco Content Services Switches (CSS).

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

The information in this document is based on these software and hardware versions:

- Cisco CSS 11000 and 11500 series
- Cisco WebNS Software Version 2.06 and later

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

Information

The sendmail module in the CSS uses the management IP address as the sender. At this time, this setup is not configurable. The default management IP address for the CSS 11000 is 1.1.1.1. By default, the CSS 11500 configuration does not include a management address. If you have more than one CSS, **it is advised that you** make the management IP addresses unique. To change the management IP address, **issue the following**:

```
config
boot
ip address x.x.x.x
```

reboot

Here is an example message:

From: 1.1.1.1 [mailto:1.1.1.1]
Sent: None
Subject: Log Message from 1.1.1.1: Alert error

Related Information

- [Cisco CSS 11000 Series Product Support Page](#)
 - [Technical Support – Cisco Systems](#)
-

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Jan 31, 2006

Document ID: 12660
