

# Configuration Changes on VCO4K Reboot

Document ID: 15269

---

- Introduction**
- Prerequisites**
  - Requirements
  - Components Used
  - Conventions
- Configuration Changes**
- Related Information**

---

## Introduction

This document explains the configuration changes on the VCO4K reboot.

## Prerequisites

### Requirements

There are no specific requirements for this document.

### Components Used

The information in this document is based on all versions of VCO Generic.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

### Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

## Configuration Changes

When the VCO 4K is rebooted, these configurations are lost and need to be reconfigured once the VCO reboots.

- Any cards that were taken Out Of Service (O), Maintenance (M), Diagnostics (D) or Remote (R) by the user in Card Maintenance. After reboot they become Active/Maintenance.
- Any paths that were set up using *Set Up Path* under the Diagnostics menu are lost and need to be set up again.

---

## Related Information

- **Voice Technology Support**
- **Voice and IP Communications Product Support**
- **Recommended Reading: Troubleshooting Cisco IP Telephony**

• **Technical Support – Cisco Systems**

---

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

---

Updated: Feb 07, 2006

Document ID: 15269

---