

Revert ECDN and ACNS Software to Factory Default Settings

Document ID: 18960

Introduction

Prerequisites

Requirements

Components Used

Conventions

Procedure

Related Information

Introduction

This document describes a procedure to remove all user customizations and configurations, and to restore factory default settings. This procedure is very useful for devices that you receive from demonstration stocks.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

The information in this document is based on these software versions:

- Cisco Enterprise Content Delivery Network (ECDN) Software 2.0 and 3.0
- Cisco Application and Content Networking System (ACNS) Software Version 4.x

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

Procedure

Perform these steps for ECDN software:

1. Log in to the console as root, and enter the default password.
2. Issue the **restate** command.
3. Issue the **reboot** command.

Perform these steps for ACNS software:

1. Log in via console or Telnet.
2. Issue the **restore factory–default** command.

After the system erases and removes all partitions, it reboots itself.

Related Information

- [Content Networking Product Support](#)
 - [Technical Support & Documentation – Cisco Systems](#)
-

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Jan 30, 2006

Document ID: 18960
