



# Cisco Unity to Cisco Unity Connection 8.6(2a) マイグレーション検証サマリ

Jun 2012


# 対象コンポーネント

Category	Component	Hardware	Version
Servers	Cisco C-series	C210 M2	1.4(1m)
Hypervisor	ESXi host on Blade Server		ESXi 4.1
MCS	Cisco Unity	MCS 7845 H2 / MCS 7845 I2	
Voice Gateway	IOS	Voice Gateway 2801	15.1(4)M2
Switch	Access Switch	Cisco 3750	
Migration Tool	COBRAS Import Tool		1.2.4
Migration Tool	COBRAS Export Tool		7.0.120
Client	Japanese OS		Win-7 & Win-XP
Client	English OS		Win-7 & Win-XP


# マイグレーションパス

SI No.	Cisco Unity	Cisco Unity Connection
1	4.0(5)	8.6(2a)SU1
2	5.0(1a)	8.6(2a)SU1
3	7.0(2)	8.6(2a)SU1
4	8.0(3)	8.6(2a)SU1

# Unity to Unity Connection Migration Topology



# テスト結果



# 制限事項

- Cobras import tool should be installed in Windows English OS. (If Cobras import tool is installed in Windows Japanese OS, then Japanese letters are not imported from Cisco Unity to Cisco unity connection)
  - ✓Cobras import tool in Windows XP and Windows 7 Japanese OS - Japanese letters are not restored from Unity to Unity Connection
  - ✓Cobras import tool in Windows XP and Windows 7 English OS- Japanese letters are restored from Unity to Unity Connection