Product End-of-Life Notice Cisco public



# End-of-Sale and End-of-Life Announcement for the Cisco Prime Performance Manager 1.x Licenses

# Contents

| Overview                  | 3  |
|---------------------------|----|
| End-of-life milestones    | 3  |
| Product part numbers      | 4  |
| Product migration options | 12 |
| For more information      | 13 |

#### Overview

#### EOL14804

Cisco announces the end-of-sale and end-of life dates for the Cisco Prime Performance Manager 1.x Licenses. The last day to order the affected product(s) is February 17, 2023. Customers with active service contracts will continue to receive support from the Cisco Technical Assistance Center (TAC) as shown in Table 1 of the EoL bulletin. Table 1 describes the end-of-life milestones, definitions, and dates for the affected product(s). Table 2 lists the product part numbers affected by this announcement. For customers with active and paid service and support contracts, support will be available under the terms and conditions of customers' service contract.

#### End-of-life milestones

| Milestone                        | Definition  | Date              |
|----------------------------------|---|-------------------|
| End-of-Life<br>Announcement Date | The date the document that announces the end-of-sale and end-of-<br>life of a product is distributed to the general public.               | August 19, 2022   |
| End-of-Sale Date<br>License      | The last date to order the product through Cisco point-of-sale mechanisms. The product is no longer for sale after this date.             | February 17, 2023 |
| Last Ship Date<br>License        | The last-possible ship date that can be requested of Cisco and/or its contract manufacturers. Actual ship date is dependent on lead time. | May 18, 2023      |

| Table 1. | End-of-Life Milestones and Dates for the Cisco Prime Performance Manager 1.x License | es |
|----------|--|----|
|----------|--|----|

### Product part numbers

| End-of-Sale Product<br>Part Number | Product Description   | Replacement Product<br>Part Number                       | Replacement Product<br>Description              | Additional<br>Information |
|------------------------------------|---|--|---|---------------------------|
| ACE4700-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ACE 4710 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| AP10K-PERF1RTM                     | Prime Performance<br>Manager 1 - SmallCell (per<br>10K AP)      | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| APPM-PERF1-1                       | Prime Perf Mgr 1 - Cisco<br>Small Cell AP - RTM (per<br>10K AP) | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| AS1000V-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASA 1000V - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ASA5585-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASA5585 - Right To<br>Manage        | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ASR1000-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 1000 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR5000-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 5000 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ASR5500-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 5500 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ASR9000V-<br>PERF1RTM              | Prime Perf Mgr 1 - Cisco<br>ASR 9000v - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9001-<br>PERF1BRTM              | Cisco Perf Manager 1.x -<br>Cisco ASR 9001 - Bundle<br>License  | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9001-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9001 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9006-<br>PERF1BRTM              | Cisco Perf Manager 1.x -<br>Cisco ASR 9006 - Bundle<br>License  | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9006-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9006 - Right To<br>Manage       | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |

#### Table 2. Product Part Numbers Affected by This Announcement

| End-of-Sale Product<br>Part Number | Product Description   | Replacement Product<br>Part Number                       | Replacement Product<br>Description              | Additional<br>Information |
|------------------------------------|---|--|---|---------------------------|
| ASR901-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ASR 901 - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9010-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9010 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR901S-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 901S - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR902-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ASR 902 - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR903-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ASR 903 - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR907-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ASR 907 - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR920-PERF1BRTM                   | Cisco Perf Manager 1.x -<br>Cisco ASR 920 - RTM<br>Bundle License | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR920-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ASR 920 - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9904-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9904 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9910-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9910 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9912-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9912 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ASR9922-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ASR 9922 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| BQX1200H-<br>PERF1RTM              | Prime Perf Mgr 1 - BlinQ<br>X1200 Hub - Right To<br>Manage        | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| BQX1200R-<br>PERF1RTM              | Prime Perf Mgr 1 - BlinQ<br>X1200 Remote - Right To<br>Manage     | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT2900-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 2900 - Right To<br>Manage    | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |

| End-of-Sale Product<br>Part Number | Product Description  | Replacement Product<br>Part Number                       | Replacement Product<br>Description              | Additional<br>Information |
|------------------------------------|--|--|---|---------------------------|
| CAT3550-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 3550 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT3560-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 3560 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT3700-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 3700 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT3850-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>CAT 3850 - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT4500-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 4500 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT4900-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 4900 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CAT6500-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Catalyst 6500 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CGR2000-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>2000 CGR - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CGS2500-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>2500 CGS - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Matrix  | _                         |
| CPT200-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>CPT200 - Right To Manage           | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CPT50-PERF1RTM                     | Prime Perf Mgr 1 - Cisco<br>CPT50 - Right To Manage            | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CPT600-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>CPT600 - Right To Manage           | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| CRS16-PERF1RTM                     | Prime Perf Mgr 1 - Cisco<br>CRS-16 - Right To Manage           | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| CRS4-PERF1RTM                      | Prime Perf Mgr 1 - Cisco<br>CRS-4 - Right To Manage            | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| CRS8-PERF1RTM                      | Prime Perf Mgr 1 - Cisco<br>CRS-8 - Right To Manage            | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | _                         |

| End-of-Sale Product<br>Part Number | Product Description   | Replacement Product<br>Part Number                       | Replacement Product<br>Description | Additional<br>Information |
|------------------------------------|---|--|------------------------------------|---------------------------|
| CSR1000V-<br>PERF1RTM              | Prime Perf Mgr 1 - Cisco<br>CSR 1000v - Right To<br>Manage        | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| DWCOMP-<br>PERF1RTM                | Prime Perf Mgr 1 -<br>Dragon.Hor.Compact -<br>Right To Manage     | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| DWQUANT-<br>PERF1RTM               | Prime Perf Mgr 1 -<br>Dragon.Hor.Quantum -<br>Right To Manage     | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| GENDEV-PERF1RTM                    | Prime Perf Mgr 1 -<br>Gen.Third Party Device -<br>Right To Manage | See Product Migration<br>Options section for<br>details. | Matrix                             | _                         |
| GENSERVER-<br>PERF1RTM             | Prime Perf Mgr 1 -<br>Gen.Driver for Servers -<br>Right To Manage | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| IAD2431-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>IAD 2431 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| IAD2432-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>IAD 2432 - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| IE2000U-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>IE2000U - Right To<br>Manage          | See Product Migration<br>Options section for<br>details. | Matrix                             | _                         |
| ISR1800-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>1800 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| ISR1900-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>1900 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | _                         |
| ISR2800-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>2800 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| ISR2900-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>2900 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| ISR3800-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>3800 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| ISR3900-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>3900 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| ISR4321-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>4321 ISR - Right To<br>Manage         | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |

| End-of-Sale Product<br>Part Number | Product Description                                       | Replacement Product<br>Part Number                       | Replacement Product<br>Description              | Additional<br>Information |
|------------------------------------|---|--|---|---------------------------|
| ISR4331-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>4330 ISR - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ISR4351-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>4351 ISR - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ISR4431-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>4431 ISR - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ISR4451-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>4451 ISR - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| MDS9100-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>MDS 9100 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| MDS9200-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>MDS 9200 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| MDS9500-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>MDS 9500 - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ME1200-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 1200 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ME2600X-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ME 2600X - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ME3400-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME-3400 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ME3600X-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ME 3600X - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ME3750-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 3750 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ME3800X-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>ME 3800X - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Evolved Programmable<br>Network Manager, Matrix | -                         |
| ME4601-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 4601 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |
| ME4605-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 4605 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix  | -                         |

| End-of-Sale Product<br>Part Number | Product Description  | Replacement Product<br>Part Number                                    | Replacement Product<br>Description              | Additional<br>Information |
|------------------------------------|--|---|---|---------------------------|
| ME4611-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 4611 - Right To<br>Manage     | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| ME4620-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 4620 - Right To<br>Manage     | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| ME4900-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 4900 - Right To<br>Manage     | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| ME6500-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>ME 6500 - Right To<br>Manage     | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| MWR1900-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>MWR 1900 - Right To<br>Manage    | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| MWR2900-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>MWR 2900 - Right To<br>Manage    | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| NCS540-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>NCS 540 - Right To<br>Manage     | See Product Migration<br>Options section for<br>details.              | Evolved Programmable<br>Network Manager, Matrix | -                         |
| NCS6008-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>NCS 6008 - Right To<br>Manage    | See Product Migration<br>Options section for<br>details.              | Evolved Programmable<br>Network Manager, Matrix | -                         |
| NETAPP-PERF1RTM                    | Prime Perf Mgr 1 - NetApp<br>Storage - Right To Manage       | There is currently no replacement product available for this product. | -   | -                         |
| NETVPX-PERF1RTM                    | Prime Perf Mgr 1 -<br>Netscaler VPX - Right To<br>Manage     | There is currently no replacement product available for this product. | -   | -                         |
| NX1000V-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>Nexus 1000v - Right To<br>Manage | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| NX1010-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 1010 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| NX2000-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 2000 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details.              | Matrix  | -                         |
| NX3000-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 3000 - Right To<br>Manage  | See Product Migration<br>Options section for<br>details.              | Matrix  | _                         |

| End-of-Sale Product<br>Part Number | Product Description  | Replacement Product<br>Part Number                                    | Replacement Product<br>Description | Additional<br>Information |
|------------------------------------|--|---|------------------------------------|---------------------------|
| NX4000-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 4000 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX5000-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 5000 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX6001-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 6001 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX6004-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 6004 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX7000-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 7000 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX9300-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 9300 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| NX9500-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>Nexus 9500 - Right To<br>Manage            | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| PERFMGR-1-<br>KPIHNBGW             | Prime Performance<br>Manager 1 - KPI HNBGW                             | There is currently no replacement product available for this product. | -                                  | -                         |
| PERFMGR-1-<br>KPISCELL             | Prime Performance<br>Manager 1 - KPI SmallCell<br>(per 10K AP)         | There is currently no replacement product available for this product. | -                                  | -                         |
| PERFMGR-1.7-SR-<br>K9              | Prime Performance<br>Mgr.1.7 - Service and<br>Minor Upgrade            | There is currently no replacement product available for this product. | -                                  | -                         |
| PERFMGR-1X-BSBY                    | Cisco Perf Manager 1.7<br>Bundle RedundancyLic<br>(LocalHA, GeoDR)     | There is currently no replacement product available for this product. | -                                  | -                         |
| PERFMGR-1X-SBY                     | Prime Performance<br>Manager-<br>RedundancyLicense(Local<br>HAorGeoDR) | There is currently no replacement product available for this product. | _                                  | -                         |
| PRIME1XPERFMGRK9                   | Prime Performance Mgr.1.x<br>(Top Level Ordering Use<br>Only)          | There is currently no replacement product available for this product. | -                                  | -                         |

| End-of-Sale Product<br>Part Number | Product Description  | Replacement Product<br>Part Number                                    | Replacement Product<br>Description | Additional<br>Information |
|------------------------------------|--|---|------------------------------------|---------------------------|
| QVPC10K-PERF1AM                    | Prime Perf. Mgr 1 -Cisco<br>QvPC 10K Sessions RTM<br>per Service | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| QVPC10K-PERF1RTM                   | Prime Perf. Mgr 1 -Cisco<br>QvPC 10K Sessions RTM<br>per Service | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| QVPC1TB-PERF1AM                    | Prime Perf. Mgr 1 -Cisco<br>QvPC 1TB Bandwidth RTM               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| QVPC1TB-<br>PERF1RTM               | Prime Perf. Mgr 1 -Cisco<br>QvPC 1TB Bandwidth RTM               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| R-<br>PRIME1XPERFMGRK9             | Prime Performance Mgr.1.x<br>(Top Level Ordering Use<br>Only)    | There is currently no replacement product available for this product. | -                                  | -                         |
| RFGWY10-<br>PERF1RTM               | Prime Perf Mgr 1 - Cisco<br>RF Gateway 10 - Right To<br>Manage   | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR10000-<br>PERF1RTM              | Prime Perf Mgr 1 - Cisco<br>10000 - Right To Manage              | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR12000-<br>PERF1RTM              | Prime Perf Mgr 1 - Cisco<br>GSR/XR 12000 - Right To<br>Manage    | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR2600-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>2600 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR7200-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>7200 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR7300-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>7300 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR7400-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>7400 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR7500-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>7500 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |
| RTR7600-PERF1RTM                   | Prime Perf Mgr 1 - Cisco<br>7600 - Right To Manage               | See Product Migration<br>Options section for<br>details.              | Matrix                             | -                         |

| End-of-Sale Product<br>Part Number | Product Description  | Replacement Product<br>Part Number                       | Replacement Product<br>Description | Additional<br>Information |
|------------------------------------|--|--|------------------------------------|---------------------------|
| RTR800-PERF1RTM                    | Prime Perf Mgr 1 - Cisco<br>800 - Right To Manage              | See Product Migration<br>Options section for<br>details. | Matrix                             | _                         |
| SYTP2700-<br>PERF1RTM              | Prime Perf Mgr 1 -<br>Symmetricom TP 2700 -<br>Right To Manage | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| SYTP5000-<br>PERF1RTM              | Prime Perf Mgr 1 -<br>Symmetricom TP 5000 -<br>Right To Manage | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| UBR10000-<br>PERF1RTM              | Prime Perf Mgr 1 - Cisco<br>uBR10000 - Right To<br>Manage      | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| UCSB-PERF1AM                       | Prime Perf Mgr 1 - Cisco<br>UCS B Blade - Right To<br>Manage   | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| UCSB-PERF1RTM                      | Prime Perf Mgr 1 - Cisco<br>UCS B Blade - Right To<br>Manage   | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| UCSC-PERF1RTM                      | Prime Perf Mgr 1 - Cisco<br>UCS C Chassis - Right To<br>Manage | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| VM-PERF1AM                         | Prime Perf Mgr 1 - 1 Virtual<br>Machines - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| VM-PERF1RTM                        | Prime Perf Mgr 1 - 1 Virtual<br>Machines - Right To<br>Manage  | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |
| VSG-PERF1RTM                       | Prime Perf Mgr 1 - Cisco<br>VSG - Right To Manage              | See Product Migration<br>Options section for<br>details. | Matrix                             | -                         |

## Product migration options

Service prices for Cisco products are subject to change after the product End-of-Sale date.

#### For more information

For more information about the Cisco End-of-Life Policy, go to: <u>https://www.cisco.com/c/en/us/products/eos-eol-policy.html</u>.

For more information about the Cisco Product Warranties, go to: <u>https://www.cisco.com/c/en/us/products/warranty-listing.html</u>.

To subscribe to receive end-of-life/end-of-sale information, go to: https://cway.cisco.com/mynotifications.

Any authorized translation issued by Cisco Systems or affiliates of this end-of-life Product Bulletin is intended to help customers understand the content described in the English version. This translation is the result of a commercially reasonable effort; however, if there are discrepancies between the English version and the translated document, please refer to the English version, which is considered authoritative.

Americas Headquarters Cisco Systems, Inc. San Jose, CA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore Europe Headquarters Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at https://www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Printed in USA