



Preface **xi**

Audience	xi
Organization	xi
Conventions	xii
Safety Overview	xiv
Related Documentation	xix
Obtaining Documentation	xx
Cisco.com	xx
Ordering Documentation	xx
Documentation Feedback	xx
Obtaining Technical Assistance	xxi
Cisco Technical Support Website	xxi
Submitting a Service Request	xxi
Definitions of Service Request Severity	xxii
Obtaining Additional Publications and Information	xxii
Licenses	xxiii

CHAPTER 1

Product Overview **1-1**

Features	1-2
Front Panel Description	1-4
Status LED	1-5
RJ-45 Connector	1-5
CSM Operation	1-6
CSM Traffic Flow	1-7

CHAPTER 2

Networking with the Content Switching Module **2-1**

Configuring Modes for Networking	2-1
Configuring the Single Subnet (Bridge) Mode	2-1
Configuring the Secure (Router) Mode	2-3
CSM Networking Topologies	2-4
CSM Inline and MSFC Not Involved	2-4
CSM Inline and MSFC on Server Side	2-5
CSM Inline and MSFC on Client Side	2-5

CSM in Aggregate Mode	2-6
Direct Server Return	2-6
Routing with the CSM	2-7
Protecting Against Denial-of-Service Attacks	2-8

CHAPTER 3

Getting Started 3-1

Operating System Support	3-1
Preparing to Configure the CSM	3-1
Using the Command-Line Interface	3-3
Accessing Online Help	3-3
Saving and Restoring Configurations	3-3
Configuring SLB Modes	3-3
Mode Command Syntax	3-4
Migrating Between Modes	3-5
Differences Between the CSM and RP Modes	3-5
CSM Mode	3-5
RP Mode	3-6
Changing Modes	3-7
CSM Mode to RP Mode	3-7
RP Mode to CSM Mode	3-7
Verifying the Configuration	3-8
Configuration Overview	3-9
Upgrading to a New Software Release	3-11
Upgrading from the Supervisor Engine Bootflash	3-11
Upgrading from a PCMCIA Card	3-12
Upgrading from an External TFTP Server	3-13

CHAPTER 4

Configuring VLANs 4-1

Configuring Client-Side VLANs	4-2
Configuring Server-Side VLANs	4-3

CHAPTER 5

Configuring Real Servers and Server Farms 5-1

Configuring Server Farms	5-1
Configuring Real Servers	5-3
Configuring Dynamic Feedback Protocol	5-5
Configuring Client NAT Pools	5-6
Configuring Server-Initiated Connections	5-6

Configuring URL Hashing	5-7
Configuring a URL Hashing Predictor	5-7
Configuring Beginning and Ending Patterns	5-8

CHAPTER 6
Configuring Virtual Servers, Maps, and Policies 6-1

Configuring Virtual Servers	6-1
Configuring TCP Parameters	6-4
Configuring Redirect Virtual Servers	6-5
Configuring Maps	6-8
Configuring Policies	6-11
Configuring Generic Header Parsing	6-12
Understanding Generic Header Parsing	6-12
Generic Header Parsing Configuration	6-13
Creating a Map for the HTTP Header	6-13
Specifying Header Fields and Match Values	6-13
Assigning an HTTP Header Map to a Policy	6-14
Assigning the Policy to a Virtual Server	6-14
Generic Header Parsing Example	6-14

CHAPTER 7
Configuring Redundant Connections 7-1

Configuring Fault Tolerance	7-1
Configuring HSRP	7-5
HSRP Configuration Overview	7-5
Creating the HSRP Gateway	7-6
Creating Fault-Tolerant HSRP Configurations	7-7
Configuring Connection Redundancy	7-8
Configuring a Hitless Upgrade	7-9

CHAPTER 8
Configuring Additional Features and Options 8-1

Configuring Session Persistence (Stickiness)	8-1
Configuring Sticky Groups	8-3
Cookie Insert	8-4
Cookie Sticky Offset and Length	8-4
URL-Learn	8-4
Configuring Route Health Injection	8-5
Understanding RHI	8-5
RHI Overview	8-6
Routing to VIP Addresses Without RHI	8-6

Routing to VIP Addresses with RHI	8-7
Understanding How the CSM Determines VIP Availability	8-7
Understanding Propagation of VIP Availability Information	8-7
Configuring RHI for Virtual Servers	8-7
Environmental Variables	8-8
Configuring Persistent Connections	8-14
HTTP Header Insert	8-15
Configuring Global Server Load Balancing	8-16
Using the GSLB Advanced Feature Set Option	8-16
Configuring GSLB	8-17
Maps	8-17
Probes	8-18
Serverfarm	8-18
Policy	8-18
Virtual Server	8-19
Configuring Network Management	8-23
Configuring SNMP Traps for Real Servers	8-23
Configuring the XML Interface	8-24
Configuring the Server Application State Protocol	8-27
Configuring SASP Groups	8-27
Configuring a GWM	8-27
Configuring Alternate bind_ids	8-28
Configuring a Unique ID for the CSM	8-29
Configuring Weight Scaling	8-29
Back-End Encryption	8-30
Configuring the Client Side	8-31
Configuring the Server Side	8-32
Configuring the CSM as the Back-End	8-32
Configuring the Real Server as the Back-End Server	8-33

CHAPTER 9

Configuring Health Monitoring 9-1

Configuring Probes for Health Monitoring	9-1
Probe Configuration Commands	9-4
Configuring an HTTP Probe	9-4
Configuring an ICMP Probe	9-5
Configuring a UDP Probe	9-6
Configuring a TCP Probe	9-7
Configuring FTP, SMTP, and Telnet Probes	9-7
Specifying the DNS Resolve Request	9-7

Configuring Inband Health Monitoring	9-8
Understanding Inband Health Monitoring	9-8
Configuring Inband Health Monitoring	9-8
Configuring HTTP Return Code Checking	9-9
Understanding HTTP Return Code Checking	9-9
Configuring HTTP Return Code Checking	9-10

CHAPTER 10

Using TCL Scripts with the CSM 10-1

Loading Scripts	10-2
Examples for Loading Scripts	10-2
Reloading TCL Scripts	10-3
TCL Scripts and the CSM	10-3
Probe Scripts	10-8
Example for Writing a Probe Script	10-8
Environment Variables	10-9
Exit Codes	10-10
EXIT_MSG Variable	10-10
Running Probe Scripts	10-11
Debugging Probe Scripts	10-13
Standalone Scripts	10-15
Example for Writing Standalone Scripts	10-15
Running Standalone Scripts	10-16
Debugging Standalone Scripts	10-16
TCL Script Frequently Asked Questions (FAQs)	10-17

CHAPTER 11

Configuring Firewall Load Balancing 11-1

Understanding How Firewalls Work	11-1
Firewall Types	11-2
How the CSM Distributes Traffic to Firewalls	11-2
Supported Firewalls	11-2
Layer 3 Load Balancing to Firewalls	11-2
Types of Firewall Configurations	11-3
IP Reverse-Sticky for Firewalls	11-3
CSM Firewall Configurations	11-3
Fault-Tolerant CSM Firewall Configurations	11-6
Configuring Stealth Firewall Load Balancing	11-7
Stealth Firewall Configuration	11-7
Stealth Firewall Configuration Example	11-8
Configuring CSM A (Stealth Firewall Example)	11-9

Configuring CSM B (Stealth Firewall Example)	11-12
Configuring Regular Firewall Load Balancing	11-16
Packet Flow in a Regular Firewall Configuration	11-16
Regular Firewall Configuration Example	11-17
Configuring CSM A (Regular Firewall Example)	11-18
Configuring CSM B (Regular Firewall Example)	11-21
Configuring Reverse-Sticky for Firewalls	11-24
Understanding Reverse-Sticky for Firewalls	11-24
Configuring Reverse-Sticky for Firewalls	11-26
Configuring Stateful Firewall Connection Remapping	11-26

APPENDIX A

Configuration Examples A-1

Configuring the Router Mode with the MSFC on the Client Side	A-1
Configuring the Bridged Mode with the MSFC on the Client Side	A-4
Configuring the Probes	A-5
Configuring the Source NAT for Server-Originated Connections to the VIP	A-7
Configuring Session Persistence (Stickiness)	A-9
Configuring Direct Access to Servers in Router Mode	A-10
Configuring Server-to-Server Load-Balanced Connections	A-12
Configuring Route Health Injection	A-13
Configuring the Server Names	A-16
Configuring a Backup Server Farm	A-18
Configuring Load-Balancing Decisions Based on the Source IP Address	A-24
Configuring Layer 7 Load Balancing	A-26
Configuring HTTP Redirect	A-29

APPENDIX B

Troubleshooting and System Messages B-1

Troubleshooting	B-1
System Messages	B-1

APPENDIX C

CSM XML Document Type Definition C-1