



RADIUS: Separate Retransmit Counter for Accounting

First Published: February 3, 2003

Last Updated: July 31, 2009

The RADIUS: Separate Retransmit Counter for Accounting feature allows users to configure an exponential backoff retransmit. That is, after the normally configured retransmission retries have been used, the router will keep on trying with an interval that doubles on each retransmission failure until a configured maximum interval is reached. This functionality allows users to retransmit accounting requests for many hours without overloading the RADIUS server when it does come back up.

Finding Feature Information

For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the [“Feature Information for RADIUS: Separate Retransmit Counter for Accounting”](#) section on page 9.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS XE software image support. To access Cisco Feature Navigator, go to <http://tools.cisco.com/ITDIT/CFN/jsp/index.jsp>. An account on Cisco.com is not required.

Contents

- [Restrictions for RADIUS: Separate Retransmit Counter for Accounting, page 2](#)
- [Information About RADIUS: Separate Retransmit Counter for Accounting, page 2 page 1](#)
- [How to Configure RADIUS: Separate Retransmit Counter for Accounting, page 3](#)
- [Configuration Examples for RADIUS: Separate Retransmit Counter for Accounting, page 6](#)
- [Additional References, page 7](#)
- [Feature Information for RADIUS: Separate Retransmit Counter for Accounting, page 9](#)



Americas Headquarters:

Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Restrictions for RADIUS: Separate Retransmit Counter for Accounting

The following tasks will result in excessive memory consumption on the router:

- Configuring this feature on a router with a high call rate.
- Configuring the **aaa accounting send stop-record authentication failure** command: an accounting record and a RADIUS packet will be generated for each user that fails to authenticate while the RADIUS server is down.
- Configuring interim accounting: new accounting records are generated and stored on the router.

Information About RADIUS: Separate Retransmit Counter for Accounting

To configure RADIUS: Separate Retransmit Counter for Accounting, you should understand the following concepts:

- [How Retransmission of Accounting Requests Works, page 2](#)
- [Benefits, page 2](#)

How Retransmission of Accounting Requests Works

In many environments, a single RADIUS server is used for authentication and accounting. Whenever this server is down for approximately 24 hours, the accounting records of users already on the router are lost after authentication, authorization, and accounting (AAA) does all the retransmissions. Before the introduction of this feature, the retransmissions could be configured for a maximum of 100 retries and the timeout could be configured for 1,000 seconds. Although these configurations keep the accounting records on the router for 24 hours, a timeout of 1,000 seconds is unreasonable, causing problems when the RADIUS server cannot be reached due to network congestion.

The RADIUS: Separate Retransmit Counter for Accounting feature allows users to configure an exponential backoff retransmit. That is, after the normally configured retransmission retries have been used, the router will keep on trying with an interval that doubles on each retransmission failure until a configured maximum interval is reached. This functionality allows users to retransmit accounting requests for many hours without overloading the RADIUS server when it does come back up.

This feature can be configured globally (via the **radius-server backoff exponential** command), per server (via the **radius-server host** command), or per group (via the **backoff exponential** command).

Benefits

With this feature, users can extend the time in which the RADIUS client (the router) sends accounting requests to the RADIUS server in the event that the RADIUS server or the connection to the server is down and there is no accounting response confirmation. This functionality enables accounting records to remain on the router for up to 24 hours.

How to Configure RADIUS: Separate Retransmit Counter for Accounting

This section contains the following tasks:

- [Configuring a Retransmit Counter for Accounting Globally or per RADIUS Host, page 3](#) (required)
- [Configuring a Retransmit Counter for Accounting per RADIUS Server Group, page 4](#) (required)
- [Verifying Retransmit Configurations, page 5](#) (optional)

Configuring a Retransmit Counter for Accounting Globally or per RADIUS Host

To configure exponential backoffs of RADIUS retransmits over an extended period of time on a global basis and per RADIUS host, perform the following steps:

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **radius-server backoff exponential** [*max-delay minutes*] [*backoff-retry retransmits*]
4. **radius-server host** {*hostname* | *ip-address*} [*test username user-name*] [*auth-port port-number*] [*ignore-auth-port*] [*acct-port port-number*] [*ignore-acct-port*] [*timeout seconds*] [*retransmit retries*] [*key string*] [*alias {hostname | ip-address}*] [*idle-time seconds*] [*backoff exponential {backoff-retry number-of-retransmits | key encryption-key | max-delay minutes}*]

DETAILED STEPS

	Command	Purpose
Step 1	enable	Enters privileged EXEC mode.
	Example: Router> enable	Enter your password if prompted.
Step 2	configure terminal	Enters global configuration mode.
	Example: Router# configure terminal	

	Command	Purpose
Step 3	<pre>Router(config)# radius-server backoff exponential [max-delay minutes] [backoff-retry retransmits]</pre> Example: <pre>Router (config)# radius-server backoff exponential max-delay 60 backoff-retry 32</pre>	Configures the router for exponential backoff retransmit of accounting requests.
Step 4	<pre>Router(config)# radius-server host {hostname ip-address} [test username user-name] [auth-port port-number] [ignore-auth-port] [acct-port port-number] [ignore-acct-port] [timeout seconds] [retransmit retries] [key string] [alias {hostname ip-address}] [idle-time seconds] [backoff exponential {backoff-retry number-of-retransmits key encryption-key max-delay minutes}]</pre> Example: <pre>Router (config)# radius-server host 192.0.2.1 test username test1 auth-port 1645 acct-port 1646</pre>	Specifies a RADIUS server host and configures that RADIUS server host for exponential backoff retransmit of accounting requests.

Configuring a Retransmit Counter for Accounting per RADIUS Server Group

To configure exponential backoffs of RADIUS retransmits over an extended period of time per RADIUS server group, perform the following steps:

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **aaa group server radius *group-name***
4. **backoff exponential [max-delay *minutes*] [backoff-retry *retransmits*]**

DETAILED STEPS

	Command	Purpose
Step 1	<pre>enable</pre> Example: <pre>Router> enable</pre>	Enters privileged EXEC mode. • Enter your password if prompted.
Step 2	<pre>configure terminal</pre> Example: <pre>Router (config)# configure terminal</pre>	Enters global configuration mode.

	Command	Purpose
Step 3	Router(config)# aaa group server radius <i>group-name</i>	Groups different RADIUS server hosts into distinct lists and distinct methods and enters server-group RADIUS configuration mode.
Step 4	Router(config-sg-radius)# backoff exponential [max-delay <i>minutes</i>] [backoff-retry <i>retransmits</i>]	Configures the router for exponential backoff retransmit of accounting requests per RADIUS server group.

Verifying Retransmit Configurations

To verify feature functionality, use any of the following EXEC commands:

SUMMARY STEPS

1. **enable**
2. **debug radius**
3. **show accounting**
4. **show radius statistics**

DETAILED STEPS

	Command	Purpose
Step 1	enable Example: Router> enable	Enters privileged EXEC mode. • Enter your password if prompted.
Step 2	debug radius Example: Router# debug radius	Displays information associated with RADIUS.
Step 3	show accounting Example: Router# show accounting	Displays all active sessions and prints all the accounting records for actively accounted functions.
Step 4	show radius statistics Example: Router# show radius statistics	Displays the RADIUS statistics for accounting packets.

Configuration Examples for RADIUS: Separate Retransmit Counter for Accounting

This section provides the following configuration examples:

- [Retransmit Counter for Accounting Comprehensive Configuration: Example, page 6](#)
- [Per-Server Configuration: Example, page 6](#)

Retransmit Counter for Accounting Comprehensive Configuration: Example

The following example shows how to configure your router for exponential backoff retransmit of accounting requests. In this example, an exponential backoff is configured globally (via the **radius-server backoff exponential** command) and for the RADIUS server host “172.107.164.206” (via the **radius-server host** command).

```
aaa new-model
aaa authentication login default group radius
aaa authentication ppp default group radius
aaa authorization exec default group radius
aaa authorization network default group radius
aaa accounting send stop-record authentication failure
aaa accounting update periodic 1
aaa accounting network default start-stop group radius
!
radius-server host 172.107.164.206 auth-port 1645 acct-port 1646 backoff exponential
max-delay 60 backoff-retry 32
radius-server backoff exponential max-delay 60 backoff-retry 32
radius-server retransmit 3
radius-server key rad123
end
```

Per-Server Configuration: Example

The following example shows how to enable exponential backoff retransmits on a per-server basis. In this example, assume that the retransmit is configured for 3 retries and the timeout is configured for 5 seconds; that is, the RADIUS request will be transmitted 3 times with a delay of 5 seconds. Thereafter, the router will continue to retransmit RADIUS requests with a delayed interval that doubles each time until 32 retries have been achieved. The router will stop doubling the retransmit intervals after the interval surpasses the configured 60 minutes; it will transmit every 60 minutes.

```
radius-server host foo.xyz.com backoff exponential max-delay 60 backoff-retry 32
```

After enabling this command, the retransmits will be sent as follows (“t” equals seconds):

```
t = 0 req sent
t = 5 retrans 1
t = 10 retrans 2
t = 15 retrans 3
t = 25 retrans 4
t = 45 retrans 5
t = 85 retrans 6
t = 165 retrans 7
t = 325 retrans 8
t = 645 retrans 9
t = 1285 retrans 10
t = 2565 retrans 11
```

```
t = 5125 retrans 12
t = 8725 retrans 13 (The interval has stabilized to 60 minutes here).
t = 12325 retrans 14 till retransmit 35
```

After all the retransmits are sent, the RADIUS request follows the same path that it would when all the normal retransmits are done.

Additional References

The following sections provide references related to the RADIUS: Separate Retransmit Counter for Accounting.

Related Documents

Related Topic	Document Title
RADIUS and AAA accounting configuration tasks and commands	- The chapters “Configuring RADIUS” and “Configuring Accounting” in the <i>Cisco IOS XE Security Configuration Guide: Configuring User Services</i>, Release 2 Cisco IOS Security Command Reference

Standards

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

MIBs

MIB	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFC	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	—

Technical Assistance

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies. To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds. Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	http://www.cisco.com/techsupport

Feature Information for RADIUS: Separate Retransmit Counter for Accounting

Table 1 lists the release history for this feature.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which Cisco IOS XE software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://tools.cisco.com/ITDIT/CFN/jsp/index.jsp>. An account on Cisco.com is not required.

**Note**

Table 1 lists only the Cisco IOS XE software release that introduced support for a given feature in a given Cisco IOS XE software release train. Unless noted otherwise, subsequent releases of that Cisco IOS XE software release train also support that feature.

Table 1 Feature Information for RADIUS: Separate Retransmit Counter for Accounting

Feature Name	Releases	Feature Information
RADIUS: Separate Retransmit Counter for Accounting	Cisco IOS XE Release 2.1	The RADIUS: Separate Retransmit Counter for Accounting feature allows users to configure an exponential backoff retransmit. That is, after the normally configured retransmission retries have been used, the router will keep on trying with an interval that doubles on each retransmission failure until a configured maximum interval is reached. This functionality allows users to retransmit accounting requests for many hours without overloading the RADIUS server when it does come back up. In Cisco IOS XE Release 2.1, this feature was introduced on the Cisco ASR 1000 Series Aggregation Services Routers. The following commands were introduced or modified: backoff exponential, radius-server host, radius-server backoff exponential.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2003–2009 Cisco Systems, Inc. All rights reserved.