



## Field Reference for Maps Pages

This chapter provides field descriptions for pages found under the **Maps** in Cisco Prime Infrastructure.

- [Wireless Maps > Site Maps > AP Mesh Info](#), on page 1

### Wireless Maps > Site Maps > AP Mesh Info

The following table describes the fields on the **Maps > Wireless Maps > Site Maps AP Mesh Info** page.

*Table 1: Maps > Wireless Maps > Site Maps > AP Mesh Bridging Link Information*

| Field                  | Description  |
|------------------------|--|
| Information fetched on | Date and time that information was compiled.       |
| Link SNR               | Link signal-to-noise ratio (SNR).                  |
| Link Type              | Hierarchical link relationship.                    |
| SNR Up                 | Signal-to-noise ratio for the uplink (dB).         |
| SNR Down               | Signal-to-noise ratio for the downlink (dB).       |
| PER                    | The packet error rate for the link.                |
| Tx Parent Packets      | The TX packets to a node while acting as a parent. |
| Rx Parent Packets      | The RX packets to a node while acting as a parent. |
| Time of Last Hello     | Date and time of last hello.                       |

