

Safety Guidelines for Breakout Patch Panel and Modules

Before you perform any procedure in this publication, you must review the safety guidelines in this section to avoid injuring yourself or damaging the equipment. Note that this section contains *guidelines*, and does not include every potentially hazardous situation. During any installation procedure, always use caution and common sense.

Review the complete list of safety warnings available at *Regulatory Compliance and Safety Information - Cisco Network Convergence System 1010.*

- Standard Warning Statements, on page 1
- Safety Information, on page 3
- Laser Radiation Emission Restrictions, on page 3
- Laser Safety During Operation, on page 3
- Electrical Safety, on page 4

Standard Warning Statements



Warning

IMPORTANT SAFETY INSTRUCTIONS

Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Read the installation instructions before using, installing, or connecting the system to the power source. Use the statement number provided at the end of each warning statement to locate its translation in the translated safety warnings for this device. Statement 1071

SAVE THESE INSTRUCTIONS







Warning

When installing the product, use the provided or designated connection cables, power cables, AC adapters, and batteries. Using any other cables or adapters could cause a malfunction or a fire. Electrical Appliance and Material Safety Law prohibits the use of UL-certified cables (that have the "UL" or "CSA" shown on the cord), not regulated with the subject law by showing "PSE" on the cord, for any other electrical devices than products designated by Cisco. Statement 371



Warning

You are strongly advised to read the safety instruction before using the product.

https://www.cisco.com/web/JP/techdoc/pldoc/pldoc.html

When installing the product, use the provided or designated connection cables/power cables/AC adapters.

〈製品仕様における安全上の注意〉

接続ケーブル、電源コードセット、ACアダプタ、バッテリなどの部品は、必ず添付品または 指定品をご使用ください、添付品・指定品以外をご使用になると故障や動作不良、火災の 原因となります。また、電源コードセットは弊社が指定する製品以外の電気機器には使用 できないためご注意ください。

Statement 407



Warning

Read the installation instructions before using, installing, or connecting the system to the power source. Statement 1004



Warning

Blank faceplates and cover panels serve three important functions: they reduce the risk of electric shock and fire, they contain electromagnetic interference (EMI) that might disrupt other equipment, and they direct the flow of cooling air through the chassis. Do not operate the system unless all cards, faceplates, front covers, and rear covers are in place. Statement 1029



Warning

Only trained and qualified personnel should be allowed to install, replace, or service this equipment. Statement 1030



Warning

Ultimate disposal of this product should be handled according to all national laws and regulations. Statement 1040



Warning

There are no serviceable parts inside. To avoid risk of electric shock, do not open. Statement 1073



Warning

To reduce risk of electric shock or fire, installation of the equipment must comply with local and national electrical codes. Statement 1074



Warning

An instructed person is someone who has been instructed and trained by a skilled person and takes the necessary precautions when working with equipment. Statement 1089

A skilled person or qualified personnel is someone who has training or experience in the equipment technology and understands potential hazards when working with equipment. Statement 1089



Warning

Only a skilled person should be allowed to install, replace, or service this equipment. See statement 1089 for the definition of a skilled person. Statement 1090



Warning

Only an instructed person or skilled person should be allowed to install, replace, or service this equipment. See statement 1089 for the definition of an instructed or skilled person. Statement 1091



Note

For more information on all the applicable statements and their translations, see *Regulatory Compliance and Safety Information - Cisco Network Convergence System 1010*.

Safety Information

Before you install, operate, or service, you must read the *Regulatory Compliance and Safety Information* - *Cisco Network Convergence System 1010* document for important safety information and warning translations.

The units are compliant with the GR 1089, UL60950 /CSA 22.2 No. 60950-00, and IEC 60950 standards.

Laser Radiation Emission Restrictions

The Class 1M Laser safety and warning label affixed to the passive optical modules indicate that the product should never be used or installed in an optical network with emissions higher than Class 1M.



Warning

Class 1M laser radiation when open. Do not view directly with optical instruments. Statement 281

Laser Safety During Operation

Cisco NCS 1010 is classified as Hazard Level 1M as per IEC 60825-2 and Laser Class 1/1M as per IEC 60825-1, since it may include Class 1 or Class 1M Laser sources.

Figure 1: Class 1M Laser Product Label




Figure 2: Class 1M Laser Product Label



CAUTION

HAZARD LEVEL 1M INVISIBLE LASER RADIATION DO NOT VIEW DIRECTLY WITH NON-ATTENUATING OPTICAL INSTRUMENTS WAVELENGTH: 850 nm TO 1610 nm

AVERTISSEMENT NIVEAU DE DANGER 1M RADIATION LASER INVISIBLE NE PAS REGARDER DIRECTEMENT AVEC DES INSTRUMENTS OPTIQUES N'ATTÉNUANT PAS LE FAISCEAU LONGUEUR D'ONDE : 850 nm À 1610 nm



Warning

Complies with 21 CFR 1040.10 and 1040.11 except for conformance with IEC 60825-1 Ed. 3., as described in Laser Notice No. 56, dated May 8, 2019.

Conforme à la norme 21 CFR 1040.10 et 1040.11, sauf conformité avec la norme IEC 60825-1 Ed. 3., comme décrit dans l'avis relatif au laser no. 56, daté du 8 Mai 2019.

Statement 291



Warning

Invisible laser radiations present. Statement 1016



Warning

Invisible laser radiation may be emitted from disconnected fibers or connectors. Do not stare into beams or view directly with optical instruments. Statement 1051

Electrical Safety

The passive optical modules are optically and electrically passive and require no electrical connections. No electrostatic discharge (ESD) or other electrical safety considerations apply.